

# **EQUIPMENT MANUAL**

**EWS Mobile Incinerator: ECO M2TN**

**AUGUST 2013**



# TABLE OF CONTENTS

<b>1.0</b>	<b>GENERAL INFORMATION.....</b>	<b>5</b>
<b>1.1</b>	<b>COMMON ACRONYMS.....</b>	<b>5</b>
<b>1.2</b>	<b>EWS CONTACT INFORMATION.....</b>	<b>7</b>
<b>1.3</b>	<b>HEALTH &amp; SAFETY PRECAUTION.....</b>	<b>8</b>
1.3.1	Health and Safety Precautions .....	8
1.3.2	Safety Warnings .....	8
1.3.3	General Safety Instructions .....	9
1.3.4	General Operating and Maintenance Safety Instructions .....	10
<b>2.0</b>	<b>OVERVIEW OF TECHNOLOGY .....</b>	<b>11</b>
<b>2.1</b>	<b>INTRODUCTION TO WASTE INCINERATION .....</b>	<b>11</b>
2.1.1	Protecting the Environment .....	11
2.1.1.1	Why Incinerate?.....	11
2.1.1.2	The Operator – Your Role .....	11
2.1.1.3	Air Pollutants of Concern.....	12
2.1.2	Basic Combustion Principles .....	13
2.1.2.1	Products of Combustion Reaction (Ideal Combustion).....	13
2.1.2.2	Incomplete Combustion .....	13
2.1.2.3	Combustion Indicators .....	13
2.1.2.4	Stack Gas Oxygen and Carbon Monoxide .....	13
2.1.2.5	Stack Gas: O <sub>2</sub> (Oxygen) concentration .....	13
2.1.2.6	Stack Gas: Carbon Monoxide (CO) concentration .....	14
2.1.2.7	Waste Characteristics.....	14
2.1.2.8	Ash Quality .....	14
2.1.2.9	Summary of Key Operation Factors Affecting Combustion .....	14
2.1.3	Technology Overview .....	15
2.1.3.1	System Description.....	15
2.1.3.2	System Process.....	15
2.1.3.3	Process Overview.....	15
2.1.3.4	Functional Description of Major Components .....	16
<b>2.2</b>	<b>DESCRIPTION OF EWS MOBILE INCINERATOR .....</b>	<b>21</b>
2.2.1	EWS Mobile Incinerator Containers .....	21
2.2.1.1	#1 Primary Chamber Container .....	22
2.2.1.2	#2 Secondary Chamber Container .....	24
2.2.1.3	#3 Controls Container.....	26
<b>2.3</b>	<b>SPECIFICATIONS &amp; MATERIALS OF CONSTRUCTION .....</b>	<b>27</b>
2.3.1	EWS Mobile Incinerator: Operating Parameters .....	27

2.3.2	EWS Mobile Incinerator: Technical Specifications .....	27
2.3.2.1	Incinerator: Materials of Construction .....	27
2.3.2.2	Incinerator: Major Components Specifications .....	28
2.3.3	EWS Mobile Incinerator: Controls Philosophy .....	29
2.3.3.1	EWS Mobile Incinerator Package Central Control System .....	29
<b>2.4</b>	<b>WASTE PROCESSING CAPABILITIES .....</b>	<b>31</b>
2.4.1	EWS Mobile Incinerator Waste Description .....	31
2.4.2	Design Waste Assumptions .....	31
2.4.3	Waste Materials Suitable for Processing .....	32
2.4.4	Waste Materials NOT Suitable for Processing .....	33
<b>2.5</b>	<b>REGULATORY COMPLIANCE .....</b>	<b>33</b>
2.5.1	Environmental Regulatory Compliance .....	33
<b>3.0</b>	<b>ASSEMBLY &amp; INSTALLATION INSTRUCTIONS .....</b>	<b>34</b>
<b>3.1</b>	<b>GENERAL ASSEMBLY &amp; INSTALLATION INFORMATION .....</b>	<b>34</b>
3.1.1	Customer Responsibility .....	34
3.1.2	Preparation Prior to Assembly & Installation .....	35
3.1.2.1	Electrical & Fuel Availability .....	35
3.1.3	Assembly & Installation Overview .....	35
3.1.3.1	Specialized Tools and Equipment for Assembly and Installation .....	35
3.1.3.2	Assembly Overview .....	36
3.1.4	Assembly Instructions .....	36
<b>3.2</b>	<b>DISASSEMBLY INSTRUCTIONS .....</b>	<b>49</b>
3.2.1	General Disassembly Information .....	49
3.2.2	Preparation Prior to Disassembly .....	49
3.2.3	Disassembly Overview .....	50
3.2.3.1	Specialized Tools and Equipment for Disassembly .....	50
3.2.3.1	Disassembly Overview .....	50
3.2.4	Disassembly Instructions .....	51
<b>3.3</b>	<b>OPERATING INSTRUCTIONS .....</b>	<b>63</b>
3.3.1	Operator Interface .....	63
3.3.1.1	Control Panel Components .....	63
3.3.1.2	Operator Interface .....	64
3.3.1.3	Starting the Cycle .....	69
3.3.1.4	Purge Cycle .....	69
3.3.1.5	Burn Cycle .....	69
3.3.1.6	Using Historical Charts .....	69
3.3.2	Procedure before Start Up .....	70
3.3.3	First Time Use (WILL ONLY BE PERFORMED ON SYSTEM ONCE) .....	74
3.3.4	Standard Operating Procedures .....	74
3.3.4.1	System Start up (solid waste only) .....	74
3.3.4.2	Clean Out .....	78
3.3.5	Start up .....	80
3.3.5.1	After Shut Down (Emergency) .....	80

3.3.5.2	After Power Failure.....	80
3.3.6	Dealing with Warnings and Faults .....	81
3.3.6.1	Troubleshooting.....	81
3.3.6.2	Possible Problems/Causes/Solutions .....	84
3.3.6.3	In Case of Alarm.....	87
3.3.6.4	System Warnings .....	87
3.3.6.5	System Faults.....	88
<b>4.0</b>	<b>MAINTENANCE INSTRUCTIONS .....</b>	<b>92</b>
<b>4.1</b>	<b>SUMMARY OF PREVENTIVE MAINTENANCE INSTRUCTIONS .....</b>	<b>92</b>
4.1.1	Daily Maintenance .....	92
4.1.2	Weekly Maintenance .....	92
4.1.3	Monthly Maintenance .....	93
4.1.4	Quarterly Maintenance .....	94
4.1.5	Yearly Maintenance .....	94
4.1.6	Level 2 and Level 3 Maintenance .....	95
<b>4.2</b>	<b>PREVENTIVE MAINTENANCE INSTRUCTIONS.....</b>	<b>96</b>
4.2.1	Instruction Classification .....	96
4.2.2	Zero Mechanical State & Lock Out Instructions .....	97
4.2.2.1	Safety .....	97
4.2.2.2	Zero Mechanical State.....	97
4.2.2.3	Zero Mechanical State (ZMS) Checklist.....	97
4.2.2.4	Power Lock Out Instructions .....	98
4.2.2.5	Power Lock Out Checklist.....	98
4.2.3	Daily Instructions .....	99
4.2.4	Weekly Instructions .....	104
4.2.5	Monthly Instructions.....	115
4.2.6	Yearly Instructions .....	127
<b>4.3</b>	<b>CORRECTIVE MAINTENANCE INSTRUCTIONS (CMI).....</b>	<b>129</b>
4.3.1	General Corrective Maintenance Instructions .....	131
4.3.2	Refractory Corrective Maintenance Instructions .....	133
4.3.3	Burner Corrective Maintenance Instructions .....	136
4.3.4	Primary & Secondary Blower Corrective Maintenance Instructions.....	141
4.3.5	Main Control Panel Corrective Maintenance Instructions.....	144
4.3.6	Additional Maintenance Instructions .....	145

## 1.0 GENERAL INFORMATION

### 1.1 COMMON ACRONYMS

Acronym	Full Name
AC	Air Conditioning
ASME	American Society of Mechanical Engineers
ASTM	American Society for Testing and Materials
Cd	Cadmium
CO	Carbon Monoxide
CO <sub>2</sub>	Carbon Dioxide
CSA	Canadian Standards Association
DCH0	Default Channel Zero
DP	Delta Pressure (amount of pressure change)
EPC	Electronic Proportional Control
ESC key	Escape Key
EWS	Eco Waste Solutions
EWS Mobile	EWS Mobile Incinerator
H <sub>2</sub> O	Water
HCl	Hydrochloric Acid
HCL	Hydrogen chloride
Hg	Mercury
HMI	Human Machine Interface
IEC	International Electrotechnical Commission
ISO	International Organization for Standards
KPa	Kilopascals
LCD	Liquid Crystal Display
LED	Light-emitting Diode
MCR	Master Control Relay
ME	Mist Eliminator
MPCB	Motor Protection Circuit Breaker
N.C.	Normally Closed
N.O.	Normally Open
NO <sub>x</sub>	Oxides of Nitrogen
O <sub>2</sub>	Oxygen
Pb	Lead
PCCD/PCCF	Dioxins & Furans
PDT	Pole Double Throw
PET	Polyethylene Terephthalate
pH meter	pH meter
P&ID	Process & Instrumentation Diagram
PLC	Programmable Logic Controller
PM	Particulate Matter

<b>Acronym</b>	<b>Full Name</b>
<b>PPM</b>	Parts Per Million
<b>SPDT</b>	Single Pole Double Throw
<b>SCFM</b>	Standard Cubic Feet Meter
<b>SO<sub>2</sub></b>	Sulphur Dioxide
<b>SOC</b>	Southern Operational Command
<b>SOW</b>	Statement of Work
<b>SO<sub>x</sub></b>	Oxides of Sulphur
<b>SP</b>	Static Pressure
<b>TEFC</b>	Totally Enclosed, Fan-Cooled
<b>THC</b>	Total Hydrocarbon
<b>USB key</b>	Universal Serial Bus
<b>VDC</b>	Volts Direct Current
<b>VFD</b>	Variable Frequency Drive
<b>W.C.</b>	Water Column

## 1.2 EWS CONTACT INFORMATION

	CONTACT INFORMATION	
<b>Eco Waste Solutions</b>	5195 Harvester Road, Unit 14	
	Burlington, Ontario, Canada	
	L7L 6E9	
<b>Phone</b>	905-634-7022	
<b>Toll Free</b>	1-866-326-2876	
<b>Fax</b>	905-634-0831	
<b>email</b>	<a href="mailto:info@ecosolutions.com">info@ecosolutions.com</a>	
<b>Ask for/Address to</b>	Customer Service Manager	

## 1.3 HEALTH & SAFETY PRECAUTION

### 1.3.1 Health and Safety Precautions

# PLEASE READ THIS SECTION BEFORE READING THE REST OF THE MANUAL

### 1.3.2 Safety Warnings



The **EWS Mobile Incinerator** has a number of safety related hazards that need to be recognized by all operators:

- Electricity
- Heavy mechanical parts which may move due to gravity
- High Temperature
- Explosive Gases
- Flammable Liquids

#### IMPORTANT POINTS TO FOLLOW

THE EWS MOBILE INCINERATOR CAN CAUSE SERIOUS INJURY OR DEATH, please follow these points below:

- 1.3.2.1 **KEEP CLEAR OF ANY MOVING PARTS AT ALL TIMES.**
- 1.3.2.2 **BEFORE STARTING THE CYCLE OF THE SYSTEM ENSURE THAT ALL PERSONNEL ARE CLEAR OF THE EWS MOBILE INCINERATOR.**
- 1.3.2.3 **DO NOT ATTEMPT TO START OR OPERATE THIS EQUIPMENT UNTIL THIS MANUAL IS READ THOROUGHLY AND IS UNDERSTOOD**
- 1.3.2.4 **RESPONSIBILITY FOR THE SAFE OPERATION AND MAINTENANCE OF THE EQUIPMENT SUPPLIED REST SOLELY ON THOSE OPERATION IT.**
- 1.3.2.5 **OBEY THE FOLLOWING GENERAL SAFETY INSTRUCTIONS AT ALL TIMES.**

#### **NOTA**

A qualified operator is a person whom the owner of the equipment deems as having the required experience, training and skills to perform the required work and shall be limited to Construction Engineering trades only.



### 1.3.3 General Safety Instructions



- 1.3.3.1 Keep the electrical panel doors closed at all times except when performing electrical maintenance or troubleshooting.
- 1.3.3.2 Allow only qualified operators to perform maintenance and troubleshooting on the machine.
- 1.3.3.3 Open and lockout the Main Disconnect Switch on the electrical control panel while working on the machine.
- 1.3.3.4 Do not bypass or tie down any of the door safety limit switches.
- 1.3.3.5 Do not open any of the doors while the Primary or Secondary Chambers are above 200°F (93 °C).
- 1.3.3.6 Do not enter the Primary Chamber unless the Emergency Stop Button is pushed
- 1.3.3.7 When opening or closing the Primary Chamber door keep clear of the door and ensure that the path for the door is clear.
- 1.3.3.8 Secure the Primary Chamber door when it is open so it cannot move accidentally.
- 1.3.3.9 Immediately correct any fuel leaks.
- 1.3.3.10 Do not fill the Primary Chamber above the breech opening. Overfilling can result in poor burning and damage to the **EWS Mobile Incinerator**.
- 1.3.3.11 Use proper tools; wear impact resistant, CSA certified industrial goggles, full face dust mask (such as Advantage 3000 Respirator) and industrial leather gloves while loading and cleaning the **EWS Mobile Incinerator**.
- 1.3.3.12 Be aware of component-specific safety hazards listed within each section of this manual.

### 1.3.4 General Operating and Maintenance Safety Instructions



Proper operating and maintenance procedures must be followed in order for the **EWS Mobile Incinerator** to perform at maximum efficiency. Do not attempt to start or operate this equipment until this manual is read thoroughly and is understood.

The equipment has been designed with many safety features, however, like all thermal processes; this equipment is not free from the inherent hazards of high temperature processes. Safety procedures and precautions must be followed at ALL times during operation.

There are component-specific safety procedures outlined in this manual, however, no amount of written instruction can replace good judgment and safe operating practices.

#### **NOTA**

**Responsibility for the safe operation and maintenance of the equipment supplied rests solely on those operating it.**

There are many engineered features incorporated into the **EWS Mobile Incinerator** to free the operator of repetitive chores. They do not, however, relieve the operator of maintenance responsibilities. In order to maximize the operating life of the equipment, it is strongly recommended that the maintenance schedule be followed diligently (please refer to the Incinerator Maintenance Plan). It is advisable to keep an equipment log) for recording maintenance activities along with unusual operation. In the event that the equipment is not operating in the normal manner contact Eco Waste Solutions immediately (please refer to *Section 1.2 EWS Contact Information*). It is important to report problems as soon as they are noticed to minimize damage that faulty operation could cause.

Proper maintenance of the equipment is essential to ensure long term, reliable operation of the **EWS Mobile Incinerator**. The preventive maintenance procedures outlined in Section 4 of this manual should be adhered to strictly for best service life.

The warranty will become void if proper maintenance is not performed as instructed.

**Please note that some of the diagrams and/or photos in this EQUIPMENT MANUAL are conceptual in nature and may not be exact representations of equipment purchased.**

## 2.0 OVERVIEW OF TECHNOLOGY

### 2.1 INTRODUCTION TO WASTE INCINERATION

#### 2.1.1 Protecting the Environment

##### 2.1.1.1 Why Incinerate?

An advanced technology incinerator like the **EWS Mobile Incinerator** is the basis of a pollution prevention approach to waste management for camp operations. Having an incinerator that can be transported to the point-of-need provides immediate and complete control over the disposal of camp waste.

Incineration is considered to be a sustainable waste management practice because it deals with the waste on-site and as it's generated. Landfills operate on the premise that once it is buried the problem is eliminated. However even landfills with the most advanced engineering can fail. The very fact that a landfill is forever predicts the deterioration and failure of landfill safety systems. The creation of a well-designed landfill has a high upfront capital cost, takes many months to build and requires on-going maintenance in perpetuity making them a poor fit for a mobile camp.

Often camps consider using open air burning to deal with waste. This may involve simply setting fire to the waste pile or the use of a barrel or pit to contain the waste while burning. Open air burning creates air pollution and can lead to damaging health effects for the operator and those living and or working nearby.

By contrast, modern advanced incineration with air pollution control allows for the complete destruction of domestic waste without polluting the air, land or water. The waste material is completely converted to a non-toxic ash that does not attract wildlife.

The primary advantages of incineration are:

- **REDUCTION** of the weight and volume of waste material that must be disposed of using landfills or other means
- **DESTRUCTION** of materials that may be an attractant to wildlife and any pathogenic agents that may be contained within waste materials

##### 2.1.1.2 The Operator – Your Role

As the Operator of the incinerator you have an extremely important role in protecting the environment through the correct operation of this equipment. It is the operator's role and responsibility to protect the environment by:

1. Ensuring that no inappropriate materials are processed and that each batch contains an average mix of waste that resembles the design waste characteristics (particularly volume/weight per batch, average density, and overall heat value). See Waste Table in Section 2.4.2 for details.
2. Understanding the environmental operating permits and commitments made by your employer to regulatory bodies and other stakeholders. This includes the emission targets, monitoring and recording requirements. Understanding the wastes that can and cannot be processed in the equipment as specified by the manufacturer as well as applicable regulatory permits or

other commitments. Undertaking all necessary operational and maintenance practices to ensure compliance with applicable emission limits and operating requirements.

3. Ensuring the burn cycle is long enough to allow for thorough burn-out and the generation of high quality ash residual that is safe for disposal
4. Minimizing particulate matter (dust) emissions during ash removal and handling
5. Disposing of ash properly by sending it to appropriate disposal sites
6. Taking responsibility for regular maintenance inspections and ensuring the appropriate attention is given to any problems immediately.

### 2.1.1.3 Air Pollutants of Concern

All combustion processes produce an exhaust emission. The **EWS Mobile Incinerator** is technologically advanced and designed to thoroughly combust the waste while producing minimal emissions.

Correct operation and rigorous attention to maintenance will ensure that the **EWS Mobile Incinerator** operates with the least possible impact on the environment.

It is recommended that incinerator operators understand the potential for the creation of pollution from incorrect operation. The following table lists the pollutants that can occur in incinerator exhaust emissions.

POLLUTANT	CONCERN	SOURCE OR CAUSE
CO (Carbon Monoxide)	Combustion Indicator	High levels of CO indicates poor quality combustion
SOx (Oxides of Sulphur)	Contributes to acid rain, respiratory irritant	High sulphur content fuels
NOx (Oxides of Nitrogen)	Contributes to acid rain, respiratory irritant	Incorrect air input, too high operating temperatures
HCl (Hydrochloric Acid)	Contributes to acid rain, corrosive, respiratory irritant	Primarily from the burning of PVC (polyvinyl chloride) plastics
PM (Particulate Matter)	Respiratory effects	Incomplete combustion, rich fuel to air ratio, dust-laden waste stream
PCCD/PCCF (Dioxins & Furans)	Persistent organic compound known to bioaccumulate	Incomplete combustion due to overloading, air ingress, improper waste mix
Heavy Metals including: Pb (Lead), Hg (Mercury), Cd (Cadmium), etc.	Toxic and known to be hazardous to human health and living ecosystems	Presence of heavy metals in the waste stream will lead to appearance in the exhaust gases

## 2.1.2 Basic Combustion Principles

Combustion is a rapid chemical reaction between oxygen and combustible elements such as carbon or hydrogen. Combustion uses the oxygen in air to react with the combustible materials producing heat which continues the process. Most of the products of combustion are gases. Good combustion produces clean gases that are invisible. Poor combustion will create smoke.

### 2.1.2.1 Products of Combustion Reaction (Ideal Combustion)

The ideal combustion reaction is often used to explain combustion. In the ideal reaction a completely combustible material - a compound of carbon, hydrogen and oxygen is heated and allowed to react with oxygen. As it is heated water is vaporized and the carbon bonds with the oxygen and heat is released.

Carbon, Hydrogen, Oxygen + Oxygen +  $\longrightarrow$  Heat Carbon Dioxide + Water and Heat

### 2.1.2.2 Incomplete Combustion

This ideal reaction is theoretical and does not occur in waste combustion systems. Factors that lead to a less than ideal reaction are poor mixing, too little combustion air, and low temperatures. Under those conditions products of incomplete combustion are emitted with the stack gases or system exhaust. The products of incomplete combustion are typically elemental carbon (or soot) and carbon monoxide (CO). Soot particles are very fine and generally result in high opacity (smoke) at the combustion stack. Other products of incomplete combustion that cause concern are hazardous organic compounds such as benzene, dioxins, and furans. Although these compounds are not found in the waste, under incomplete combustion conditions they can be formed as intermediate combustion products.

The waste feed also includes inorganic materials; generally, they are not involved in the combustion reaction. The inorganic materials in the waste feed (ash) are either retained in the ash or are emitted as particulate matter in the combustion gas. Air velocities in the combustion chamber are controlled to reduce the amount of inorganic material entrained (picked up by) the combustion gas and emitted with the combustion gas. If combustion is not complete, organics will remain in the ash.

### 2.1.2.3 Combustion Indicators

One of the most obvious combustion indicators is the presence of a visible exhaust emission or smoke.

### 2.1.2.4 Stack Gas Oxygen and Carbon Monoxide

More reliable indicators that can be used to monitor combustion quality are the concentrations of key compounds in the stack gas.

### 2.1.2.5 Stack Gas: O<sub>2</sub> (Oxygen) concentration

The stack gas O<sub>2</sub> concentration provides a measure of excess air. Waste incinerators typically operate at 140 to 200 percent excess air, which roughly corresponds to 12 to 14 percent O<sub>2</sub> in the stack gas.

- High O<sub>2</sub> means too much excess air (cools gases).
- Low O<sub>2</sub> means insufficient air (incomplete combustion).

#### 2.1.2.6 Stack Gas: Carbon Monoxide (CO) concentration

Each combustion system has a "typical operating range" for CO. If the stack gas, CO concentration goes above this typical range, combustion problems are likely. With a waste incinerator this is typically <100 ppm.

#### 2.1.2.7 Waste Characteristics

Different waste types have different heating values, densities and moisture contents. These primary characteristics of the waste will affect the combustion process.

The **HEATING VALUE** of waste is a measure of the energy released when the waste is burned. It is measured in units of joules per kilogram (J/kg). The heating value is proportional to the energy released when burned. A heating value of about 11.6 MJ/kg or greater is needed to sustain combustion. Wastes with lower heating values can be burned but they will not maintain adequate temperature without the addition of auxiliary fuel.

The **MOISTURE CONTENT** of waste is a measure of the quantity of water contained or saturated in solid dry waste material. It is measured by a ratio or a percentage. The wetter the waste, the higher the moisture content and the longer it will take the waste to burn. As a result, a longer burn time requires more fuel while operating the incinerator. On the contrary, drier waste has lower moisture content. This dry waste requires a shorter burn time which results in less fuel being required.

#### 2.1.2.8 Ash Quality

Visual appearance of the ash can be an indicator of combustion problems. If an incinerator is operating properly, little organic material will remain in the ash. Whitish gray ash indicates better burnout and less carbon than black. The extent of organics combustion can be measured by the quantity of combustible materials remaining in the ash. A noted increase in ash combustibles indicates a combustion problem which may include temperatures that are too low, improper distribution of combustion air in the chamber (plugged air inlets), or burn cycle time is too short.

#### 2.1.2.9 Summary of Key Operation Factors Affecting Combustion

- 2.1.2.9.1 Combustion Air supply
  - i. Sufficient air for complete reaction
  - ii. Distributed to promote mixing
- 2.1.2.9.2 Mixing/Turbulence
  - i. Assure contact of oxygen and organics
- 2.1.2.9.3 Temperature
  - i. High enough to sustain combustion
  - ii. High enough to complete reaction
- 2.1.2.9.4 Residence time/Retention time
  - i. Sufficient time to allow reaction to complete

#### 2.1.2.9.5 Waste Feed Characteristics

- i. Waste feed must be representative of the waste feed assumptions used for the design of the incinerator


All of these key factors are interrelated.

---

### 2.1.3 Technology Overview

#### 2.1.3.1 System Description

The **EWS Mobile Incinerator** is a fully containerized transportable waste incinerator system designed to meet the strictest environmental standards. The EWS Mobile Incinerator is comprised of 3 containerized modules and additional shipping container shown below.



**View of the EWS Mobile Incinerator Containers**

(Left to right: Container 3 - Controls Container, Container 2 - Secondary Chamber Container, Container 1 - Primary Chamber Container, Container 4 – Shipping Container)

#### 2.1.3.2 System Process

##### **Stage One** (Container 1 in diagram)

This container houses the incinerator's **Primary Chamber**. Waste is placed into the chamber until it is full, then the door is sealed shut and the system can be started. The waste will remain in this chamber, for the entire cycle, where it will be burned down to ash.

##### **Stage Two** (Container 2 in diagram)


This container houses the Incinerator's **Secondary Chamber** which burns the off-gases coming from the Primary Chamber that are continually formed as the waste is burned.

#### 2.1.3.3 Process Overview

The following illustration depicts the process flow described previously and provides a schematic representation of the creation of gases and their flow through the system.

The system shown below is a graphic representation of the process and does not show the modules housed in ISO containers.





#### 2.1.3.4 Functional Description of Major Components


The components within the Mobile Incinerator package that involve combustion are referred to as the incinerator. The main modules of the incinerator are the Primary Chamber and the Secondary Chamber. Both Chambers are large vessels constructed of steel with a special insulating liner known as refractory. The Primary and Secondary Chambers are described in detail below.

##### 2.1.3.4.1 Primary Chamber

The **Primary Chamber** has a large front-opening door for loading of solid waste and removal of the ash residuals. Waste is loaded using a small skid-steer loader. The waste is dumped into the front of the chamber then pushed towards the back until full. Once the chamber is full, the door is closed and sealed shut using the toggle clamps. The operator will then use the control panel located in the Control Container to start the system. The Secondary Chamber must be at operating temperature before the Primary Chamber can activate.

To begin the process of burning the solid waste the **Primary Chamber Burner** is used to elevate the temperature of the Primary Chamber to ignite the waste. The burner package has a single motor that operates both the diesel fuel pump and combustion air supply fan of the burner. The burner ignites the fuel and supplies combustion air to create heat.






1. Louver
2. Container door
3. Opening for loading
4. Base frame
5. Toggle clamps

**Front View: Primary Chamber Container (Chamber open)**

A **Thermocouple** is used to measure the temperature of the Chamber. Once the Chamber reaches a temperature of approximately 650-850°C, the burn process becomes self-fuelling and the burner will shut off. To save fuel and control temperatures, only when the energy contained within the waste is depleted will the burner periodically turn on.

The amount of heat released from the oxidation of the waste, is controlled by limiting the air into the Primary Chamber to less than what is required for complete combustion. This is described as *starved air* conditions. With controlled air and temperature the waste is dried, heated and oxidized thereby releasing moisture and volatile components. The non-volatile, combustible portion of the waste is burned to provide heat while the non-combustible portion accumulates as residual. These conditions ensure that the waste is allowed to fully combust and is rendered sterile. Waste volume is reduced by over 90%. After enduring the combustion process, metals and glass remain intact. Preservation of metals and glass protects the refractory lining from damage caused by melted and fused metals and glass, but also allows for post-combustion recycling where possible.

This chamber also has a small **cooling fan**, typically referred to as the **Primary Chamber Blower**. The blower does not operate during the burn cycle but will activate automatically once the burn is complete and the system goes into cool down phase. The blower then cools the chamber for a period of 12 hours so that the chamber will be sufficiently cool for the Operator to safely remove the ash and begin to load a new batch of waste.



1. Thermocouple
2. Burner (Diesel-fired)
3. Primary Chamber Blower/Cooling Fan

## Primary Chamber Container

### 2.1.3.4.2 Secondary Chamber

As waste burns in the Primary Chamber, gases containing the products of combustion are pulled continuously into the high temperature zone of the **Secondary Chamber** where the oxidation reaction of the combustible products is completed.


To accomplish this, the Secondary Chamber controls the temperature at 1000°C using a thermocouple to constantly measure the temperature inside the chamber. The temperature readings are monitored by the system's PLC and the PLC will initiate operational changes such as increasing or decreasing the speed of the **Secondary Chamber Blower** and the output of the **Secondary Chamber Burner (Diesel-fired)**.

The **Secondary Chamber Blower** air is introduced into the chamber by an air ring manifold that surrounds the Secondary Chamber. The manifold has small air jets called tweers that open into the chamber at the side walls and create a powerful vortex of excess air to mix the incoming gases and ensure complete combustion. The flow of air is tightly managed by the control system using a Variable Frequency Drive (VFD) to control the speed of the fan and modulating motors on the blower inlet dampers.

The blower is extremely important as it creates the turbulence required to mix the gases and oxygenate them. This fosters the high efficiency combustion required to break hydrocarbon chains into carbon dioxide and water vapour. It also acts to cool the chamber and prevent temperature overruns.


**Secondary Chamber Burner (Diesel-fired)** is similar to the burner used in the Primary Chamber except that it is a much higher output burner and its output is self-modulated over a broad range for very precise temperature control.

The Secondary Chamber is sized to allow two seconds of retention time. This is the time that the gases from the Primary Chamber are retained in the Secondary Chamber before they exit to the next stage. Two seconds of retention is considered to be ideal to destroy any harmful organic hydrocarbons produced from the Primary Chamber.



1. Waste Oil Burner
2. Secondary Chamber Blower/Fan
3. Secondary Chamber Burner (Diesel-fired)

**Front View: Secondary Chamber Container**



1. Stack
2. Secondary Chamber View Port
3. Secondary Chamber Access Door

**Sample Rear View: Secondary Chamber Container**



#### 2.1.3.4.3 Main Control Panel


There is one Main Control Panel that controls all of the interconnecting modules. The Operator has one simple interface to start the equipment, view system status and change control settings if required. The entire process is managed using a **PLC** (programmable logic controller) to automate the operation. The critical process parameters such as temperature, combustion airflow and burner output are operated using EWS' patented system control program to maintain optimal combustion.




**Front View: Main Control Panel**

## 2.2 DESCRIPTION OF EWS MOBILE INCINERATOR

### 2.2.1 EWS Mobile Incinerator Containers



Front View



Rear View

The **EWS Mobile Incinerator** consists of the following containers as depicted in the drawing.

- 2.2.1.1      **Primary Chamber Container:** containing the Primary Chamber and diesel oil connectors
- 2.2.1.2      **Secondary Chamber Container:** containing the Secondary Chamber
- 2.2.1.3      **Controls Container:** containing the Main Control Panel (Monitoring and Control Centre) as well as the electrical hook-ups and Air Compressor
- 2.2.1.4      **Shipping Container:** Container to hold components during transportation (Not Shown)

EWS Mobile Incinerator: Description of each Container

#### 2.2.1.1    **#1 Primary Chamber Container**


- a. This standard 20' ISO shipping container permanently encloses the **Primary Chamber**.
- b. At one end of the container the operator can open the container and gain access to the large front-loading primary chamber door. The Primary Chamber door will pivot on its hinge to allow for an opening of 90°.
- c. At the other end of the container the doors will allow for unencumbered access to the auxiliary fuel (diesel) burner. Also located at this end is the Primary Chamber cooling fan. Other than during periodic maintenance and installation and disassembly, there is no need to regularly access these components and therefore these doors will be kept closed.
  - i. The Primary Chamber including all of its major components and plumbing will be shipped fully assembled within the container, with minimal assembly of interconnections required in the field.
- d. This container includes its own air handling system.
- e. This container is modified to allow interconnections to the other containers:
  - i. Hatch opening for interconnecting duct Breech between Primary and Secondary Chamber Containers
  - ii. Utility Bridge for fuel in, fuel return line out, electrical power in and instrument cables out





1. Primary Chamber View ports (2)
2. Toggle Clamps (4)
3. Door Bearings (3)
4. Primary Chamber Container Door

**Front View: Primary Chamber Container**  
(with Primary Chamber Door Closed)



1. Container Louver
2. Primary Chamber Container Door
3. Opening into Primary Chamber (loading area)
4. Base frame
5. Toggle Clamps

**Front View: Primary Chamber Container**  
(with Primary Chamber Door Open)



1. Thermocouple
2. Burner (Diesel-fired)
3. Primary Chamber Blower/Cooling Fan

**Rear View: Primary Chamber Container**

#### **2.2.1.2 #2 Secondary Chamber Container**


- a. This standard 20' ISO shipping container permanently encloses the **Secondary Chamber**.
- b. This container will be accessed by the Operator on a daily basis. The doors provide access for periodic maintenance and for access during installation and disassembly.
- c. The Secondary Chamber including all of its major components and plumbing will be shipped fully assembled within the container, with minimal assembly of interconnections required in the field.
- d. The Secondary Chamber includes an access door for inspection and maintenance access for the Secondary Burner
- e. This container includes its own air handling system.
- f. This container is modified to allow inter connections to the other containers.
  - i. Hatch opening for interconnecting duct, Breech between Primary and Secondary Chamber Containers
  - ii. Utility Bridge (Secondary Chamber to Primary Chamber) Interface for fuel in, fuel return line out, electrical power in and instrument cables out.
  - iii. Utility Bridge (Secondary Chamber to Controls Container) fuel, electrical, instrument and air.





1. Waste Oil Burner
2. Secondary Chamber Blower/Fan
3. Secondary Chamber Burner (Diesel-fired)

**Front View: Secondary Chamber Container**



1. Stack
2. Secondary Chamber View Port
3. Secondary Chamber Access Door
4. Toggle Clamps (2)
5. Door Bearings

**Rear View: Secondary Chamber Container**

### 2.2.1.3 #3 Controls Container

- a. This standard 20' ISO shipping container houses the Main Control Panel for the entire **EWS Mobile Incinerator** package.
- b. This container will be the main point of operations and control for the entire **EWS Mobile Incinerator** package.
- c. This container is modified to allow inter connections to the other containers.
  - i. Utility Bridge Interface with Secondary Chamber, fuel, electrical, instrument and air.
  - ii. Main power supply connection



- 1. Main Power Supply Connection 2" (power supply cable and coupling to be supplied by customer)
- 2. Control Room Door

## **2.3 SPECIFICATIONS & MATERIALS OF CONSTRUCTION**

### **2.3.1 EWS Mobile Incinerator: Operating Parameters**

<b>Operational Parameter</b>	<b>Rating</b>
Incinerator Type	Controlled-air, two-stage
Fuel Type	Main: Diesel; Auxiliary: Waste Oil
Waste load capacity	2000 kg
Batch cycle time	8-10 hours estimate
Factory Pre-set minimum burn time	480 minutes
Cool down cycle	10-12 hours
Pre-set automated cool down cycle operation time	720 minutes

### **2.3.2 EWS Mobile Incinerator: Technical Specifications**

#### **2.3.2.1 Incinerator: Materials of Construction**

<b>Component</b>	<b>Material of Construction</b>
Incinerator Shell	¼" thick mild steel, welded with continuous bead welds Sand-blasted and painted with rust-inhibiting, high temperature paint
Incinerator Lining – Primary Chamber Floor	Factory cured, reinforced castable monolithic refractory, 6" thick Rated to 1760°C
Incinerator Lining – Primary Chamber walls and roof, Secondary Chamber interior	Ceramic fibre modules, 6" thick Rated to 1200°C Modules are lightweight and are individually anchored to the shell (Heavy, high-strength material not required or desirable in these areas) Highly reflective, does not retain heat against shell Immune to thermal shock from temperature cycling inherent in batch operation
Incinerator Lining – Door jambs, lintels, breech openings, and other penetrations	Factory cured, formed, reinforced castable refractory, 6" thick Rated to 1200°C High-strength, erosion and abrasion resistant material required in the susceptible areas
Fuel Oil Tanks (Diesel & Waste Oil)	Mild steel tank, sand-blasted and coated with corrosion resistant paint. Double-wall construction.


### 2.3.2.2 Incinerator: Major Components Specifications


Component	Description	Size/Rating
Control System	Single main control cabinet houses all motor starters, breakers and overloads. PLC process controller, Variable Frequency Drive (VFDs) to control Secondary Blower. LCD Operator Interface.	Electrical Power Design Input: 600V, 60 A
Packaged Diesel Fired Burners	Industrial burners each with built-in blower to supply combustion air, oil pump driven by same motor. Burner complete with integral relief valve and filter, fuel pressure gauge, air proving switch and igniters.	Primary Burner Rating: 97/154-395 kW <b>Motor: 0.7 kW</b>  Secondary Burner Rating: 332/711-1482 kW <b>Motor: 2.1 kW</b>
Blowers	Factory run tested packaged design. Fan construction able to withstand high heat environment.	<u>Primary Blower:</u> Flow rate:1700 m <sup>3</sup> /h Standard Static Pressure (SP): 31.5 mmH <sub>2</sub> O <b>Motor: 1.12 kW (1.5 HP)</b>  <u>Secondary Blower:</u> Flow Rate:4247 m <sup>3</sup> /h Standard SP: 61 mmH <sub>2</sub> O <b>Motor: 1.5 kW (2 HP)</b>  Note: Standard Air, 70°F, 0.075IB/CF (21°C, 1.20 kg/m <sup>3</sup> )
Diesel Fuel Tank	Includes all required accessories: vent, drain, level sensor and lifting lugs.	Volume: 2200 litres
Waste Oil Tank	Includes all required accessories: vent, drain, level sensors, heater and lifting lugs.	Volume: 500 litres



## 2.3.3 EWS Mobile Incinerator: Controls Philosophy

### 2.3.3.1 EWS Mobile Incinerator Package Central Control System





## 2.4 WASTE PROCESSING CAPABILITIES

### 2.4.1 EWS Mobile Incinerator Waste Description

The waste types to be processed include: personal domestic waste, kitchen waste, dewatered sewage sludge, paper, packaging, lumber and textiles, documents, occasional tires and clinical medical waste (only gauze and needles). Furthermore, the specification indicates that hazardous materials including batteries will be eliminated from the incinerator waste stream.

### 2.4.2 Design Waste Assumptions

Quantity	2000 kg/day
Density	160-240 kg/m <sup>3</sup>
Higher Heat Value	15,150 KJ/kg
Moisture Content	Up to 40%

System capacity of 2000 kg per day is based on the above waste mix assumptions. Waste will be loose, as received and not compacted prior to loading. If high volumes of PET (clear plastic) water bottles are received some compaction is recommended to ensure that the waste mix characteristics are representative of materials presented in the quote AMR-ECO M 2TN.

#### NOTA

- 2.4.2.1 Higher heat value materials should be mixed with lower heat value materials to ensure that the average heat value of the batch load is approximately that listed above. Overloading the system with high heat value materials can cause uncontrolled combustion leading to pollution and/or damage to the incinerator system.
- 2.4.2.2 A batch system capacity is closely related to the waste density. If a large amount of very low density, low weight materials are loaded into the system at one time the volume of the Primary Chamber may limit the capacity to much less than it is rated for. Care should be taken to mix waste materials to ensure the correct density range. Also, materials containing large air spaces such as empty plastic bottles, and cardboard boxes should be flattened before loading.
- 2.4.2.3 When processing batches of very wet materials the burn cycle time should be increased to accommodate the additional time required to dry the waste before it can combust.
- 2.4.2.4 Do not load the system with more than 25% by volume of extremely wet materials such as grey water or wet garbage.
- 2.4.2.5 When possible layer the materials so that the load is a mix of wet and dry, and/or high and low heat value materials.
- 2.4.2.6 Never load more than approximately 20 litres of high heat value waste such as kitchen grease or used cooking oil as this can lead to an uncontrolled burn.
- 2.4.2.7 See the list in Section 2.4.4 "Unacceptable Waste Materials" for items that should not be processed in the **EWS Mobile Incinerator**.

### 2.4.3 Waste Materials Suitable for Processing

#### Waste Materials Suitable for Processing in the EWS Mobile Incinerator

The following table is a generic description of waste materials that can be processed effectively using this equipment.

Solid Waste	Description	Origin
Food Waste	Food, food packaging and containers, plastic and paper waste from food preparation	Kitchen and dining areas
Domestic waste	General refuse such as paper, plastics, cans, bottles, cardboard, newsprint	Dormitory areas, recreation facilities, office areas, warehouse, plant and production facilities
Packaging	Cardboard boxes, paper, plastic containers, plastic film, styrofoam, poly-weave bags	Inbound supplies to all work areas
Wood waste	Skids, pallets, crates	Construction activity, inbound supplies
Absorbents	Rags, wipes, spill cleanup materials	From all work areas
Filters – Air and Fluid	Filters coated with fine particles and trapped solids, saturated with water or fluids (glycol, lube oils, fuel)	From water treatment facility, or generated at point of maintenance of vehicles, machinery and equipment
Clinical Waste	Bandages, dressings, gloves, swabs, syringes, sharps	Medical clinic or first aid centre
Tires & Rubbers	Tires (only 1 at a time), belts, hoses	From vehicles and equipment maintenance shop
Semi-solid Waste	Description	Origin
Kitchen grease, oils	Solid kitchen fats, grease, used cooking oil in small pails (maximum volume 10 litres per burn)	Kitchen grease traps, fryers



## 2.4.4 Waste Materials NOT Suitable for Processing

### Unacceptable Waste Materials

Waste Type	Examples
Bulky Materials	Automotive or heavy equipment parts such as engine blocks and transmissions
Non-Combustible Materials	Drywall, asbestos, bricks, concrete, soils
Radioactive Materials	Smoke detectors, laboratory wastes
Potentially Explosive Materials	Pressurized vessels including, but not limited to propane tanks, aerosol cans (deodorant, shaving, cleaning, etc) and the like. Actual explosives.
High Alkaline or High Acid Materials	By-products of industrial processes, unrefined fuels.
Solvents	Solvents such as acetone, xylene, methanol

### NOTA

All materials of these types are strictly forbidden from processing. It is very important that all materials in these categories are diverted away from the incinerator in-feed. The examples provided are not an exhaustive list of all possible forms of these waste types.

A waste and procurement audit is highly recommended and encouraged to ensure that all sources of heavy metals (especially mercury) are identified and diverted from the incinerator.

## 2.5 REGULATORY COMPLIANCE

### 2.5.1 Environmental Regulatory Compliance

The Mobile Incinerator Package is required to operate with air emissions that comply with the regulations as set out by the CCME Canada Wide Standard for Dioxin and Furans.

EWS guarantees compliance of the **EWS Mobile Incinerator** with the stated limits in the CCME Canada Wide Standard for Dioxin and Furans, subject to the conditions outlined below (see Performance Criteria Conditions).

## 3.0 ASSEMBLY & INSTALLATION INSTRUCTIONS

### 3.1 GENERAL ASSEMBLY & INSTALLATION INFORMATION

The **EWS Mobile Incinerator** is largely assembled with interconnections and external components to be mounted as required.

#### 3.1.1 Customer Responsibility

- 3.1.1.1 Provide all foundation work of concrete blocks for the ends of the containers and packed gravel under the frame and tanks

#### **NOTA**

- a. **Fuel tanks should be out of the way and protected using bollards against accidental impact of mobile equipment (e.g. trucks, etc.)**

- b. Foundation requirements between pads to be determined by customer

- c. Specific locations to be determined by customer and site restrictions

- 3.1.1.2 Install I-beams, spacers and equipment using a crane, forklift, come-alongs, hydraulic jacks/hand-pumps, etc.

- 3.1.1.3 Provide all utility services including connections to the equipment including fuel, electrical, water, air, etc. using basic hand tools.

- 3.1.1.4 Provide all external thermal insulation and heat tracing when required on incoming and outgoing utilities.

- 3.1.1.5 Provide proper protection of all equipment from accidental damage or vandalism (bollards, exterior lighting, etc).

- 3.1.1.6 Perform any touch up painting and cleanup of equipment after assembly.

- 3.1.1.7 Locate the fuel tank at the specified distances to ensure maximum positive supply pressure on the suction side.

- 3.1.1.8 Obtain any and all construction, operating and environmental permits and other approvals as may be required in the area of jurisdiction where the equipment is being deployed and operated. EWS will assist in supplying technical information required for these permits to the customer as it relates to EWS equipment.

- 3.1.1.9 Maintain ample space around all equipment for maintenance, cleaning and safety considerations. A suggested provision would be to provide a minimum of 1.83 meters from all major equipment surfaces and edges. Always allow proper space for the swing radius of the chamber doors including vehicular traffic.

#### **NOTA**

**Do not scale drawings: If certain dimensions are required which are not shown on drawings, EWS should be contacted for the required dimension. EWS will not be**

responsible for any dimensional conflicts resulting from dimensions not shown on a certified drawing. Do not use general sales literature or other general equipment submittals for construction, assembly and/or erection, unless so indicated.

Please note that some of the diagrams and/or photos in this MANUAL are conceptual in nature and may not be exact representations of the equipment purchased.

---

### 3.1.2 Preparation Prior to Assembly & Installation

---

#### 3.1.2.1 Electrical & Fuel Availability

The electrical supply must be the Canadian supply of 600 V 60 Hz, 3 phases. There is one main electrical hook-up opening 2" located on the side of the Controls Container. All electrical connections are distributed from the Controls Container to the Primary Chamber Container and the Secondary Chamber Container.



**DO NOT CONNECT THE EXTERNAL POWER SUPPLY TO THE EWS MOBILE INCINERATOR UNTIL ALL INTERNAL ELECTRICAL CONNECTIONS ARE COMPLETE AND THE SYSTEM IS COMPLETELY ASSEMBLED.**

The fuel supply connections are located on the Primary Chamber Container and connect the fuel supply to the fuel tank located externally. There are fuel lines between the containers for fuel distribution which are to be connected before the external hook-ups and connections are made.



**DO NOT CONNECT THE EXTERNAL FUEL SUPPLY TO THE EWS MOBILE INCINERATOR UNTIL ALL INTERNAL FUEL CONNECTIONS ARE COMPLETE AND THE SYSTEM IS COMPLETELY ASSEMBLED.**

---

### 3.1.3 Assembly & Installation Overview

---

#### 3.1.3.1 Specialized Tools and Equipment for Assembly and Installation

The complete assembly of the **EWS Mobile Incinerator** will require 2-3 full time personnel for 2 days. The following list identifies the tools and equipment required to be supplied by the customer in order to proceed with the assembly:

- a. Crane
- b. Forklift
- c. Boom Lift, Scissor Lift and/or Scaffolding
- d. Steel Shims
- e. Ladder (12')
- f. Come-along
- g. Hydraulic Jack/pump
- h. Level
- i. Erection Wrench / Alignment bar
- j. Container Clamp 2"-Wrench

- k. Sling
- l. I-beam Clamp

The following list identifies the consumable items to proceed with the assembly:

- a. Anti-Seize Compound (Generic Graphite-Based Anti-Seize Compound)
- b. Gasket Spray-on Adhesive (Generic Spray-On Contact Cement)

### 3.1.3.2 Assembly Overview

The following general steps are the order in which the **EWS Mobile Incinerator** Package needs to be installed. Each step is detailed in the subsequent section.

#### **ORDER OF ASSEMBLY (and detailed in Section 3.1.4)**

- 1) I-Beam & Spacer Base Structure (Base Frame Structure)
- 2) Connections Between Primary and Secondary Chamber Containers
- 3) T-Stack Section on Secondary Chamber Container
- 4) Stacks and opacity monitor
- 5) Internal Component Connections
- 6) Internal Connections
- 7) External Connections

#### **NOTA**

#### **Important Notes to Consider Prior to and During Assembly**

- a. Lifting lugs are provided on the stacks, and major accessories, and should be used in setting these units into position.
- b. Do not allow lifting chains or cables to put loads on piping, or mounting flanges as they may be damaged.
- c. Avoid dragging lifting gear across painted surfaces.
- d. When placing the system into position, be careful not to subject the refractory to mechanical shock, which may result in refractory damage.

---

### 3.1.4 Assembly Instructions

#### 3.1.4.1 I-BEAM & SPACER BASE STRUCTURE (Base Frame Structure)

#### **NOTA**

For all fasteners used in assembly use regular-grade anti-seize spray to ensure that fasteners will be easily removed when disassembly is required.


#### **NOTA**

Do not fully torque bolts during initial assembly.


#### Correct Clamp Installation

When installing the clamps, install in such a manner that the installer pulls back on the





### 3.1.4.2 CONNECTIONS BETWEEN PRIMARY AND SECONDARY CHAMBER CONTAINERS







Gasket adhesive spray being applied





Correctly Installed Gasket




**NOTA**


Once breech flanges are aligned and together bolt flanges together using the numerical order described in the pattern below.








### 3.1.4.3 T-STACK SECTION AND SECONDARY CHAMBER CONTAINER





**NOTA**


One of the washers must be a lock washer.

**3.1.4.4 OPACITY MONITOR**

The sensors and purge air unit of the opacity monitor are shipped unassembled and in boxes.

The sensor's mounting flanges are pre-installed in the stack section and the bracket for the purge air unit are installed in the T –stack.

The Control Unit D-R 290 AW is installed inside the Secondary chamber container and pre-wired to the PLC



Standard	* Optional
1 Control unit, D-R 290 AZ (stack display) Or D-R 290 AW (evaluation unit)	6 Customer supplied recorder or data logging system
2 Transceiver, D-R 290 MK	7 & 8 Weather Hood, US built systems use one
3 Reflector, D-R 290 R1 or R2	Large weather hood for blower and optics
4 Mounting flange, D-R 280 E	9 Fail-safe shutters
5 Purge air unit	10 Fail-safe shutter control electronics

Install the Transceiver and Reflector in the flanges provided in the stack section

Install the Purge Air Unit in the bracket provided in the T-Stack

Connect the Transceiver to the Control unit

Connect power to the Purge Air Unit

### 3.1.4.5 INTERNAL COMPONENT CONNECTIONS



Flexible conduit in  
Container 2 (secondary  
chamber)

Feed flexible conduit from container 2 to containers 1 and 3 through the openings connecting the containers



Junction Boxes in  
container 3 (control  
container)

Connect each flexible conduit to the correspondent Junction Box (i.e. JB1 conduit with JB1 box) wire the terminal block inside the junction box following the labels on both the wires and the terminal block

Junction Boxes in  
container 1 (primary  
chamber)






Complete all Junction boxes in both Container 3 and Container 1




**DO NOT CONNECT THE ELECTRICAL UNLESS THE MAIN SUPPLY FROM THE SITE HAS BEEN INTERRUPTED AND THE INCINERATOR BREAKERS ARE IN THE OFF POSITION**




2" opening for power supply in container 3

Feed the 600v 40Amp 60Hz power through the 2" opening in container 3 (power supply cable and 2"coupling to be provided by the customer) and connect the wires to the Main Disconnect. The main supply from the site can be turned on now.



Switch on all incinerator breakers in the Breaker Panel






### 3.1.4.6 INTERNAL CONNECTIONS




Compressed air quick connect for Waste Oil Burner

Connect the air hose from the Waste oil Burner to the quick connect fitting



**IMPORTANT:**  
Diesel lines and Waste Oil lines need to be primed immediately after connections are made




To fuel tanks  
(diesel and waste oil)

Diesel Return  
(yellow thin)

Diesel Supply  
(yellow thick)

Waste Oil  
(orange)



Feed wires for the tanks' level sensors and waste oil tank heater from the tanks through the opening beside the hose adaptors and connect to the junction boxes

## 3.2 DISASSEMBLY INSTRUCTIONS

### 3.2.1 General Disassembly Information

The customer's personnel and/or contractors are responsible to:

- 3.2.1.1 Perform disassembly according to instructions provided by EWS in this *Manual*.
- 3.2.1.2 Disassemble I-beams, spacers and all incinerator component equipment using a crane, forklift, come-alongs, hydraulic jacks/hand-pumps, etc...
- 3.2.1.3 Disconnect all utility services including connections to the equipment including fuel, electrical, water, air, etc. using basic hand tools prior to disassembly

#### **NOTA**

Do not scale drawings: If certain dimensions are required which are not shown on drawings, EWS should be contacted for the required dimension. EWS will not be responsible for any dimensional conflicts resulting from dimensions not shown on a certified drawing. Do not use general sales literature or other general equipment submittals for construction, assembly and/or erection, unless so indicated.

Please note that some of the diagrams and/or photos in this FACILITY MANUAL are conceptual in nature and may not be exact representation of equipment purchased.

### 3.2.2 Preparation Prior to Disassembly

#### **NOTA**

**DO NOT DISCONNECT THE INTERNAL ELECTRICAL CONNECTIONS UNTIL THE EXTERNAL POWER SUPPLY TO THE MOBILE INCINERATOR HAS BEEN SAFELY DISCONNECTED.**

#### **NOTA**

**TURN POWER OFF AT CUSTOMER SUPPLIED GENERATORS**

The fuel supply connections (diesel and waste-oil) are located on the Primary Chamber Container and disconnect the fuel supply from the fuel tanks located externally. There are fuel lines between the containers for fuel distribution which are to be disconnected after the external hook-ups and connections have been disconnected.

#### **NOTA**

**DO NOT DISCONNECT THE INTERNAL FUEL CONNECTIONS UNTIL THE EXTERNAL FUEL SUPPLY TO THE MOBILE INCINERATOR HAS BEEN DISCONNECTED.**

### 3.2.3 Disassembly Overview

#### 3.2.3.1 Specialized Tools and Equipment for Disassembly

The complete disassembly of the **EWS Mobile Incinerator** will require 2-3 full time personnel for 2 days. The following list identifies the equipment required to be supplied by the customer in order to proceed with the disassembly:

- a. Crane
- b. Forklift
- c. Scissor Lift
- d. Shims
- e. Ladder (12')
- f. Come-along
- g. Hydraulic Jack/pump
- h. Level
- i. Erection Wrench / Alignment bar
- j. Container Clamp 2-Wrench
- k. Sling
- l. I-beam Clamp

#### 3.2.3.1 Disassembly Overview

The following general steps are the order in which the **EWS Mobile Incinerator** Package needs to be disassembled. Each step is detailed in the subsequent section.

#### ORDER OF DISASSEMBLY (as detailed in Section 3.2.4)

- 3.2.4.1 External Disconnections
- 3.2.4.2 Internal Disconnections
- 3.2.4.3 Internal Component Disconnections
- 3.2.4.4 Removal of opacity monitor
- 3.2.4.5 Removal of Stack Sections
- 3.2.4.6 Disassembly and Removal of Containers from Base Frame Structure
- 3.2.4.7 Disassembly of Base Frame Structure



#### **NOTA**

#### Important Notes to Consider Prior to and during Disassembly


- a. Lifting lugs are provided on the stacks, and major accessories, and should be used when disassembling the incinerator
- b. Do not allow lifting chains or cables to put loads on piping, or mounting flanges as they may be damaged.
- c. Avoid dragging lifting gear across painted surfaces.
- d. When removing the system from its position, be careful not to subject the refractory to mechanical shock, which may result in refractory damage.

### 3.2.4 Disassembly Instructions

#### 3.2.4.1 EXTERNAL CONNECTIONS







Switch off all breakers in the Breaker Panel



**DO NOT DISCONNECT THE ELECTRICAL UNLESS THE BREAKERS  
ARE IN OFF POSITION**



**DO NOT DISCONNECT THE MAIN POWER FEED UNLESS THE MAIN SUPPLY  
FORM THE SITE HAS BEEN INTERRUPTED**



2" opening for power  
supply in container 3

Disconnect the wires to the Main Disconnect and remove the 600v 40Amp 60Hz power through the 2" opening in container 3



**IMPORTANT:**  
Diesel lines to be disconnected  
and drained (along with Waste  
Oil line)



Diesel Return  
(yellow thin)

Diesel Supply  
(yellow thick)

Waste Oil  
(orange)



Disconnect wires to the tanks level sensors and waste oil tank heater from the junction boxes and remove them through the opening beside the hose adaptors.

#### 3.2.4.2 INTERNAL CONNECTIONS



Junction Boxes in  
container 1 (primary  
chamber)





Junction Boxes in  
container 3 (control  
container)

Disconnect the wires from the terminal block inside every junction box in both Container 1 and 3, replace any wire labels and conduit labels missing or damaged



Flexible conduit in  
Container 2 (secondary  
chamber)

Pull the flexible conduit from container 1 and 3 into container 2 through the openings connecting the containers




Compressed air quick connect for Waste Oil Burner

Disconnect the air hose for the Waste oil Burner from the quick connect fitting



Quick Connect for  
Compressed Air in  
Container B

### 3.2.4.3 REMOVAL OF OPACITY MONITOR



Standard	* Optional
1 Control unit, D-R 290 AZ (stack display) Or D-R 290 AW (evaluation unit)	6 Customer supplied recorder or data logging system
2 Transceiver, D-R 290 MK	7 & 8 Weather Hood, US built systems use one
3 Reflector, D-R 290 R1 or R2	Large weather hood for blower and optics
4 Mounting flange, D-R 280 E	9 Fail-safe shutters
5 Purge air unit	10 Fail-safe shutter control electronics



Disconnect power to the Purge Air Unit

Disconnect the Transceiver to the Control unit

Uninstall the Purge Air Unit in the bracket provided in the T-Stack



Uninstall the Transceiver and Reflector in the flanges provided in the stack section


#### 3.2.4.4 REMOVAL OF STACK SECTIONS



#### 3.2.4.5 DISASSEMBLY AND REMOVAL OF CONTAINERS FROM BASE FRAME STRUCTURE











## DISASSEMBLY OF BASE FRAME STRUCTURE



**Miscellaneous Final Items:**

- Replace all remaining hatch covers on Containers A, B and C
- Pack all remaining parts for shipment:
  - Nuts, bolts and washers
  - Stacks, t-section and breech on marked skids
  - I-beams and spacers from the base-frame
  - Fuel and Waste Oil tanks

**3.2.4.6 PREPARATION FOR STORAGE AND WHILE IN STORAGE**

The following items will be required for final packing and storage:

- Lubricant (Lithium Spray Grease)
- Standard Grease (Mobilgrease 28)
- Silicone (MONO Ultra)
- Desiccant (Shipping Container Desiccant)

**1. Primary Chamber Container (1) and Secondary Chamber Container (2):**

**General**

- a. Place desiccant bags under chambers and replace every 6 months
- b. Lubricate door frames (hinges and bearings) using standard grease.
- c. Place desiccant bags in the Primary and Secondary Chambers and replace every 6 months.
- d. Seal all container openings with silicone rubber caulking (Sealastic® or equal - block to discourage pilfering).

**Ventilation and Exhaust Fans**

- e. Coat coupling and all external machined parts with standard grease.
- f. Spray light penetrating oil on fan wheel.
- g. For long term or outdoor storage, mounted bearings should be re-greased and wrapped with plastic for protection. Rotate the fan wheel by hand at least every two weeks to redistribute grease on internal bearing parts. Each month the bearings should be purged with new grease to remove condensation, since even a filled bearing can accumulate moisture. Use caution when purging, as excessive pressure can damage the seals. Rotate the shaft while slowly adding grease. Place desiccant bag in fan housing and replace every 6 months.

**Fan and Pump Motors**

- h. Spray light penetrating oil on the shafts of the motors.
- i. Fill bearing housing with grease containing five percent rust-preventive concentrate.

- j. Coat all exposed machined parts with standard grease
- k. Do not rotate motors

## 2. Controls Container (3)

### Air Compressor


- a. Purge compressor cylinders of hydrocarbons.
- b. Blank compressor suction and discharge.
- c. Fill crankcase, cooling water jacket and valves with oil containing five percent rust-preventive concentrate. Allow space for thermal expansion.
- d. Coat all exposed machined parts with standard grease.
- e. Top-up oil level in the cooling water jacket.
- f. Controls container must be stored in a climate-controlled building during this period to protect the PLC and instrumentation from freezing temperatures or fluctuations in temperature that go below the dew point. No components will require special attention if the container is stored in a building kept above the dew point temperature (e.g. above 15°C at less than 35% relative humidity).

### 3.2.4.7 PACKING SKIDS AND CRATES IN CONTAINERS

- 1. Prior to shipment ensure all components are strapped and fastened within the container.
- 2. If all above items were followed for the preparation and while in storage, the system should be ready for shipment and usage.

### 3.3 OPERATING INSTRUCTIONS

The operation of the Mobile Waste Incinerator package follows 6 general steps that take place over a 24 hour period.



This section focuses on Steps 3 and 4 and how to start the system and monitor it during operation, however it is assumed that the waste is properly loaded with the weight, density and type stated in Part II Section 4. It is also assumed that the waste is loaded after the ash has been removed from the previous burn cycle and any daily maintenance routines have been completed.

#### 3.3.1 Operator Interface

##### 3.3.1.1 Control Panel Components



#### Panel View:


1. Main Disconnect Switch
2. Panel View Operator Panel
3. Control Power ON
4. Emergency Stop Button
5. Ethernet Ports

1. Main Disconnect Switch : Controls all power to the system.


2. PanelView Operator Interface (“PanelView”): Displays various screens reflecting system performance.
3. Control Power On:
  - 1 – Green light indicates the control power in the panel is on;
  - 2 – Pushing this button if the E-stop is out will turn on the control power.
4. Emergency Stop Keylock Button: Stops the current burn cycle in progress and disables the ability to restarting it.
5. USB Flash Drive Port: Port used to insert USB drive to download system historical usage data.

### 3.3.1.2 Operator Interface

The PanelView Operator Interface controls the operation of the mobile incinerator package directly from the Control Panel.




The main screen displays all the available options for viewing the system in operation. The PanelView is a touch-screen and items can be selected by touching them on the screen.



When the **TOP VIEW** button is selected, an overview of the incinerator and related components are displayed. This shows key temperatures, flows, and other indicators of what is happening in the process in a real-time basis.

The system will not start if there are alarms or faults present. To clear (acknowledge faults)  
At any time, touch or press **MENU** to go back to the main screen.




When the PRIMARY or SECONDARY SYSTEM STATUS is selected from the Main Menu a screen (above) will display the status of all the operating parameters of the respective chamber such as the temperatures and the time remaining in the cycle as well as displaying other informational items such as status of the door and blowers, etc.




The operator can change the burn time of the cycle by selecting “BURN TIME” and entering a time (in minutes). The operator may do this over time to either prolong the burn time, or decrease the burn time depending on the waste mix. (E.g. a very wet batch of garbage will take more time than a dryer batch of waste).

At any time, touch or press **MENU** to go back to the main screen.




When the **TEMPERATURE HISTORY** is selected the screen will display the temperature history for the last burn showing various temperatures throughout the system. This information is stored for 30 days.



When **ALARM HISTORY** is selected the screen displays the last 25 faults with the date & time of occurrence. The operator can press the **CLEAR ALARM HISTORY** to clear all of the faults. The operator can also clear individual alarms by selecting them on-screen and pressing the **ACKNOWLEDGE** button.



The operator can select **ALARM COUNT**, and view the specific number of alarm faults.

At any time, touch or press **MENU** to go back to the main screen.





When the **DRAFT HISTORY** is selected the screen will display the draft history for the last burn showing data throughout the system. This information is stored for 30 days.

At any time, touch or press **MENU** to go back to the main screen.



When the **MOTOR CURRENT HISTORY** is selected the screen will display the motor current history for the last burn showing data throughout the system. This information is stored for 30 days.

At any time, touch or press **MENU** to go back to the main screen.



When the **OPACITY HISTORY** is selected the screen will display the opacity current history for the last burn showing data throughout the system. This information is stored for 30 days.

At any time, touch or press **MENU** to go back to the main screen.

### **3.3.1.3 Starting the Cycle**

To start the burn cycle, ensure that the waste is loaded into the system according to the waste mix described in Part II Section 4 and not blocking the burner cone or area where the flame will be directed into the Primary Chamber. Make sure the door is clamped in all places on the Primary Chamber.

At the control panel, on the Panel View press the “Start System” button and the system will initiate the Purge Cycle, followed by the Burn Cycle and then ending with the Cool Down Cycle.

### **3.3.1.4 Purge Cycle**

This is the first step in the burn cycle and is in place for safety reasons. The purge exhausts potentially explosive gases that could be remaining in the system and burners. The primary and secondary blowers will run to purge both chambers. The primary and secondary blower indicators on the Top View screen on the Operator Interface will say “Primary Chamber Blower On” and “Secondary Blower On”

### **3.3.1.5 Burn Cycle**

When the purge is finished the Secondary Burner will come on and for safety reasons will perform a purge and then ignite. Once the Secondary Chamber temperature reaches 1000°C the Primary burner will purge and then ignite. The burn cycle time will start when the Primary Chamber temperature reaches 427°C

The Secondary Burner will modulate to maintain Secondary temperature. If the Secondary Chamber starts getting too hot the Secondary damper opens and the blower will increase in speed to assist with cooling. When the secondary chamber cools down the damper will start to close again.

When the waste in the Primary chamber starts to burn hot enough, the primary burner turns off (815°C) and stays off. When the waste can no longer sustain the temperature in the Primary chamber, the primary burner will come back on (760°C). This will continue until the remaining burn time reaches zero.

When the burn time reaches zero, the system will enter the cool down cycle. The Primary chamber and Secondary chamber burners turn off; the secondary chamber blower turns off and the primary blower starts and runs until the cool down cycle is complete. The cool down cycle is complete after the cool down timer has timed out.

### **3.3.1.6 Using Historical Charts**

- a. Go to the Main Screen of the control panel operator interface.
- b. Select the historical chart you want to view (e.g. Temperature, Draft, etc).
- c. Once the desired chart appears the “buttons” on the bottom left and right of the screen can be used to scroll through to previous days’ information by selecting them and holding down.
- d. Once the desired date is selected the graph will be on the screen indicating the time and specific data trends (e.g. Temperature, Draft, etc) of the burn.

### 3.3.2 Procedure before Start Up

The operating instructions are to occur once the assembly of the system is completed and inspected. Before you continue with the operating instructions ensure that the following items are completed:

- a. All physical components attached and bolted
- b. All internal electrical connections are completed
- c. All internal fuel and air connections are completed
- d. All external fuel lines have been connected (tanks to container)

#### **NOTA**

**Before connecting the external electrical connection, ensure that all internal electrical connections have been made**

Once all the above activities and the assembly instructions have been completed, follow the procedure outlined below:

- 3.3.2.1 Located in the control room of the Controls Container turn on the power on the Main Disconnect
  - a. If red light is illuminated, change the phase on customer-supplied power. DO NOT TRY CHANGING THE PHASE ON EWS SUPPLY.
  - b. If green light is illuminated, power supply and phasing are confirmed and start-up procedures can be continued
- 3.3.2.2 Turn lights on, located in the auxiliary power breaker panel
- 3.3.2.3 Turn exhaust fan on, located at the auxiliary power breaker panel
  - a. If outside ambient temperature < 5°C: Turn heater on from the auxiliary power breaker panel because the temperature in Controls side of container must be > 5°C
- 3.3.2.4 Turn on remaining breaker in auxiliary panel
- 3.3.2.5 Once the Human Machine Interface (HMI) (Panel View) is running and power sequence is correct push the "Control Power On" button.
- 3.3.2.6 Ensure there is power supply to all containers by selecting the Top View from Panel view and check:
  - a. All temperature readings (if 1371°C is displayed the thermocouple is not connected or is faulty.)
  - b. That the Primary and Secondary Chamber door position on screen is the same as on the system, if shown incorrectly check limit switch
- 3.3.2.7 Fill fuel tank and the Waste Oil Tank if the planned burn is with waste oil

**NOTA ONLY DIESEL FUEL CAN BE STORED IN THE DIESEL FUEL TANK**



Before filling the tank ensure:

- a. The storage tank is in good condition, e.g. tank shall not exhibit severe rusting, apparent structural defects or deterioration.
- b. No leaking visible. If leaking is detected perform the following clean-up steps:
  - i. Stop the release
  - ii. Contain the released fuel
  - iii. Clean up and properly manage the released fuel as per best environmental standards
  - iv. Repair or replace the leaking tank prior to returning it to service.
- c. Inspect the bottom of tank for sludge formation. Perform the following steps.
  - i. Remove fuel tank access cover.
  - ii. Do a visual inspection of the inside of the tank, clean if necessary. A drain valve is located at the bottom of the tank to assist with cleanout. Ensure the drain valve is in place before filling.
  - iii. Ensure valve is closed
  - iv. Fill the tank through the access.

**NOTA**

**Load the oldest liquid inventory first. Long term storage may result in the formation of sludge or the growth of soluble and insoluble bacteria that can clog the downstream filters.**

When the tank is full, do a “walk around” of the tank and inspect tank for leaks and structural defects.

3.3.2.8 Ensure all ball valves are in the open position.

3.3.2.9 Physically prime the Primary Burner located in the Primary Chamber container

- a. Using scaffolding, a scissor-lift, or another safe method of elevation, prime the fuel line by inserting a funnel into the opening where the line meets the connector to the tank. Fill using a 20 L diesel fuel container until the line is devoid of air, taking care to avoid spillage.
- b. **Before starting the burner, make sure that the tank return line is not clogged.**
- c. The pump leaves the factory with the by-pass closed.




Figure A

- d. In order for self-priming to take place, one of the screws (#3) must be loosened in order to bleed off the air contained in the suction line; see Figure A (above) of the pump. Start with switch #1 see Figure B (below) in the "ON" position. The pump must rotate in the direction of the arrow marked on the cover.





Figure B

- e. The pump can be considered to be primed when the light oil starts coming out of the screw #3 see Figure A (above). Stop the burner: switch #1 see Figure B (above) set to "OFF" and tighten the screw #3 see Figure A (above). The time required for this operation depends upon the diameter and length of the suction tubing. If the pump fails to prime at the first starting of the burner and the burner locks out, wait approx. 15 seconds, reset the burner (by pressing the reset button, red illuminated button on the control box), and then repeat the starting operation as often as required. And so on.
- f. After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.
- g. Do not let extraneous light hit the photocell or the burner will lock out; the burner should lock out anyway about 10 seconds after it starts.
- h. **NOTA** The pump is full of fuel when it leaves the factory. If the pump has been drained, fill it with fuel through the opening on the vacuum meter prior to starting; otherwise, the pump will seize.
- i. Whenever the length of the suction piping exceeds 20-30 meters, the supply line must be filled using a separate pump

3.3.2.10 Physically prime the Secondary Burner located in the Secondary Chamber container


- a. Before starting the burner, make sure that the tank return line is not clogged. Obstructions in the line could cause the sealing organ located on the pump shaft to break.
- b. In order for self-priming to take place, screw #3 see Figure C (below) of the pump must be loosened in order to bleed off the air contained in the suction line.



D1226

Figure C

- c. Start the burner by closing the control devices with switch #1 in Figure D (below) in the "MAN" position. As soon as the burner starts, check the direction of rotation of the fan blade, by looking through the flame inspection window.



D791

Figure D

- d. The pump can be considered primed when the light oil starts coming out of screw #3 in Figure C (above). Stop the burner: switch #1 in Figure D (above) set to "OFF" and tighten screw #3 in Figure C (above). The time required for this operation depends upon the diameter and length of the suction tubing. If the pump fails to prime at the first starting of the burner and the burner locks out, wait approx. 15 seconds, reset the burner, as often as required. After 5 or 6 starting operations allow 2 or 3 minutes for the transformer to cool.
- e. **NOTA** The pump is already full of fuel when it leaves the factory. If the pump has been drained, fill it with fuel through the opening on the vacuum meter prior to starting; otherwise, the pump will seize.

Whenever the length of the suction piping exceeds 20-30 meters, the supply line must be filled using a separate pump.

### 3.3.3 First Time Use (WILL ONLY BE PERFORMED ON SYSTEM ONCE)

**NOTA:**

This is to be performed the first time the system is ever used; it will only be required to be done once.



- 3.3.3.1 From Panel View Main Screen select Curing.
- 3.3.3.2 From the Curing menu select Curing Status push the following buttons to set up the curing for Primary and Secondary Chamber “Push to enable Primary Curing” and push “Push to enable Secondary Curing”
- 3.3.3.3 From Panel View press Start Cure
- 3.3.3.4 The system will start the curing process which takes 24 – 30 hours
- 3.3.3.5 If the curing cycle is interrupted reset the curing cycle from the Curing Status screen
- 3.3.3.6 The cycle will restart from where it got interrupted.


### 3.3.4 Standard Operating Procedures

The following section details the procedures for the operation of the incinerator.

#### 3.3.4.1 System Start up (solid waste only)


- a. Drain the air compressor before starting system
- b. Ensure that manual slide gates for each blower are in the open position for free airflow into the Primary and Secondary Chambers.





1. Primary Chamber blower  
Manual Slide Gate Open  
Position
2. Primary Chamber blower  
Manual Slide Gate Closed  
Position
3. Secondary Chamber blower  
Manual Slide Gate Open

- c. Visually inspect the burner hoses to ensure that there are no fuel leaks. Check to see if lines are brittle or cracked, check for any oil spills near the burner, which would indicate a leak.
- d. Ensure the draft gauge hose connection is tight and sealed. This is a copper tubing located in the back upper corner of the Primary Chamber.



Draft Gauge Hose connection

- e. Unlatch all four clamps on the Primary Chamber door, open and secure in the open position





- f. Ensure that the Primary Chamber has been cleaned out, and the Chamber floor is cool (less than 40°C).

**NOTA**

If the floor is hotter than this temperature the waste may spontaneously catch on fire during loading.

- g. Weigh the waste on scale and begin loading the Primary Chamber from the front (or hand bomb as required).

**NOTA**

In the event that some waste is loaded by hand do not deliberately throw the waste towards the sides of the Primary Chamber. Doing so will damage the ceramic blanket refractory.

**NOTA**

When loading the waste loading avoid contact with refractory (wall modules, door jams, sills, lintel, etc)

**NOTA**

Load only the waste stream that the unit has been rated for see Facility Manual Part II Section 4 Waste Processing Capabilities.


**NOTA**

Do not load the Primary Chamber above its rated capacity by weight


**NOTA**

Do not load the Primary Chamber such that the breech section is blocked in any way

- h. Close the Primary Chamber access door by clamping each latch until it is tight
- i. Ensure that the waste oil burner is all the way out (limit switch in the back of the bracket activated), insert the waste oil plug in place and insert the locking pin to avoid burner from swinging



Waste oil all the way out limit switch made



Secondary chamber plug being installed




Waste oil burner secured with pin

- j. Proceed to the Control Panel on the HMI Panel View, from the Top View menu choose solid waste only.
- k. The burn time will be set to the previous burn, if you wish to change the set time, proceed to the Primary Status screen and click on the BURN TIME button. The minimum number of minutes you can enter is 480 (8 hours). When you have finished, the time will be displayed in minutes beside the BURN TIME button

**NOTA**

The burn time value (in minutes) determines the length of the burn cycle before cool down cycle starts.



### Main Control Panel

- I. On the Main Control Panel press “Start” on HMI (Panel View). The following steps will automatically take place, controlled by the Control Panel:
  - i. The Primary Blower and Secondary Blower will purge the system for 2 minutes
  - ii. The Secondary Burner will purge for safety, and upon completion will ignite
  - iii. Once the Secondary Chamber temperature reaches 1000°C, the Primary Burner will purge for safety and upon completion will ignite
  - iv. The Burn time will start counting down when the temperature in the Primary Chamber reaches 427°C

#### **NOTA**

**The Control System will maintain proper operating conditions and will provide continuous monitoring capability**

- v. After the burn cycle is completed, the system will automatically enter the Cool Down cycle and the following will be shown on the system status:
  - Primary Chamber & Secondary Chamber burners OFF
  - Secondary Chamber Blower OFF
  - Primary Modutrol 100% open
  - Primary Blower ON
- vi. Once fully cooled and the temperature is below 90°C, proceed to the Primary Chamber Clean Out procedures

#### **NOTA**

**System drains and exhausts should discharge at atmospheric pressure. In order to prevent inaccurate readings or instrument damage, do not allow the discharge side to back up or freeze.**

### 3.3.4.2 Clean Out

Operators responsible for loading and cleaning out incinerators shall wear appropriate protective equipment, including dust masks, heavy gloves and safety shoes with puncture-proof toes and soles to avoid injury. Although the ash from the system is considered sterile and will not contain microorganisms, it may contain a quantity of sharp objects, such as broken glass and other sharps which may not be fully destroyed in the burning process, and may thus still pose a hazard to persons who clean out the ash and residues. Also removing the ash does create dust particles in the air. Dust shall not be inhaled. The operator shall wear dust protection safety gear.

**When the internal temperature of the Primary Chamber has cooled to less than 90°C, lock out the power to the system on the Main Control Panel by moving the main disconnect to the “OFF” position.**

- a. Unlock all door latches on the access door to the Primary Chamber
- b. While standing in front of the Primary Chamber door, slowly open the door to its fully open position. Secure Primary Door in the open position.

- c. Inspect the interior for wear and inspect around the door seals to ensure the door will maintain a tight seal upon closure
- d. Check the air inlet holes and remove any obstructions if necessary.
- e. Inspect the door seals to ensure there are no gaps between the door gasket and the door jamb
- f. Close the Primary Chamber access door by clamping each latch until it is tight
- g. Clean the inspection view port (glass) with a mild soap and water. To clean the view port, unscrew it by hand and re-tighten by hand.

#### 3.3.4.3 Burning Waste Oil




Do not use this incinerator to burn waste oil only. Always burn a complete load of solid waste when burning waste oil

- a. Follow all the procedures to load the primary chamber as per procedure 3.3.4.1 above.
- b. Ensure that the secondary chamber plug is removed, the burner cannot swing open by locking the pin and the waste oil burner is all the way in (limit switch in the front of the bracket activated).



With the burner all the way out remove pin




Swing the burner open





Remove plug



Swing the burner close, secure with pin and push all the way in until front limit switch is made

- c. Proceed to the Control Panel on the HMI Panel View, from the Top View menu choose Solid Waste and Waste Oil.

---

### 3.3.5 Start up

#### 3.3.5.1 After Shut Down (Emergency)

- a. Once the power is restored main disconnect back on
- b. The Operator Interface and PLC will begin a boot up procedure
- c. Wait until the HMI on the control panel has booted up before turning the control power to the panel back on by pressing the Control Power ON button
- d. When the power is restored to the Main Control Panel, the button should illuminate.
- e. If the system was interrupted during a burn cycle, restart the system by pressing “Start” on HMI. If the system was interrupted during cool down, it will resume the cycle where it left off.

#### 3.3.5.2 After Power Failure

- a. On the main menu of the Panel View (HMI), press the Configuration Key and the application will now shut down. (This will take 1-2 minutes).
- b. There will be a GREY screen with a number of Touch Buttons.
- c. Press the “RUN (F1)” button on this screen.
- d. The application will now restart. (This will take approximately 1-2 minutes)
- e. When it is up and running, the system is now ready for operation



**NOTA**

In the event of a power shut down to the system, the control panel must be re-started from the HMI Panel View:

### 3.3.6 Dealing with Warnings and Faults

#### 3.3.6.1 Troubleshooting

The burn cycle will not start if one of the following conditions exists

- a. The Systems is in the “cool down” part of the cycle. Wait until the “cool down” cycle is complete.
- b. There is a fault in the system as indicated on the Panel View.
- c. Loss of Power due to any one or more of the following:
  - i. The main disconnect (see image) is off or there is no electrical power. Turn on the disconnect switch or check why there is no power.




- ii. An open breaker. Check the breakers and replace any that are defective.
- iii. The emergency stop is pushed in. Twist the emergency stop button to unlock, and then push the control power on button. The control power button should now be illuminated.



- d. If on the "Top View" screen on the HMI the primary door is not closed, the door has not been shut properly. Adjust the limit switch lever arm if necessary. Check the limit switch and that the wiring is in working order.
- e. If on the "Top View" screen on the HMI the secondary door is not closed, the door has not been shut properly. Adjust the limit switch lever arm, if necessary. Check the limit switch and that the wiring is in working order.
- f. If fuel tank is low, system will not start. Tank on the HMI will be red, indicating the level is low and needs to be filled.

g. PLC Processor Problem



- i. Check the run light on the PLC processor. If the run light is on, the PLC is ready.
- ii. "OK light" is green = Controller is OK
- iii. "OK light" is Red Flashing = this is a recoverable fault, check the PLC processor. This fault is very unlikely to occur.
- iv. OK light is Red = this is a non-recoverable controller fault. Cycle Power. The OK LED should change to flashing red. If LED remains solid red, replace the PLC. This fault is very unlikely to occur.
- v. "Default Channel Zero (DCH0) light" is green = this indicates the PLC processor has lost the program. The PLC is equipped with a flash card that will automatically load the program back onto the PLC

### 3.3.6.2 Possible Problems/Causes/Solutions

Problem	Causes	Solutions
Blower Fails to start	Breaker tripped	Turn power off at Main Disconnect Open Panel and check which breaker has tripped, turn back on
	Motor starters or contactor coil is burnt out	Locate contactor for blower and visually observe if the contactor is pulled in. Use a multi meter to check for voltage across the coil If there is voltage across the coil and the contactor is not pulled in, replace the contactor. See <i>Part IV Section 4 CMI 4.4.4/01-001G</i>
Secondary Burner won't ignite	Bad Electrodes	<i>Refer to Part IV Section 2 Preventive Maintenance Instructions (PMI) 01/02-002.D.01</i>
	Low Oil Pressure	Adjust pressure setting on burner pump by turning the screw located at the bottom of the pump. Turn clockwise to increase pressure and counter clockwise to decrease pressure.
	Fuel Line Leak	Visually inspect the lines for the leak Tighten any fittings that are near the leak
	Door Switch not making contact	Make sure main door is closed and latched shut Make sure limit switch is hitting striker plate.
	Bad Thermocouple	Replace thermocouple see Section IV Part 4 CMI 4.4.1/05-002A
Primary Burner won't ignite	Bad Electrode	<i>Refer to Part IV Section 2 PMI 01/02-002.D.01</i>
	Low Oil Pressure	Adjust pressure setting on burner pump by turning the screw located at the bottom of the pump. Turn clockwise to increase pressure and counter clockwise to decrease pressure.
	Fuel Line Leak	Visually inspect the lines for the leak Tighten any fittings that are near the leak
	Door Switch not making contact or broken	Make sure main door is closed and latched shut. Make sure limit switch is hitting striker plate.

<b>Problem</b>	<b>Causes</b>	<b>Solutions</b>
	Secondary temperature not at 1000°C	Wait until Secondary temperature is at 1000°C and try again
	Burner main switch is turned off	Turn switch on
	Burner alarm has been tripped	Acknowledge burn alarm and then hit the reset button on control panel
Persistent Black Smoke	Insufficient air supply to Secondary Chamber to completely consume emissions	Check to ensure combustion air blower/damper assembly is operating properly.
	Secondary Chamber is not hot enough.	Check that the Secondary temperature is operating at required temperature set point.
	Overloading or loading highly volatile material	Decrease load size on next batch (confirm by weighing), ensure the waste mix is correct.
	Burner failure	Check burner operation – if no flame or a poor flame is visible through the flame view port adjust air/fuel ratio
	Operation at too high a Primary Chamber temperature	Check/decrease primary chamber combustion air
Smoke coming out of Primary	Too much air	Check dampers on primary blower
	Too much volatile material loaded	Decrease load size on next batch (confirm by weighing), ensure the waste mix is correct.
	Primary Chamber temperature too high	Waste loaded may not be a good mix of heat value
Too much fuel usage	Too much secondary combustion air	Check/reduce secondary combustion air
	Too much air infiltration	Reduce air flow by adjusting the damper
	Fuel leakage	Check fuel trains and burners for fuel leakage
	Wet waste	Spread wet waste with other waste through several loads – do not charge all of the wet waste at one time
	Excessive draft	Check/reduce draft – check door seals and other seals for leakage adjust damper
	Burner setting too high	Check air/fuel mix
<b>Waste Oil Burner</b>		
Pump fails to start	Breaker tripped	Switch Breaker into off position and then switch to on position again. If breaker continues to trip, check for short in the system.
	Motor Starter	Check motor starter
	Overload	Reset overload




<b>Problem</b>	<b>Causes</b>	<b>Solutions</b>
Waste Oil Nozzle not turning on	A ball valve is closed	Ensure all ball valves are open.
	Solenoid Valve has failed	Diagnose if valve has failed. Replace if necessary See Part IV Section 4 CMI 4.4.5/02-003B (page 451)
	Fuel Leak	Check all pipes and hoses
	Secondary Chamber not at temperature	Wait until Secondary Chamber reaches 982°C.
System will not start when Solid is selected	Waste Oil burner is inserted into the back of the Secondary Chamber	Remove Waste Oil burner assembly from the Secondary Chamber.

### 3.3.6.3 In Case of Alarm

**IF BURN IS IN PROGRESS DO NOT HIT EMERGENCY STOP BUTTON ON MAIN CONTROL PANEL.**


- Go to the manual slide gates on the Primary Chamber, located just after the blower, and close them all the way. This will help to put the fire in the chamber out.
- Check alarms to see what the problem is.
- Do not open the doors of the Primary Chamber unless the temperature inside the chamber is below 90°C


### 3.3.6.4 System Warnings




Warnings indicate that a non critical value or device has malfunctioned and requires an operator to review what may be causing this to occur. If not resolved some of the warnings may become a fault.

### 3.3.6.5 System Faults



ALARM	SOLUTION
The Primary Chamber thermocouple has faulted	Refer to <i>Part IV Section 2 PMI 05-002.W.01</i>
The Secondary Chamber thermocouple has faulted	Refer to <i>Part IV Section 2 PMI 05-002.W.01</i>
The primary burner is faulted	The primary burner has failed to light when it received a signal telling it to start. To reset the burner, press the reset button located on the Burner and look into sight glass for ignition:
	Check that the pressure is 1378 kPa
	If a spark is present and burner won't ignite: <ul style="list-style-type: none"> <li>• Check fuel lines for leaks</li> <li>• Check that fuel pump is not clogged</li> </ul>
	If no spark is present: <ul style="list-style-type: none"> <li>• Clean electrodes</li> </ul>
The secondary burner is faulted	The secondary burner has failed to light when it received a signal telling it to start. To reset the burner, press the reset button located on the Burner and look into sight glass for ignition:
	If a spark is present and burner won't ignite: <ul style="list-style-type: none"> <li>• Check fuel lines for leaks</li> <li>• Check that fuel pump is not clogged</li> </ul>
	If no spark is present: <ul style="list-style-type: none"> <li>• Clean electrodes</li> </ul>
The system has shut down due to primary blower low air flow.	Visually examine the primary blower for any obstructions that may be causing low air flow
	Check slide gate located between Primary chamber and blower, ensure it is open.
	Check damper assembly, ensuring modutrol crank arm is still connected and that butterfly damper is open, allowing air flow.
	Air proving switch may be defective. See <i>Part IV Section 4 CMI 4.4.4/01-001A &amp; 02-002A</i>
	There are two ports on the air proving switch marked V and P. Ensure the inlet tube is attached to the port marked "P" for pressure. V stands for vacuum. Ensure the "V" port is open to atmosphere and is not blocked
	If no air restriction is observed (i.e. blockage in the tube) change the air proving switch see <i>Part IV Section 4 CMI 4.4.4/01-001A &amp; 02-002A</i>
The primary blower motor breaker is tripped or open.	Turn power off on Control panel by turning the Main Disconnect to the off position CB1

ALARM	SOLUTION
	Open the main control panel and switch break switch to off and then to the on position "CB9"
The system has shut down due to secondary blower low air flow.	Visually examine the primary blower for any obstructions that may be causing low air flow
	Check slide gate located between Secondary chamber and blower, ensure it is open.
	Check damper assembly, ensuring modutrol crank arm is still connected ( <i>if not see Part IV Section 2 PMI 01/02-001.W.01 Damper Crank Arm</i> ) and that butterfly damper is open, allowing air flow.
	Air proving switch may be defective. See <i>Part IV Section 4 CMI 4.4.4/01-001A &amp; 02-002A</i>
	There are two ports on the air proving switch marked V and P. Ensure the inlet tube is attached to the port marked "P" for pressure. V stands for vacuum. Ensure the "V" port is open to atmosphere and is not blocked
	If no air restriction is observed (i.e. blockage in the tube) change the air proving switch see <i>Part IV Section 4 CMI 4.4.4/01-001A &amp; 02-002A</i>
The Secondary blower motor breaker is tripped or open.	Turn power off on Control panel by turning the Main Disconnect to the off position
	Open the main control panel and switch the breaker to off and then to the on position "CB10"
The Secondary blower variable frequency drive is faulted.	Push fault reset button on the Panel view
	If fault persist check the error code on the variable frequency drive and check OEM manual for troubleshooting alarm.
The burner fuel level is low.	Add fuel to the fuel tank and the alarm should reset itself
	If alarm persist replace the low level switch <i>as per See Part IV Section 4 CMI 4.4.3/01-002G &amp; 02-002G</i>
Selected Solid & Waste Oil The waste oil burner is not in.	Check to see if the waste oil burner is pushed all the way into the Secondary Chamber. <ul style="list-style-type: none"> <li>• Push waste oil burner all the way in, ensuring it makes contact with the limit switch</li> <li>• If the waste oil burner is all the way in and making contact with the limit switch, replace the limit switch. See <i>Part IV Section 4 CMI 4.4.1/05-005A (page 436)</i></li> </ul>



<b>ALARM</b>	<b>SOLUTION</b>
Solid Waste Only Selected The waste oil burner is not out.	Check to see if the waste oil burner is pulled all the way out of the Secondary Chamber <ul style="list-style-type: none"><li>• Pull waste oil burner all the way out, ensuring it makes contact with the limit switch</li><li>• If the waste oil burner is all the way out and making contact with the limit switch, replace the limit switch. See Part IV Section 4 CMI 4.4.1/05-005A (page 436)</li></ul>
The waste oil burner is faulted.	The waste oil tank is empty, fill tank
	Check that the instrument air is going to the burner check the air pressure gauge on the burner and adjust regulator if necessary.
	Check that the fuel pump is in working condition
	Check that the waste oil breaker is not tripped "CB15"

## **4.0 MAINTENANCE INSTRUCTIONS**

### **4.1 SUMMARY OF PREVENTIVE MAINTENANCE INSTRUCTIONS**

IF APPLICABLE: The air compressor pump is shipped with break-in oil which should be changed after the first 8 hours of operation.

#### **4.1.1 Daily Maintenance**

<b>Freq.</b>	<b>Routine</b>	<b>Component</b>	<b>Description</b>
Daily	Inspection & Cleaning	Burners	Clean electrodes & HT Leads.
Daily	Inspection & Cleaning	Burners	Inspect fuel lines for leaks.
Daily	Inspection & Cleaning	Burners	Inspect nozzles in burners.
Daily	Inspection & Cleaning	Refractory	Check inside the Chambers for shrinkage or any exposed metal.

#### **4.1.2 Weekly Maintenance**

<b>Routine</b>	<b>Component</b>	<b>Description</b>
Inspection & Cleaning	Air compressor	Check oil level
Inspection & Cleaning	Air compressor	Check air filter
Inspection & Cleaning	Air compressor	Pull ring on safety valve and allow the ring to snap back to normal position (Check for free operation of the safety valve)
Inspection & Cleaning	Blowers and Assembly	Modutrol crank arm connected to damper.
Inspection & Cleaning	Blowers and Assembly	Slide gates are open.
Inspection & Cleaning	Burners	Clean photocell / UV Detector
Inspection & Cleaning	Burners	Clean the glass on the flame inspection window.
Inspection & Cleaning	Burners	Check diffuser disc.
Inspection & Cleaning	Waste Oil Burner Filter	Clean the canister filter
Inspection & Cleaning	Thermocouples	Remove and clean thermocouples as necessary – inspect for damage. Replace if necessary.

#### 4.1.3 Monthly Maintenance

Routine	Component	Description
Inspection & Cleaning	Air compressor	Check all fasteners for proper tightness.
Inspection & Cleaning	Blowers and Assembly	Check the fan wheel for any wear or corrosion, as either can cause catastrophic failures
Inspection & Cleaning	Burners	Check flexible hoses to make sure that they are still in good condition.
Inspection & Cleaning	Burners	Pump delivery pressure must be stable. If the pressure is found to be unstable or if the pump runs noisily see manual for details.
Inspection & Cleaning	Burners	Check that no dust has accumulated inside the fan or on its blades.
Inspection & Cleaning	Burners	Check that all parts of the combustion head are in good condition, positioned correctly, free of all impurities, and that no deformation has been caused by operation at high temperatures.
Inspection & Cleaning	Refractory	Check the refractory in the Secondary Chamber for shrinkage, anything greater than 1.2cm should be patched (i.e. gaps between modules exposing metal surface)
Inspection & Cleaning	Waste Oil	Visually check all electrical components
Inspection & Cleaning	Waste Oil	Remove heater element from casing and inspect for build-up. Clean any deposits. When reinstalling the heater element always ensure the bundle will be restarted immersed. NEVER use the inline oil heater dry

#### 4.1.4 Quarterly Maintenance

Routine	Component	Description
Lubrication Service	Air compressor	Change the oil
Inspection & Cleaning	Blowers and Assembly	Lubricate all bearings – lubrication intervals depend on operating speed (RPM). Clean cooling fan on motors.
Inspection & Cleaning	Blowers and Assembly	Check the V-belt drive (Secondary Blower) for proper alignment and tension (see manual). If belts are worn, replace them as a set, matched within manufacturer's tolerances.
Inspection & Cleaning	Burners	Check all components for heat damage.
Inspection & Cleaning	Refractory	Inspect door gasket for damage or heat damage. Replace segments, if necessary. Doors must close tightly and securely.
Inspection & Cleaning	Refractory	Check all refractory for damage. Patch or replace as needed. Patch if modules show a little gap and replace modules if the modules have shrunk excessively (greater than 1")
Inspection & Cleaning	Paint	Maintain paint exterior to protect metal from heat damage

#### 4.1.5 Yearly Maintenance

Routine	Component	Description
Detailed Maintenance	Refractory	Replace door gasket
Inspection & Cleaning	Electrical	Check the limit switch

#### **4.1.6 Level 2 and Level 3 Maintenance**

Please refer to the OEM Manual for additional information regarding maintenance instructions for Level 2 and Level 3.

<b>Periodicity</b>	<b>Level of Repair</b>	<b>Routine</b>	<b>Component</b>	<b>Description</b>
24 Monthly	3	Detailed Maintenance	Refractory	Replace the door sills on Primary Chamber
24 Monthly	3	Detailed Maintenance	Refractory	Replace the door sills on Secondary Chamber
60 monthly	3	Detailed Maintenance	Refractory	Relining of Secondary Chamber.
60 monthly	3	Detailed Maintenance	Refractory	First stack section to be relined.
60 monthly	3	Detailed Maintenance	Fuel Tanks	Inspect Fuel tanks



## 4.2 PREVENTIVE MAINTENANCE INSTRUCTIONS

The following preventive maintenance instructions (PMI) are to be read in conjunction with the IPDs found in Section 4.3.

### 4.2.1 Instruction Classification


Each component is associated with an identification number, see table below:

System Component	Identification number
Primary Blower	01-001
Secondary Blower	02-001
Primary Burner	01-002
Secondary Burner	02-002
Air Compressor	03-001
Waste Oil Burner	02-003
Main Control Panel	03-010
Refractory	05-001
Thermocouple	05-002
Paint	05-003
Electrical	05-004
Limit Switch	05-005

To differentiate if the instruction is weekly, monthly, quarterly or yearly, the above identification number will be followed by a letter:

Daily: D  
Weekly: W  
Monthly: M  
Quarterly: Q  
Yearly: Y

For example,



## **4.2.2 Zero Mechanical State & Lock Out Instructions**

Proper maintenance of the equipment is essential to ensure long term, reliable operation of the EWS model Incinerator. The preventive maintenance instructions are outlined in this section of the Facility Manual.

### **NOTA**

**The warranty will become void if proper maintenance is not performed as instructed.**

#### **4.2.2.1 Safety**

During maintenance of the EWS mobile incinerator, it is very important to be aware of special hazards. Two safety programs are described in the following sections:

1. Zero Mechanical State
2. Power Lock Out Instructions



**Failure to comply with these instructions during maintenance could result in injury or death. The responsibility for implementation of a comprehensive safety program rests with the operating staff and supervision. The safety instructions in this Facility Manual should be considered only as a starting point for the safety program at site.**



**ACCIDENTS CAN BE PREVENTED  
A CAREFUL WORKER IS THE BEST SAFETY DEVICE**

#### **4.2.2.2 Zero Mechanical State**

Zero Mechanical State (ZMS) exists when the possibility of an unexpected mechanical movement has been eliminated. During maintenance, it is mandatory to totally deactivate the incinerator so that there is no possibility of an unexpected machine movement. Power lock-out, described in the next section, is commonly used for this purpose. Most machines are powered by electrical, hydraulic or pneumatic drives. Energy may be stored in a shutdown machine in various ways: Air pressure in a cylinder, hydraulic fluid stored in pressurized hoses, or machine members whose weight can generate fluid pressure. Therefore, just cutting off the electrical power may not be enough to neutralize all power sources. Certain maintenance instructions at site should require ZMS condition as a matter of course.

#### **4.2.2.3 Zero Mechanical State (ZMS) Checklist**

1. Every electrical power source to the incinerator must be cut off and locked out (to prevent others who may not be aware of maintenance work from turning the power back on inadvertently).
2. Ensure that the mechanical potential energy of the incinerator is at its lowest practical value so that opening of pipe, tubing, hose or actuation of any valve will not produce an unexpected movement that could cause injury.

3. Check that there is no pressurized fluid (air, oil, gas or other) trapped in the incinerator lines, cylinders or other components. This will ensure that there will be no incinerator motion when a valve is actuated.
4. Secure loose or freely moving parts so that there is no possibility of accidental movement.

#### 4.2.2.4 Power Lock Out Instructions



**Unexpected operation of electrical equipment started by automatic or manual remote control may cause injuries to persons who happen to be nearby. For this reason, when repair work is to be done on motors or other electrical equipment the circuit should be opened at the switch box and the switch pad locked in the OFF position. Tag the switch with a lock out tag indicating who must be contacted before the power is turned back on again.**

**BECAUSE OF THE SEVERE CONSEQUENCES, INCLUDING DEATH, OF NOT PROPERLY LOCKING OUT ELECTRICITY SUPPLIES DURING MAINTENANCE, THE SUPERVISOR SHOULD ENSURE THAT THERE IS ONLY 1 KEY FOR THE LOCK USED TO LOCK OUT THE POWER SUPPLY.**

For identification, locks may be color coded to indicate different crews or shifts.

The Supervisor should maintain the master key and list of key numbers, and should keep an extra key to each lock for his department. The master key should not be loaned out under any circumstances.

No matter what method is used to lock out power, strict discipline and constant supervision should be employed during any equipment maintenance work.

#### 4.2.2.5 Power Lock Out Checklist

1. Alert the operator of the equipment.
2. Before starting the work on an engine, motor, line shaft or other power transmission equipment or power-driven machine, make sure it cannot be set in motion without your knowledge.
3. Place your own padlock on the control switch, lever, or valve, even if someone has locked the control panel before you. You will not be protected unless you put your own padlock on it. (Another maintenance person could remove their lock and then someone else could start the equipment if they were not aware of maintenance work being done.)

When you are finished working, remove your own padlock. Never permit someone else to remove it for you. Be sure you are not exposing someone else to danger by removing your padlock.

### 4.2.3 Daily Instructions

#### Primary & Secondary Chamber Burners: (01-002.D & 02-002.D)




**Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.**

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death.


Burner shall be installed and maintained in accordance with manufacturer's requirements as outlined in the Burner manual, local codes and authorities having jurisdiction.

#### **INSTRUCTION 01/02-002.D.01: INSPECTING AND CLEANING ELECTRODES AND HT LEADS**

1. Remove the cover from the Burners as described in 01-002.W.01 and 02-002.W.01.
2. Inspect the electrodes for any soot build-up.



1. Electrode
2. U-bolt
3. Diffuser Disc




4. HT Leads


3. Clean/wipe down the ignition electrode with a cloth should there be a build-up of soot.

**NOTA** Do not use sand paper as this will increase the deposit of future soot.

4. If electrodes are damaged remove the screws and u-bolt (see above photo) and install new electrodes. When reinstalling the electrodes make sure that they are positioned as shown below.
- 5.



**Primary Burner**




**Secondary Burner**

Check the High Temperature (HT) Leads for any heat damage. If HT Leads are severely damaged (i.e., you can see the wire beneath the sheathing) then replace. (See *Part IV Section 4 CMI 4.4.3/01-002A & 4.4.3/02-002A*)



**INSTRUCTION 01/02-002.D.02: INSPECTING THE FUEL LINES**

1. Visually inspect all fuel lines to the Primary and Secondary Burner as well as to the Waste Oil burner for any leaks.
2. The Primary and Secondary Burner have two oil lines, one feed and one return. The Waste Oil Burner only has one feed line.
3. If any leaks are observed tighten or replace the fitting where the leak is occurring



1. Fuel In Ball Valve
2. Fuel Filter
3. Fuel Line In
4. Fuel Line Out
5. Secondary Burner
6. Waste Oil Ball valve
7. Waste Oil Filter
8. Waste Oil Line In
9. Waste Oil J-pump
10. Waste Oil Burner
11. Secondary Blower

**INSTRUCTION 01/02-002.D.03: INSPECT AND CLEAN BURNER NOZZLES**

Primary Burner:

1. Remove the burner cover as outlined in 01/02-002.W.01 REMOVAL OF BURNER COVERS
2. Remove the centre retaining bolt.
3. Slide burner out.
4. Check nozzle. If there is carbon, remove the nozzle and clean.
5. Reinstall or replace if necessary

Secondary Burner:

1. Remove the burner cover as outlined in 01/02-002.W.01 REMOVAL OF BURNER COVERS
2. Remove the 4 retaining bolts on either side of the burner.
3. Slide burner out.
4. Check nozzle. If there is carbon, remove the nozzle and clean.
5. Reinstall or replace if necessary

**Refractory: (05-001.D)**



**When working with the refractory make sure you use the proper tools; wear goggles, approved dust mask and gloves**

**INSTRUCTION 05-001.D.01: INSPECTING THE REFRACTORY**

Ensure power is locked out.

Please follow all instructions outlined in *Section 4.2.2 Zero Mechanical State & Lock Out Instructions*.

1. Open Primary Chamber door by unlatching all four clamps.
2. Tie-off door to open position to ensure that it will not close unintentionally.
3. Enter Primary Chamber and check the refractory for shrinkage, any gap between the modules greater than 2.5 cm should be patched with the blanket refractory
4. Check for any exposed metal between the modules, if metal is exposed make sure to patch area with blanket material or new module (*Part IV Section 4 CMI 4.4.2/05-001A & 4.4.2/05-001B*)

#### 4.2.4 Weekly Instructions

##### Primary & Secondary Chamber Blowers: (01-001.W & 02-001.W)



**Do not attempt any maintenance on a fan unless the electrical supply has been completely disconnected and locked.**

Please follow all instructions outlined in *Section 4.2.2 Zero Mechanical State & Lock Out Instructions*.


A fan can windmill despite removal of all electrical power therefore, take extra care when working with fans in the system.

The rotating assembly should be blocked securely before attempting maintenance of any kind.

**INSTRUCTION 01/02-001.W.01: DAMPER CRANK ARM**


Check to see that the damper crank arm is connected to the damper and the rod.

Ensure mechanical linkage on damper is tight, if loose tighten with wrench.




**PRIMARY BLOWER**

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper



**SECONDARY BLOWER**

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper




- A. Damper Crank arm and connection to Damper and Rod




**INSTRUCTION 01/02-001.W.02: SLIDE GATES**

Check to see if slide gates move freely.


1. Move slide gate in and out to ensure free movement. If sticking, use lubricant to loosen. Lubricant should be rated for a high temperature (>150°F) application.
2. Gates must be opened to allow under fire air to enter the chamber. They should only be closed to reduce air in abnormal operating conditions.



1. Primary Chamber Slide Gate Open



2. Primary Chamber Slide Gate Closed



3. Secondary Chamber Slide gate Open



**Primary & Secondary Chamber Burners: (01-002.W & 02-002.W)**



**Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.**

Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death.


Burner shall be installed and maintained in accordance with manufacturer's requirements as outlined in the Burner manual, local codes and authorities having jurisdiction.

### **INSTRUCTION 01/02-002.W.01: REMOVAL OF BURNER COVERS**

Switch off the electrical power. Please follow all instructions outlined in *Section 4.2.2 Zero Mechanical State & Lock Out Instructions*. Cover must be removed to perform maintenance on burners.

To remove the cover and to pull out the Primary or Secondary Burner, follow instructions below:


1. Loosen screw (Item #1, in the following diagrams) and withdraw the cover (Item #2, in the following diagrams)
2. Primary Burner has one screw to remove the cover. The Secondary Burner has four screws to remove the cover.
3. Remove bolt (Item #3) for the Primary Burner, or screws (Item #3) for the Secondary Burner.
4. Pull (Part A) backwards keeping it slightly raised to avoid damaging the diffuser disk (Item #6).



Primary Burner has 1 screw



**Primary**



Secondary Burner has 4 screws (2 on each side)



**Secondary**

**INSTRUCTION 01/02-002.W.02: CLEANING THE PHOTO CELL AND U.V. DETECTOR**

1. Remove the cover from the Burners as described in Instruction 01/02-002.W.01.
2. Clean Photo Electric (P.E) cell with a wet cloth
3. P.E. cell (Item #1 on the Primary Burner photo) (Item #1 on the Secondary Burner photo) can be removed by pulling it outward forcefully. Ensure you take note of the position of the eye while removing, this will help when reinstalling.
4. Once cleaned insert P.E. cell back into position ensuring the eye is not facing directly into the chamber (where the flame will be) but on the same angle as before it was removed.
5. Reinstall burner cover.



Primary Burner PE Cell




Secondary Burner

**INSTRUCTION 01/02-002.W.03: CLEANING THE INSPECTION WINDOWS**

Clean the inspection windows with a wet cloth.




1. Primary Burner Inspection Window



2. Secondary Burner Inspection Window

**INSTRUCTION 01/02-002.W.04: INSPECTING THE DIFFUSER DISC ASSEMBLY**

1. Remove the cover from the Burners as described in 01/02-002.W.01.
2. Check the diffuser disc assembly and the diffuser disc for any heat damage
3. If any heat damage, deformation or excess rust is noted, replace. (*Part IV Section 4 CMI 4.4.3/01-002B*)



1. Electrode
2. U-bolt
3. Diffuser Disc

**Air Compressor: (03-001.W)**



**INTAKE AIR.** Can contain carbon monoxide or other contaminants. Will cause serious injury or death. This air compressor is not designed, intended or approved for breathing air. Compressed air should not be used for breathing air application.



**HAZARDOUS VOLTAGE.** Can cause serious injury or death. Disconnect power and bleed pressure from the tank before servicing.



**MOVING PARTS.** Can cause serious injury. Do not operate with guards removed. Machine may start automatically. Disconnect power before servicing.



**HOT SURFACES.** Can cause serious injury. Do not touch. Allow to cool before servicing. Do not touch hot compressor or tubing.



**HIGH PRESSURE AIR.** Bypassing, modifying or removing safety/relief valves can cause serious injury or death. Do not bypass, modify or remove safety/relief valves. Do not direct the air stream at body. Rusted tanks can cause explosion and severe injury or death. Drain tank before each use. Drain valve located at bottom of tank.



**RISK OF BURSTING.** Use only suitable air handling parts acceptable for pressure of not less than the maximum allowable working pressure of the machine.

Before maintenance is performed on electrical or rotating equipment make sure that the appropriate electrical disconnects are locked out/tagged out. Before removing the vessel access ports make sure that the equipment is off and cool.

**NOTA**

Too much or too little oil will harm the compressor.

### **INSTRUCTION 03-001.W.02: INSPECTING AIR FILTERS IN AIR COMPRESSOR**

1. Remove both filter covers
2. Gently grab filter element and remove.
3. Visually inspect filter for damage or dirt.
4. If damaged, replace the filter. If dirty, blow out the filter with compressed air.
5. Reinstall the filters and their covers

### **INSTRUCTION 03-001.W.03: CLEANING AIR COMPRESSOR & CHECKING SAFETY VALVE**

#### **Cleaning**

A dirty compressor will cause abnormally high temperature and result in oil carbonization on valve components. Clean all external parts of the compressor with compressed air. Concentrate the cleaning on the external fins where dirt can accumulate as cooling air is forced across them.

#### **Check Safety Valve**

1. Check the safety valve manually by pulling ring or lever to make sure that it moves freely and is not siezed.
2. Allow the ring to snap back to normal position.






**Thermocouple: (05-002.W)**



**When working with electrical components, ensure lock out instructions are being followed.**




Thermocouple Assembly



Thermocouple Element

**INSTRUCTION 05-002.W.01: INSPECT THERMOCOUPLE FOR DAMAGE**

Turn main power to the system off - Remove thermocouple and visually inspect for damage. If damaged, see *Part IV Section 4 CMI 4.4.1/05-002A*



1. Primary Thermocouple (TC1)



2. Secondary Thermocouple (TC2) on  
Secondary Chamber Container

#### 4.2.5 Monthly Instructions

##### Primary & Secondary Chamber Blowers: (01-001.M & 02-001.M)



**Do not attempt any maintenance on a fan unless the electrical supply has been completely disconnected and locked. In many cases, a fan can windmill despite removal of all electrical power. The rotating assembly should be blocked securely before attempting maintenance of any kind.**

Please follow all instructions outlined in *Section 4.2.2 Zero Mechanical State & Lock Out Instructions*.

##### **INSTRUCTION 01/02-001.M.01: CHECK FAN WHEEL**



1. Check the fan wheel for any wear or corrosion, as either can cause catastrophic failures, if left in operation.
2. The wheel can be accessed one of two ways.
  - a. Remove the blower assembly from the unit and look down the outlet of the blower.
  - b. Remove the damper assembly from the inlet of the blower and inspect by looking through the inlet of the blower.
3. Check also for the build-up of material which can cause unbalance resulting in vibration, bearing wear and serious safety hazards.
4. Clean the wheel as required.
5. If replacement is necessary follow these steps:
  - a. Remove damper assembly from the unit
  - b. Remove the blower assembly
  - c. Remove the blower housing around the wheel
  - d. Loosen all set screws that are located on the wheel.
  - e. A puller may be required if the wheel hasn't been removed for some time.
  - f. Ensure the shaft "key" is installed on the shaft before installing the new wheel.
  - g. When installing a new wheel, the wheel should be positioned in the housing with the correct spacing between the edge of the inlet cone and the wheel. The wheel to cone clearance on the Primary Blower is 0.3175 cm.
  - h. Ensure that the wheel is installed securely before reassembling the blower assembly.
  - i. Install the blower assembly
  - j. Install the damper assembly


### Primary & Secondary Chamber Burners: (01-002.M & 02-002.M)




**Do not store flammable or hazardous materials in the vicinity of fuel burning appliances. Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death. Refer to the Burner manual for instructional or additional information.**

#### **INSTRUCTION 01/02-002.M.01: CHECK FLEXIBLE OIL LINE**

1. Check flexible oil lines to make sure that they are still in good condition. This includes frayed, leaking, or worn swivel joints.
2. If any type of damage is observed replace the flexible oil lines see *Part IV Section 4 CMI 4.4.3/01-002F & 4.4.3/02-0002F*



Primary Chamber Burner Flexible lines  
(1 Above)



Secondary Chamber Burner Flexible Lines  
(1 Above)

#### **INSTRUCTION 01/02-002.M.02: INSPECT BURNER PUMP DELIVERY PRESSURE**


1. Remove the cover from the Burners as described in Instruction 01/02-002.W.01.
2. The pump delivery pressure must be between 180-210 psi, and can be viewed on the gauge shown below.




3. If the pressure is found to be unstable or if the pump is running noisily try the following:



- a. Detach the flexible hose from the line filter (Shown below as #1).
- b. At the tank pour fuel into the supply line.
- c. If there is fuel coming in through the filter it means the filter is not clogged. If no fuel is coming through the filter remove and replace.
- d.



**Primary Chamber Burner Flexible lines**



**Secondary Chamber Burner Flexible Lines**

4. If the pump is found to be responsible:
  - a. Loosen the bleed screw.
  - b. Turn on the burner
  - c. Once all the air has been bled out. Close the bleed screw.

If the pump is still not working after these steps replace the pump: see *Part IV Section 4 CMI 4.4.7/01-002I or 4.4.7/02-002I*.

5. If the problem lies in the suction line, check to make sure that the filter is clean and that air is not entering the piping from a loose fitting or damaged line.

**INSTRUCTION 01/02-002.M.03: CLEAN BURNERS OF DUST**

1. Remove the cover from the Burners as described in Instruction 01/02-002.W.01.
2. Check that no dust has accumulated inside the burner fan or on fan blades.
3. If any dust is visible take a clean soft cloth to the fan or the blades and wipe clean.

**INSTRUCTION 01/02-002.M.04: CHECK BURNER COMBUSTION HEAD**

1. Remove the cover from the Burners as described in Instruction 01/02-002.W.01.
2. Check that all parts of the combustion head are in good condition, free of all impurities, and that no deformation has been caused by operation at high temperatures.

**(Below is an example of burner in good condition)**



If damage is found, please refer to *Part IV Section 4 CMI 4.4.3/01-002D & 4.4.3/02-002D*



**Refractory: (05-001.M)**



**When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves**

Please follow all instructions outlined in *Section 4.2.2 Zero Mechanical State & Lock Out Instructions*.

**INSTRUCTION 05-001.M.01: INSPECT REFRACTORY**

1. Ensure power is locked out.
2. Open Secondary Chamber door.
3. Fasten door open, ensuring it will not close by its own weight.
4. Enter Secondary Chamber and check the refractory for shrinkage, any gaps between the modules greater than 2.5 cm should be patched.
5. Fix gaps with supplied blanket by stuffing material into opening. (See *Part IV Section 4 CMI 4.4.2/05-001A*)
6. Check for any exposed metal, if metal is exposed make sure to patch area with blanket material or new module. (See *Part IV Section 4 CMI 4.4.2/05-001A & 4.4.2/05-001B*)
7. Pay special attention to areas where the junction boxes are located, as any excessive heat may melt the wires within the box.

Some cracking is normal, however if pieces are missing or have fallen out, (See *Part IV Section 4 CMI 4.4.2/05-001E*)

### **Air Compressor: (03-001.M)**



**INTAKE AIR.** Can contain carbon monoxide or other contaminants. Will cause serious injury or death. This air compressor is not designed, intended or approved for breathing air. Compressed air should not be used for breathing air application unless treated in accordance with all applicable codes and regulations.



**HAZARDOUS VOLTAGE.** Can cause serious injury or death. Disconnect power and bleed pressure from the tank before servicing. Compressor must be connected to properly grounded circuit. Do not operate compressor in wet conditions. Store indoors.



**MOVING PARTS.** Can cause serious injury. Do not operate with guards removed. Machine may start automatically. Disconnect power before servicing. Lockout/Tagout machine.



**HOT SURFACES.** Can cause serious injury. Do not touch. Allow to cool before servicing.



**HIGH PRESSURE AIR.** Bypassing, modifying or removing safety/relief valves can cause serious injury or death. Do not bypass, modify or remove safety/relief valves. Do not direct air-stream at body. Rusted tanks can cause explosion and severe injury or death. Drain tank before each use. Drain valve located at bottom of tank.


**RISK OF BURSTING.** Use only suitable air handling parts acceptable for pressure of not less than the maximum allowable working pressure of the machine.

#### **INSTRUCTION 03-001.M.01: CHECK FASTENERS FOR TIGHTNESS**

1. Check all fasteners for tightness (tighten as required).
2. Check the safety valve manually, by pulling ring or lever, to make sure that it is not stuck. Allow the ring to snap back to normal position


### Quarterly Instructions

#### Primary & Secondary Chamber Burners: (01-002.Q & 02-002.Q)



 Do not store flammable or hazardous materials in the vicinity of fuel burning appliances. Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or death. Refer to the Burner manual for instructional or additional information.

#### **INSTRUCTION 01/02-002.Q.01: INSPECT COMPONENTS FOR HEAT DAMAGE**

1. Check all components for heat damage.
2. Look for excessive rust, deformation of all the parts including but not limited to the end cone and the diffuser disc.
3. Check to see that the High Temperature Leads (HT leads) are still intact and have not melted from any excessive heat coming back into the burner. If they are damaged replace with new HT Lead.
  - a. The HT leads are attached to the control box and the electrode via a squeeze fitting. Remove the leads from the electrode and control box by simply pulling them out.



1. Electrode
2. U-Bolt
3. Diffuser Disc
4. HT Leads



End cone

**Refractory: (05-001.Q)**




**When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves**


Please follow all instructions outlined in *Section 4.2.2 Zero Mechanical State & Lock Out Instructions*.

**INSTRUCTION 05-001.Q.01: INSPECT DOOR GASKETS**

1. Open Primary and Secondary Chamber doors.
2. Fasten doors open, ensuring the door will not close on its own.
3. Inspect door gasket for damage.
4. Replace any damaged segments of door gasket if necessary. Cut out the damaged section and replace with new door gasket. See *Part IV Section 4 CMI 4.4.2/05-001C*.
5. Doors must close tightly and securely, ensuring a good seal.



Primary Door (refractory lined)



1. Primary Door Gasket




Secondary Door (refractory lined)




1. Secondary Door Gasket

**INSTRUCTION 05-001.Q.02: INSPECT REFRACTORY FOR SHRINKAGE**

1. Ensure power is locked out.
  2. Open Primary and Secondary Chamber doors.
  3. Fasten doors open, ensuring they will not close on their own.
  4. Enter Primary and Secondary Chamber and check the refractory for shrinkage, anything greater than 2.54 cm should be patched.
  5. Check to make sure the anchoring of the modules is still strong and intact, if any modules seem loose replace complete module with new module.
- A. REMOVAL: Remove existing Module (physically pull away existing refractory from underlying Module Anchor).
- B. Remove welded stud from steel casing (cut with hack saw or other device between Module Anchor and Furnace Casing/Shell).



**Figure 1:** Side view of the Weld Loc Module



**Figure 2:** Stud Gun with rasp and Torque Tube.

- A. INSTALLATION: Once the new module is in place take the stud gun with rasp to the Torque Tube and drill into place.
- B. Once it has tightened the Torque Tube should come off with the drill.



### **Air Compressor (03-001.Q)**



**INTAKE AIR.** Can contain carbon monoxide or other contaminants. Will cause serious injury or death. This air compressor is not designed, intended or approved for breathing air. Compressed air should not be used for breathing air application unless treated in accordance with all applicable codes and regulations.



**HAZARDOUS VOLTAGE.** Can cause serious injury or death. Disconnect power and bleed pressure from the tank before servicing. Lockout/Tagout machine. Compressor must be connected to properly grounded circuit.



**MOVING PARTS.** Can cause serious injury. Do not operate with guards removed. Machine may start automatically. Disconnect power before servicing. Lockout/Tagout machine.



**HOT SURFACES.** Can cause serious injury. Do not touch. Allow to cool before servicing. Do not Touch hot compressor or tubing.



**HIGH PRESSURE AIR.** Bypassing, modifying or removing safety/relief valves can cause serious injury or death. Do not bypass, modify or remove safety/relief valves. Do not direct air-stream at body. Rusted tanks can cause explosion and severe injury or death. Drain tank before each use. Drain valve located at bottom of tank.




**RISK OF BURSTING.** Use only suitable air handling parts acceptable for pressure of not less than the maximum allowable working pressure of the machine.



**INSTRUCTION 03-001.Q.01: CHANGE THE OIL**

1. Change the oil



2. Remove the oil cap (above) to drain the oil.
3. Replace oil cap.
4. Refill the oil reservoir, using compressor oil, to the fill line as illustrated above.
5. Maintain oil level mid-way between the upper and lower lines of the crankcase sight gauge. See illustration above.

### **Paint: (05-003.Q)**



**Ensure proper ventilation and proper equipment is being used when using any paint product.**

#### **INSTRUCTION 05-003.Q.01: INSPECT AND MAINTAIN EXTERIOR PAINT**

1. Maintain paint exterior to protect metal from heat and corrosion damage. This includes all components in the system including containers and incinerator components.
2. If discoloration is noted and painting needs to be performed, on areas where paint will be applied, you must do a light sanding before application.
3. Follow paint manufacturer's application instructions which will include surface preparation, priming and painting.
4. If components within the container need to be painted, for example the Primary Chamber or the Secondary Chamber, proceed as above. Use a type of paint that meets the following specifications:

#### **Paint Specifications:**

Incinerator Paint: This is the paint coated directly on the incinerator shell. This includes the following components:

1. Primary Chamber
2. Secondary Chamber
3. Breech Section
4. Hot Stack Section (Black)

Finish needs to be able to withstand temperatures in the 650-750°F (340-400°C) range.

Container Paint: Paint to conform to Customer outlined specifications.

Parts: There are no paint specifications for each individual component. This is left up to the discretion of the customer.

#### 4.2.6 Yearly Instructions

##### Refractory: (05-001.Y)




When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves

##### **INSTRUCTION 05-001.Y.01:**

##### **CHECK DOOR GASKET ALONG PRIMARY & SECONDARY CHAMBER DOORS**


1. If required replace the door gasket. The gasket can last over 2 years but will depend on the careful use by the operator when loading and unloading.
2. Remove the damaged section of door gasket from door and reinstall new gasket



**Primary Door (refractory lined)**



**Primary Door Gasket**



**Secondary Door (refractory lined)**



**Secondary Door Gasket**

**Electrical: (05-004.Y)**




**When working with electrical components ensure lock out instructions are being followed**

Please follow all instructions outlined in *Section 4.2.2 Zero Mechanical State & Lock Out Instructions*.


**INSTRUCTION 05-004.Y.01: CHECK LIMIT SWITCHES**

**NOTA** System must not be running or in cool down to perform this inspection.

1. Open Primary and Secondary Chamber doors and check top view screen on the HMI Panel view to ensure that it indicates door is open.
2. Close Primary and Secondary Chamber doors and check top view screen on the HMI Panel View to ensure that it indicates door is closed.
3. All limit switches located on the unit are checked this way.
4. Replace limit switches if necessary.



**Primary Chamber Limit Switch**



**Secondary Chamber Limit Switch**

5. See *Part IV Section 4 CMI 4.4.1/05-005A*.
6. Check all other limit switches in the system.

### 4.3 CORRECTIVE MAINTENANCE INSTRUCTIONS (CMI)

The following instructions relate to the replacement or correction (fixing) of components of the EWS Mobile Incinerator Package.

These Corrective Instructions are grouped in this section by the following:

- 4.4.1 General Corrective Maintenance Instructions
- 4.4.2 Refractory Corrective Maintenance Instructions
- 4.4.3 Primary & Secondary Burner Corrective Maintenance Instructions
- 4.4.4 Primary & Secondary Blower Corrective Maintenance Instructions
- 4.4.5 Main Control Panel Corrective Maintenance Instructions

As per the *Preventive Maintenance Instructions Section 4.2* of this *Manual*, the following table is utilized to identify the components of the system that require corrective maintenance.

System Component	Identification number
<b>Primary Burner</b>	<b>01-002</b>
Replacing Fuel Filter	4.4.1/01-002A
<b>Secondary Burner</b>	<b>02-002</b>
Replacing Fuel Filter	4.4.1/02-002A
<b>Thermocouple</b>	<b>05-002</b>
Replacing Thermocouple	4.4.1/05-002A
<b>Limit Switch</b>	<b>05-005</b>
Limit Switch Replacement	4.4.1/05-005A
<b>Container Door Gasket</b>	<b>05-006</b>
Replacement of Container Door Gasket	4.4.1/05-006A
<b>Refractory</b>	<b>05-001</b>
Wall Refractory: Gaps between the Modules	4.4.2/05-001A
Wall Refractory: Replacement of the Modules	4.4.2/05-001B
Door Gasket	4.4.2/05-001C
Castable Refractory	4.4.2/05-001D
Temporary Repair of Castable	4.4.2/05-001E
<b>Primary Burner</b>	<b>01-002</b>
HT Lead & Electrode Replacement	4.4.3/01-002A
Diffuser Disc Replacement	4.4.3/01-002B
Nozzle Replacement	4.4.3/01-002C
End Cone Replacement	4.4.3/01-002D
Nozzle Assembly Repair or Replacement	4.4.3/01-002E
Burner Flexible Oil Line Replacement	4.4.3/01-002F
Low Level Switch Replacement	4.4.3/01-002G
Inspection Window Replacement	4.4.3/01-002H
Fuel Pump Replacement	4.4.3/01-002I
Control Box Replacement	4.4.3/01-002J
Oil Tube Replacement	4.4.3/01-002K
Burner PE Cell & UV Detector Replacement	4.4.3/01-002L
Burner Fan Motor Replacement	4.4.3/01-002M
<b>Secondary Burner</b>	<b>02-002</b>
HT Lead & Electrode Replacement	4.4.3/02-002A

	Diffuser Disc Replacement		4.4.3/02-002B
	Nozzle Replacement		4.4.3/02-002C
	End Cone Replacement		4.4.3/02-002D
	Nozzle Assembly Repair or Replacement		4.4.3/02-002E
	Burner Flexible Oil Line Replacement		4.4.3/02-002F
	Low Level Switch Replacement		4.4.3/02-002G
	Inspection Window Replacement		4.4.3/02-002H
	Fuel Pump Replacement		4.4.3/02-002I
	Control Box Replacement		4.4.3/02-002J
	Oil Tube Replacement		4.4.3/02-002K
	Burner PE Cell & UV Detector Replacement		4.4.3/02-002L
	Burner Fan Motor Replacement		4.4.3/02-002M
<b>Primary Blower</b>		<b>01-001</b>	
	Air Proving Switch Replacement		4.4.4/01-001A
	Damper Calibration		4.4.4/01-001B
	Modutrol Resistor Replacement		4.4.4/01-001C
	Damper Crank Arm Replacement		4.4.4/01-001D
	Motor Replacement		4.4.4/01-001E
	Modutrol Motor & Transformer Replacement		4.4.4/01-001F
	Replace the Blower Contactor		4.4.4/01-001G
<b>Secondary Blower</b>		<b>02-001</b>	
	Air Proving Switch Replacement		4.4.4/02-001A
	Damper Calibration		4.4.4/02-001B
	Modutrol Resistor Replacement		4.4.4/02-001C
	Damper Crank Arm Replacement		4.4.4/02-001D
	Motor Replacement		4.4.4/02-001E
	Modutrol Motor & Transformer Replacement		4.4.4/01-001F
	Replace the Blower Contactor		4.4.4/01-001G
<b>Main Control Panel</b>		<b>03-010</b>	
	Main Control Panel		4.4.6/03-010A
	Reboot PLC		4.4.6/03-010B
	PLC Parts Replacement		4.4.6/03-010C



#### **4.3.1 General Corrective Maintenance Instructions**

##### **LIMIT SWITCH REPLACEMENT (4.4.1/05-005A)**

1. Loosen the 2 screws holding the limit switch in place.
2. Remove limit switch, replace with a new one.
3. Take arm off of old body and mount to new.
4. Tighten the 2 screws holding the limit switch body.

##### **REPLACING THERMOCOUPLE (4.4.1/05-002A)**

The thermocouple will require routine replacement. The environment inside the incinerator will erode the protection tube to the point of failure. If the element is exposed to this environment it will be destroyed and will need to be replaced.

1. Unscrew thermocouple lid and remove wires.
2. Remove protection tube. To aid with this a vise and a pipe wrench will be needed.
3. Remove element and replace with new element and protection tube





4. Reinstall on incinerator.
5. After installation turn power back on. Observe the temperature reading of the thermocouple you were just working on. If the wires were installed incorrectly the temperature will read the opposite temperature. (I.e. 20°C would read as -20°C). If this is the case open the thermocouple housing and switch the wires.

#### **REPLACING FUEL FILTER (4.4.1/01-002A AND 02-002A)**

The fuel filter will require routine replacement to ensure clean fuel delivery to the Primary and Secondary Chamber burners.

1. Close the Ball Valve on the supply line.



2. Unscrew the used Red filter. Use a bucket to catch the surplus fuel when you unscrew the filter.



3. Before installing the filter lubricate the seal on the new filter.
4. Install the new filter, and open the supply line ball valve.

#### 4.3.2 Refractory Corrective Maintenance Instructions



**When working with the refractory make sure you use the proper tools; wear goggles, dust mask and gloves**

##### **WALL REFRACTORY: GAPS BETWEEN THE MODULES (4.4.2/05-001A)**


The ceramic block refractory will shrink over time exposing the exterior metal shell. These gaps need to be filled in with ceramic refractory blanket.

1. Identify gaps in the chamber that are larger than 1" in width between the modules or if you can see exterior shell.
2. With a Utility knife cut a length of ceramic blanket that will fit in the gap between the modules.
3. Stuff the blanket into the space with a straight edge or ruler.


##### **WALL REFRACTORY: REPLACEMENT OF MODULES (4.4.2/05-001B)**

Excessive damage to a section of refractory may necessitate the replacement of modules in the incinerator. Such damage is largely due to mechanical wear. The following diagram walks through the removal and installation of new modules.

- A. **REMOVAL:** Remove existing Module (physically pull away existing refractory from underlying Module Anchor)
- B. Remove welded stud from steel casing (cut with hack saw or other device between Module Anchor and Furnace Casing/Shell)



**Figure 2: Stud Gun with rasp and Torque Tube (part of module assembly).**



**Figure 1: Side view of the Weld Loc Module**

- C. **INSTALLATION:** Once the new module is in place take the stud gun (PN: Eco-Stud; EIN: 11-E-S-01-04-016-016) with rasp to the Torque Tube and drill into place.
- D. Once it has tightened the Torque Tube should come off with the drill.

#### **DOOR GASKET REFRACTORY (4.4.2/05-001C)**

The door gasket will degrade over time and will need to be replaced over time. The bottom of the door will see more degradation due to the waste burning in that vicinity.

1. Identify the damaged section of gasket that will need to be removed
2. With a utility knife cut out the section that needs to be replaced.
3. A new piece of gasket will need to be cut the same length as the removed piece.
4. With contact cement coat the gasket on one side and the door section and install.

#### **CASTABLE REFRACTORY (4.4.2/05-001D)**

Operators will notice that the castable refractory will show signs of minor cracking. The minor cracking is normal. Large sections of castable should not separate from the rest of the monolithic cast. Such occurrences are largely due to a sudden impact from machinery or

dropping of the units themselves. Mortar is supplied to help with a temporary repair while a permanent repair is resolved. Such permanent repairs are a third level repair and have to be considered on a case by case basis.

#### **TEMPORARY REPAIR OF CASTABLE (4.4.2/05-001E)**


1. Find the pieces of castable refractory that have separated.
2. Clean both the pieces of refractory and the area where the separation occurred.
3. Spread an even amount of high temperature mortar on the pieces and the area of separation.
4. Put the pieces back where they originated and support as necessary for a minimum of an hour while the mortar cures.

### 4.3.3 Burner Corrective Maintenance Instructions




**Do not store flammable or hazardous materials in the vicinity of fuel burning appliances.**


The Burners are pieces of equipment that will require routine corrective and preventive maintenance. Parts within this assembly will need to be repaired or replaced. The most common parts to be repaired or replaced are located at the front end of the burner where the parts are exposed to high temperatures.




**Front End Primary Burner**



**Front End Secondary Burner**



1. Electrode
2. U-bolt
3. Diffuser Disc




4. HT Leads




#### **HT LEAD & ELECTRODE REPLACEMENT (4.4.3/01-002A & 02-002A)**

1. In order to change out the HT leads or Electrode the U-Bolt will have to be removed
2. Remove the electrode by pulling the lead out of the white ceramic tube, replace and re-install.
3. To change the Leads the wire will need to be removed from the burner.
4. Pull the wire out of the burner housing through the rubber grommet.
5. The other end is connected to the back of the control box. Pull the wire straight out and the spring fitting will disengage.
6. Replace the lead with a new one reversing the above directions.
7. When reinstalling the electrodes make sure that they are positioned as shown below:



**Primary Burner**



**Secondary Burner**

#### **DIFFUSER DISC REPLACEMENT (4.4.3/01-002B & 02-002B)**

1. Locate the diffuser disc in the above pictures.
2. The disc assembly is secured to the nozzle housing by 2 hex nuts.
3. Remove these nuts and remove the assembly from the burner.
4. The disc is attached to the assembly with 2 screws.
5. Remove the screws and replace the disc.
  - Primary Chamber Burner diffuser disc
  - Secondary Chamber Burner diffuser disc
6. Reassemble.

#### **NOZZLE REPLACEMENT (4.4.3/01-002C & 02-002C)**

1. Locate the nozzle at the very front end of the burner just behind the diffuser disc.
2. Remove the nozzle with a wrench.
3. Install the new nozzle.
  - Primary Chamber Burner nozzle
  - Secondary Chamber Burner nozzle

#### **END CONE REPLACEMENT (4.4.3/01-002D & 02-002D)**

The End Cone is marked Item #7 in the first diagram of Section 4.4.3. The end cone will need replacement when the flame becomes unstable from too much heat damage.

1. Loosen and remove the 4 hex bolts that hold the burner on the flange.
2. Remove the burner completely from the incinerator. This will require more than one operator because the burner is heavy.
3. There are two screws that hold the End Cone on. Remove and save the screws for the new End Cone.
4. Install the new End Cone with the old screws.
  - Primary Chamber burner end cone
  - Secondary Chamber burner end cone
5. Reinstall the burner.

#### **NOZZLE ASSEMBLY REPAIR OR REPLACEMENT (4.4.3/01-002E & 02-002E)**

The nozzle assembly is subjected to high heat cycling. The heat cycling will eventually cause the seals and assembly to leak. The assembly will have to be replaced when this occurs. First identify the location of the nozzle assembly.

- Primary Chamber Burner nozzle assembly:
- Secondary Chamber Burner nozzle assembly:

The parts (seals, nozzle assembly) needed for these replacements are all included under one part number.

- Primary Chamber Burner nozzle assembly:
- Secondary Chamber Burner nozzle assembly:


Remove all connections to the nozzle assembly and replace with the above parts.

### **BURNER FLEXIBLE OIL LINE REPLACEMENT (4.4.3/01-002F & 02-002F)**

1. Turn the inline ball valve to the closed position to isolate the fuel supply from the burner. This valve is located down line from the burner.
2. Remove flexible lines.
3. Replace with new lines.
  - Primary Chamber Burner flexible oil line:
  - Secondary Chamber Burner flexible oil line
4. Open ball valve.



Primary Chamber Burner Flexible lines  
(1 Above)



Secondary Chamber Burner Flexible Lines  
(1 Above)

### **LEVEL SWITCH REPLACEMENT (4.4.3/01-002G & 02-002G)**

The level switch is located in the Diesel Tank.

#### **NOTA**

**Tanks do not have to be emptied to replace.**

1. Unplug the level switch from tank.
2. Disconnect the cord and remove the level switch.
3. Replace level switch and reconnect the cord.
4. Plug in the level switch to tank.

### **INSPECTION WINDOW REPLACEMENT (4.4.3/01-002H & 02-002H)**

The inspection window can be identified as Item # 7 on IPD-I03 for the Primary Burner and Item # 32 on IPD-I04 for the Secondary Burner. To replace the window simply remove the old inspection window and replace with a new one:

- Primary Burner inspection window
- Secondary Burner inspection window

### **FUEL PUMP REPLACEMENT (4.4.3/01-002I & 02-002I)**

Identify the pump on the burner you wish to replace the pump on:

- Primary Burner:
- Secondary Burner :

Remove all fuel connections to the pump with the appropriate wrench. Unbolt the pump from the main body of the burner and pull the pump away from the burner to remove.

Reinstall the new pump, and reattach all fuel connections.

- Primary Burner:
- Secondary Burner :

### **CONTROL BOX REPLACEMENT (4.4.3/01-002J & 02-002J)**

Identify the control box on the burner you wish to replace the control box on:

- Primary Burner:
- Secondary Burner :

Ensure the power is off, unscrew the old control box, and install the new one.

- Primary Burner:
- Secondary Burner :

### **OIL TUBE REPLACEMENT (4.4.3/01-002K & 02-002K)**

Oil tubes leak due to heat cycling which causes the fittings to fail or a loose fitting.

1. Identify the oil tubes on the Primary Burner and Secondary burner
2. First try tightening the fittings to see if the leak stops. If the leak does not stop:
3. Remove the old oil tubes with a wrench and install the new ones:
  - Primary Burner Tubes:
  - Secondary Burner Tubes

### **BURNER PE CELL & UV DETECTOR REPLACEMENT (4.4.3/01-002L & 02-002L)**

**Primary Burner:** If the PE cell has been damaged, then it will need to be replaced. The PE cell while removed needs to be unplugged from the control box. This is accomplished by pulling the connection towards you. With the new PE cell install the control box end first by pushing the connection hard. Reinstall the PE cell in the burner.

**Secondary Burner:** If the UV Detector has been damaged, then it will need to be replaced. The UV Detector while removed needs to be unplugged from the control box. This is accomplished by pulling the connection towards you. With the new UV Detector install the control box end first by pushing the connection hard. Reinstall the UV Detector in the burner.

### **BURNER FAN MOTOR REPLACEMENT (4.4.3/01-002M & 02-002M)**

Identify the malfunctioning motor in the affected burner:

- Primary Burner –
- Secondary Burner -


Unbolt and remove the malfunctioning motor from the housing the burner. Disconnect all electrical connections. Reinstall the new motor exactly how the old motor was installed.

#### **4.3.4 Primary & Secondary Blower Corrective Maintenance Instructions**



**Do not attempt any maintenance on a fan unless the electrical supply has been completely disconnected and locked. In many cases, a fan can windmill despite removal of all electrical power. The rotating assembly should be blocked securely before attempting maintenance of any kind.**


Primary Blower Assemblies are not a commonly repaired part on the incinerator. Parts within this assembly will need to be repaired or replaced. They are outlined below.



**Primary Blower**

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper

Secondary Blower Assemblies are not a commonly repaired part on the incinerator. Parts within this assembly will need to be repaired or replaced. They are outlined below.



**Secondary Blower**

1. Air Proving Switch
2. Modutrol Motor
3. Motor Crank Arm
4. Damper Crank Arm
5. Rod
6. Damper

**AIR PROVING SWITCH REPLACEMENT (4.4.4/01-001A & 02-001A)**

1. Ensure all power is locked out.
2. Remove wiring from switch.
3. Remove tubing from switch.
4. Unscrew screws at the two locations and remove switch.
5. Reinstall new switch complete with tubing and wiring and then retighten.
6. Turn power back on.

**DAMPER CALIBRATION (4.4.4/01-001B & 02-001B)**

Sometimes the damper linkage will slip when the connections become loose (Items 3,4,5 in the Secondary Blower photo) In order to ensure that the linkage is correctly calibrated the operator will need to look at the display screen on the control panel while the unit is in operation

1. Read the %Open value on the control panel operator interface (PanelView) for the Primary Blower.
2. During operation the damper is factory preset to be 0% open, or fully closed.
3. Look inside the damper (Item 6) and ensure that the linkage is completely closed.
4. If it is then this maintenance is complete.
5. Should the damper be open even a small percentage the linkages are to be loosened and the damper adjusted to be completely closed, and then retighten.



#### **MODUTROL RESISTOR REPLACEMENT (4.4.4/01-001C & 02-001C)**

The Modutrol resistors are located inside the top lid of the Modutrol motor. Remove the lid to the Modutrol motor by unscrewing the top four (4) screws. The connection between the control panel and the Modutrol is made with a small white connector with 3 terminals. Jumped between these terminals is the resistors.

Remove and replace the resistors one at a time to ensure the correct resistors are replaced. You identify the correct resistor by examining the color band on the center node of the resistor. Replace like resistors.

#### **DAMPER CRANK ARM REPLACEMENT (4.4.4/01-001D & 02-001D)**

The crank arm will only need to be replaced if the arm is damaged due to misuse. Identify the damper crank arm (Item #4 in the picture on the previous page).

Identify the location of the linkage on the rod and the damper arm with a marker, so the new crank arm will be in the same spot when reinstalled. Remove the connections to the crank arm and replace with the new one and ensure it is in the same spot as the old one.

#### **MOTOR REPLACEMENT (4.4.4/01-001E & 02-001E)**

Replacing the motor requires a second level maintenance. This information can be found in the OEM manual New York Blower, Installation, Maintenance and Operating, IM-160 Junior Fans.

#### **MODUTROL MOTOR & TRANSFORMER REPLACEMENT (4.4.4/01-001F & 02-001F)**

To replace a Modutrol motor requires all power to be off to the system as you will need to expose electrical connections. Firstly get the new motor and orientate the motor in the same direction as the old motor. Identify where the conduit is connected on the old motor and punch the connector holes for the new motor.

##### **Removal**

1. Remove and electrical terminations and remove the transformer.
2. Install the transformer in the new Modutrol motor.
3. Remove all conduit connections on the motor.
4. Remove the damper arm and linkage from the motor.
5. Unbolt the motor from the damper, and ensure all nuts and bolts are kept for the new motor install

##### **Install**

1. Bolt the new motor in the same orientation as the old motor.
2. Install the damper arm and linkage to the motor
3. Install all conduit connections

Terminate all electrical connections the same as the old motor.

#### **REPLACE THE BLOWER CONTACTOR 4.4.4/01-001G**

1. Turn off Main Disconnect.
2. Open Panel.
3. Remove the wires from blower contactor.
4. Pull the retaining clip up.
5. Tilt contactor forward and remove.
6. To reinstall tilt new contactor until it clicks back in.
7. Pull the retaining clip back down to lock.
8. Reinstall wires to contactor.
9. Close panel.
10. Turn power back on.

---

#### **4.3.5 Main Control Panel Corrective Maintenance Instructions**

##### **MAIN CONTROL PANEL (4.4.6/03-010A)**

All control panel diagnostics are to be completed by certified or trained technicians. Electrical drawings / diagrams are provided to aid electricians with any diagnostics. For reference the parts diagrams for the main control panels are drawings

##### **REBOOT PLC (4.4.6/03-010B)**

Turn Main Disconnect to the off position on the front of the Control Panel. Turn the main disconnect back on.

##### **PLC PARTS REPLACEMENT (4.4.6/03-010C)**

For detailed repair procedures, refer to the OEM Manual, Part IV Control Panel, PLC.



**Read all warnings for procedures in each OEM Manual as they contain critical safety information. Disconnect the power from each component before starting each corrective maintenance procedure.**

Component	Procedure	OEM Manual	Page No.
Panelview 1000-Series	Replacing the Battery	<u>Panelview (2711P-T10C4A8)</u>	130
Panelview 1000-Series	Replacing the Backlight	<u>Panelview (2711P-T10C4A8)</u>	126

Panelview 1000-Series	Load and SD card	<u>Panelview (2711P-T10C4A8)</u>	135
Panelview 1000-Series	Removing the Product ID Label	<u>Panelview (2711P-T10C4A8)</u>	134
Panelview 1000-Series	Replacing the Bezel	<u>Panelview (2711P-T10C4A8)</u>	124
Panelview 1000-Series	Cleaning the Display Window	<u>Panelview (2711P-T10C4A8)</u>	136
16 Point Relay Output Module	Replacing a Single Module	<u>I/O Modules Compact 16-PointRelay Output Module (1756-OA16)</u>	156
8 Channel Analog Output Module	Replacing a Single Module	<u>Analog I/O modules Compact 1756-OF4 Analog Output Module</u>	187
8 Channel Analog Input Card	Replacing a Single Module	<u>Analog I/O Modules Compact 1756-IF8 Input Card</u>	187
6 Channel Thermocouple Input Module	Replacing a Single Module	<u>Analog I/O Compact 1756-IT6I Thermocouple Input Module</u>	187

#### 4.3.6 Additional Maintenance Instructions

For more detailed and additional maintenance instructions please refer to the OEM manuals for the Incinerator components.