

DE- Nicht verbiegen
Nicht kürzen
Nicht verlängern

EN- Do **not** bend
Do **not** shorten
Do **not** lengthen

FR - Ne pas déformer
Ne pas raccourcir
Ne pas rallonger

ES - No torcer
No acortar
No alargar


IT - Non stringere o allargare
Non accorciare o allungare
Non piegare

NL- Niet verbuigen
Niet inkorten
Niet verlengen

Endress + Hauser

7


DE- Geräte-Identifikation
 EN- Device Identification
 FR - Dénomination
 ES - Identificación del equipo
 IT - Identificazione dello strumento
 NL- Instrument-identificatie





A	ATEX II 3 G	EEx nC II T6, WHG
B	ATEX II 3 G	T85°C ³
C	ATEX II 3 G	EEx nA II T6, WHG
D	ATEX II 3 D	T85°C ³
E	ATEX II 1/2 G	EEx de IIC T6, WHG
F	ATEX II 1/2 G	EEx ia IIC T6, WHG
G	ATEX II 1/2 D	T80°C ³
H	ATEX II 1/2 G	EEx ia IIC T6
I	ATEX II 1/2 G	EEx de IIC T6
J	ATEX II 1 G	EEx ia IIC T6, WHG
K	ATEX II 1/2 G	EEx d IIC T6
L	ATEX II 1/2 G	EEx d IIC T6, WHG
M	NEPSI Ex ia IIC T6	
N	NEPSI Ex d IIC T6	
P	FM IS, Cl. I, II, III, Div. 1, Gr. A-G	
Q	FM XP, Cl. I, II, III, Div. 1, Gr. B-G, ES => Gr. A-G	
R	FM NI, Cl. I, Div. 2, Gr. A-D	
S	CSA IS, Cl. I, II, III, Div. 1, Gr. A-G	
T	CSA XP, Cl. I, II, III, Div. 1, Gr. A-G	
U	CSA General purpose	
V	TIIS Ex ia IIC T3	
W	TIIS Ex d IIB T3	
X	TIIS Ex ia IIC T6	
Y	TIIS Ex d IIC T3	
Y ²	TIIS Ex d IIC T6	






KA163

KA163








E1	F27	NEMA6P, NPT ¾	
E4	F16,	NEMA4X, NPT ¾	
E5	F13/17,	NEMA4X, NPT ¾	
E6	F15,	NEMA4X, NPT ¾	
F1	F27,	IP68, G ½	
F4	F16,	IP66, G ½	
F5	F13/17,	IP66, G ½	
F6	F15,	IP66, G ½	
G1	F27,	IP68, M20	
G4	F16,	IP66, M20	
G5	F13/17,	IP66, M20	
G6	F15,	IP66, M20	
N4	F16,	IP66, M12	
N5	F13/17,	IP66, M12	
N6	F15,	IP66, M12	
Y9	*2		
#3	Kompakt-Gehäuse / compact housing / boîtier compact / cabezal compacto / testa compacta / compact behuizing		
#7	Alu.sep.		
A	*1		
B	PVS free		
C	EN 10204 - 3.1, 316L		
K	Spec. adjustment density H20		
L	Spec. adjustment density H20, EN10204-3.1		
N	EN 10204 - 3.1, NACE MR0175, 316L		
P	100 bar (F.TL51)		
R	100 bar, EN 10204 - 3.1, NACE MR0175, 316L (F.TL51)		
S	GL/ABS marine certificate (F.TL51: max. 1600 mm)		
Y	*2		
A	*1		
<div> <div> <div></div> <div>F16 (PBT)</div> </div> <div> <div></div> <div>F13/17 (Alu)</div> </div> <div> <div></div> <div>F15 (316L)</div> </div> </div>			
<div> <div></div> <div>KA220</div> </div>			
<div> <div></div> <div>KA163</div> </div>			
<div> <div>ohne / without / sans / sin / senza / zonder</div> <div>*1</div> </div>			
<div> <div>andere / others / autres / otros / altri / andere</div> <div>*2</div> </div>			
<div> <div>"L II" Schaltpunkt / Switchpoint / Point de commutation / Punto de comutación / Punto di commutazione / Schakelpunt</div> <div>Liquiphant II FTL 360/365, FDL 30/35</div> </div>			
<div> <div>Temperaturdistanzstück / Temperature spacer / Élément de refroidissement / Tramo disipador de temperatura / Distanziale per temperatura / Temperatuurverdundestuk</div> <div>"T"</div> </div>			
<div> <div>Druckdichte Durchführung / Pressure sealed bushing / Entrée résistant à la pression / Extensión resistente a la presión / Passacavo a tenuta di pressione / Gasdichte doorvoering</div> <div>"p"</div> </div>			

DE- Flansche
 EN- Flanges
 FR- Brides
 ES- Brides
 IT - Flangia
 NL- Flens



ANSI B 16.5

AA2 1 1/2", 150 lbs, RF, 316/316L (FTL51)
 AB2 1 1/2", 300 lbs, RF, 316/316L (FTL51)
 AC2 1 1/2", 150 lbs, RF, 316/316L (FTL51)
 AD2 1 1/2", 300 lbs, RF, 316/316L (FTL51)
 AE2 2", 150 lbs, RF, 316/316L (FTL51)
 AE3 2", 150 lbs, RF, Alloy C4 >316/316L
 AE6 2", 300 lbs, RF, Alloy C22 >316/316L
 AF2 2", 300 lbs, RF, 316/316L
 AG2 2", 600 lbs, RF, 316/316L (FTL51)
 AJ2 2 1/2", 300 lbs, RF, 316/316L (FTL51)
 AL2 3", 150 lbs, RF, 316/316L
 AM2 3", 300 lbs, RF, 316/316L (FTL51)
 AN2 3", 600 lbs, RF, 316/316L (FTL51)
 AP2 4", 150 lbs, RF, 316/316L
 AQ2 4", 300 lbs, RF, 316/316L (FTL51)
 AR2 4", 600 lbs, RF, 316/316L (FTL51)
 AS2 1", 150 lbs, RF, 316/316L

EN 1092-1

BA2 DN32, PN6 A, 316L
 BB2 DN32, PN25/40 A, 316L
 BC2 DN40, PN6 A, 316L
 BD2 DN40, PN25/40 A, 316L
 BE2 DN50, PN6 A, 316L
 BG2 DN50, PN25/40 A, 316L
 BH2 DN65, PN6 A, 316L
 BJ2 DN50, PN100 A, 316L
 BK2 DN65, PN25/40 A, 316L
 BM2 DN80, PN10/16 A, 316L
 BN2 DN80, PN25/40 A, 316L
 BQ2 DN100, PN10/16 A, 316L
 BR2 DN100, PN25/40 A, 316L

B12	DN80,	PN100 A,	316L (FTL51)
B82	DN25,	PN25/40 A,	316L
CA2	DN32,	PN6 B1,	316L
CA5	DN32,	PN6,	Alloy C4 > 316L
CA6	DN32,	PN6,	Alloy C22 > 316L
CE2	DN50,	PN6 B1,	316L
CE5	DN50,	PN6,	Alloy C4 > 316L
CE6	DN50,	PN6,	Alloy C22 > 316L
CG2	DN50,	PN25/40 B1,	316L
CG5	DN50,	PN25/40,	Alloy C4 > 316L
CG6	DN50,	PN25/40,	Alloy C22 > 316L
CJ2	DN50,	PN100 B2,	316L (FTL51)
CN2	DN80,	PN25/40 B1,	316L
CN5	DN80,	PN25/40,	Alloy C4 > 316L
CN6	DN80,	PN25/40,	Alloy C22 > 316L
CQ2	DN100,	PN10/16 B1,	316L
CQ5	DN100,	PN10/16,	Alloy C4 > 316L
CQ6	DN100,	PN10/16,	Alloy C22 > 316L
C12	DN80,	PN100 B2,	316L (FTL51)
C82	DN25,	PN25/40 B1,	316L
C85	DN25,	PN25/40,	Alloy C4 > 316L
C86	DN25,	PN25/40,	Alloy C22 > 316L
DG2	DN50,	PN40 B1,	316L
DN2	DN80,	PN40 B1,	316L
D82	DN25,	PN40 B1,	316L
FG2	DN50,	PN40 C,	316L
NG2	DN50,	PN40 D,	316L

JIS B2220

KA2	10K 25,	RF,	316L
KC2	10K 40,	RF,	316L
KE2	10K 50,	RF,	316L
KE5	10K 50,	RF,	Alloy C4 > 316L
KE6	10K 50,	RF,	Alloy C22 > 316L
KL2	10K 80,	RF,	316L
KP2	10K 100,	RF,	316L

DE- Verwendung	Grenzstanddetektion in Flüssigkeiten
EN- Application	Point level detection in fluids
FR - Utilisation	Détection de niveau dans les liquides
ES - Aplicación	Detección de nivel en líquidos agua
IT - Applicazione	Controllo livello nei liquidi
NL- Toepassing	Niveaudectie in vloeistoffen

Grenzstanddetektion in Flüssigkeiten	EN- Application	Point level detection in fluids
	FR- Utilisation	Détection de niveau dans les liquids
	ES- Aplicación	Detección de nivel en líquidos agua
	IT - Applicazione	Controllo livello nei liquidi
	NL-Toepassing	Niveaudetectie in vloeistoffen

Flüssigkeiten	
EN - Application	Point level detection in fluids
FR - Utilisation	Détection de niveau dans les liquids
ES - Aplicación	Detección de nivel en líquidos agua
IT - Applicazione	Controllo livello nei liquidi
NL - Toepassing	Niveaudetectie in vloeistoffen

EN- Application	Point level detection in fluids
FR - Utilisation	Détection de niveau dans les liquids
ES - Aplicación	Detección de nivel en líquidos agua
IT - Applicazione	Controllo livello nei liquidi
NL- Toepassing	Niveaudetectie in vloeistoffen

- Point level detection in fluids
- FR - Utilisation**
 - Détection de niveau dans les liquids
- ES - Aplicación**
 - Detección de nivel en líquidos agua
- IT - Applicazione**
 - Controllo livello nei liquidi
- NL - Toepassing**
 - Niveaudetectie in vloeistoffen

- FR - Utilisation**
Détection de niveau dans les liquides
- ES - Aplicación**
Detección de nivel en líquidos agua
- IT - Applicazione**
Controllo livello nei liquidi
- NL- Toepassing**
Niveaudectie in vloeistoffen

Détection de niveau dans les liquids	
ES - Aplicación	
Detección de nivel en líquidos agua	
IT - Applicazione	
Controllo livello nei liquidi	
NL- Toepassing	
Niveaudetectie in vloeistoffen	

- liquids
- ES - **Aplicación**
Detección de nivel en líquidos agua
- IT - **Applicazione**
Controllo livello nei liquidi
- NL- **Toepassing**
Niveaudetectie in vloeistoffen

- ES - Aplicación**
 - Detección de nivel en líquidos agua
- IT - Applicazione**
 - Controllo livello nei liquidi
- NL- Toepassing**
 - Niveaudetectie in vloeistoffen

Detección de nivel en líquidos agua

IT - Applicazione

Controllo livello nei liquidi

NL- Toepassing

Niveaudetectie in vloeistoffen

IT - Applicazione
Controllo livello nei liquidi
NL- Toepassing
Niveaudetectie in vloeistoffen

Controllo livello nei liquidi


NL-Toepassing

Niveaudetectie in vloeistoffen

NL-Toepassing

Niveaudetectie in vloeistoffen

Niveaudetectie in vloeistoffen



Elektronikeinsätze
Electronic inserts
Electronique
Electrónica
Inserti elettronici
Elektronica-insert

Order code:
FTL5# - # ### ## ## #

FEL51
FEL52
FEL54

*) Externe Last
External load
Charge externe
Carga externa
Carico esterno
Externe belasting

DE- Messeinrichtung
für direkten Anschluss

EN- Measuring system
for direct connection

FR- Ensemble de détection de niveau
pour raccordement direct

ES - Sistema de medida
para conexión directa

IT - Sistema di misura
per connessione diretta


NL- Meetopstelling
voor directe aansluiting

DE- Messeinrichtung für Anschluss über Schaltgerät	
EN- Measuring system for connection via switching unit	
FR - Ensemble de détection de niveau pour raccordement via détecteur	
ES - Sistema de medida para conexión vía interruptores	
IT - Sistema di misura per connessione mediante unità di commutazione	
NL- Meetopstelling voor aansluiting aan een schakelversterker	

Order code:
FTL5# - # ### ## # ## #

Elektronikeinsätze
Electronic inserts
Electronique
Electrónica
Inserti elettronici
Elektronica-insert

FEL55
FEL56
FEL57
FEL58



DE- Messeinrichtung
für Anschluss an PROFIBUS PA


EN- Measuring system
for connection to PROFIBUS PA

**FR - Ensemble de détection
de niveau**
pour le raccordement à
PROFIBUS PA

ES - Sistema de medida
para conexión a PROFIBUS PA

IT - Sistema di misura
per connessione a PROFIBUS PA

NL- Meetopstelling
voor aansluiting aan PROFIBUS PA



	<p>DE- Einbau Schaltpunkt in Abhängigkeit vom Einbau</p> <p>EN- Installation Switchpoint depends on mounting position</p> <p>FR - Montage Point de commutation en fonction de l'implantation</p> <p>ES- Montaje Punto de conmutación dependiendo de la posición de montaje</p> <p>IT - Montaggio Punto di commutazione in funzione della posizione di montaggio</p> <p>NL- Inbouw Schakelpunt afhankelijk van inbouw</p>

DE- Einbaubeispiele
in Abhängigkeit von der
Viskosität v der Flüssigkeit

EN- Mounting examples
as a function of liquid viscosity v


FR- Exemples d'implantation
dépendant de la viscosité v
du liquide

ES- Ejemplos de montaje
dependiendo de la viscosidad v
del líquido

IT- Esempi di montaggio
come funzione di viscosità v
del liquido


NL- Inbouwvoorbeelden
afhankelijk van de viscositeit v
van de vloeistof



v = 0...2000 mm²/s
(v = 0...2000 cSt)






* entgraten / deburr / ébarber / libre / sbavare / ontbramen

v = 0...10000 mm²/s
(v = 0...10000 cSt)





* Abstand! / Distance! / Distanza! / Distancia! / Afstand!



DE- Ansatzbildung berücksichtigen.
Schwinggabel darf Ansatz nicht
berühren.

EN- Consider build-up.
Fork may not contact the build-up.


FR - Tenir compte du colmatage.
Fourche ne doit pas entrer en
contact avec le dépôt.

ES - Tener en cuenta las adherencias.
Las horquillas no deben estar en
contacto con las adherencias.

IT - Tenere conto dei depositi.
La forcella non deve entrare in
contatto con i depositi.


NL- Rekening houden met aangroei.
Trilvork mag de aangroei niet
aanraken.

DE- Bei dynamischer Belastung
abstützen
EN- In cases of dynamic forces support
FR - En cas de contraintes dynamiques,
étayer le tube
ES - En caso de cargas dinámicas altas
debe ser apoyado
IT - In caso di carichi dinamici,
rinforzare con un supporto
meccanico
NL- Bij mechanische belasting
versteven



Endress + Hauser

"T" = mit Temperaturdistanzstück für isolierten Tank
 "T" = with temperature spacer for insulated tanks
 "T" = avec élément de refroidissement pour réservoir isolé
 "T" = con tramo disipador de temperatura para tanques aislados
 "T" = con distanziale di temperatura per serbatoi isolati
 "T" = met temperatuurreductiestuk voor geïsoleerde tanks



DE- Freiraum vorsehen
 EN- Allow clearance
 FR- Prévoir un espace libre
 ES- Prever espacio
 IT - Lasciare spazio per estrazione
 NL- Ruimte vrijhouden

DE- Schwinggabel ausrichten:
Markierung oben oder unten



EN- Orientation of fork tines:
Marking above or below

FR- Orientation des lames vibrantes:
Repères en haut ou en bas

ES- Orientación de la horquilla:
Marca arriba o abajo

IT- Allineamento della forcella:
Marcatura in alto o in basso

NL- Vork uitrichten:
Markering boven of onder



<p>G $\frac{3}{4}$, 32 mm (1 $\frac{1}{4}$)\" G 1, 41 mm (1 $\frac{5}{8}$)\"</p>	<p>DE- Liquiphant einschrauben. Nicht am Gehäuse drehen.</p> <p>EN- Screw Liquiphant into process connection. Don't use housing to turn.</p> <p>FR - Visser le Liquiphant. Ne pas se servir du boîtier.</p> <p>ES - Roscar el Liquiphant a la conexión a proceso. No girar el cabezal.</p> <p>IT - Avvitare il Liquiphant all'attacco di processo. Allo scopo non utilizzare la custodia.</p>
<p>NPT $\frac{3}{4}$, R $\frac{3}{4}$, G $\frac{3}{4}$, 32 mm (1 $\frac{1}{4}$)\" NPT 1, R 1, G 1, 41 mm (1 $\frac{5}{8}$)\"</p>	<p>NL- Schroef de Liquiphant in de procesaansluiting. Draai hierbij niet aan de behuizing.</p>

DE- Ausrichten in Rohrleitungen:
Markierung in Fließrichtung


EN- Orientation in pipes:
Marking in direction of flow

FR- Orientation dans une conduite:
Repère dans le sens de l'écoulement


ES- Montaje y orientación dentro de tuberías:
Marca en dirección del caudal

IT- Allineamento per montaggio in tubazioni:
Marcatura nella direzione del flusso


NL- Opstelling in leidingen:
Markering in de stroomrichting



F15, F27



F16, F13, F17



DE- Kabeleinführung ausrichten
EN- Cable gland orientation
FR- Positionnement de l'entrée
 de câble
ES- Ajuste del prensaestopa
IT- Posizionamento del passacavo
NL- Kabelinvoer uitrichten

* Anzugsdrehmoment /
 Torque /
 Couple de serrage /
 Esfuerzo de torsión /
 Coppia di torsione /
 Aandraaimoment

DE- Einstellungen
Minimum-/Maximum-
Sicherheitsschaltung


EN- Setting-up
Minimum/maximum
fail-safe mode


FR - Réglage
Sécurité minimum/maximum

ES - Ajuste
Commutador de seguridad
mín./máx.

IT - Messa in servizio
Selezione della modalità
di sicurezza min./max.

NL- Instellingen
Minimum/maximum
veiligheidsschakeling





DE- Dichte der Flüssigkeit.
Dichte ρ gemessen in g/cm³
oder in kg/l.

EN- Liquid density.
Density ρ measured in g/cm³
or in kg/l.

FR - Densité du liquide.
Unité de mesure de la densité ρ :
g/cm³ ou kg/l.

ES - Densidad de líquidos.
Densidad ρ medida en g/cm³
o en kg/l.

IT - Densità del liquido.
Densità ρ misurata in g/cm³
o in kg/l.

NL- Dichtheid van de vloeistof.
Dichtheid ρ gemeten in g/cm³
of in kg/l.

DE- Selbsttest FEL57
(Funktion siehe Seite 46, 47
und Schaltgerät)


EN- Selftest FEL57
(see page 46, 47 and
switching unit for sequence)


FR - Auto-test FEL57
(voir pages 46, 47 et détecteur)

ES - Prueba automática FEL57
(ver pág. 46, 47 e interruptor
para secuencia)

IT - Prova automatica FEL57
(vds. pag. 46, 47 e
unità di commutazione)

NL- Functietest FEL57
(zie voor functie pag 46, 47
en schakelversterker)





DE- Geräteadresse einstellen
(Einstellung der Parameter
siehe BA141F)

EN- Setting Device Address
(Setting the parameters,
see BA141F)


FR - Réglage de l'adresse d'appareil
(Réglage des paramètres
voir BA141F)

ES - Configuración de la dirección
del equipo
(Ver configuración parámetros
en BA141F)



IT - Impostare indirizzo del dispositivo
(Per impostazione parametri
vds. BA141F)

NL- Instrumentadres instellen
(Parameter instelling zie BA141F)

DE- Lichtsignale
 EN- Light signals
 FR- Signaux lumineux
 ES- Señales luminosas
 IT - Segnali luminosi
 NL- Lichtsignalen



Füllstand variieren
 Vary level
 Varier le niveau
 Nivel variable
 Variare livello
 Niveau variëren



Leuchtdioden / LEDs / DEL / LED's / LED's

- Betrieb / Stand-by / Fonctionnement / Reposo / Attesa / stand-by
- ☀ Schaltzustand / Switching status / Etat de commutation / Estado conexión / Stato di commutazione / schakelstand
- ☀ FEL57, FEL50A: Bedeckung / Covering / Recouvrement / Cubierto / Copertura / bedekking



- ☀ leuchtet / on / allumée / iluminado / on / aan
- ☀ blinkt / flashes / clignote / parpadea / lampeggia / knippert

- aus / off / éteinte / apagado / off / uit
- ➔ Ausgangssignal / Output signal / Signal de sortie / Señal de salida / Segnale uscita / uitgangssignaal

- ⏏ Störung / Fault / Défaut / Fallo / Guasto / storing



Nationale Normen und Vorschriften beachten!
Note national regulations!
Respecter les lois et règles locales en vigueur!
Considere reglamentaciones nacionales
Osservare le norme nazionali!
Nationale voorschriften in acht nemen!



DE- Anschluss
EN- Connections
FR- Raccordement
ES- Conexiones
IT - Collegamenti elettrici
NL- Aansluiting

***Cable entry**
Nickel-plated brass:
Ød = 7...10,5 mm (0,28...0,41 in)
Plastic:
Ød = 5...10 mm (0,2...0,38 in)
Stainless steel:
Ød = 7...12 mm (0,28...0,47 in)

DE- Anschluss FEL51
Zweileiter-

Wechselstromanschluss

EN-Connections FEL51

Two-wire AC connection

FR - Raccordement FEL51

Raccordement 2 fils

courant alternatif

ES - Conexiones FEL51
Conexión a corriente alterna
a dos hilos

IT - Collegamenti elettrici FEL51

Collegamento bifilare

con corrente alternata

NL- Aansluiting FEL51

2-draads

wisselspanningsaansluiting

Zerstörung
Destruction


Destruction



Destruction

Destrucción

Distruzione


Storing



I_L max.	1.5 A	
I_L max.	350 mA	
	max. 89 VA / 253 V	
	max. 8.4 VA / 24 V	
	min. 2.5 VA / 253 V (10 mA)	
	min. 0.5 VA / 24 V (20 mA)	

Endress+Hauser

DE- Anschluss FEL52 Gleichstromanschluss (PNP)	
EN- Connections FEL52 DC connection (PNP)	
FR- Raccordement FEL52 Courant continu (PNP)	
ES- Conexiones FEL52 Alimentación CC (PNP)	
IT- Collegamenti elettrici FEL52 Collegamento CC (PNP)	
NL- Aansluiting FEL52 Gelijkspanningsaansluiting (PNP)	



auch für DI-Module
also for DI modules
également pour des modules DI
también para módulos DI
anche per DI modules
aan de DI-module
EN 61131-2

<div> </div>					
		GN	RD		FEL52
↑		☀	●	L+ 1 → 3	→ (L-) R
Max.		☀	☀	L+ 1 → 3	→ (L-) R
↓		☀	●	L+ 1 → 3	→ (L-) R
Min.		☀	☀	L+ 1 → 3	→ (L-) R
		☀	☀	L+ 1 → 3	→ (L-) R
		●	●	L+ 1 → 3	→ (L-) R

DE- Funktion FEL52
 EN- Function FEL52
 FR- Fonction FEL52
 ES- Funcionamiento FEL52
 IT - Funzione FEL52
 NL- Functie FEL52

ΔU_{FEL52} max. 3 V

DE- Anschluss FEL54
Allstromanschluss
Relaisausgang

EN-Connections FEL54
Universal connection
Relay output

FR - Raccordement FEL54
Tous courants
Sorties relais

ES - Conexiones FEL54
Conexión universal
Salida por relé

IT - Collegamenti elettrici FEL54
Collegamento corrente universale
Uscita relè

NL- Aansluiting FEL54
 Universele spanningsaansluiting
 Relaisuitgang



Endress+Hauser

DE- Funktion FEL54
EN- Function FEL54
FR- Fonction FEL54
ES- Funcionamiento FEL54
IT- Funzione FEL54
NL- Functie FEL54

	GN	RD	FEL54
↑			
Max.			
↓			
Min.			

DE- Anschluss FEL55
Ausgang 8/16 mA
* In nasser Umgebung.

EN- Connections FEL55
Output 8/16 mA
* Wet location.


FR - Raccordement FEL55
Sortie 8/16 mA
* Dans les environnements humides.

ES - Conexiones FEL55
Salida 8/16 mA
* En ambientes húmedos.

IT - Collegamenti elettrici FEL55
Uscita 8/16 mA
* In ambienti umidi.

NL- Aansluiting FEL55
Uitgang 8/16 mA
* In vochtige omgevingen.

FEL55



****For non-Ex application:**
Fuse required!
Use only power supply units
with safe galvanic separation
e.g. SELVI!

T 50 mA**

F

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+

-

+


























PLC, AI modules, ...

$$R_{\max} = \frac{U - 11 \text{ V}}{16.8 \text{ mA}}$$

4...20 mA
EN 61131-2

U= 11 ...36 V (DC)

U= 11 ...35 V (DC)*

<div>  </div>				
		GN	RD	FEL55
<div>  </div>	<div>  </div>			<div>  </div> <div> <div>+</div> <div>2</div> </div> <div>  </div> <div> <div>~ 16 mA</div> <div>1</div> </div>
				<div>  </div> <div> <div>+</div> <div>2</div> </div> <div>  </div> <div> <div>~ 8 mA</div> <div>1</div> </div>
				<div>  </div> <div> <div>+</div> <div>2</div> </div> <div>  </div> <div> <div>~ 16 mA</div> <div>1</div> </div>
				<div>  </div> <div> <div>+</div> <div>2</div> </div> <div>  </div> <div> <div>~ 8 mA</div> <div>1</div> </div>
<div>  </div>	<div>  </div>			<div>  </div> <div> <div>+</div> <div>2</div> </div> <div>  </div> <div> <div>< 3.6 mA</div> <div>1</div> </div>

DE- Funktion FEL55
 EN- Function FEL55
 FR- Fonction FEL55
 ES- Funcionamiento FEL55
 IT - Funzione FEL55
 NL- Functie FEL55

DE- Anschluss FEL56
NAMUR- Ausgang L-H
< 1,0 mA / > 2,2 mA

EN- Connections FEL56
NAMUR output L-H
< 1,0 mA / > 2,2 mA


FR - Raccordement FEL56
Sortie NAMUR L-H
< 1,0 mA / > 2,2 mA

ES - Conexiones FEL56
Salida NAMUR L-H
< 1,0 mA / > 2,2 mA


IT - Collegamenti elettrici FEL56
NAMUR uscita L-H
< 1,0 mA / > 2,2 mA

NL- Aansluiting FEL56
NAMUR uitgang L-H
< 1,0 mA / > 2,2 mA

Power supply
DC: 8.2 V +/- 20%



DE- Funktion FEL56
EN- Function FEL56
FR- Fonction FEL56
ES- Funcionamiento FEL56
IT- Funzione FEL56
NL- Functie FEL56



		GN	RD	FEL56
↑				0.6... 1.0 mA → 1
Max.				2.2... 2.8 mA → 1
↓				0.6... 1.0 mA → 1
Min.				2.2... 2.8 mA → 1
				2.2... 2.8 mA → 1


Ausgang PFM
150 Hz / 50 Hz


PFM output
150 Hz / 50 Hz

Sortie PFM
150 Hz / 50 HzSalida PFM
150 Hz / 50 Hz

PFM uscita
150 Hz / 50 Hz

PFM uitgang
150 Hz / 50 Hz





* Einschaltverhalten / Switch-on behaviour /
Comportement à la mise sous tension / Comportamiento del cambio de estado /
Comportamento accensione / Einschaltgedrag

DE- Einschaltverhalten

Selbsttest (STD)

EN- Switch-on behaviour

Selftest (STD)

FR - Comportement à la mise sous tension

Auto-test (STD)

ES - Comportamiento del cambio de e stado


Prueba automática (STD)









IT - Comportamento in fase di accensione

Prova automatica (STD)


NL- Inschakelgedrag






Functiontest (STD)



		Simulation / Simulation / Simulation / Simulación / Simulazione / Simulate	
			
		1 s	4 s
		10 Hz	150 Hz
FEL57 		3 s	50 Hz
			150 Hz
		Simulation / Simulation / Simulation / Simulación / Simulazione / Simulate	
			
		1 s	4 s
		10 Hz	50 Hz
FEL57 		3 s	
			50 Hz

DE- Anschluss FEL50A
 EN- Connections FEL50A
 FR- Raccordement FEL50A
 ES- Conexiones FEL50A
 IT - Collegamenti elettrici FEL50A
 NL- Aansluiting FEL50A



<div>  </div>				<div>  FEL50A PA-Bussignal / PA Bus Signal / Signal bus PA / Señal Bus PA / Segnale bus PA / PA bussignaal </div>	
nicht invertiert not inverted non inversé no invertido non invertito niet geïnverteerd				GN	●
				YE	●
				OUT_D = 0	●
				OUT_D = 1	●
invertiert inverted inversé invertido invertito geïnverteerd				OUT_D = 0	●
				OUT_D = 1	●
				OUT_D = 0	●
				OUT_D = 1	●
<div>  SPS Commuwin II </div>				Kommunikation/ Communication/ Communication / Comunicación / Comunicazione / Communicatie	
<div>  </div>				Status siehe BA141F Status, see BA141F Etat, voir BA141F Estado, ver BA141F Stato, vedere BA141F Status, zie BA141F	
<div>  Uf 0V </div>				..	

DE- Anschluss FEL58
NAMUR- Ausgang H-L
> 2,2 mA / < 1,0 mA

EN- Connections FEL58
NAMUR output H-L
> 2,2 mA / < 1,0 mA


FR - Raccordement FEL58
Sortie NAMUR H-L
> 2,2 mA / < 1,0 mA










ES - Conexiones FEL58
Salida NAMUR H-L
> 2,2 mA / < 1,0 mA

IT - Collegamenti elettrici FEL58
NAMUR uscita H-L
> 2,2 mA / < 1,0 mA

NL- Aansluiting FEL58
NAMUR uitgang H-L
> 2,2 mA / < 1,0 mA

Power supply
DC: 8.2 V +/- 20%



<div>  </div>					
		GN	YE		FEL58
↑		 1 Hz		+ 2	2.2... 3.5 mA → 1
Max.		 1 Hz	●	+ 2	0.6... 1.0 mA → 1
↓		 1 Hz		+ 2	2.2... 3.5 mA → 1
Min.		 1 Hz	●	+ 2	0.6... 1.0 mA → 1
		 0.3 Hz	●	+ 2	< 1.0 mA → 1

Endress + Hauser

DE- Funktion FEL58
 EN- Function FEL58
 FR- Fonction FEL58
 ES- Funcionamiento FEL58
 IT - Funzione FEL58
 NL- Functie FEL58

DE- Funktion Prüftaste FEL58

Sicherheitsschaltung MAX

EN- Function test button FEL58

Fail-safe mode MAX

FR- Fonction touche test FEL58

Sécurité MAX

ES- Funcionamiento

botón de prueba FEL58

















Commutador de seguridad MAX



















IT - Funzione pulsante test FEL58

Selezione della modalità di sicurezza MAX

NL- Functie testknop FEL58

Veiligheidsschakeling MAX

MAX  + 		
1. Normaler Betrieb / Normal operation / Fonctionnement normal / Funcionamiento normal / Funzionamento normale / Normaal bedrijf	GN  1 Hz YE  + 2.2... 3.5 mA 2 → 1	GN  1 Hz YE  + 0.6... 1.0 mA 2 → 1
2. Prüftaste drücken / Press test button / Appuyer sur la touche test / Pulse el botón de prueba / Premere il pulsante test / Testknop indrukken	GN  1 Hz YE  + 0 mA 2 → 1	GN  1 Hz YE  + 0 mA 2 → 1
3. Prüftaste loslassen, nach ~2 s normaler Betrieb / Release the test button, after ~2 s normal operation / Relâcher la touche test, après ~2 s fonctionnement normal / Deje de presionar el botón de prueba, después de ~2 s funcionamiento normal / Rilasciare il pulsante test, dopo ~2 s funzionamento normale / De testknop loslaten, na ~2 s normaal bedrijf	GN  1 Hz YE  + 2.2... 3.5 mA 2 → 1	GN  1 Hz YE  + 0.6... 1.0 mA 2 → 1

MIN  + 			DE- Funktion Prüftaste FEL58 Sicherheitsschaltung MIN EN- Function test button FEL58 Fail-safe mode MIN FR- Fonction touche test FEL58 Sécurité MIN ES- Funcionamiento botón de prueba FEL58 Commutador de seguridad MIN IT - Funzione pulsante test FEL58 Selezione della modalità di sicurezza MIN NL- Functie testknop FEL58 Veiligheidsschakeling MIN
1. Normaler Betrieb / Normal operation / Fonctionnement normal / Funcionamiento normal / Normaal bedrijf	GN  1 Hz YE  + 2.2... 2 3.5 mA → 1	GN  1 Hz YE  + 0.6... 2 1.0 mA → 1	
2. Prüftaste drücken / Press test button / Appuyer sur la touche test / Pulse el botón de prueba / Premere il pulsante test / Testknop indrukken	GN  1 Hz YE  + 0 mA 2 → 1	GN  1 Hz YE  + 0 mA 2 → 1	
3. Prüftaste loslassen, nach ~2 s normaler Betrieb / Release the test button, after ~2 s normal operation / Relâcher la touche test, après ~2 s fonctionnement normal / Deje de presionar el botón de prueba, después de ~2 s funcionamiento normal / Rilasciare il pulsante test, dopo ~2 s funzionamento normale / De testknop loslaten, na ~2 s normaal bedrijf	GN  1 Hz YE  + 2.2... 2 3.5 mA → 1	GN  1 Hz YE  + 0.6... 2 1.0 mA → 1	 

DE- Wartung, Reinigung
Anbackungen entfernen


EN- Maintenance, Cleaning
Removal of encrustation

FR- Entretien, Nettoyage
Enlever les incrustations


ES- Mantenimiento, Limpieza
Eliminación de adherencias


IT - Manutenzione, Pulizia
Rimozione dei depositi

NL- Onderhoud, Reiniging
Aangroei verwijderen





Nicht besteigen!
Don't use as a step!
Ne pas marcher
sur les lames vibrantes!
No usar como peldaño!
Non usare come scalino!
Niet op staan!





DE- Prozessdruck p_e
 Prozesstemperatur T_p
EN- Process pressure p_e
 Process temperature T_p
FR- Pression de process p_e
 Température de process T_p
ES- Presión del proceso p_e
 Temperatura del proceso T_p
IT- Pressione di processo p_e
 Temperatura di processo T_p
NL- Procesdruk p_e
 Procestemperatuur T_p





DE- Hochdruck-Schiebemuffen
EN- High pressure sliding sleeves
FR - Manchons coulissants
 haute pression
ES - Mangitos deslizantes
 para alta presión
IT - Manicotto scorrevole
 per impieghi ad alta pressione
NL- Schuifmof
 voor toepassing onder druk

siehe / see / voir / ver / vedi / zie :
 KA001 53F (G 1, NPT 1)
 KA001 54F (G 1½, NPT 1½)

100 mm = 3. 94 in

EN- High pressure sliding sleeves
FR - Manchons coulissants
haute pression
ES - Mangitos deslizantes
para alta presión
IT - Manicotto scorrevole
per impieghi ad alta pressione
NL- Schuifmof
voor toepassing onder druk

ziehe / see / voir / ver / vedi / zie :
KA001 53F (G 1, NPT 1)
KA001 54F (G 1½, NPT 1½)

100 mm = 3. 94 in

FR - Manchons couissants
haute pression

ES - Mangitos desizantes
para alta presión

IT - Manicotto scorrevole
per impieghi ad alta pressione

NL- Schuifmof
voor toepassing onder druk

ziehe / see / voir / ver / vedi / zie :
KA001 53F (G 1, NPT 1)
KA001 54F (G 1½, NPT 1½)

100 mm = 3. 94 in

ES - Manguitos deslizantes
para alta presión

IT - Manicotto scorrevole
per impieghi ad alta pressione

NL - Schuifmof
voor toepassing onder druk

siehe / see / voir / ver / vedi / zie :
KA001 53F (G 1, NPT 1)
KA001 54F (G 1½, NPT 1½)

100 mm = 3. 94 in


IT - Manicotto scorrevole
per impieghi ad alta pressione

NL- Schuifmof
voor toepassing onder druk


siehe / see / voir / ver / vedi / zie :
KA001 53F (G 1, NPT 1)
KA001 54F (G 1½, NPT 1½)

100 mm = 3. 94 in


NL- Schuifmof
voor toepassing onder druk




G 1
1.4435 (AISI 316L)
52003663
Alloy C4: 52003664
Alloy C2: 71118691




NPT 1 - 11/2
1.4435 (AISI 316L)
52003667
Alloy C4: 52003668
Alloy C2: 71118694



G 1
1.4435 (AISI 316L)
52003663
Alloy C4: 52003664
Alloy C2: 71118691



NPT 1 - 11/2
1.4435 (AISI 316L)
52003667
Alloy C4: 52003668
Alloy C2: 71118694



NPT 1½ - 11½
 1.4435 (AISI 316L)
 52003669

Alloy C4: 52003670
 Alloy C22: 71118693

G 1½
 1.4435 (AISI 316L)
 52003665

Alloy C4: 52003666
 Alloy C22: 71118693

NPT 1½ - 11½
 1.4435 (AISI 316L)
 52003669


Alloy C4: 52003670
 Alloy C22: 71118693

G 1½
 1.4435 (AISI 316L)
 52003665

Alloy C4: 52003666
 Alloy C22: 71118693

58

Endress+Hauser



DE- Fehlersuche

DE- Fehlersuche		
Fehlfunktion	Ursache	Maßnahme
Schaltet nicht	Versorgungsspannung fehlt	Versorgung prüfen
	Signalleitung defekt	Signalleitung prüfen
	Elektronikeinsatz defekt	Austauschen
	- FEL51 direkt an L1 und N angeschlossen	- FEL51 immer über externe Last anschließen
	Dichte der Flüssigkeit zu gering	Am Elektronikeinsatz Dichte auf > 0,5 einstellen
	Schwinggabel verkrustet	Schwinggabel säubern
	Schwinggabel korrodiert (Anzeige am FEL: rot/ gelb blinkt, FEL58: grün blinkt 0,3 Hz)	Schwinggabel komplett mit Prozessanschluss austauschen
	FEL51: Relais mit zu großem Innenwiderstand angeschlossen	Geeignetes Relais anschließen
	FEL51: Relais mit zu geringem Haltestrom angeschlossen	Widerstand parallel zum Relais anschließen
	FEL54: Kontakte verschweißt (nach einem Kurzschluss)	FEL54 austauschen; Sicherung in den Koh-taktstromkreis
Schaltet falsch	Minimum-/Maximum- Sicherheits-schaltung vertauscht	Am Elektronikeinsatz Sicherheitsschaltung richtig einstellen
	Dichter schwerer Schaum, wilde Turbulenzen, aufgeschäumte Flüssigkeit	Liquiphant im Bypass montieren
	Extreme Funkstörung	Verbindungskabel abschirmen
	Extreme Vibrationen	Entkoppeln, dämpfen, Schwinggabel 90° drehen
	Wasser im Gehäuse	Deckel und Kabeldurchführungen fest zuschrauben
Fehlschaltung nach Netzausfall	FEL52: Ausgang überlastet	Last, (Leitungs-) Kapazität verringern
	FEL57, Verhalten beim Einschalttest (wiederkehrende Prüfung)	Schaltverhalten FEL57 beachten; Anlagensteuerung nach Netzausfall bis ca. 45 s blockieren

FR - Recherche de défauts

Défaut	Cause	Mesure
Ne commute pas	Tension d'alimentation manquante	Vérifier la tension d'alimentation
	Câble de signal défectueux	Vérifier le câble de signal
	Electronique défectueuse - FEL51 relié directement à L1 et N	Remplacer - Relier FEL51 toujours via la charge externe
	Densité du liquide trop faible	Régler la densité sur > 0,5 sur l'électronique
	Lames vibrantes encroûtées	Nettoyer les lames vibrantes
	Lames vibrantes corrodées (Sur FEL: rouge/jaune clignote, FEL58: vert clignote 0,3 Hz)	Remplacer les lames vibrantes ainsi que le raccord process
	FEL51: relais avec résistance interne trop élevée	Raccorder un relais approprié
	FEL51: relais avec courant de maintien trop faible	Raccorder une résistance en parallèle au relais
	FEL54: contacts soudés (après un court-circuit)	Remplacer FEL54; fusible dans le circuit courant
	Sécurité min/max inversée	Régler correctement le circuit de sécurité sur l'électronique
Mauvaise commutation		Monter le Liquiphant en bypass
Mauvaise commutation, sporadique	Mousse dense et lourde, fortes turbulences, liquide émulsionné	
	Parasites pulsants	Blinder le câble de liaison
	Vibrations importantes	Découpler, amortir, tourner la touche de 90°
	Eau dans le boîtier	Visser fermement le couvercle et les entrées de câble
	FEL52: surcharge de la sortie	Réduire la charge et la capacité (de ligne)
Mauvaise commutation après coupure	FEL57, comportement lors du test de mise sous tension (test cyclique)	Observer le comportement du FEL57 à la mise sous tension; bloquer la commande de l'installation après coupure de courant pendant max. 45 s

Fallo	Causa	Solución	ES - Identificación de fallos
No conmuta	No hay alimentación	Comprobar alimentación	
	Señal defectuosa	Comprobar cable de señal	
	Electrónica defectuosa - FEL51 conectada directamente a L1 y N	Cambio - Siempre conectar FEL51 vía una carga externa	
	Densidad del líquido demasiado baja	Fijar densidad a > 0.5 en la electrónica	
	Horquillas con adherencias	Limpia horquillas	
	Horquillas corroidas (En FEL: rojo/amarillo parpadea, FEL58: verde parpadea 0.3 Hz)	Cambiar la horquilla y la conexión a proceso	
	FEL51: Relé con resistencia interna demasiado grande	Conectar un relé adecuado	
	FEL51: El relé conectado retiene muy poca corriente	Resistencia conectada en paralelo con el relé	
	FEL54: Contactos soldados juntos (después del corto circuito)	Cambiar FEL54; poner fusible en el circuito de contacto	
Conmuta incorrectamente	El modo de fallo mín./máx. está mal ajustado	Ajustar el modo correcto en la electrónica	
Fallos de conmutación esporádicos	Espuma muy densa, turbulencias, líquidos espumosos	Montar el Líquiphant en bypass	
	RFT extremo	Utilizar cable apantallado	
	Vibraciones extremas	Desacoplar, amortiguar y girar las horquillas 90°	
	Agua en el cabezal	Roscar la cubierta y el prensaestopas finamente	
	FEL52: Salida con sobretensión	Reducir carga, capacidad (cable)	
Conmuta incorrectamente después de un fallo de alimentación	FEL57, comportamiento durante la comprobación de conmutación (test de funcionamiento)	Observar el comportamiento de conmutación del FEL57; del fallo de alimentación, bloqueo del control de la planta durante 45 s aprox.	

**IT - Individuazione e
eliminazione delle anomalie**

Guasto	Motivo	Rimedio
Non commuta	Manca alimentazione	Controllare l'alimentazione
	Linea segnale guasta	Controllare segnale linea
	Inserito elettronico guasto - FEL51 connesso direttamente a L1 e N	Sostituire - connettere sempre FEL51 mediante carico esterno
	Densità del liquido troppo bassa	Impostare la densità a > 0,5 sull'inserito elettronico
	Forcella incrostata	Pulire la forcella
	Forcella corrosa (Sul FEL: rosso/giallo lampeggiano, FEL58: verde lampeggiano 0,3 Hz)	Sostituire la forcella e la connessione al processo
	FEL51: resistenza interna del relè connesso troppo grande	Collegare il relè adeguato
	FEL51: corrente di mantenimento del relè connesso troppo grande	Connettere resistenza in parallelo al relè
	FEL54: contatti saldati insieme (dopo il corto circuito)	Sostituire FEL54; mettere il fusibile nel circuito di contatto
	Modalità di sicurezza min-/max- impostata in modo errato	Impostare la modalità corretta nell'inserito elettronico
Commutazione sporadicamente dilettoza	Schiama pesante e torbida condizioni molto turbolente, liquido che produce schiuma	Montare il Liquiphant nel bypass
	RFI forte	Usare cavo schermato
	Forte vibrazione	Disaccoppiare, smorzare, ruotare la forcella di 90°
	Acqua nella custodia	Avvitare correttamente il coperchio e il passacavi
	FEL52: Uscita sovraccaricata	Ridurre il carico, capacità (cavo)
Commutazione non corretta dopo la mancanza alimentazione	FEL57, comportamento durante la fase di test all'accensione (test di funzionamento)	Osservare il comportamento di commutazione del FEL57; dopo il ripristino di una mancanza di alimentazione inibire il controllo dell'impianto per 45 s

Fout	Oorzaak	Maatregel	NL-Fout zoeken
Schakelt niet	Voeding ontbreekt	Voeding controleren	
	Signaalleiding defect	Signaalleiding controleren	
	Insert defect	Ver vangen	
	- FEL51 direct op L1 en N aangesloten	- FEL51 altijd via een belasting aansluiten	
	Dichtheid van de vloeistof te gering	Op elektronica- insert dichtheid op > 0, 5 instellen	
	Trilvork te veel vervuld	Trilvork reinigen	
	Trilvork gecorrodeerd (LED op FEL knippert rood/geel, FEL58: groen knippert 0,3 Hz)	Trilvork compleet met procesaansluiting vervangen	
	FEL51: Relais met te grote inwendige weerstand aangesloten	Pasender relais aansluiten	
	FEL51: Relais met te geringe houdstroom aangesloten	Weerstand parallel aan relais aansluiten	
	FEL54: Contacten verkleeft (na een kortsluiting)	FEL54 vervangen; zekering in circuit aanbrengen	
Schakelt foutief	Minimum- /Maximum-fail-safe instelling verwisseld	FEL fail-safe keuze correct instellen	
Sporadische foutschakeling	Dik zwaar schuim, wilde turbulentie, opgeschuimde vloeistof	Liquiphant in by-pass monteren	
	Extreme RF invloed	Verbindingskabel afschermen	
	Extreme vibraties	Ontkoppelen, dempen, vork 90° draaien	
	Water in de behuizing	Deksel en wartels vast aandraaien	
	FEL52: uitgang overbelast	Schakelbelasting verminderen	
Foutmelding	FEL57: gedrag bij inschakelen na neutrital (periodieke testfunctie)	Schakelgedrag FEL57 controleren; procesherstart na neutrital ca. 45 s blokkeren	

DE- Ergänzung Fehlersuche	EN- Trouble- shooting Supplement	FR - Additif recherche de défauts
Ist das Schaltverhalten der Gabel ungewöhnlich, kann an PIN 4 der Diagnosebuchse die Gabelfrequenz gemessen werden. Bei den Elektroneikeinsätzen FEL51/52/54/55/56/57/58 ist dies eine sinusförmige Schwingung deren Amplitude einen Rückschluss auf den Gabelzustand zulässt. Bei FEL50A ist aufgrund eines Rechtecksignals nur noch die Gabelfrequenzmessung möglich.	If the switching behaviour of the fork is abnormal, the fork frequency can be measured at PIN 4 of the diagnosis socket. With electronic inserts FEL51/52/54/55/56/57/58 this is a sinusoidal vibration whose amplitude makes it possible to determine the condition of the fork. With FEL50A, only the fork frequency measurement is possible due to a rectangular pulse signal.	Si la commutation de la fourche est inhabituelle, il est possible de mesurer la fréquence de cette dernière au PIN 4 de la prise diagnostic. Pour les électroniques FEL51/52/54/55/56/57/58 il s'agit d'une oscillation sinusoïdale dont l'amplitude permet d'évaluer l'état de la fourche. Pour FEL50A, le signal rectangulaire ne permet qu'une mesure de la fréquence de fourche.

ES - Suplemento para la identificación de fallos	IT - Suplemento alla ricerca dei malfunzionamenti	NL - Bijlage problemen oplossen
<p>Si el comportamiento de conmutación de la horquilla es anormal, puede medir la frecuencia de la misma en el PIN 4 del interruptor de diagnosis.</p> <p>Con las electrónicas FEL51/52/54/55/56/57/58 se consigue una vibración sinusoidal cuya amplitud hace posible determinar la condición de la horquilla.</p> <p>Con FEL50A, sólo es posible medir la frecuencia de la horquilla debido a una señal de impulsos rectangular.</p>	<p>Se le condizioni di commutazione dei rebbi non è normale la frequenza di vibrazione può essere misurata al PIN 4 del connettore per la diagnosi.</p> <p>Con gli inserti elettronici FEL51/52/54/55/56/57/58 è possibile determinare la condizione dei rebbi anche tramite l'ampiezza dell'onda sinusoidale.</p> <p>Con FEL50A il segnale è un onda quadra, per cui è possibile valutare solo il valore di frequenza.</p>	<p>Indien het schakelgedrag van de trilvork niet normaal verloopt kan de frequentie van de vork gemeten worden op pen 4 van de diagnoseconnector.</p> <p>Bij de elektronica inserts van de FEL51/52/54/55/56/57/58 is dit een sinusvormige trilling waarvan de amplitude een beeld geeft van de conditie van de vork.</p> <p>Bij de FEL50A is alleen de vorkfrequentie te meten als gevolg van een rechthoekig pulssignaal.</p>

DE- Ersatzteile
Elektronikeinsätze

EN- Spare parts
Electronic inserts

FR- Pièces de rechange
Electroniques

ES- Repuestos
Electrónicas

IT - Ricambi
Inserti elettronici

NL- Reserve-onderdelen
Elektronica inserts



FEL51 52002304
FEL52 52002305
FEL54 52002306
FEL55 52002307
FEL56 52002308
FEL57 52002309
FEL58 52006454
FEL50A 52010527

Installationsregel: Bei der Installation ist zu beachten, dass elektrische Betriebsmittel (Elektronikeinsätze) die mit nichteigensicheren Stromkreisen gespeist wurden, grundsätzlich **nicht** mehr mit eigensicheren Stromkreisen zusammengeschaltet werden dürfen.


Installation specification: During installation, please keep in mind that electrical resources (electronic inserts) which are powered by non-intrinsically-safe circuits may **no** longer be interconnected with intrinsically-safe circuits.












Directive d'installation : Lors de l'installation, tenir compte du fait que les matériels électriques (électroniques) alimentés par des circuits sans sécurité intrinsèque **ne** doivent plus être connectés à des circuits à sécurité intrinsèque.


Normas de instalación: Durante la instalación, tenga en cuenta que los elementos eléctricos (electrónicas) alimentadas por circuitos no intrínsecamente seguros, **no** podrán estar interconectadas con circuitos intrínsecamente seguros.

Specifiche di installazione: Durante l'installazione è necessario tenere presente che gli impianti elettrici (inserti elettronici) alimentati da circuiti elettrici non a sicurezza intrinseca **non** possono più essere collegati con circuiti elettrici a sicurezza intrinseca.

Installatievoorschrift: Bij de installatie moet erop worden gelet, dat elektrisch materiaal (elektronica-units) die via niet-intrinsiekeveilige circuits worden gevoed, in principe **niet** meer met intrinsiekveilige circuits mogen worden samengeschakeld.



DE- Ergänzende Dokumentation	Technische Information / Technical Information / Information technique / Información técnica / Informazioni tecniche / Technische Informatie
EN- Supplementary Documentation	Liquiphant FTL50, FTL50H, FTL51, FTL51H
FR- Documentation complémentaire	Weld-in adapter, leven and pressure
ES- Documentación adicional	Betriebsanleitung / Operating Instruction / Mise en service / Instrucciones de funcionamiento / Istruzioni operative / Inbedrijfstellingsvoorschrift
IT - Documentazione supplementare	BA00141F FEL50A, PROFIBUS PA
NL- Aanvullende documentatie	Sicherheitshinweise / Notes on Safety / Conseils de sécurité / Notas sobre seguridad / Note sulla sicurezza / Veiligheidsinstructies
	<p>XA00031F  II 1/2 G, Ex d IIC/IIB</p> <p>XA00063F  II 1/2 G, II 1/2 D, Ex ia/ib IIC/IIB</p> <p>XA00064F  II 1 G, Ex ia IIC/IIB</p> <p>XA00108F  II 1/2 G, Ex de IIC/IIB</p> <p>XA00113F  II 1/2 G, Ex ia/ib IIC</p> <p>XA00114F  II 1/2 G, Ex d IIC</p> <p>XA00115F  II 1/2 G, Ex de IIC</p> <p>XA00154F  II 1/2 G, II 1/2 D, Ex ia/ib IIC/IIB</p> <p>XA00158F  II 1/2 G, Ex ia/ib IIC</p> <p>XA00159F  II 1 G, Ex ia IIC/IIB</p> <p>XA00182F  II 3 G, II 3 D, Ex nA/nC IIC/IIIC</p>





www.endress.com/worldwide



MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL
AMARUQ WTP – NUNAVUT
VEOLIA PROJECT: 5000 218 009

ENDRESS + HAUSER


SOLISWITCH FTE31, LEVEL LIMIT SWITCH (PADDLE TYPE)

WATER TECHNOLOGIES

LEFT BLANK

KA 094R/09/a3/01.09
No.: 510 00917

FTE 31



- d** Füllstandgrenzschalter
- e** Level Limit Switch
- f** Détecteur de niveau

d	Inhalt	Seite	e	Contents	Page	f	Sommaire	Page
	Sicherheitshinweise	3		Notes on safety	3		Conseils de sécurité	3
	Einbaubeispiele	4		Mounting examples	4		Exemples	
	Funktion	7		Function	7		d'implantation	4
	Anschluss	8		Connection	8		Fonction	7
	Wartung	10		Maintenance	10		Raccordement	8
	Technische Daten	11		Technical data	11		Entretien	10
	Abmessungen und Werkstoffe	13		Dimensions and materials	13		Caractéristiques techniques	11
	Geräteidentifikation	14		Device identification	14		Dimensions et matériaux	13
	Ergänzende Dokumentation	16		Supplementary documentation	16		Dénomination	14
							Documentation complémentaire	16

d **Sicherheitshinweise**

Der FTE 31 darf nur als Füllstandsgrenzscharter für spezialisierte Schüttgüter eingesetzt werden. Bei unsachgemäßem Gebrauch können Gefahren von ihm ausgehen.

Das Gerät darf nur von **qualifiziertem und autorisiertem Fachpersonal unter besonderer Beachtung dieser Betriebsanleitung**, der gesetzlichen Vorschriften und der Zertifikate (je nach Anwendung) eingebaut, angeschlossen, in Betrieb genommen und gewartet werden.



Achtung!

= verboten - führt zu fehlerhaftem Betrieb oder Zerstörung.

e

Notes on safety

The FTE 31 paddle switch is a level limit switch, designed for use in fine-grained bulk solids in non-hazardous areas.

If used incorrectly it is possible that application-related dangers may arise.

The FTE 31 paddle switch may be installed,

connected, commissioned, operated and maintained **by**

qualified and authorised

personnel only, under strict observance of these operating instructions, any relevant standards, legal requirements, and, where appropriate, the certificate.



Caution!

= forbidden - leads to incorrect operation or destruction.

f

Conseils de sécurité

Le FTE 31 est un détecteur de niveau à palette rotative pour produits solides en vrac de faible granulométrie, utilisable en zones non explosibles. Il peut être source de danger en cas d'utilisation non conforme aux prescriptions. L'appareil ne doit être installé, raccordé, mis en service et maintenu **que par un personnel qualifié et autorisé**, qui tiendra compte des indications contenues dans la présente mise en service, des normes en vigueur et des certificats disponibles (selon l'application).



Attention!

= interdit - peut provoquer des dysfonctionnements ou la destruction.

d Einbaubeispiele


* Schutzdach

e Mounting examples


* Protective roof

f Exemples d'implantation


* Déflecteur




- d** Füllstandgrenzschalter
FTE 31 einschrauben
Nicht am Gehäuse drehen!
- e** Screw the FTE 31 paddle
switch into the process
connection
Don't use housing to turn!
- f** Visser le détecteur à palette
relative FTE 31
Ne pas se servir du boîtier!



- d** Gehäuse in richtige Position drehen.
- e** Screw the housing to the correct position.
- f** Positionner le boîtier.





d Funktion


e Funktion



f Funktion






d Anschluss FTE 31

e Connection FTE 31

f Raccordement FTE 31







 ENDRESS+HAUSER <small>67464 Nesselwang / Germany</small>	
FTE 31 	
Order Code:	FTE 31 - Axxx
Ser.-No.:	xx.xxxx
<div><div><div>U = 115 VAC f = 50-60Hz P = 4.5 VA</div></div><div> Contact ratings max. 250 VAC 10A</div></div>	
Ta: -20°C ... +60°C / -4... +10 F	
<div>  DIP / CL II+III, DIV 1+2, GR E, F, G NEMA Type 4X CAUTION: OPEN CIRCUIT BEFORE REMOVING COVER</div>	


- d** Beachten Sie die Anschluss-
spannung auf dem Typen-
schild
- e** Take note of the power
supply indicated on the
legend plate
- f** Tenir compte de la tension
indiquée sur la plaque
signalétique

- d Wartung**
Anbackungen entfernen
- e Maintenance**
Build up removal
- f Entretien**
Enlever les incrustations



- d Nicht besteigen!**
- e Don't use as a step!**
- f Ne pas marcher sur les lames vibrantes!**






- d Technische Daten**
Schüttgröße und
Korngewicht
- e Technical data**
Solids density
and grain size in mm.
- f Caractéristiques
techniques**
Densité apparente
et granulométrie en mm.

d Umgebungstemperatur T_a
 Betriebstemperatur T_M
 Betriebsdruck p_e

e Ambient temperature T_a
 Operating temperature T_M
 Operating pressure p_e


f Température ambiante T_a
 Température de service T_M
 Pression de service p_e



d Abmessungen in mm und Werkstoffe

e Dimensions in mm and materials

f Dimensions en mm et matériaux



d

f

316L

1/4" NPT

1/4" Valox 553

1 230 VAC

2 115 VAC


3 24 VDC

FM

APPROVED

CSA

C









d	Ergänzende Dokumentation	TI 068R/09/de	Technische Information Füllstandgrenzscharter FTE 31
e	Supplementary documentation	TI 068R/09/en	Technical information Paddle limit switch FTE 31
f	Documentation complémentaire		

d Notizen:

e Notes:

f Notes:

Endress+Hauser

- d**  **Hinweis!**
- e**  **Note!**
- f**  **Remarque !**
- es**  **¡Nota!**
- i**  **Nota !**
- nl**  **Opmerking!**

Mechanische Lebensdauer: min. 500 000 Schaltzyklen
 Mechanical life time: min. 500 000 switch cycles
 Durée de vie mécanique : min. 500 000 cycles de commutation
 Vida estimada: mínimo 500 000 usos
 Tempo di vita delle parti meccaniche: min. 500 000 cicli di commutazione
 Mechanische levensduur: min. 500 000 schakelcycli

- d** **Reparatur**
- e** **Repairs**
- f** **Réparation**
- es** **Repuestos**
- i** **Riparazioni**
- nl** **Reparatie**

Bei Austausch von Teilen nur original E+H Ersatzteile verwenden!
 When exchanging only use original E+H spare parts.
 Lors du remplacement de pièces, n'utiliser que des pièces de rechange d'origine E+H.
 Cuando realice sustituciones utilice sólo recambios originales E+H.
 In caso di riparazione utilizzare solo ricambi originali E+H.
 Bij wisseling van onderdelen uitsluitend originele E+H service onderdelen toepassen

Austria Endress+Hauser Ges.m.b.H. Wien Tel. (0222) 88056-0, Fax (0222) 88056-35	Hong Kong Endress+Hauser (H.K.) Ltd. Hong Kong Tel. 25 28 31 20, Fax 28 65 41 71	Spain Endress+Hauser S.A. Barcelona Tel. (93) 4 80 33 66, Fax (93) 4 73 38 39
Belgium, Luxembourg Endress+Hauser S.A./N.V. Brussels Tel. (02) 248 06 00, Fax (02) 248 05 53	Italy Endress+Hauser Italia S.p.A. Cernusco s/N Milano Tel. (02) 92 10 64 21, Fax (02) 92 10 71 53	Sweden Endress+Hauser AB Sollentuna Tel. (08) 626 16 00, Fax (08) 626 94 77
Canada Endress+Hauser Ltd. Burlington, Ontario Tel. (905) 681 92 92, Fax (905) 681 94 44	Japan Sakura Endress Co., Ltd. Tokyo Tel. (0422) 54 06 11, Fax (0422) 55 02 75	Switzerland Endress+Hauser AG Reinach/BL 1 Tel. (061) 715 75 75, Fax (061) 711 16 50
Denmark Endress+Hauser A/S Søborg Tel. 70 13 11 32, Fax 70 13 21 33	Malaysia Endress+Hauser (M) Sdn. Bhd. Petaling Jaya, Selangor Darul Ehsan Tel. (03) 733 48 48, Fax (03) 733 88 00	Thailand Endress+Hauser Ltd. Bangkok Tel. (2) 9 96 78 11 -20, Fax (2) 9 96 78 10
Finland Endress+Hauser Oy Espoo Tel. (90) 859 61 55, Fax (90) 859 60 55	Netherlands Endress+Hauser B.V. Naarden Tel. (035) 695 86 11, Fax (035) 695 88 25	USA Endress+Hauser Inc. Greenwood, Indiana Tel. (317) 535-7138, Fax (317) 535-1489
France Endress+Hauser Huningue Tel. 89 69 67 68, Fax 89 69 48 02	Norway Endress+Hauser A/S Lierstogen Tel. (032) 85 98 50, Fax (032) 85 98 51	International Endress+Hauser GmbH+Co. Instruments International Weil am Rhein Tel. (07621) 975 02, Fax (07621) 975 345 http://www.endress.com
Germany Endress+Hauser Messtechnik GmbH+Co. Weil am Rhein Tel. (07621) 975 01, Fax (07621) 975 555	Singapore Endress+Hauser (S.E.A.) Pte., Ltd. Singapore Tel. 5 66 82 22, Fax 5 66 68 48	
Great Britain Endress+Hauser Ltd. Manchester Tel. (0161) 2865000, Fax (0161) 998 18 41	South Africa Endress+Hauser Pty. Ltd. Sandton Tel. (011) 444 1386, Fax (011) 444 19 77	





MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL
AMARUQ WTP – NUNAVUT
VEOLIA PROJECT: 5000 218 009

ENDRESS + HAUSER

CERABAR T PMC131, PRESSURE TRANSDUCER

WATER TECHNOLOGIES

LEFT BLANK



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components





Services



Solutions

Operating Instructions

Cerabar T PMC131



de - Drucktransducer

en - Pressure Transducer

fr - Transducteur de pression

it - Trasduttore di pressione

es - Transmisorde presión

nl - Druk-transducer

KA00085P/00/A6/13.12
71158704

Endress+Hauser
People for Process Automation


de - Inhalt	en - Contents	fr - Sommaire
Geräte-Identifikation	4	Dénomination de l'appareil
Abmessungen	5	Dimensions
Montage	6	Montage
Elektrischer Anschluss	8	Raccordement électrique
Technische Daten	10	Caractéristiques techniques

de - Sicherheitshinweise	en - Notes on Safety	fr - Conseils de sécurité
Der Cerabar T dient der Absolut- und Relativdruckmessung in Gasen, Dämpfen, Flüssigkeiten und Stäuben. Bei unsachgemäßem Einsatz können Gefahren von ihm ausgehen. Das Gerät darf nur von qualifiziertem und autorisiertem Fachpersonal unter strenger Beachtung dieser Betriebsanleitung und der Technischen Information TI00415P, der einschlägigen Normen, gesetzlichen Vorschriften und Zertifikate eingebaut, angeschlossen, in Betrieb genommen und gewartet werden.	The Cerabar T is designed for measuring absolute and gauge pressure of gases, vapours, liquids and dusts. If used incorrectly it is possible that application related dangers may arise. The Cerabar T may be installed, commissioned, operated and maintained by qualified and authorised personnel only, under strict observance of these operating instructions and Technical Information TI00415P, any relevant standards, legal requirements, and, where appropriate, the certificate.	Le Cerabar T est destiné à la mesure de pression absolue et relative dans les gaz, vapeurs, liquides et poussières. Il peut être source de danger en cas d'utilisation non conforme aux prescriptions. L'appareil ne doit être installé, raccordé, mis en service et maintenu que par un personnel qualifié et autorisé, qui tiendra compte des indications contenues dans la présente mise en service et de l' Information Technique TI00415P, des normes en vigueur et des certificats disponibles (selon l' application).


es - Índice	it - Indice	nl - Inhoud
Identificación del equipo	4	Instrument-identificatie
Dimensiones	5	Afmetingen
Montaje	7	Montage
Conexiones eléctricas	8	Elektrische aansluiting
Datos técnicos	10	Omgevingscondities


es - Notas sobre seguridad	it - Note sulla sicurezza	nl - Veiligheidsinstructies
Cerabar T está diseñado para medir presión absoluta y relativa en gases, vapores, líquidos y sólidos pulverulentos. Su empleo inapropiado puede resultar peligroso. El equipo deberá ser montado, conectado, instalado y mantenido única y exclusivamente por personal cualificado y autorizado, bajo rigurosa observación de las presentes instrucciones de servicio y de la Información Técnica TI0041SP, de las normativas y legislaciones vigentes, así como de los certificados (dependiendo de la aplicación).	Il Cerabar T è stato progettato per la misura della pressione assoluta e relativa di gas, vapori, liquidi e polveri. Un'installazione non corretta può determinare pericolo per le persone e le cose. Lo strumento deve essere montato collegato e messo in servizio solamente da personale qualificato ed autorizzato, nel totale rispetto delle indicazioni operative qui riportate, delle prescrizioni presenti nelle informazioni tecniche TI0041SP ed in accordo a tutte le norme e legislazioni vigenti e le certificazioni utilizzate.	De Cerabar T is ontworpen voor het meten absoluut en overdruk van gasen, dampen, vloeistoffen en vaste stoffen. Bij niet correct gebruik kunnen gevaarlijke situaties ontstaan. Het instrument mag uitsluitend door gekwalificeerd en geautoriseerd vakpersoneel geïnstalleerd, aangesloten en inbedrijf genomen worden met inachtneming van dit inbedrijf-stellingsvoorschrift, het bijbehorende Technisch Informatie blad TI0041SP en de betreffende normen, de wettelijke voorschriften en eventuele certificaten in acht.

- de - Geräte-Identification
- en - Device Identification
- fr - Dénomination de l'appareil
- es - Identificación del equipo
- it - Identificazione dello strumento
- nl - Instrument-identificatie



- | | |
|----|--|
| A1 | = M16x1.5, ISO 4400, IP 65/NEMA 4X |
| A2 | = ½ NPT, ISO 4400, IP 65/NEMA 4X |
| A3 | = 5 m (15 ft), IP 68/NEMA 6P |
| A4 | = 25 m (75 ft), IP 68/NEMA 6P |
| A5 | = M12, IP65/NEMA 4 |
| B1 | = M16x1.5, ISO 4400, IP 65/NEMA 4X |
| B3 | = 5 m, IP 68/NEMA 6P |
| B5 | = M12, IP 65, ATEX II 3G EEX nA II T4 |
| C1 | = M16x1.5, ISO 4400, IP 65/NEMA 4X |
| C2 | = ½ NPT, ISO 4400, IP 65/NEMA 4X, CSA GP |
| C3 | = 5 m (15 ft), IP 68/NEMA 6P, CSA GP |
| C5 | = M12, IP 65/NEMA 4, CSA GP |





de - Montage

- Die Funktion des Drucktransducers ist unabhängig von der Einbaulage.
- Zum Schutz des Gewindes und der Druckmembran darf die Schutzkappe am Gewindestutzen erst kurz vor dem Einbau entfernt werden.
- Der Drucktransducer ist nach den gleichen Richtlinien wie ein Manometer zu montieren. Wir empfehlen die Verwendung von Abspernröhren und Wassersackrohren.
- Beim Einbau ist darauf zu achten, dass kein Tropfwasser in das Gehäuse eindringen kann.
- Einsatzgrenzen für Sauerstoff beachten (bei FKM Viton/O₂ gemäß BAM-Liste).
- Bei Anwendungen in explosionsfähiger Atmosphäre der Zone 2 (Zündschutzart Ex nA), Gehäuse vor Schlagwirkung schützen.

en - Mounting



- The function of the transducer is independent of mounting orientation.
- To protect the thread and pressure diaphragm from damage, the protective cover on the threaded nozzle should be removed just before installation only.
- The pressure transducer is to be mounted like a manometer. The guidelines are identical. Isolating valves and water pocket pipes should be used.
- When installing, ensure that no water enters the housing.
- Note the application limits for oxygen (for FKM Viton/O₂ as per BAM list).
- In the event of applications in a Zone 2 explosive atmosphere (Ex nA explosion protection) protect the housing from impact.

fr - Montage

- Le fonctionnement du transducteur de pression est indépendant de son implantation.
- Afin de protéger le filetage et la membrane, ne retirer le capot de protection, placé sur le raccord fileté, qu'au moment du montage.
- Le transducteur de pression doit être monté conformément aux directives concernant les manomètres. Nous recommandons l'utilisation de robinets d'isolement et de siphons.
- Lors du montage, veiller à ce qu'il n'y ait pas d'infiltration d'eau dans le boîtier.
- Tenir compte des limites d'utilisation sur l'oxygène (pour FKM Viton/O₂ selon liste BAM).
- Les applications en atmosphère explosive de zone 2 (mode de protection antidéflagrant Ex nA), protéger le boîtier contre les chocs.

es - Montaje	it - Montaggio	nl - Montage
<ul style="list-style-type: none"> ■ El funcionamiento del transmisor de presión es independiente de la orientación de montaje. ■ No retirar la protección del casquillo roscado hasta el momento previo a su instalación para evitar dañar la rosca o el diafragma de presión. ■ El transmisor de presión se deberá montar como un manómetro. El procedimiento es el mismo. Utilizar válvulas de corte y sifón. ■ Durante la instalación asegurar que no entre agua en la caja. ■ Observar los límites de utilización en oxígeno (para FKP Viton/O₂ según lista BAM). ■ En las aplicaciones en atmósferas con riesgo de explosión de la zona 2 (tipo de protección contra ignición Ex nA) se debe proteger la carcasa contra el efecto de los impactos. 	<ul style="list-style-type: none"> ■ Il funzionamento del trasduttore non dipende dalla posizione di montaggio. ■ Per proteggere la filettatura e la membrana di pressione da eventuali danneggiamenti, eliminare il coperchio di protezione dell'ugello filettato solo immediatamente prima dell'installazione. ■ Il trasduttore di pressione deve essere montato come un manometro. Utilizzare solo valvole di arresto e tubi separatori d'acqua. ■ Durante l'installazione, assicurarsi che non entri acqua nella custodia. ■ Osservare i limiti operativi per ossigeno (per FKM Viton/O₂ in accordo con lista BAM). ■ Per l'utilizzo in ambienti a rischio di esplosione della zona 2 (Protezione antideflagrante Ex nA), proteggere le custodie contro gli urti. 	<ul style="list-style-type: none"> ■ Het functioneren van de Druktransducer is onafhankelijk van de montagepositie. ■ Ter bescherming van de buitendraad en het membraan moet de beschermhuls pas vlak voor de montage verwijderd worden. ■ De Druktransducer moet identiek als een manometer gemonteerd worden. De richtlijnen t.a.v. gebruik van afsluiterkranen, afstandstukken en watersloten moeten worden aangehouden. ■ Bij installatie ervoor zorgen dat er geen water in de behuizing kan komen, ook niet via de connector/wartel. ■ Toepassingen in zuurstof bekijken (met FKM Viton/O₂ conform BAM lijst). ■ Bescherm de behuizing tegen schokken bij toepassingen in explosiegevaarlijke atmosferen zone 2 (ontstekingsklasse Ex nA).

de - Elektrischer Anschluss
Stecker-Version
en - Electrical Connection
Plug version
fr - Raccordement électrique
Version connecteur
es - Conexión eléctrica
Con conector
it - Collegamento elettrico
Spina
nl - Elektrische aansluiting
Steker-versie



The diagram shows the Endress+Hauser CERABART device with two connection points. The top connection is a Pg11 port with a cable labeled 'Referenzluft-Zuführung' (Reference air supply) leading to a terminal block with '+' (red), '-' (black), and 'PE' (green/yellow) terminals. The bottom connection is an M12 port with a cable labeled 'Tubo de compensación de presión atmosférica' (Atmospheric pressure compensation tube) leading to a terminal block with terminals 1, 2, 3, and 4. Terminal 1 is connected to a red wire, terminal 2 to a black wire, terminal 3 to a green/yellow wire, and terminal 4 to a blue wire. The device is labeled 'ENDRESS+HAUSER CERABART'.

de - Referenzluft- Zuführung
Nicht verschließen! Vor Wasser schützen!

en - Reference air tube
Do not close! Protect from water!

fr - Mise à l'atmosphère
Ne pas boucher! Protéger de l'eau!

es - Tubo de compensación de presión atmosférica
No tapar! Proteger del agua!

it - Ingresso aria di riferimento
Non chiudere! Proteggere dall'acqua!

nl - Drukvereffening
Niet laten vervuilen en beschermen tegen vocht!

de + = rot; - = schwarz, PE = grün/gelb
en + = red; - = black, PE = green/yellow
fr + = rouge; - = noir, PE = vert/jaune
es + = rojo, - = negro, PE = verde/amarillo
it + = rosso, - = nero, PE = verde/giallo
nl + = rood; - = zwart, PE = groen/geel

de - Elektrischer Anschluß
Kabel-/Stecker-Version
en - Electrical Connection
Cable/plug version
fr - Raccordement électrique
Version câble/connecteur
es - Conexión eléctrica
Cable/conector
it - Collegamento elettrico
Cavo/spina
nl - Elektrische aansluiting
Kabel-/stekker-versie

de - Einsatzbedingungen <ul style="list-style-type: none"> ■ Umgebungstemperatur: -20...85 °C ■ Lagerungstemperatur: -50...100 °C ■ Meßstofftemperaturgrenze: max. 100 °C ■ Meßstoffdruckgrenze: p_{max} ■ Geräte mit CSA GP-Zulassung dürfen nur mit einer SELV oder Class 2 Spannungsversorgung betrieben werden. 	fr - Conditions d'utilisation <ul style="list-style-type: none"> ■ Température ambiante: -20...85 °C ■ Température de stockage: -50...100 °C ■ Limite de température du produit: max. 100 °C ■ Limite de pression du produit: p_{max} ■ Les appareils avec agrément CSA GP ne doivent être utilisés qu'avec une tension d'alimentation SELV ou Class 2. 	it - Condizioni operative <ul style="list-style-type: none"> ■ Temperatura ambiente: -20...85 °C ■ Temperatura per la conservazione in magazzino: -50...100 °C ■ Temperatura limite del prodotto: max. 100 °C ■ Pressione limite del prodotto: p_{max} ■ Strumenti con approvazione CSA GP possono essere alimentati solo con unità tipo SELV o Classe 2
en - Operating Conditions <ul style="list-style-type: none"> ■ Ambient temperature range: -20...85 °C ■ Storage temperature range: -50...100 °C ■ Limiting temperature range: max. 100 °C ■ Limiting pressure range: p_{max} ■ Devices with CSA GP approval may only be operated with a SELV or Class 2 power supply. 	es - Condiciones de operación <ul style="list-style-type: none"> ■ Rango de temperatura ambiental: -20...85 °C ■ Rango de temperatura de almacenamiento: -50...100 °C ■ Temperatura máxima de trabajo: máx. 100 °C ■ Presión máx. de trabajo: p_{max} ■ Los equipos con la certificación CSA GP sólo pueden trabajar con alimentación de clase 2 o SELV. 	nl - Omgevingscondities <ul style="list-style-type: none"> ■ Omgevingstemperatuur: -20...+85 °C ■ Opslagtemperatuur: -50...100 °C ■ Producttemp. : max. 100 °C ■ max. procesdruk: p_{max} ■ Instrumenten met een CSA GP certificaat mogen uitsluitend via een SELV of een klasse 2 voeding gevoed worden.

www.endress.com/worldwide

KA00085P/00/A6/13.12 71158704/CCS/FM9



71158704



MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL
AMARUQ WTP – NUNAVUT
VEOLIA PROJECT: 5000 218 009

ENDRESS + HAUSER

CERABAR S PMC71, PRESSURE TRANSMITTER

WATER TECHNOLOGIES

LEFT BLANK



Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services




Solutions

Operating Instructions

Cerabar S PMC71, PMP71, PMP75


Process pressure measurement



BA00271P/00/EN/18.14
71270361

valid from Software version:
02.20.zz

Endress+Hauser 
People for Process Automation



A0023555

Table of contents

1	Safety instructions	4	8	Trouble-shooting	49
1.1	Designated use	4	8.1	Messages	49
1.2	Installation, commissioning and operation	4	8.2	Response of outputs to errors	57
1.3	Operational safety and process safety	4	8.3	Confirming messages	59
1.4	Notes on safety conventions and icons	5	8.4	Repair	60
2	Identification	6	8.5	Repair of Ex-certified devices	60
2.1	Product identification	6	8.6	Spare Parts	60
2.2	Device designation	6	8.7	Return	60
2.3	Scope of delivery	8	8.8	Disposal	60
2.4	Certificates and approvals	8	8.9	Software history	61
2.5	Registered trademarks	8	9	Technical data	63
3	Installation	9	Index	64	
3.1	Incoming acceptance, transport, storage	9			
3.2	Installation conditions	9			
3.3	Installation instructions	9			
3.4	Post-installation check	18			
4	Wiring	19			
4.1	Connecting the device	19			
4.2	Connecting the measuring unit	21			
4.3	Potential matching	23			
4.4	Overvoltage protection (optional)	23			
4.5	Post-connection check	23			
5	Operation	24			
5.1	On-site display (optional)	24			
5.2	Operating elements	25			
5.3	On-site operation – on-site display not connected	27			
5.4	On-site operation – on-site display connected	30			
5.5	HistoROM®/M-DAT (optional)	32			
5.6	Operation via SFX100	36			
5.7	Endress+Hauser operating program	36			
5.8	Locking/unlocking operation	37			
5.9	Factory setting (reset)	38			
6	Commissioning	40			
6.1	Function check	40			
6.2	Selecting language and measuring mode	40			
6.3	Position adjustment	41			
6.4	Pressure measurement	42			
6.5	Level measurement	44			
7	Maintenance	48			
7.1	Cleaning instructions	48			
7.2	Exterior cleaning	48			

1 Safety instructions

1.1 Designated use

The Cerabar S is a pressure transmitter for measuring pressure and level.

The manufacturer accepts no liability for damages resulting from incorrect use or use other than that designated.


1.2 Installation, commissioning and operation

The device has been designed to operate safely in accordance with current technical, safety and EU standards. If installed incorrectly or used for applications for which it is not intended, however, it is possible that application-related dangers may arise, e.g. product overflow due to incorrect installation or calibration. For this reason, the instrument must be installed, connected, operated and maintained according to the instructions in this manual: personnel must be authorised and suitably qualified. The manual must have been read and understood, and the instructions followed. Modifications and repairs to the device are permissible only when they are expressly approved in the manual. Pay particular attention to the technical data on the nameplate.

1.3 Operational safety and process safety

Alternative monitoring measures must be taken to ensure operational safety and process safety during configuration, testing and maintenance work on the device.

1.3.1 Hazardous areas (optional)

Devices for use in hazardous areas are fitted with an additional nameplate (→  6). If the device is to be installed in an explosion hazardous area, then the specifications in the certificate as well as all national and local regulations must be observed. The device is accompanied by separate "Ex documentation", which is an integral part of this Operating Instructions. The installation regulations, connection values and Safety Instructions listed in this Ex document must be observed. The documentation number of the related Safety Instructions is also indicated on the additional nameplate.














- Ensure that all personnel are suitably qualified.

1.3.2 Functional Safety SIL3 (optional)

If using devices for applications with safety integrity, the Functional Safety Manual (SD00190P) must be observed thoroughly.

1.4 Notes on safety conventions and icons

In order to highlight safety-relevant or alternative operating procedures in the manual, the following conventions have been used, each indicated by a corresponding icon in the margin.

Safety conventions	
	Warning! A warning highlights actions or procedures which, if not performed correctly, will lead to personal injury, a safety hazard or destruction of the instrument.
	Caution! Caution highlights actions or procedures which, if not performed correctly, may lead to personal injury or incorrect functioning of the instrument.
	Note! A note highlights actions or procedures which, if not performed correctly, may indirectly affect operation or may lead to an instrument response which is not planned.
	Device certified for use in explosion hazardous area If the device has this symbol embossed on its nameplate, it can be installed in an explosion hazardous area or a non-explosion hazardous area, according to the approval.
	Explosion hazardous area Symbol used in drawings to indicate explosion hazardous areas. – Devices used in hazardous areas must possess an appropriate type of protection.
	Safe area (non-explosion hazardous area) Symbol used in drawings to indicate, if necessary, non-explosion hazardous areas. – Devices used in hazardous areas must possess an appropriate type of protection. Lines used in hazardous areas must meet the necessary safety-related characteristic quantities.
	Direct voltage A terminal to which or from which a direct current or voltage may be applied or supplied.
	Alternating voltage A terminal to which or from which an alternating (sine-wave) current or voltage may be applied or supplied.
	Grounded terminal A grounded terminal, which as far as the operator is concerned, is already grounded by means of an earth grounding system.
	Protective grounding (earth) terminal A terminal which must be connected to earth ground prior to making any other connection to the equipment.
	Equipotential connection (earth bonding) A connection made to the plant grounding system which may be of type e.g. neutral star or equipotential line according to national or company practice.
	Temperature resistance of the connection cables States, that the connection cables must be resistant to a temperature of at least 85 °C (185 °F).
	Safety instruction For safety instructions refer to the manual for the appropriate instrument version.

2 Identification

2.1 Product identification

The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in W@M Device Viewer (www.endress.com/deviceviewer): All information about the measuring device is displayed.

For an overview of the technical documentation provided, enter the serial number from the nameplates in the W@M Device Viewer (www.endress.com/deviceviewer).

2.2 Device designation

2.2.1 Nameplate



Note!

- The MWP (maximum working pressure) is specified on the nameplate. This value refers to a reference temperature of 20°C (68°F) or 100°F (38 °C) for ASME flanges.
- The pressure values permitted at higher temperatures can be found in the following standards:
 - EN 1092-1: 2001 Tab. 18 ¹⁾
 - ASME B 16.5a – 1998 Tab. 2-2.2 F316
 - ASME B 16.5a – 1998 Tab. 2.3.8 N10276
 - JIS B 2220
- The test pressure corresponds to the over pressure limit (OPL) of the device = MWP x 1.5 ²⁾.
- The Pressure Equipment Directive (EC Directive 97/23/EC) uses the abbreviation "PS". The abbreviation "PS" corresponds to the MWP (maximum working pressure) of the measuring device.

- 1) With regard to their temperature stability properties, the materials 1.4404 and 1.4435 are grouped under 13E0 in EN 1092-1 Tab. 18. The chemical composition of the two materials can be identical.
- 2) The equation does not apply for PMP71 and PMP75 with a 40 bar (600 psi) or a 100 bar (1500 psi) measuring cell.

Aluminium and stainless steel housing (T14)




Fig. 1: Nameplate

- 1 Device name
- 2 Order code (for re-orders)
- 3 Extended order code (complete)
- 4 Technical data
- 5 Serial number (for identification)
- 6 Address of manufacturer

Devices for use in hazardous areas are fitted with an additional nameplate.




Fig. 2: Additional nameplate

- 1 Approval-specific information
- 2 Document number for safety instructions or drawing number

Devices suitable for oxygen applications or with PVDF process connection are fitted with an additional nameplate.




Fig. 3: Additional nameplate

- 1 Application limits

Hygienic stainless steel housing (T17)




Fig. 4: Nameplate

- 1 Device name
- 2 Address of manufacturer
- 3 Order code (for re-orders)
- 4 Extended order code (complete)
- 5 Serial number (for identification)
- 6 Technical data
- 7 Approval-specific information and document number for safety instructions or drawing number

2.2.2 Identifying the sensor type

See parameter "Sensor Meas.Type" in Operating Instruction BA00274P.

2.3 Scope of delivery

The scope of delivery comprises:

- Cerabar S pressure transmitter
- For devices with the "HistoROM/M-DAT" option:
CD-ROM with Endress+Hauser operating program
- Optional accessories

Documentation supplied:

- The Operating Instructions BA00271P and BA00274P are available via the Internet.
→ See: www.endress.com → Download.
- Brief Operating Instructions KA01019P
- Leporello KA00218P
- Final inspection report
- Also Safety Instructions with ATEX, IECEx and NEPSI devices
- Optional: factory calibration form, test certificates

2.4 Certificates and approvals

CE mark, declaration of conformity

The device is designed to meet state-of-the-art safety requirements, has been tested and left the factory in a condition in which it is safe to operate. The device complies with the applicable standards and regulations as listed in the EC declaration of conformity and thus complies with the statutory requirements of the EC Directives. Endress+Hauser confirms the successful testing of the device by affixing to it the CE mark.

2.5 Registered trademarks

KALREZ®, VITON®, TEFLON®

Registered trademarks of E.I. Du Pont de Nemours & Co., Wilmington, USA

TRI-CLAMP®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

HART®

Registered trademark of the HART Communication Foundation, Austin, USA.

GORE-TEX®

Registered trademark of W.L. Gore & Associates, Inc., USA

3 Installation

3.1 Incoming acceptance, transport, storage

3.1.1 Incoming acceptance

- Check the packaging and the contents for damage.
- Check the shipment, make sure nothing is missing and that the scope of supply matches your order.

3.1.2 Transport



Caution!

Follow the safety instructions and transport conditions for devices of more than 18 kg (39.69 lbs). Transport the measuring device to the measuring point in its original packaging or at the process connection.

3.1.3 Storage

The device must be stored in a dry, clean area and protected against damage from impact (EN 837-2).

Storage temperature range:

- -40 °C to +90°C (-40 °F to +194°F)
- On-site display: -40 °C to +85°C (-40 °F to +185°F)
- Separate housing: -40 °C to +60°C (-40 °F to +140°F)

3.2 Installation conditions

3.2.1 Dimensions

For dimensions, please refer to "Mechanical construction" section in TI00383P.

3.3 Installation instructions



Note!

- Due to the orientation of the Cerabar S, there may be a shift in the measured value, i.e. when the container is empty, the measured value does not display zero. You may correct this zero point shift either directly on the device using the "E"-key or by remote operation. See
→ 26, "Function of the operating elements – on-site display not connected" or
→ 41, "Position adjustment".
- For PMP75, please refer to → 12, "Installation instructions for devices with diaphragm seals – PMP75".
- To ensure optimal readability of the on-site display, it is possible to rotate the housing up to 380°.
→ 18, "Rotating the housing".
- Endress+Hauser offers a mounting bracket for installing on pipes or walls.
→ 15, "Wall and pipe-mounting (optional)".


3.3.1 Installation instructions for devices without diaphragm seals – PMP71, PMC71




Note!

- If a heated Cerabar S is cooled during the cleaning (e.g. by cold water), a vacuum develops for a short time, whereby water can penetrate the sensor through the pressure compensation (1).

If this is the case, mount the sensor with the pressure compensation (1) pointing downwards.



- Keep the pressure compensation and GORE-TEX® filter (1) free from contaminations and water.
- Cerabar S without diaphragm seal are mounted as per the norms for a manometer (DIN EN 837-2). We recommend the use of shut-off devices and siphons. The orientation depends on the measuring application.
- Do not clean or touch process isolating diaphragm seals with hard or pointed objects.
- The device must be installed as follows in order to comply with the cleanability requirements of the ASME-BPE (Part SD Cleanability):



Pressure measurement in gases




Fig. 5: Measuring arrangement for pressure measurement in gases

- 1 Cerabar S
2 Shut-off device

Mount Cerabar S with shut-off device above the tapping point so that any condensate can flow into the process.

Pressure measurement in steams




Fig. 6: Measuring arrangement for pressure measurement in steams

- 1 Cerabar S
- 2 Shut-off device
- 3 U-shaped siphon
- 4 Circular siphon

- Use siphons for pressure measurement in steam. The siphon reduces the temperature to almost ambient temperature. Preferably mount the Cerabar S with the siphon below the tapping point. Advantages:
 - defined water column only causes minimal/negligible measured errors
 - only minimal/negligible thermal effects on the device
 Mounting above the tapping point is also possible. Pay attention to the maximum permitted ambient temperature of the transmitter!
- Fill the siphon with liquid before commissioning.

Pressure measurement in liquids




Fig. 7: Measuring arrangement for pressure measurement in liquids

- 1 Cerabar S
- 2 Shut-off device

Mount Cerabar S with shut-off device below or at the same level as the tapping point.

Level measurement




Fig. 8: Measuring arrangement for level

- Mount Cerabar S below the lowest measuring point.
- Do not mount the device at the following positions:
In the fill flow, in the tank outlet or at a point in the container which could be affected by pressure pulses from an agitator.
- Do not mount the device in the suction area of a pump.
- The calibration and functional test can be carried out more easily if you mount the device after a shut-off device.

PVDF adapter



Note!

For instruments with PVDF adapter, a maximum torque of 7 Nm (5.16 lbf ft) is permitted. The thread connection may become loose at high temperatures and pressures. This means that the integrity of the thread must be checked regularly and may need to be tightened using the torque given above. Teflon tape is recommended for sealing with the 1/2 NPT thread.

3.3.2 Installation instructions for devices with diaphragm seals – PMP75



Note!

- The Cerabar S with diaphragm seal is screwed in, flanged or clamped, depending on the type of diaphragm seal.
- The diaphragm seal and the pressure sensor together form a closed and calibrated system which is filled with filling fluid through a hole in the upper part. This hole is sealed and not to be opened.
- Do not clean or touch process isolating diaphragm of the diaphragm seals with hard or pointed objects.
- Do not remove the protection of the process isolating diaphragm until shortly before installation.
- When using a mounting bracket, sufficient strain relief must be ensured for the capillaries in order to prevent the capillary bending down (bending radius ≥ 100 mm (3.94 in)).
- Please note that the hydrostatic pressure of the liquid columns in the capillaries can cause zero point shift. The zero point shift can be corrected. → 41, "Position adjustment".
- Please note the application limits of the diaphragm seal filling oil as detailed in the Technical Information for Cerabar S TI00383P, Section "Planning instructions for diaphragm seal systems".


In order to obtain more precise measurement results and to avoid a defect in the device, mount the capillaries as follows:

- Vibration-free (in order to avoid additional pressure fluctuations)
- Not in the vicinity of heating or cooling lines
- Insulate if the ambient temperature is below or above the reference temperature
- With a bending radius of ≥ 100 mm (3.94 in).


Vacuum application

For applications under vacuum, Endress+Hauser recommends mounting the pressure transmitter underneath the diaphragm seal. A vacuum load of the diaphragm seal caused by the presence of filling oil in the capillaries is hereby prevented.

When the pressure transmitter is mounted above the diaphragm seal, the maximum height difference H_1 in accordance with the illustration below on the left must not be exceeded. The maximum height difference is dependent on the density of the filling oil and the smallest ever pressure that is permitted to occur at the diaphragm seal (empty container), see illustration below, on the right.



Mounting with temperature isolator



Endress+Hauser recommends the use of temperature separators in the event of constant extreme fluid temperatures which lead to the maximum permissible electronics temperature of +85 °C (+185 °F) being exceeded. To minimise the influence of rising heat, Endress+Hauser recommends the device be mounted horizontally or with the housing pointing downwards. The additional installation height also brings about a zero point shift of approx. 21 mbar (0.315 psi) due to the hydrostatic columns in the temperature isolator. You can correct this zero point shift. See also

- 26, "Function of the operating elements – on-site display not connected" or
- 41, "Position adjustment".

3.3.3 Seal for flange mounting




Fig. 11: Mounting the versions with flange or diaphragm seal

- 1 Process isolating diaphragm
2 Seal



Warning!

The seal is not allowed to press on the process isolating diaphragm as this could affect the measurement result.

3.3.4 Installation with heat insulation – PMC71 high temperature version and PMP75

The devices must only be insulated up to a certain height. The maximum permitted insulation height is labelled on the devices and applies to an insulation material with a specific heat conductivity and to the maximum permitted ambient and process temperature (see following table). The data were determined under the most critical application "quiescent air".





Fig. 12: Maximum insulation height, here e.g. PMC71 with flange

	PMC71	PMP75
Ambient temperature (T_A)	$\leq 70^\circ\text{C}$ (158°F)	$\leq 70^\circ\text{C}$ (158°F)
Process temperature (T_P)	$\leq 150^\circ\text{C}$ (302°F)	$\leq 400^\circ\text{C}$ (752°F) ¹⁾
Heat conductivity Insulation material	$\leq 0,04 \text{ W}/(\text{m} \times \text{K})$	

- 1) Depending on the diaphragm seal filling oil used (see Technical Information TI00383P Cerabar S)

3.3.5 Wall and pipe-mounting (optional)

Endress+Hauser offers a mounting bracket for installing on pipes or walls.



P01-xMx5xxx-06-xx-xx-xx-001

Please note the following when mounting:

- Devices with capillary lines: mount capillaries with a bending radius of ≥ 100 mm (3.94 in).
- In the case of pipe mounting, the nuts on the bracket must be tightened uniformly with a torque of at least 5 Nm (3.69 lbf ft).

3.3.6 Assembling and mounting the "separate housing" version




Fig. 13: "Separate housing" version

- 1 In the "separate housing" version, the sensor is supplied with process connection and cable fitted.
- 2 Cable with connection jack
- 3 Pressure compensation
- 4 Plug
- 5 Locking screw
- 6 Housing fitted with housing adapter, included
- 7 Mounting bracket suitable for wall and pipe mounting, included

Assembly and mounting

1. Connect plug (item 4) into the corresponding connection jack of the cable (item 2).
2. Plug the cable into the housing adapter (item 6).
3. Tighten the locking screw (item 5).
4. Mount the housing on a wall or pipe using the mounting bracket (item 7). When mounting on a pipe, tighten the nuts on the bracket uniformly with a torque of at least 5 Nm (3.69 lbf ft). Mount the cable with a bending radius (r) ≥ 120 mm (4.72 in).

3.3.7 PMP71, version prepared for diaphragm seal mount – welding recommendation




Fig. 14: Version U1: prepared for diaphragm seal mount

1 Hole for filling fluid

2 Bearing

3 Threaded pin

A1 See the following table "Welding recommendation"


Welding recommendation

For the "U1 Prepared for diaphragm seal mount" version in feature 70 "Process connection; Material" in the order code of up to including 40 bar (600 psi)-sensors, Endress+Hauser recommends welding on the diaphragm seal as follows: the total welding depth of the fillet weld is 1 mm (0.04 in) at an external diameter of 16 mm (0.63 in). Welding is performed according to the WIG method.

Consecutive seam no.	Sketch/welding groove shape, dimension as per DIN 8551	Base material matching	Welding process DIN EN ISO 24063	Welding position	Inert gas, additives
A1 for sensors ≤ 40 bar (600 psi)	<p>P01-PMP71xxx-11-xx-xx-xx-001</p>	Adapter made of 316L (1.4435) to be welded to diaphragm seal made of 316L (1.4404/1.4435)	141	PB	Inert gas Ar/H 95/5 Additive: 1.4430 (ER 316L Si)

3.3.8 Rotating the housing

The housing can be rotated up to 380° by loosening the Allen screw.



P01-PMC71xxx-17-xx-xx-xx-000

Fig. 15: Aligning the housing

- T14 housing: Loosen setscrew with a 2 mm (0.08 in) Allen key.
- Hygenic T17 housing: Loosen setscrew with a 3 mm (0.12 in) Allen key.
- Rotate housing (max. up to 380°).
- Retighten setscrew with 1 Nm (0,74 lbf ft).


3.3.9 Closing the housing cover



Note!

When closing the housing cover, please ensure that the thread of the cover and housing are free from dirt, e.g. sand. If you feel any resistance when closing the cover, check the thread on both again to ensure that they are free from dirt.

Close cover on a hygenic stainless steel housing (T17)



P01-PMD75xxx-17-xx-xx-xx-000

Fig. 16: Close cover

The covers for the terminal and electronics compartment are hooked into the casing and closed with a screw. These screws should be finger-tightened (2 Nm (1.48 lbf ft)) to the stop to ensure that the covers sit tightly.

3.4 Post-installation check

After installing the device, carry out the following checks:

- Are all screws firmly tightened?
- Are the housing covers screwed down tight?

4 Wiring

4.1 Connecting the device



Warning!

Risk of electric shock!

If the operating voltage is > 35 VDC: Dangerous contact voltage at terminals.

In a wet environment, do not open the cover if voltage is present.



Warning!

Limitation of electrical safety due to incorrect connection!

- Risk of electric shock and/or explosion in hazardous areas! In a wet environment, do not open the cover if voltage is present.
- When using the measuring device in hazardous areas, installation must comply with the corresponding national standards and regulations and the Safety Instructions or Installation or Control Drawings.
- Devices with integrated overvoltage protection must be earthed.
- Protective circuits against reverse polarity, HF influences and overvoltage peaks are installed.
- The supply voltage must match the supply voltage on the nameplate (→ 6, "Nameplate").
- Switch off the supply voltage before connecting the device.
- Remove housing cover of the terminal compartment.
- Guide cable through the gland. Preferably use twisted, screened two-wire cable.
- Connect device in accordance with the following diagram.
- Screw down housing cover.
- Switch on supply voltage.




Fig. 17: Electrical connection 4 to 20 mA HART. Observe also → 21, "Supply voltage".

- 1 Housing
- 2 Jumper for 4 to 20 mA test signal.
→ 21, "Taking 4 to 20 mA test signal" part.
- 3 Internal earth terminal
- 4 External earth terminal
- 5 4 to 20 mA test signal between plus and test terminal
- 6 Minimum supply voltage = 10.5 V DC, jumper is inserted in accordance with the illustration.
- 7 Minimum supply voltage = 11.5 V DC, jumper is inserted in "Test" position.
- 8 Devices with integrated overvoltage protection are labelled OVP (overvoltage protection) here.

4.1.1 Devices with Harting plug Han7D




Fig. 18: Left: electrical connection for devices with Harting plug Han7D
Right: view of the plug connector at the device

4.1.2 Devices with M12 plug

	PIN	Meaning
	1	signal +
	2	not used
	3	signal -
	4	ground

4.1.3 Connecting the cable version




Fig. 19: rd = red, bk = black, gnye = green-yellow

4.2 Connecting the measuring unit

4.2.1 Supply voltage



Note!

- All explosion protection data are given in separate documentation which is available upon request. The Ex documentation is supplied as standard with all devices approved for use in explosion hazardous areas.
- When using the measuring device in hazardous areas, installation must comply with the corresponding national standards and regulations and the Safety Instructions or Installation or Control Drawings.

Electronic version	Jumper for 4 to 20 mA test signal in "Test" position (Delivery status)	Jumper for 4 to 20 mA test signal in "Non-Test" position
4 to 20 mA HART, for non-hazardous areas	11.5 to 45 V DC	10.5 to 45 V DC

Taking 4 to 20 mA test signal

A 4 to 20 mA signal may be measured via the positive and test terminal without interrupting the measurement. The minimum supply voltage of the device can be reduced by simply changing the position of the jumper. As a result, operation is also possible with lower voltage sources. To keep the measured error below 0.1 %, the current measuring device should display an internal resistance of $< 0.7 \Omega$. Observe the position of the jumper in accordance with the following table.

Jumper position for test signal	Description
	<ul style="list-style-type: none"> – Taking 4 to 20 mA test signal via plus and test terminal: possible. (Thus, the output current can be measured without interruption via the diode.) – Delivery status – Minimum supply voltage: 11.5 V DC
	<ul style="list-style-type: none"> – Taking 4 to 20 mA test signal via plus and test terminal: not possible. – Minimum supply voltage: 10.5 V DC

4.2.2 Cable specification

- Endress+Hauser recommends using twisted, screened two-wire cables.
- Terminals for wire cross-sections 0.5 to 2.5 mm² (20 to 14 AWG)
- Cable external diameter: 5 to 9 mm (0.2 to 0.35 in)

4.2.3 Load




Fig. 20: Load diagram, observe the position of the jumper and the explosion protection.
(→ 21, "Taking 4 to 20 mA test signal" part.)

- 1 Jumper for the 4 to 20 mA test signal inserted in "Non-Test" position
 - 2 Jumper for the 4 to 20 mA test signal inserted in "Test" position
 - 3 Supply voltage 10.5 (11.5) to 30 V DC for 1/2 G, 1 GD, 1/2 GD, FM IS, CSA IS, IECEx ia, NEPSI Ex ia
 - 4 Supply voltage 10.5 (11.5) to 45 V DC for devices for non-hazardous areas, 1/2 D, 1/3 D, 2 G Ex d, 3 G Ex nA, FM XP, FM DIP, FM NI, CSA XP and CSA Dust-Ex, NEPSI Ex d
 - 5 Supply voltage 11 (12) to 45 V DC for PMC71, Ex d[ia], NEPSI Ex d[ia]
- R_{Lmax} Maximum load resistance
 U Supply voltage



Note!

When operating via a handheld terminal or via PC with an operating program, a minimum communication resistance of 250 Ω must exist within the loop.

4.2.4 Screening/potential matching

- You achieve optimum screening against disturbances if the screening is connected on both sides (in the cabinet and on the device). If you have to reckon with potential equalisation currents in the plant, only earth screening on one side, preferably at the transmitter.
- When using in hazardous areas, you must observe the applicable regulations.
Separate Ex documentation with additional technical data and instructions is included with all Ex systems as standard.

4.2.5 Connecting Field Xpert SFX100

Compact, flexible and robust industry handheld terminal for remote parametrization and measured value inspection via the HART current output (4-20mA).

For details refer to Operating Instructions BA00060S/04/EN.

4.2.6 Connecting Commubox FXA195

The Commubox FXA195 connects intrinsically safe transmitters with the HART protocol to a computer's USB port. This allows remote operation of the transmitter using Endress+Hauser's FieldCare operating program. Power is supplied to the Commubox through the USB port. The Commubox is also suitable for connection to intrinsically safe circuits. → See Technical Information TI00404F for further information.

4.2.7 Connecting Commubox FXA291/ToF Adapter FXA291 for operation via FieldCare

Connecting Commubox FXA291

The Commubox FXA291 connects Endress+Hauser field instruments with CDI interface (= Endress+Hauser Common Data Interface) to the USB interface of a personal computer or a notebook. For details refer to TI00405C/07/EN.



Note!

For the device you need the "ToF Adapter FXA291" as an additional accessory.

Connecting ToF Adapter FXA291

The ToF Adapter FXA291 connects the Commubox FXA291 via the USB interface of a personal computer or a notebook to the device. For details refer to KA00271F/00/A2.

4.3 Potential matching

Ex applications: Connect all devices to the local potential matching.
Observe the applicable regulations.

4.4 Overvoltage protection (optional)

Devices showing version "M" in feature 100 "Additional options 1" or feature 110 "Additional options 2" in the order code are equipped with overvoltage protection (see also Technical Information TI00383P "Ordering information").

- Overvoltage protection:
 - Nominal functioning DC voltage: 600 V
 - Nominal discharge current: 10 kA
- Surge current check $\hat{i} = 20 \text{ kA}$ as per DIN EN 60079-14: 8/20 μs satisfied
- Arrester AC current check $I = 10 \text{ A}$ satisfied



Warning!

Devices with integrated overvoltage protection must be earthed.

4.5 Post-connection check

Perform the following checks after completing electrical installation of the device:

- Does the supply voltage match the specifications on the nameplate?
- Is the device properly connected (→ 19)?
- Are all screws firmly tightened?
- Are the housing covers screwed down tight?

As soon as voltage is applied to the device, the green LED on the electronic insert lights up for a few seconds or the connected on-site display lights up.

5 Operation

Feature 20 "Output; operation" in the order code provides you with information on the operating options available to you.

Versions in the order code		Operation
A	4 to 20 mA HART; external operation, LCD	Via on-site display and 3 keys on the exterior of the device
B	4 to 20 mA HART; internal operation, LCD	Via on-site display and 3 keys on the inside of the device
C	4 to 20 mA; internal operation	Without on-site display, 3 keys on the inside of the device

5.1 On-site display (optional)


A 4-line liquid crystal display (LCD) is used for display and operation.

The on-site display shows measured values, dialog texts, fault messages and notice messages.

The display of the device can be turned in 90° steps. Depending on the installation position of the device, this makes it easy to operate the device and read the measured values.

Functions:

- 8-digit measured value display including sign and decimal point, bargraph for current display
- Simple and complete menu guidance thanks to separation of the parameters into several levels and groups
- Each parameter is given a 3-digit ID number for easy navigation
- Option for configuring the display according to individual requirements and desires, such as language, alternating display, contrast setting, display of other measured values such as sensor temperature
- Comprehensive diagnostic functions (fault and warning message, peak-hold indicators, etc.)
- Rapid and safe commissioning with the Quick Setup menus



P01-xMx7xxxx-07-xx-xx-xx-001

The following table illustrates the symbols that can appear on the on-site display. Four symbols can occur at one time.

Symbol	Meaning
	Alarm symbol – Symbol flashing: warning, device continues measuring. – Symbol permanently lit: error, device does not continue measuring. <i>Note:</i> The alarm symbol may overlie the tendency symbol.
	Lock symbol The operation of the device is locked. Unlock device, → 38.
	Communication symbol Data transfer via communication. <i>Note:</i> The alarm symbol may overlie the communication symbol.
	Tendency symbol (increasing) The measured value is increasing.
	Tendency symbol (decreasing) The measured value is decreasing.
	Tendency symbol (constant) The measured value has remained constant over the past few minutes.

5.2 Operating elements

5.2.1 Position of operating elements

With regard to aluminium or stainless steel housings (T14), the operating keys are located either outside the device under the protection cap or inside on the electronic insert. In hygienic stainless steel housings (T17), the operating keys are always located inside on the electronic insert.




Fig. 21: Operating keys, external

- 1 Operating keys on the exterior of the device under the protective flap



















Fig. 22: Operating keys, internal











- 1 Operating keys
 2 Slot for optional display
 3 Slot for optional HistoROM®/M-DAT
 4 DIP-switch for locking/unlocking measured-value-relevant parameters
 5 DIP-switch for damping on/off
 6 Green LED to indicate value being accepted

5.2.2 Function of the operating elements – on-site display not connected

Press and hold the key or the key combination for at least 3 seconds to execute the corresponding function. Press the key combination for at least 6 seconds for a reset.

Operating key(s)	Meaning
	Adopt lower range value. A reference pressure is present at the device. See also →  27, "Pressure measuring mode" or →  28, "Level measuring mode".
	Adopt upper range value. A reference pressure is present at the device. See also →  27, "Pressure measuring mode" or →  28, "Level measuring mode".
	Position adjustment
 and  and 	Reset all parameters. The reset via operating keys corresponds to the software reset code 7864.
 and 	Copy the configuration data from the optional HistoROM®/M-DAT module to the device.
 and 	Copy the configuration data from the device to the optional HistoROM®/M-DAT module.
 P01-xxxxxxx-19-xx-xx-xx-057	<ul style="list-style-type: none"> – DIP-switch 1: for locking/unlocking measured-value-relevant parameters Factory setting: off (unlocked) – DIP-switch 2: damping on/off, Factory setting: on (damping on)

5.2.3 Function of the operating elements – on-site display connected

Operating key(s)	Meaning
	<ul style="list-style-type: none"> – Navigate upwards in the picklist – Edit the numerical values and characters within a function
	<ul style="list-style-type: none"> – Navigate downwards in the picklist – Edit the numerical values and characters within a function
	<ul style="list-style-type: none"> – Confirm entry – Jump to the next item
 and 	Contrast setting of on-site display: darker
 and 	Contrast setting of on-site display: brighter
 and 	<p>ESC functions:</p> <ul style="list-style-type: none"> – Exit edit mode without saving the changed value. – You are in a menu within a function group. The first time you press the keys simultaneously, you go back a parameter within the function group. Each time you press the keys simultaneously after that, you go up a level in the menu. – You are in a menu at a selection level. Each time you press the keys simultaneously, you go up a level in the menu. <p><i>Note:</i> The terms function group, level and selection level are explained in →  30, "General structure of the operating menu".</p>

5.3 On-site operation – on-site display not connected



Note!

To operate the device with a HistoROM®/M-DAT module see → 32, "HistoROM®/M-DAT (optional)".

5.3.1 Pressure measuring mode

If no on-site display is connected, the following functions are possible by means of the three keys on the electronic insert or on the exterior of the device:

- Position adjustment (zero point correction)
- Setting lower range value and upper range value
- Device reset, → 26, "Function of the operating elements – on-site display not connected".



Note!

- The operation must be unlocked. → 37, "Locking/unlocking operation".
- The device is configured for the Pressure measuring mode as standard. You can switch measuring modes by means of the MEASURING MODE parameter. → 40, "Selecting language and measuring mode".
- The pressure applied must be within the nominal pressure limits of the sensor. See information on the nameplate.



Warning!


If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

Carry out position adjustment. ¹⁾		Setting lower range value.		Setting upper range value.	
Pressure is present at device.		Desired pressure for lower range value is present at device.		Desired pressure for upper range value is present at device.	
↓		↓		↓	
Press "E"-key for 3 s.		Press "-"-key for 3 s.		Press "+"-key for 3 s.	
↓		↓		↓	
Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?	
Yes	No	Yes	No	Yes	No
↓	↓	↓	↓	↓	↓
Applied pressure for position adjustment has been accepted.	Applied pressure for position adjustment has not been accepted. Observe the input limits.	Applied pressure for lower range value has been accepted.	Applied pressure for lower range value has not been accepted. Observe the input limits.	Applied pressure for upper range value has been accepted.	Applied pressure for upper range value has not been accepted. Observe the input limits.

1) Observe "Warning", → 40, "Commissioning".

5.3.2 Level measuring mode

If no on-site display is connected, the following functions are possible by means of the three keys on the electronic insert or on the exterior of the device:


- Position adjustment (zero point correction)
- Set the lower and upper pressure value and assign to the lower and upper level value
- Device reset, →  26, "Function of the operating elements – on-site display not connected".



Note!

- The "-" and "+"- keys only have a function in the following cases:
 - LEVEL SELECTION "Level Easy Pressure", CALIBRATION MODE "Wet"
 - LEVEL SELECTION "Level Standard", LEVEL MODE "Linear", CALIBRATION MODE "Wet"



The keys have no function in other settings.

- The device is configured for the Pressure measuring mode as standard. You can switch measuring modes by means of the MEASURING MODE parameter. →  40, "Selecting language and measuring mode".

The following parameters are set to the following values in the factory:

- LEVEL SELECTION: Level Easy Pressure
- CALIBRATION MODE: Wet
- OUTPUT UNIT or LIN. MEASURAND: %
- EMPTY CALIB.: 0.0
- FULL CALIB.: 100.0.
- SET LRV: 0.0 (corresponds to 4 mA value)
- SET URV: 100.0 (corresponds to 20 mA value)

These parameters can only be modified by means of the on-site display or remote operation such as the FieldCare.


- The operation must be unlocked. →  37, "Locking/unlocking operation".
- The pressure applied must be within the nominal pressure limits of the sensor. See information on the nameplate.
- See also →  44, "Level measurement". For parameter description see Operating Instructions BA00274P.
- LEVEL SELECTION, CALIBRATION MODE, LEVEL MODE, EMPTY CALIB., FULL CALIB, SET LRV and SET URV are parameter names used for on-site display or remote operation such as FieldCare, for instance.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

Carry out position adjustment. ¹⁾		Setting lower pressure value.		Setting upper pressure value.	
Pressure is present at device.		Desired pressure for lower pressure value (EMPTY PRESSURE ²⁾) is present at device.		Desired pressure for upper pressure value (FULL PRESSURE ¹⁾) is present at device.	
↓		↓		↓	
Press "E"-key for 3 s.		Press "-"-key for 3 s.		Press "+"-key for 3 s.	
↓		↓		↓	
Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?		Does the LED on the electronic insert light up briefly?	
Yes	No	Yes	No	Yes	No
↓	↓	↓	↓	↓	↓
Applied pressure for position adjustment has been accepted.	Applied pressure for position adjustment has not been accepted. Observe the input limits.	The pressure present was saved as the lower pressure value (EMPTY PRESSURE ¹⁾) and assigned to the lower level value (EMPTY CALIB. ¹⁾ .	The pressure present was not saved as the lower pressure value. Observe the input limits.	The pressure present was saved as the upper pressure value (FULL PRESSURE ¹⁾) and assigned to the upper level value (FULL CALIB. ¹⁾ .	The pressure present was not saved as the upper pressure value. Observe the input limits.

1) Observe "Warning", →  40, "Commissioning".


2) Parameter name used for the on-site display or remote operation such as the FieldCare.

5.4 On-site operation – on-site display connected

If the on-site display is connected, the three operating keys are used to navigate through the operating menu, → 26, "Function of the operating elements – on-site display connected".

5.4.1 General structure of the operating menu

The menu is split into four levels. The three upper levels are used to navigate while you use the bottom level to enter numerical values, select options and save settings. The structure of the OPERATING MENU depends on the measuring mode selected, e.g. if the "Pressure" measuring mode is selected, only the functions necessary for this mode are displayed.






Note!

The LANGUAGE and MEASURING MODE parameters are only displayed via the on-site display on the 1st selection level. In the digital communication, the LANGUAGE parameter is displayed in the DISPLAY group and the MEASURING MODE parameter is displayed in the QUICK SETUP menus or in the BASIC SETUP function group.

5.4.2 Selecting an option






Example: select "English" as the language of the menu.



On-site display	Operation
 <p>SPRACHE 079 ✓Deutsch Français Italiano</p> <p>P01-xxxxxxx-19-xx-xx-xx-017</p>	German is selected as the language. A ✓ in front of the menu text indicates the active option.
 <p>SPRACHE 079 English ✓Deutsch Français</p> <p>P01-xxxxxxx-19-xx-xx-xx-033</p>	Select English with "+" or "-".
 <p>LANGUAGE 079 ✓English Deutsch Français</p> <p>P01-xxxxxxx-19-xx-xx-xx-034</p>	<ol style="list-style-type: none"> 1. Confirm your choice with "E". A ✓ in front of the menu text indicates the active option. (English is now selected as the menu language.) 2. Jump to the next item with "E".

5.4.3 Editing a value

Example: adjusting DAMPING VALUE function from 2.0 s to 30.0 s.





→ 26, "Function of the operating elements – on-site display connected".

On-site display	Operation
 <p>DAMPING VALUE 247 2.0 s</p> <p>P01-xxxxxxx-19-xx-xx-xx-023</p>	The on-site display shows the parameter to be changed. The value highlighted in black can be changed. The "s" unit is fixed and cannot be changed.
 <p>DAMPING VALUE 247 2.0 s</p> <p>P01-xxxxxxx-19-xx-xx-xx-027</p>	<ol style="list-style-type: none"> 1. Press "+" or "-" to get to the editing mode. 2. The first digit is highlighted in black.
 <p>DAMPING VALUE 247 3.0 s</p> <p>P01-xxxxxxx-19-xx-xx-xx-028</p>	<ol style="list-style-type: none"> 1. Use "+" to change "2" to "3". 2. Confirm "3" with "E". The cursor jumps to the next position (highlighted in black).
 <p>DAMPING VALUE 247 3.0 s</p> <p>P01-xxxxxxx-19-xx-xx-xx-029</p>	The decimal point is highlighted in black, i.e. you can now edit it.
 <p>DAMPING VALUE 247 30.0 s</p> <p>P01-xxxxxxx-19-xx-xx-xx-030</p>	<ol style="list-style-type: none"> 1. Keep pressing "+" or "-" until "0" is displayed. 2. Confirm "0" with "E". The cursor jumps to the next position. ↵ is displayed and is highlighted in black. → See next graphic.

On-site display	Operation
 <p>P01-xxxxxxx-19-xx-xx-xx-031</p>	Use "E" to save the new value and exit the editing mode. See next graphic.
 <p>P01-xxxxxxx-19-xx-xx-xx-032</p>	<p>The new value for the damping is now 30.0 s.</p> <ul style="list-style-type: none"> – Jump to the next parameter with "E". – You can get back to the editing mode with "+" or "-".

5.4.4 Taking pressure applied at device as value

Example: configuring upper range value – assign 20 mA to the pressure value 400 mbar (6 psi).

On-site display	Operation
 <p>P01-xxxxxxx-19-xx-xx-xx-035</p>	The bottom line on the on-site display displays the pressure present, here 400 mbar (6 psi).
 <p>P01-xxxxxxx-19-xx-xx-xx-036</p>	Use "+" or "-" to switch to the "Confirm" option. The active selection is highlighted in black.
 <p>P01-xxxxxxx-19-xx-xx-xx-037</p>	Use "E" to assign the value (400 mbar (6 psi)) to the GET URV parameter. The device confirms the calibration and jumps back to the parameter, here GET URV (see next graphic).
 <p>P01-xxxxxxx-19-xx-xx-xx-035</p>	Switch to the next parameter with "E".

5.5 HistoROM®/M-DAT (optional)

HistoROM®/M-DAT is a memory module, which is attached to the electronic insert and fulfils the following functions:

- Back-up copy of configuration data
- Copying configuration data of a transmitter into another transmitter
- Cyclic recording of pressure and sensor-temperature measured values
- Recording diverse events, such as alarms, configuration changes, counters for measuring range undershooting and exceeding for pressure and temperature, exceeding and undershooting the user limits for pressure and temperature, etc.



Warning!


Detach HistoROM®/M-DAT from the electronic insert or attach it to the insert in a deenergised state only.



Note!

- The HistoROM®/M-DAT module may be retrofitted at any time (Order No.: 52027785).
- The HistoROM data and the data in the device are analysed once a HistoROM®/M-DAT is attached to the electronic insert and power is reestablished to the device. During the analysis, the messages "W702, HistoROM data not consistent" and "W706, Configuration in HistoROM and device not identical" can occur. For measures, → 49, "Messages."

5.5.1 Copying configuration data



P01-xxxxxxx-19-xx-xx-xx-099

Abb. 24: Electronic insert with optional HistoROM®/M-DAT memory module

- 1 Optional HistoROM®/M-DAT
- 2 To copy configuration data from the HistoROM®/M-DAT module to a device or from a device to a HistoROM®/M-DAT, the operation must be unlocked DIP-switch 1, Position "off", parameter INSERT PIN NO. = 100).
Observe → 37, "Locking/unlocking operation".

On-site operation – on-site display not connected

Copying configuration data from a device to a HistoROM®/M-DAT module:



Note!

The operation must be unlocked.

1. Disconnect device from supply voltage.
2. Attach the HistoROM®/M-DAT module to the electronic insert.
3. Reestablish supply voltage to the device.
4. Press "E" and "-"-keys (for at least 3 seconds) until the LED on the electronic insert lights up.
5. Wait approx. 20 seconds. Configuration data are loaded from the device to the HistoROM®/M-DAT. The device is not restarted.
6. Disconnect device from the supply voltage again.
7. Detach memory module.
8. Reestablish supply voltage to the device.

Copying configuration data from a HistoROM®/M-DAT to a device:

Note!

The operation must be unlocked.

1. Disconnect device from supply voltage.
2. Attach the HistoROM®/M-DAT module to the electronic insert. Configuration data from another device are stored in the HistoROM®/M-DAT.
3. Reestablish supply voltage to the device.
4. Press "E" und "+"-keys (for at least 3 seconds) until the LED on the electronic insert lights up.
5. Wait approx. 20 seconds. All parameters except DEVICE SERIAL No, DEVICE DESIGN., CUST. TAG NUMBER, LONG TAG NUMBER, DESCRIPTION, BUS ADDRESS, CURRENT MODE and the parameters in the POSITION ADJUSTMENT and PROCESS CONNECTION group are loaded into the device by HistoROM®/M-DAT. The device is restarted.
6. Before removing the HistoROM®/M-DAT again from the electronic insert, disconnect the device from supply voltage.

On-site operation via on-site display (optional) or remote operation**Copying configuration data from a device to a HistoROM®/M-DAT:**

Note!

The operation must be unlocked.

1. Disconnect device from supply voltage.
2. Attach the HistoROM®/M-DAT module to the electronic insert.
3. Reestablish supply voltage to the device.
4. The DOWNLOAD SELECT. parameter setting has no influence on an upload from the device into HistoROM.
(Menu path: (GROUP SELECTION →) OPERATING MENU → OPERATION)
5. Using the HistoROM CONTROL parameter select the option "Device → HistoROM" as the data transfer direction.
(Menu path: GROUPSELECTION → OPERATING MENU → OPERATION)
6. Wait approx. 20 seconds. Configuration data are loaded from the device to the HistoROM®/M-DAT. The device is not restarted.
7. Disconnect device from the supply voltage again.
8. Detach memory module.
9. Reestablish supply voltage to the device.

Copying configuration data from a HistoROM®/M-DAT to a device:

Note!

The operation must be unlocked.

1. Disconnect device from supply voltage.
2. Attach the HistoROM®/M-DAT module to the electronic insert. Configuration data from another device are stored in the HistoROM®/M-DAT.
3. Reestablish supply voltage to the device.
4. Use the DOWNLOAD SELECT parameter to select which parameters are to be overwritten (Menu path: (GROUPS SELECTION →) OPERATING MENU → OPERATION).

The following parameters are overwritten according to the selection:

– **Configuration copy (factory setting):**

all parameters except DEVICE SERIAL No., DEVICE DESIGN, CUST. TAG NUMBER, LONG TAG NUMBER, DESCRIPTION, BUS ADDRESS, CURRENT MODE and the parameters in the POSITION ADJUSTMENT, PROCESS CONNECTION, CURR. TRIM (SERVICE/SYSTEM 2), SENSOR TRIM and SENSOR DATA group.

– **Device replacement:**

all parameters except DEVICE SERIAL No., DEVICE DESIGN and the parameters in the POSITION ADJUSTMENT, PROCESS CONNECTION, CURR. TRIM (SERVICE/SYSTEM 2), SENSOR TRIM and SENSOR DATA group.

– **Electronics replace:**

all parameters except the parameters in the CURR. TRIM (SERVICE/SYSTEM 2) and SENSOR DATA group.

Factory setting: Configuration copy

5. Using the HistoROM CONTROL parameter select the option "HistoROM → Device" as the data transfer direction.
(Menu path: GROUP SELECTION → OPERATING MENU → OPERATION)
6. Wait approx. 20 seconds. Configuration data are loaded from the device to the HistoROM®/M-DAT. The device is restarted.
7. Before removing the HistoROM®/M-DAT again from the electronic insert, disconnect the device from supply voltage.

5.6 Operation via SFX100

Compact, flexible and robust industry handheld terminal for remote parametrization and measured value inspection via the HART current output (4-20mA).
For details refer to Operating Instructions BA00060S/04/EN.

5.7 Endress+Hauser operating program

The operating program FieldCare is an Endress+Hauser Plant Asset Management Tool based on FDT technology. You can use FieldCare to configure all your Endress+Hauser devices, as well as devices from other manufacturers that support the FDT standard. Hardware and software requirements you can find on the www.endress.com → select your country → Search: FieldCare → FieldCare → Technical Data.

FieldCare supports the following functions:

- Configuration of transmitters in online operation
- Loading and saving device data (upload/download)
- Tank linearization
- HistoROM®/M-DAT analysis
- Documentation of the measuring point

Connection options:

- HART via Fieldgate FXA520
- HART via Commubox FXA195 and USB interface of a computer
- Commubox FXA291 with ToF Adapter FXA291 via service interface



Note!

- See also → 23, "Connecting Commubox FXA195".
- In the "Level Standard" measuring mode, the configuration data that were loaded with FDT upload cannot be written again (FDT download). These data are only used to document the measuring point.
- Further information on the FieldCare can be found on the Internet:
<http://www.endress.com> → Download → Text Search: FieldCare.

5.8 Locking/unlocking operation

Once you have entered all the parameters, you can lock your entries against unauthorised and undesired access.

You have the following possibilities for locking/unlocking the operation:

- Via a DIP-switch on the electronic insert, locally on the display.
- Via the on-site display (optional)
- Via digital communication.

The -symbol on the on-site display indicates that operation is locked. Parameters which refer to how the display appears, e.g. LANGUAGE and DISPLAY CONTRAST can still be altered.



Note!


If operation is locked by means of the DIP-switch, you can only unlock operation again by means of the DIP-switch. If operation is locked by means of the on-site display or remote operation e.g. FieldCare, you can only unlock operation again by means of the on-site display or remote operation.

The table provides an overview of the locking functions:

Locking via	View/read parameter	Modify/write via ¹⁾		Unlocking via		
		On-site display	Remote operation	DIP-switch	On-site display	Remote operation
DIP-switch	Yes	No	No	Yes	No	No
On-site display	Yes	No	No	No	Yes	Yes
Remote operation	Yes	No	No	No	Yes	Yes

1) Parameters which refer to how the display appears, e.g. LANGUAGE and DISPLAY CONTRAST can still be altered.

5.8.1 Locking/unlocking operation locally via DIP-switch



P01-xxxxxxx-19-xx-xx-xx-133

Fig. 25: DIP-switch position "Hardware locking" on the electronic insert


- 1 If necessary, remove on-site display (optional)
- 2 DIP-switch is at "on": operation is locked.
- 3 DIP-switch is at "off": operation is unlocked (operation possible)

5.8.2 Locking/unlocking operation via on-site display or remote operation

	Description
Locking operation	<ol style="list-style-type: none"> 1. Select INSERT PIN NO. parameter, Menu path: OPERATING MENU → OPERATION → INSERT PIN NO. 2. To lock operation, enter a number for this parameter between 0 to 9999 that is ≠100.
Unlocking operation	<ol style="list-style-type: none"> 1. Select INSERT PIN NO. parameter. 2. To unlock operation, enter "100" for the parameter.

5.9 Factory setting (reset)

By entering a certain code, you can completely, or partially, reset the entries for the parameters to the factory settings. (For factory settings refer to the Operating Instructions BA00274P "Cerabar S/Deltabar S/Deltapilot S, Description of device functions".) Enter the code by means of the ENTER RESET CODE parameter (Menu path: (GROUP SELECTION →) OPERATING MENU → OPERATING).

There are various reset codes for the device. The following table illustrates which parameters are reset by the particular reset codes. Operation must be unlocked to reset parameters (→  37, "Locking/unlocking operation").



Note!

Any customer-specific configuration carried out by the factory is not affected by a reset (customer-specific configuration remains). If, after a reset, you wish the parameters to be reset to the factory settings, please contact Endress+Hauser Service.

Reset code	Description and effect
1846	Display reset <ul style="list-style-type: none"> – This reset resets all parameters which have to do with how the display appears (DISPLAY group). – Any simulation which may be running is ended. – The device is restarted.
62	PowerUp reset (warm start) <ul style="list-style-type: none"> – This reset resets all the parameters in the RAM. Data are read back anew from the EEPROM (processor is initialised again). – Any simulation which may be running is ended. – The device is restarted.
2710	Measuring mode level reset <ul style="list-style-type: none"> – Depending on the settings for the LEVEL MODE, LIN MEASURAND, LINdMEASURAND or COMB. MEASURAND parameters, the parameters needed for this measuring task will be reset. – Any simulation which may be running is ended. – The device is restarted. <p>Example LEVEL MODE = linear and LIN. MEASURAND = Height</p> <ul style="list-style-type: none"> ■ HEIGHT UNIT = m ■ CALIBRATION MODE = wet ■ EMPTY CALIB. = 0 ■ FULL CALIB. = Sensor end value converted to mH₂O, e.g. 4.79 mH₂O for a 400 mbar (6 psi) sensor
333	User reset <ul style="list-style-type: none"> – Affects the following parameters: <ul style="list-style-type: none"> – Function group POSITION ADJUSTMENT – Function group BASIC SETUP, except for the customer-specific units – Function group EXTENDED SETUP – Group OUTPUT – Function group HART DATA: CURRENT MODE, BUS ADDRESS and PREAMBLE NUMBER – Any simulation which may be running is ended. – The device is restarted.

Reset code	Description and effect
7864	Total reset <ul style="list-style-type: none"> – Affects the following parameters: <ul style="list-style-type: none"> – Function group POSITION ADJUSTMENT – Function group BASIC SETUP – Function group EXTENDED SETUP – Function group LINEARISATION (an existing linearisation table is erased) – Group OUTPUT – Function group PEAK HOLD INDICATOR – Function group HART DATA – All configurable messages ("Error" type) are set to factory setting. → ↗ 49, "Messages" and → ↗ 57, "Response of outputs to errors". – Function group USER LIMITS – Function group SYSTEM 2 – Any simulation which may be running is ended. – The device is restarted.
8888	HistoROM reset The measured value memory and event memory are cleared. During the reset, the HistoROM must be attached to the electronic insert.

6 Commissioning



Warning!

- If a pressure smaller than the minimum permitted pressure is present at the device, the messages "E120 Sensor low pressure" and "E727 Sensor pressure error - overrange" are output in succession.
- If a pressure greater than the maximum permitted pressure is present at the device, the messages "E115 Sensor overpressure" and "E727 Sensor pressure error - overrange" are output in succession.
- Messages E727, E115 and E120 are "Error"-type messages and can be configured as a "Warning" or an "Alarm". These messages are configured as "Warning" messages at the factory. This setting prevents the current output from assuming the set alarm current value for applications (e.g. cascade measurement) where the user is consciously aware of the fact that the sensor range can be exceeded
- We recommend setting messages E727, E115 and E120 to "Alarm" in the following instances:
 - The sensor range does not have to be exceeded for the measuring application.
 - Position adjustment has to be carried out that has to correct a large measured error as a result of the orientation of the device (e.g. devices with a diaphragm seal).



Note!

The device is configured for the Pressure measuring mode as standard. The measuring range and the unit in which the measured value is transmitted correspond to the specifications on the nameplate.

6.1 Function check

Carry out a post-installation and a post-connection check as per the checklist before commissioning the device.

- "Post-installation check" checklist, → 18.
- "Post-connection check" checklist, → 23.

6.2 Selecting language and measuring mode

6.2.1 On-site operation

The LANGUAGE and MEASURING MODE parameters are located on the top menu level.
See also → 30, "General structure of the operating menu".

The following measuring modes are available:

- Pressure
- Level

6.2.2 Digital communication

The MEASURING MODE parameter is displayed in the digital communication in the QUICK SETUP menus and in the BASIC SETUP function group (OPERATING MENU → SETTINGS → BASIC SETUP).

The following measuring modes are available:

- Pressure
- Level

The LANGUAGE parameter is arranged in the DISPLAY group (OPERATING MENU → DISPLAY).

- Use the LANGUAGE parameter to select the menu language for the on-site display.
- Select the menu language for FieldCare by means of the "Language Button" in the configuration window. Select the menu language for the FieldCare frame via the "Extra" menu → "Options" → "Display" → "Language".

6.3 Position adjustment

Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the measured value parameter does not display zero. There are three options to choose from when performing position adjustment.

(Menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → POSITION ADJUSTMENT)

Parameter name	Description
POS. ZERO ADJUST (685) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 2.2 mbar (0.032 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar – The current value is also corrected. <p>The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.</p> <p>Factory setting: 0.0</p>
POS. INPUT VALUE (563) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e. g. from a reference device).</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 0.5 mbar (0.0073 psi) – For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.029 psi). ($\text{MEASURED VALUE}_{\text{new}} = \text{POS. INPUT VALUE}$) – MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.029 psi) – The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. $\text{CALIB. OFFSET} = \text{MEASURED VALUE}_{\text{old}} - \text{POS. INPUT VALUE}$, here: $\text{CALIB. OFFSET} = 0.5 \text{ mbar (0.0073 psi)} - 2.0 \text{ mbar (0.029 psi)} = -1.5 \text{ mbar (0.022 psi)}$ – The current value is also corrected. <p>Factory setting: 0.0</p>
CALIB. OFFSET (319) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure is known.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 2.2 mbar (0.032 psi) – Via the CALIB. OFFSET parameter, enter the value by which the MEASURED VALUE should be corrected. To correct the MEASURED VALUE to 0.0 mbar, you must enter the value 2.2 here. ($\text{MEASURED VALUE}_{\text{new}} = \text{MEASURED VALUE}_{\text{old}} - \text{CALIB. OFFSET}$) – MEASURED VALUE (after entry for calib. offset) = 0.0 mbar – The current value is also corrected. <p>Factory setting: 0.0</p>

6.4 Pressure measurement

6.4.1 Information on pressure measurement



- Note!
- There is a Quick Setup menu for each of the measuring modes Pressure and Level which guides you through the most important basic functions. With the setting in the MEASURING MODE parameter, you specify which Quick Setup menu should be displayed.
→ 40, "Selecting language and measuring mode".
 - For a detailed description of the parameters see the Operating Instructions BA00274P "Cerabar S/Deltabar S/Deltapilot S, Description of device functions"
 - Table 6, POSITION ADJUSTMENT
 - Table 7, BASIC SETUP
 - Table 15, EXTENDED SETUP
 - For pressure measurement, select the "Pressure" option by means of the MEASURING MODE parameter. The operating menu is structured appropriately.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

6.4.2 Quick Setup menu for Pressure measuring mode




Fig. 26: Quick Setup menu for Pressure measuring mode



On-site operation	Digital communication
Measured value display On-site display: Switch from the measured value display to GROUP SELECTION with .	Measured value display Select QUICK SETUP menu.
GROUP SELECTION Select MEASURING MODE.	MEASURING MODE Select "Pressure" option.
MEASURING MODE Select "Pressure" option.	
GROUP SELECTION Select QUICK SETUP menu.	

On-site operation	Digital communication
POS. ZERO ADJUST Due to orientation of the device, there may be a shift in the measured value. You correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option, i. e. you assign the value 0.0 to the pressure present.	POS. ZERO ADJUST Due to orientation of the device, there may be a shift in the measured value. You correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option, i. e. you assign the value 0.0 to the pressure present.
POS. INPUT VALUE Due to orientation of the device, there may be a shift in the measured value. For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE.	POS. INPUT VALUE Due to orientation of the device, there may be a shift in the measured value. For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE.
SET LRV Set the measuring range (enter 4 mA value). Specify a pressure value for the lower current value (4 mA value). A reference pressure does not have to be present at the device.	SET LRV Set the measuring range (enter 4 mA value). Specify a pressure value for the lower current value (4 mA value). A reference pressure does not have to be present at the device.
SET URV Set the measuring range (enter 20 mA value). Specify a pressure value for the upper current value (20 mA value). A reference pressure does not have to be present at the device.	SET URV Set the measuring range (enter 20 mA value). Specify a pressure value for the upper current value (20 mA value). A reference pressure does not have to be present at the device.
DAMPING TIME Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.	DAMPING TIME Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.



Note!

For on-site operation, see also

-  26, "Function of the operating elements – on-site display connected" and
-  30, "On-site operation – on-site display connected".

6.5 Level measurement

6.5.1 Information on level measurement



Note!

- The Pressure and Level operating modes each have a quick setup menu which guides you through the most important basic functions. → 46, "Quick Setup menu for Level measuring mode".
- Furthermore, the three level modes "Level Easy Pressure", "Level Easy Height" and "Level Standard" are available to you for level measurement. You can select from the "Linear", "Pressure linearized" and "Height linearized" level types for the "Level Standard" level mode. The table in the "Overview of level measurement" section below provides an overview of the various measuring tasks.
 - In the "Level Easy Pressure" and "Level Easy Height" level modes, the values entered are not tested as extensively as in the "Level Standard" level mode. The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE, EMPTY HEIGHT/FULL HEIGHT and SET LRV/SET URV must have a minimum interval of 1 % for the "Level Easy Pressure" and "Level Easy Height" level modes. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
 - The "Level Easy Pressure" and "Level Easy Height" level modes encompass fewer parameters than the "Level Standard" mode and are used for quick and easy configuration of a level application.
 - Customer-specific units of fill level, volume and mass or a linearization table may only be entered in the "Level Standard" level mode.
 - Where the device is intended for use as a subsystem in a safety function (SIL), a "Device configuration with enhanced parameter security" (SAFETY CONFIRM.) is only possible for the "Level" operating mode in the "Level Easy Pressure" level mode. All parameters previously entered are checked after a password is entered. Once the "Level Easy Height" or "Level Standard" has been selected, the configuration will first have to be reset to the ex-works setting using the RESET parameter (menu path: (GROUP SELECTION →) OPERATING MENU → OPERATION) using the reset code "7864".
For further information see the Cerabar S (SD00190P) Functional Safety Manual.
- See the Operating Instructions BA00274P "Cerabar S/Deltabar S/Deltapilot S, Description of device functions".

6.5.2 Overview of level measurement

Measuring task	LEVEL SELECTION/ LEVEL MODE	Measured variable options	Description	Comment	Measured value display
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering two pressure-level value pairs.	LEVEL SELECTION: Level Easy Pressure	Via OUTPUT UNIT parameter: %, level, volume or mass units.	<ul style="list-style-type: none"> – Calibration with reference pressure – wet calibration, see Operating Instructions BA00274P. – Calibration without reference pressure – dry calibration, see Operating Instructions BA00274P. 	<ul style="list-style-type: none"> – Incorrect entries are possible – SIL mode possible – Customised units are not possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering the density and two height-level value pairs.	LEVEL SELECTION: Level Easy Height	Via OUTPUT UNIT parameter: %, level, volume or mass units.	<ul style="list-style-type: none"> – Calibration with reference pressure – wet calibration, see Operating Instructions BA00274P. – Calibration without reference pressure – dry calibration, see Operating Instructions BA00274P. 	<ul style="list-style-type: none"> – Incorrect entries are possible – SIL mode not possible – Customised units are not possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is in direct proportion to the measured pressure.	LEVEL SELECTION: Level standard/ LEVEL MODE: Linear	Via LIN. MEASURAND parameter: <ul style="list-style-type: none"> – % (level) – Level – Volume – Mass 	<ul style="list-style-type: none"> – Calibration with reference pressure – wet calibration, see Operating Instructions BA00274P. – Calibration without reference pressure – dry calibration, see Operating Instructions BA00274P. 	<ul style="list-style-type: none"> – Incorrect entries are rejected by the device – SIL mode not possible – Customised level, volume and mass units are possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is not in direct proportion to the measured pressure as, for example, with containers with a conical outlet. A linearisation table must be entered for the calibration.	LEVEL SELECTION: Level standard/ LEVEL MODE: Pressure linearized	Via LIND MEASURAND parameter: <ul style="list-style-type: none"> – Pressure + % – Pressure + volume – Pressure + mass 	<ul style="list-style-type: none"> – Calibration with reference pressure: semiautomatic entry of linearisation table, see Operating Instructions BA00274P. – Calibration without reference pressure: manual entry of linearisation table, see Operating Instructions BA00274P. 	<ul style="list-style-type: none"> – Incorrect entries are rejected by the device – SIL mode not possible – Customised level, volume and mass units are possible 	The measured value display and the TANK CONTENT parameter show the measured value.
<ul style="list-style-type: none"> – Two measured variables are required or – The container shape is given by value pairs, such as height and volume. <p>The 1st measured variable %-height or height must be in direct proportion to the measured pressure. The 2nd measured variable volume, mass or % must not be in direct proportion to the measured pressure. A linearisation table must be entered for the 2nd measured variable. The 2nd measured variable is assigned to the 1st measured variable by means of this table.</p>	LEVEL SELECTION: Level standard/ LEVEL MODE: Height linearized	Via COMB. MEASURAND parameter: <ul style="list-style-type: none"> – Height + volume – Height + mass – Height + % – %-Height + volume – %-Height + mass – %-Height + % 	<ul style="list-style-type: none"> – Calibration with reference pressure: wet calibration and semiautomatic entry of linearisation table, see Operating Instructions BA00274P. – Calibration without reference pressure: dry calibration and manual entry of linearisation table, see Operating Instructions BA00274P. 	<ul style="list-style-type: none"> – Incorrect entries are rejected by the device – SIL mode not possible – Customised level, volume and mass units are possible 	<p>The measured value display and the TANK CONTENT parameter show the 2nd measured value (volume, mass or %).</p> <p>The LEVEL BEFORE LIN parameter displays the 1st measured value (%-height or height).</p>

6.5.3 Quick Setup menu for Level measuring mode



Note!

- Some parameters are only displayed if other parameters are appropriately configured. For example, the EMPTY CALIB. parameter is only displayed in the following cases:
 - LEVEL SELECTION "Level Easy Pressure" and CALIBRATION MODE "Wet"
 - LEVEL SELECTION "Level Standard", LEVEL MODE "Linear" and CALIBRATION MODE "WET"
- You can find the LEVEL MODE parameter in the BASIC SETTINGS function group (menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETTINGS).
- The following parameters are set to the following values in the factory:
 - LEVEL SELECTION: Level Easy Pressure
 - CALIBRATION MODE: Wet
 - OUTPUT UNIT or LIN. MEASURAND: %
 - EMPTY CALIB.: 0.0
 - FULL CALIB.: 100.0
 - SET LRV (BASIC SETTINGS group): 0.0 (corresponds to 4 mA value)
 - SET URV (BASIC SETTINGS group): 100.0 (corresponds to 20 mA value).
- The quick setup is suitable for simple and quick commissioning. If you wish to make more complex settings, e.g. change the unit from "%" to "m", you will have to calibrate using the BASIC SETTINGS group. See Operating Instructions BA00274P.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.





Fig. 27: Quick Setup menu for the Level measuring mode

On-site operation	Digital communication
Measured value display On-site display: Switch from the measured value display to GROUP SELECTION with  .	Measured value display Select QUICK SETUP menu.
GROUP SELECTION Select MEASURING MODE.	MEASURING MODE Select "Level" option.
MEASURING MODE Select "Level" option.	

On-site operation	Digital communication
LEVEL SELECTION Select level mode. For an overview see → 45.	LEVEL SELECTION Select level mode. For an overview see → 45.
GROUP SELECTION Select QUICK SETUP menu.	
POS. ZERO ADJUST Due to orientation of the device, there may be a shift in the measured value. You correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option, i. e. you assign the value 0.0 to the pressure present.	POS. ZERO ADJUST Due to orientation of the device, there may be a shift in the measured value. You correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option, i. e. you assign the value 0.0 to the pressure present.
POS. INPUT VALUE Due to orientation of the device, there may be a shift in the measured value. For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE.	POS. INPUT VALUE Due to orientation of the device, there may be a shift in the measured value. For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE.
EMPTY CALIB. ¹⁾ Enter level for the lower calibration point. For this parameter, enter a level value which is assigned to the pressure present at the device.	EMPTY CALIB. ¹⁾ Enter level for the lower calibration point. For this parameter, enter a level value which is assigned to the pressure present at the device.
FULL CALIB. ¹⁾ Enter level for the upper calibration point. For this parameter, enter a level value which is assigned to the pressure present at the device.	FULL CALIB. ¹⁾ Enter level for the upper calibration point. For this parameter, enter a level value which is assigned to the pressure present at the device.
DAMPING TIME Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.	DAMPING TIME Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.

- 1) – LEVEL SELECTION "Level Easy Pressure" and CALIBRATION MODE "Wet"
 – LEVEL SELECTION "Level Standard", LEVEL MODE "Linear" and CALIBRATION MODE "Wet"




Note!

For on-site operation, see also

- 26, "Function of the operating elements – on-site display connected" and
 → 30, "On-site operation – on-site display connected".

7 Maintenance

Keep the pressure compensation and GORE-TEX® filter (1) free from contaminations and water.



P01-PMC71xxx-17-xx-xx-xx-001

7.1 Cleaning instructions

Endress+Hauser offer flushing rings as accessories to clean process isolating diaphragms without taking the transmitters out of the process.

For further information please contact your local Endress+Hauser Sales Center.

7.1.1 PMP75

We recommend you perform CIP (cleaning in place (hot water)) before SIP (sterilization in place (steam)) for pipe diaphragm seals.

A frequent use of sterilization in place (SIP) will increase the stress on the process isolating diaphragm. Under unfavorable circumstances in the long term view we cannot exclude that a frequent temperature change could lead to a material fatigue of the process isolating diaphragm and possibly to a leakage.

7.2 Exterior cleaning

Please note the following points when cleaning the device:

- The cleaning agents used should not attack the surface and the seals.
- Mechanical damage to the process isolating diaphragm, e.g. due to pointed objects, must be avoided.
- Observe degree of protection. See therefor nameplate if necessary (→ 6).

8 Trouble-shooting

8.1 Messages

The following table lists all the possible messages that can occur.



The device differentiates between the error types "Alarm", "Warning" and "Error". You may specify whether the instrument should react as if for an "Alarm" or "Warning" for "Error" messages.

→ See "Error type/NA 64" column and Section 8.2 "Response of outputs to errors".

In addition, the "Error type/NA 64" column classifies the messages in accordance with NAMUR Recommendation NA 64:

- Break down: indicated with "B"
- Maintenance need: indicated with "C" (check request)
- Function check: indicated with "I" (in service)

Error message display on the on-site display:

- The measured value display shows the message with the highest priority. → See "Priority" column.
- The ALARM STATUS parameter shows all the messages present in descending order of priority. You can scroll through all the messages present with the -key or -key.


Message display via the digital communication:



The ALARM STATUS parameter shows the message with the highest priority.

See "Priority" column.



Note!

- If the device detects a defect in the on-site display during initialization, special error messages are generated. For the error messages →  57, "On-site display error messages".
- For support and further information, please contact Endress+Hauser Service.
- See also Section "Repair", "Repair of Ex-certified devices" and "Spare Parts".

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Pri ority
101 (A101)	Alarm B	Failure (F)	B>Sensor electronic EEPROM error	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. (→  63) This message normally only appears briefly. – Sensor defect. 	<ul style="list-style-type: none"> – Wait a few minutes. – Restart the device. Perform reset (Code 62). – Block off electromagnetic effects or eliminate source of disturbance. – Replace sensor. 	17
102 (W102)	Warning C	Maintenance request (M)	C>Checksum error in EEPROM: peakhold segment	<ul style="list-style-type: none"> – Main electronics defect. Correct measurement can continue as long as you do not need the peak hold indicator function. 	<ul style="list-style-type: none"> – Replace main electronics. 	53
106 (W106)	Warning C	Function check (C)	C>Downloading - please wait	<ul style="list-style-type: none"> – Downloading. 	<ul style="list-style-type: none"> – Wait for download to complete. 	52
110 (A110)	Alarm B	Failure (F)	B>Checksum error in EEPROM: configuration segment	<ul style="list-style-type: none"> – The supply voltage is disconnected when writing. – Electromagnetic effects are greater than specifications in the technical data. (→  63) – Main electronics defect. 	<ul style="list-style-type: none"> – Reestablish supply voltage. Perform reset (Code 7864) if necessary. Carry out calibration again. – Block off electromagnetic effects or eliminate sources of disturbance. – Replace main electronics. 	6
113 (A113)	Alarm B	Failure (F)	B>ROM failure in transmitter electronic	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	1

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
115 (E115)	Error B factory setting: Warning C	Out of specification (S)	B>Sensor overpressure	<ul style="list-style-type: none"> – Overpressure present. – Sensor defect. 	<ul style="list-style-type: none"> – Reduce pressure until message disappears. – Replace sensor. 	29
116 (W116)	Warning C	Maintenance request (M)	C>Download error, repeat download	<ul style="list-style-type: none"> – The file is defect. – During the download, the data are not correctly transmitted to the processor, e.g. because of open cable connections, spikes (ripple) on the supply voltage or electromagnetic effects. 	<ul style="list-style-type: none"> – Use another file. – Check cable connection PC – transmitter. – Block off electromagnetic effects or eliminate sources of disturbance. – Perform reset (Code 7864) and carry out calibration again. – Repeat download. 	36
120 (E120)	Error B factory setting: Warning C	Out of specification (S)	B>Sensor low pressure	<ul style="list-style-type: none"> – Pressure too low. – Sensor defect. 	<ul style="list-style-type: none"> – Increase pressure until message disappears. – Replace sensor. 	30
121 (A121)	Alarm B	Failure (F)	B>Checksum error in factory segment of EEPROM	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	5
122 (A122)	Alarm B	Failure (F)	B>Sensor not connected	<ul style="list-style-type: none"> – Cable connection sensor –main electronics disconnected. – Electromagnetic effects are greater than specifications in the technical data. (→ 63) – Main electronics defect. – Sensor defect. 	<ul style="list-style-type: none"> – Check cable connection and repair if necessary. – Block off electromagnetic effects or eliminate source of disturbance. – Replace main electronics. – Replace sensor. 	13
130 (A130)	Alarm B	Failure (F)	B>EEPROM is defect.	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	10
131 (A131)	Alarm B	Failure (F)	B>Checksum error in EEPROM: min/max segment	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	9
132 (A132)	Alarm B	Failure (F)	B>Checksum error in totalizer EEPROM	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	7
133 (A133)	Alarm B	Failure (F)	B>Checksum error in History EEPROM	<ul style="list-style-type: none"> – An error occurred when writing. – Main electronics defect. 	<ul style="list-style-type: none"> – Perform reset (Code 7864) and carry out calibration again. – Replace electronics. 	8
602 (W602)	Warning C	Funktion check (C)	C>Linearisation curve not monoton	<ul style="list-style-type: none"> – The linearisation table is not monotonic increasing or decreasing. 	<ul style="list-style-type: none"> – Add to linearisation table or perform linearisation again. 	57

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Pri ority
604 (W604)	Warning C	Funktion check (C)	C>Linearisation table not valid. Less than 2 points or points too close	<ul style="list-style-type: none"> – The linearisation table consists of less than 2 points. – At least 2 points in the linearisation table are too close together. A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN. 	<ul style="list-style-type: none"> – Add to linearisation table. If necessary, perform linearisation again. – Correct linearisation table and accept again. 	58
613 (W613)	Warning I	Funktion check (C)	I>Simulation is active	<ul style="list-style-type: none"> – Simulation is switched on, i.e. the device is not measuring at present. 	<ul style="list-style-type: none"> – Switch off simulation. 	60
620 (E620)	Error C Factory setting: Warning C	Out of specification (S)	C>Current output out of range	<ul style="list-style-type: none"> – The current is outside the permitted range 3.8 to 20.5 mA. – The pressure applied is outside the set measuring range (but within the sensor range). – Loose connection at sensor cable 	<ul style="list-style-type: none"> – Check pressure applied, reconfigure measuring range if necessary (See also Operating Instructions BA00274P, chapter 4 to 6 or these Operating Instructions) – Perform reset (Code 7864) and carry out calibration again. – Wait a short period of time and tighten the connection, or avoid loose connection. 	49
700 (W700)	Warning C	Maintenance request (M)	C>Last configuration not stored	<ul style="list-style-type: none"> – An error occurred when writing or reading configuration data or the power supply was disconnected. – Main electronics defect. 	<ul style="list-style-type: none"> – Perform reset (Code 7864) and carry out calibration again. – Replace main electronics. 	54
701 (W701)	Warning C	Funktion check (C)	C>Measuring chain config. exceeds sensor range	<ul style="list-style-type: none"> – The calibration carried out would result in the sensor nominal operating range being undershot or overshot. 	<ul style="list-style-type: none"> – Carry out calibration again. 	50
702 (W702)	Warning C	Maintenance request (M)	C>HistoROM data not consistent.	<ul style="list-style-type: none"> – Data were not written correctly to the HistoROM, e.g. if the HistoROM was detached during the writing process. – HistoROM does not have any data. 	<ul style="list-style-type: none"> – Repeat upload. – Perform reset (Code 7864) and carry out calibration again. – Copy suitable data to the HistoROM. (See also → 33, "Copying configuration data".) 	55
703 (A703)	Alarm B	Failure (F)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	22
704 (A704)	Alarm B	Funktion check (C)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	12
705 (A705)	Alarm B	Failure (F)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	21

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
706 (W706)	Warning C	Maintenance request (M)	C>Configuration in HistoROM and device not identical	<ul style="list-style-type: none"> Configuration (parameters) in the HistoROM and in the device is not identical. 	<ul style="list-style-type: none"> Copy data from the device to the HistoROM. (See also → 33, "Copying configuration data".) Copy data from the HistoROM to the device. (See also → 33, "Copying configuration data".) The message remains if the HistoROM and the device have different software versions. The message goes out if you copy the data from the device to the HistoROM. Device reset codes such as 7864 do not have any effect on the HistoROM. That means that if you do a reset, the configurations in the HistoROM and in the device may not be the same. 	59
707 (A707)	Alarm B	Funktion check (C)	B>X-VAL. of lin. table out of edit limits.	<ul style="list-style-type: none"> At least one X-VALUE in the linearisation table is either below the value for HYDR. PRESS. MIN. or MIN. LEVEL or above the value for HYDR. PRESS. MAX. or LEVEL MAX. 	<ul style="list-style-type: none"> Carry out calibration again. (See also Operating Instructions BA00274P, chapter 5 or these Operating Instructions) 	38
710 (W710)	Warning C	Funktion check (C)	B>Set span too small. Not allowed.	<ul style="list-style-type: none"> Values for calibration (e.g. lower range value and upper range value) are too close together. The sensor was replaced and the customer-specific configuration does not suit the sensor. Unsuitable download carried out. 	<ul style="list-style-type: none"> Adjust calibration to suit sensor. (See also Operating Instructions BA00274P, parameter description MINIMUM SPAN or these Operating Instructions) Adjust calibration to suit sensor. Replace sensor with a suitable sensor. Check configuration and perform download again. 	51
711 (A711)	Alarm B	Funktion check (C)	B>LRV or URV out of edit limits	<ul style="list-style-type: none"> Lower range value and/or upper range value undershoot or overshoot the sensor range limits. The sensor was replaced and the customer-specific configuration does not suit the sensor. Unsuitable download carried out. 	<ul style="list-style-type: none"> Reconfigure lower range value and/or upper range value to suit the sensor. Pay attention to position factor. Reconfigure lower range value and/or upper range value to suit the sensor. Pay attention to position factor. Replace sensor with a suitable sensor. Check configuration and perform download again. 	37
713 (A713)	Alarm B	Funktion check (C)	B>100% POINT level out of edit limits	<ul style="list-style-type: none"> The sensor was replaced. 	<ul style="list-style-type: none"> Carry out calibration again. 	39
715 (E715)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor over temperature	<ul style="list-style-type: none"> The temperature measured in the sensor is greater than the upper nominal temperature of the sensor. (See also Operating Instructions BA00274P, parameter description Tmax SENSOR or these Operating Instructions) Unsuitable download carried out. 	<ul style="list-style-type: none"> Reduce process temperature/ ambient temperature. Check configuration and perform download again. 	32

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
716 (E716)	Error B Factory setting: Alarm B	Failure (F)	B>Process isolating diaphragm broken	– Sensor defect.	– Replace Sensor. – Reduce pressure.	24
717 (E717)	Error C Factory setting: Warning C	Out of specification (S)	C>Transmitter over temperature	– The temperature measured in the electronics is greater than the upper nominal temperature of the electronics (+88 °C (+190 °F)). – Unsuitable download carried out.	– Reduce ambient temperature. – Check configuration and perform download again.	34
718 (E718)	Error C Factory setting: Warning C	Out of specification (S)	C>Transmitter under temperature	– The temperature measured in the electronics is smaller than the lower nominal temperature of the electronics (–43 °C (–45 °F)). – Unsuitable download carried out.	– Increase ambient temperature. Insulate device if necessary. – Check configuration and perform download again.	35
719 (A719)	Alarm B	Funktion check (C)	B>Y-VAL of lin. table out of edit limits	– At least on Y-VALUE in the linearisation table is below the MIN. TANK CONTANT or above the MAX. TANK CONTENT.	– Carry out calibration again. (See also Operating Instructions BA00274P, chapter 5 or these Operating Instructions)	40
720 (E720)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor under temperature	– The temperature measured in the sensor is smaller than the lower nominal temperature of the sensor. (See also Operating Instructions BA00274P, parameter description Tmin SENSOR or Operating Instructions) – Unsuitable download carried out. – Loose connection at sensor cable	– Increase process temperature/ ambient temperature. – Check configuration and perform download again. – Wait a short period of time and tighten the connection, or avoid loose connection.	33
721 (A721)	Alarm B	Funktion check (C)	B>ZERO POSITION level out of edit limits	– LEVEL MIN or LEVEL MAX has been changed.	– Perform reset (Code 2710) and carry out calibration again.	41
722 (A722)	Alarm B	Funktion check (C)	B>EMPTY CALIB. or FULL CALIB. out of edit limits	– LEVEL MIN or LEVEL MAX has been changed.	– Perform reset (Code 2710) and carry out calibration again.	42
723 (A723)	Alarm B	Funktion check (C)	B>MAX. FLOW out of edit limits	– FLOW-MEAS. TYPE has been changed.	– Carry out calibration again.	43
725 (A725)	Alarm B	Failure (F)	B>Sensor connection error, cycle disturbance	– Electromagnetic effects are greater than specifications in the technical data. (→ See Section 9.) – Setscrew loose. – Sensor or main electronics defect.	– Block off electromagnetic effects or eliminate source of disturbance. – Retighten setscrew with 1 Nm (0,74 lbf ft) (see Chap. 3.3.8). – Replace sensor or main electronics.	25

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
726 (E726)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor temperature error - overrange	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. (→ 63) – Process temperature is outside permitted range. – Sensor defect. 	<ul style="list-style-type: none"> – Block off electromagnetic effects or eliminate source of disturbance. – Check temperature present, reduce or increase if necessary. – If the process temperature is within the permitted range, replace sensor. 	31
727 (E727)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor pressure error - overrange	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. (→ 63) – Pressure is outside permitted range. – Sensor defect. 	<ul style="list-style-type: none"> – Block off electromagnetic effects or eliminate source of disturbance. – Check pressure present, reduce or increase if necessary. – If the pressure is within the permitted range, replace sensor. 	28
728 (A728)	Alarm B	Failure (F)	B>RAM error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	2
729 (A729)	Alarm B	Failure (F)	B>RAM error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	3
730 (E730)	Error C Factory setting: Warning C	Out of specification (S)	C>LRV user limits exceeded	<ul style="list-style-type: none"> – Pressure measured value has undershot the value specified for the Pmin ALARM WINDOW parameter. – Loose connection at sensor cable 	<ul style="list-style-type: none"> – Check system/pressure measured value. – Change value for Pmin ALARM WINDOW if necessary. (See also Operating Instructions BA00274P, parameter description Pmin ALARM WINDOW or these Operating Instructions) – Wait a short period of time and tighten the connection, or avoid loose connection. 	46
731 (E731)	Error C Factory setting: Warning C	Out of specification (S)	C>URV user limits exceeded	<ul style="list-style-type: none"> – Pressure measured value has overshoot the value specified for the Pmax ALARM WINDOW parameter. – Loose connection at sensor cable 	<ul style="list-style-type: none"> – Check system/pressure measured value. – Change value for Pmax ALARM WINDOW if necessary. (See also Operating Instructions BA00274P, parameter description Pmax ALARM WINDOW or these Operating Instructions) – Wait a short period of time and tighten the connection, or avoid loose connection. 	45
		Out of specification (S)	C>LRV Temp. User limits exceeded	<ul style="list-style-type: none"> – Temperature measured value has undershot the value specified for the Tmin ALARM WINDOW parameter. 	<ul style="list-style-type: none"> – Check system/temperature measured value. – Change value for Tmin ALARM WINDOW if necessary. (See also Operating Instructions BA00274P, parameter description Tmin ALARM WINDOW or these Operating Instructions) 	
732 (E732)	Error C Factory setting: Warning C		C>LRV Temp. User limits exceeded	<ul style="list-style-type: none"> – Temperature measured value has undershot the value specified for the Tmin ALARM WINDOW parameter. 	<ul style="list-style-type: none"> – Check system/temperature measured value. – Change value for Tmin ALARM WINDOW if necessary. (See also Operating Instructions BA00274P, parameter description Tmin ALARM WINDOW or these Operating Instructions) 	48
733 (E733)	Error C Factory setting: Warning C	Out of specification (S)	C>URV Temp. User limits exceeded	<ul style="list-style-type: none"> – Temperature measured value has overshoot the value specified for the Tmax ALARM WINDOW parameter. 	<ul style="list-style-type: none"> – Check system/temperature measured value. – Change value for Tmax ALARM WINDOW if necessary. (See also Operating Instructions BA00274P, parameter description Tmax ALARM WINDOW or these Operating Instructions) 	47

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
736 (A736)	Alarm B	Failure (F)	B>RAM error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	4
737 (A737)	Alarm B	Failure (F)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	20
738 (A738)	Alarm B	Failure (F)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	19
739 (A739)	Alarm B	Failure (F)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	23
740 (E740)	Error C Factory setting; Warning C	Maintenance request (M)	C>Calculation overflow, bad configuration, hardware defect	<ul style="list-style-type: none"> – Level measuring mode: the measured pressure has undershot the value for HYDR. PRESS. MIN. or overshot the value for HYDR. PRESS. MAX. – Level measuring mode: The measured level did not reach the LEVEL MIN value or exceeded the LEVEL MAX value. – Flow measuring mode: the measured pressure has undershot the value for MAX. PRESS. FLOW. 	<ul style="list-style-type: none"> – Check configuration and carry out calibration again if necessary. – Select a device with a suitable measuring range. – Check configuration and carry out calibration again if necessary. (See also Operating Instructions BA00274P, parameter description LEVEL MIN. these Operating Instructions) – Check configuration and carry out calibration again if necessary. – Select a device with a suitable measuring range. 	27
741 (A741)	Alarm B	Funktion check (C)	B>TANK HEIGHT out of edit limits	<ul style="list-style-type: none"> – LEVEL MIN or LEVEL MAX has been changed. 	<ul style="list-style-type: none"> – Perform reset (Code 2710) and carry out calibration again. 	44
742 (A742)	Alarm B	Failure (F)	B>Sensor connection error (upload)	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. (→ 63) This message normally only appears briefly. – Cable connection sensor –main electronics disconnected. – Sensor defect. 	<ul style="list-style-type: none"> – Wait a few minutes. – Perform reset (Code 7864) and carry out calibration again. – Check cable connection and repair if necessary. – Replace sensor. 	18
743 (E743)	Alarm B	Failure (F)	B>Electronic PCB error during initialisation	<ul style="list-style-type: none"> – This message normally only appears briefly. – Main electronics defect. 	<ul style="list-style-type: none"> – Wait a few minutes. – Restart the device. Perform reset (Code 62). – Replace main electronics. 	14
744 (A744)	Alarm B	Failure (F)	B>Main electronic PCB error	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. (→ 63) – Main electronics defect. 	<ul style="list-style-type: none"> – Restart the device. Perform reset (Code 62). – Block off electromagnetic effects or eliminate source of disturbance. – Replace main electronics. 	11
745 (W745)	Warning C	Maintenance request (M)	C>Sensor data unknown	<ul style="list-style-type: none"> – Sensor does not suit the device (electronic sensor nameplate). Device continues measuring. 	<ul style="list-style-type: none"> – Replace sensor with a suitable sensor. 	56

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
746 (W746)	Warning C	Funktion check (C)	C>Sensor connection error - initialising	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. (→ 63) This message normally only appears briefly. – Overpressure or low pressure present. 	<ul style="list-style-type: none"> – Wait a few minutes. – Restart the device. Perform reset (Code 7864). – Block off electromagnetic effects or eliminate source of disturbance. – Reduce or increase pressure. 	26
747 (A747)	Alarm B	Failure (F)	B>Sensor software not compatible to electronics	<ul style="list-style-type: none"> – Sensor does not suit the device (electronic sensor nameplate). 	<ul style="list-style-type: none"> – Replace sensor with a suitable sensor. 	16
748 (A748)	Alarm B	Failure (F)	B>Memory failure in signal processor	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. (→ 63) – Main electronics defect. 	<ul style="list-style-type: none"> – Block off electromagnetic effects or eliminate source of disturbance. – Replace main electronics. 	15



8.1.1 On-site display error messages

If the device detects a defect in the on-site display during initialization, the following error messages can be displayed:

Message	Measure
Initialization, VU Electr. Defect A110	Exchange on-site display.
Initialization, VU Electr. Defect A114	
Initialization, VU Electr. Defect A281	
Initialization, VU Checksum Err. A110	
Initialization, VU Checksum Err. A112	
Initialization, VU Checksum Err. A171	

8.2 Response of outputs to errors

The device differentiates between the error types Alarm, Warning and Error. See the following table and → 49, "Messages".

Output	A (Alarm)	W (Warning)	E (Error: Alarm/Warning)
Current output	Assumes the value specified via the OUTPUT FAIL MODE ¹⁾ , ALT. CURR. OUTPUT ¹ and SET MAX. ALARM ¹ parameter. See also the following section "Configuring current output for an alarm".	Device continues measuring.	For this error, you can enter whether the device should react as in the event of an alarm or as in the event of a warning. See corresponding "Alarm" or "Warning" column. (See also Operating Instructions BA00274P, parameter description SELECT ALARM TYPE or these Operating Instructions)
Bargraph (on-site display)	The bargraph adopts the value defined by the OUTPUT FAIL MODE ¹ parameter.	The bargraph adopts the value which corresponds to the current value.	See this table, "Alarm" or "Warning" column, depending on selection.
On-site display	<ul style="list-style-type: none"> – The measured value and message are displayed alternately – Measured value display: -symbol is permanently displayed. <p>Message display</p> <ul style="list-style-type: none"> – 3-digit number such as A122 and description 	<ul style="list-style-type: none"> – The measured value and message are displayed alternately – Measured value display: -symbol flashes. <p>Message display:</p> <ul style="list-style-type: none"> – 3-digit number such as W613 and description 	<ul style="list-style-type: none"> – The measured value and message are displayed alternately – Measured value display: see corresponding "Alarm" or "Warning" column <p>Message display:</p> <ul style="list-style-type: none"> – 3-digit number such as E731 and description
Remote operation (digital communication)	In the case of an alarm, the ALARM STATUS ²⁾ parameter displays a 3-digit number such as 122 for "Sensor not connected".	In the case of a warning, the ALARM STATUS ²⁾ parameter displays a 3-digit number such as 613 for "Simulation is active".	In the case of an error, the ALARM STATUS ²⁾ parameter displays a 3-digit number such as 731 for "URV user limits exceeded".

1) Menu path: (GROUP SELECTION →) OPERATING MENU → OUTPUT

2) Menu path: (GROUP SELECTION →) OPERATING MENU → MESSAGES

8.2.1 Configuring current output for an alarm

You can configure the current output for the event of an alarm by means of the OUTPUT FAIL MODE, ALT. CURR. OUTPUT and SET MAX. ALARM parameters. These parameters are displayed in the OUTPUT group (menu path: (GROUP SELECTION →) OPERATING MENU → OUTPUT).

In the event of an alarm, the current and the bargraph assume the value entered with the OUTPUT FAIL MODE parameter.




Fig. 28: Current output in the event of an alarm

Options:

- 1 Max. alarm (110%): can be set between 21 to 23 mA via the SET MAX. ALARM parameter
- 2 Hold meas. value: last measured value is kept
- 3 Min. alarm (-10%): 3.6 mA

Factory setting:

- OUTPUT FAIL MODE: Max. Alarm (110%)
- SET MAX. ALARM: 22 mA

Use the ALT. CURR. OUTPUT parameter to set the current output value for the error messages E 120 "Sensor low pressure" and E 115 "Sensor overpressure". You have the following options:

- Normal: the current output assumes the value set via the OUTPUT FAIL MODE and SET MAX. ALARM parameters.
- Special
 - Lower sensor limit undershot (E 120 "Sensor low pressure"): 3.6 mA
 - Upper sensor limit overshoot (E 115 "Sensor overpressure") overshoot: current output assumes the value set via the SET MAX ALARM parameter.

Attention : when using the case "special", the behavior is limited to an over/underpressure in a range LRL -10% up to LRL -30% and URL +10% up to URL +30%.

Factory setting:




ALT. CURR. OUTPUT: normal

8.3 Confirming messages


Depending on the settings for the ALARM DISPL. TIME and ACK. ALARM MODE parameters, the following measures should be taken to clear a message:

Settings ¹⁾	Measures
<ul style="list-style-type: none"> – ALARM DISPL. TIME = 0 s – ACK. ALARM MODE = off 	<ul style="list-style-type: none"> – Rectify cause of the message (→ 49).
<ul style="list-style-type: none"> – ALARM DISPL. TIME > 0 s – ACK. ALARM MODE = off 	<ul style="list-style-type: none"> – Rectify cause of the message (→ 49). – Wait for the alarm display time to elapse.
<ul style="list-style-type: none"> – ALARM DISPL. TIME = 0 s – ACK. ALARM MODE = on 	<ul style="list-style-type: none"> – Rectify cause of the message (→ 49). – Confirm message using ACK. ALARM parameter.
<ul style="list-style-type: none"> – ALARM DISPL. TIME > 0 s – ACK. ALARM MODE = on 	<ul style="list-style-type: none"> – Rectify cause of the message (→ 49). – Confirm message using ACK. ALARM parameter. – Wait for the alarm display time to elapse. If a message appears and the alarm display time elapses before the message has been acknowledged, the message will be cleared once it has been acknowledged.

1) Menu path for ALARM DISPL. TIME and ACK. ALARM MODE: (GROUP SELECTION →) OPERATING MENU → DIAGNOSTICS → MESSAGES

If the on-site display displays a message, you can suppress it with the -key. If there are several messages, the on-site display shows the message which has the highest priority (→ 49). Once you have suppressed this message using the -key, the message with the next highest priority is displayed. You can use the -key to suppress each message, one after the other. The ALARM STATUS parameter continues to display all the messages present.

8.4 Repair

The Endress+Hauser repairs concept provides for measuring devices to have a modular design and also the customer may carry out repairs (→  60, "Spare Parts").



Note!

- For certified devices, please consult Chapter "Repair of Ex-certified devices".
- For more information on service and spare parts contact the Endress+Hauser Service.
See www.endress.com/worldwide.

8.5 Repair of Ex-certified devices



Warning!

When repairing Ex-certified devices, please note the following:

- Only specialist personnel or Endress+Hauser may undertake repairs of certified devices.
- Relevant standards, national hazardous area regulations and Safety Instructions and Certificates must be observed.
- Only genuine Endress+Hauser spare parts may be used.
- When ordering spare parts, please check the device designation on the nameplate. Identical parts may only be used as replacements.
- Electronic inserts or sensors already in use in a standard instrument may not be used as spare parts for a certified device.
- Carry out repairs according to the instructions. After repairs, the device must fulfil the requirements of the specified individual tests.
- A certified device may only be converted into another certified variant by Endress+Hauser.
- All repairs and modifications must be documented.

8.6 Spare Parts

- Some replaceable measuring device components are identified by means of a spare part nameplate. This contains information about the spare part.
- All the spare parts for the measuring device along with the order code are listed in the W@M Device Viewer (www.endress.com/deviceviewer) and can be ordered. If available, users can also download the associated Installation Instructions.



Note!

Measuring device serial number:

- Located on the device and spare part nameplate.
- Can be read out via the "DEVICE SERIAL No" parameter in the "TRANSMITTER DATA" submenu.

8.7 Return

The measuring device must be returned if repairs or a factory calibration are required, or if the wrong measuring device has been ordered or delivered. According to legal regulations, Endress+Hauser, as a ISO-certified company, is required to follow certain procedures when handling returned products that are in contact with process fluids.

To ensure swift, safe and professional device returns, please read the return procedures and conditions on the Endress+Hauser website at www.services.endress.com/return-material.

8.8 Disposal

When disposing, separate and recycle the device components based on the materials.

8.9 Software history

Date	Software version	Changes software	Documentation	
			Operating Instructions	Description of Instrument Functions
11.2003	01.00.zz	Original software. Compatible with: – ToF Tool Field Tool Package, version 1.04.00 or higher – Commuwin II version 2.08.-1, Update G or higher – HART Communicator 375 with Device Rev.: 10, DD Rev.: 1	BA271P/00/EN/10.03 52020517	—
06.2004	02.00.zz	– Number of parameters in the Quick Setup menus has been reduced. – On-site operation: LANGUAGE and MEASURING MODE parameters have been moved to the top level. – New SAFETY CONFIRM. group implemented for SIL. → See also SD00190P Safety Manual Cerabar S. – MEASURING MODE "Level", LEVEL MODE "Linear": AREA UNIT and TANK SECTION parameters have been replaced with the TANK VOLUME and TANK HEIGHT parameters. – Function of the UNIT FLOW parameter has been split across four parameters. – Function of the SIMULATED VALUE parameter has been split across six parameters. – SENSOR TRIM and CURRENT TRIM groups have been removed. – Sensor adapt reset, code 1209 and sensor calibration reset, code 2509 have been removed. – Quick Setup menus are available via ToF Tool. Compatible with: – ToF Tool Field Tool Package version 2.00.00 or higher – Commuwin II version 2.08.-1, Update > G – HART Communicator 375/475 with Device Rev.: 20, DD Rev.: 1	BA271P/00/EN/05.04 52022795	BA274P/00/EN/05.04 52021469
06.2005	02.01.zz	– Operating keys also integrated on the optional on-site display. – Chinese and Japanese are available as the menu language on request. Compatible with: – ToF Tool Field Tool Package version 3.00.00 or higher – FieldCare version 2.01.00, DTM Library version 2.06.00, DTM: Deltabar S/MD7x/V02.00 V 1.4.98.74* – HART Communicator 375/475 with Device Rev.: 20, DD Rev.: 1* * Menu languages Chinese and Japanese not selectable	BA271P/00/EN/06.05 71000115	BA274P/00/EN/05.04 52021469
			BA271P/00/EN/11.05 71009589	BA274P/00/EN/05.04 52021469

Date	Software version	Changes software	Documentation	
			Operating Instructions	Description of Instrument Functions
06.2006	02.10.zz	<ul style="list-style-type: none"> – New "Level Easy Pressure" and "Level Easy Height" level modes implemented. New LEVEL SELECTION parameter implemented. – OPERATION group with DOWNLOAD SELECT parameter extended. – SAFETY CONFIRM group extended for the "Level" operating mode in the "Level Easy Pressure" level selection. → See also SD00190P Safety Manual Cerabar S. – Factory setting for the "Error" messages redefined. – Chinese and Japanese included as menu languages by default. <p>Compatible with:</p> <ul style="list-style-type: none"> – ToF Tool Field Tool Package version 4.0 – FieldCare version 2.02.00 – HART Communicator 375/475 with Device Rev.: 21, DD Rev.: 1 	BA271P/00/EN/07.06 71027246	BA274P/00/EN/07.06 71027249
			BA271P/00/EN/08.06 71027246	BA274P/00/EN/07.06 71027249
			BA271P/00/EN/10.07 71043296	BA274P/00/EN/07.07 71061022
			BA271P/00/EN/12.07 71043296	BA274P/00/EN/07.07 71061022
			BA271P/00/EN/05.08 71071770	BA274P/00/EN/05.08 71071855
			BA271P/00/EN/08.08 71077544	BA274P/00/EN/05.08 71071855
			BA271P/00/EN/06.09 71095434	BA274P/00/EN/06.09 71095452
			BA271P/00/EN/05.10 71111792	BA274P/00/EN/05.10 71118244
			BA00271P/00/EN/13.11 71139779	BA00274P/00/EN/13.11 71139795
			BA00271P/00/EN/14.12 71161896	BA00274P/00/EN/13.11 71139795
01.2013	02.11.zz	<p>"Russian" is included as a menu language by default. The menu language "Nederlands" is no longer supported.</p>	BA00271P/00/EN/15.13 71204567	BA00274P/00/EN/14.13 71204628
			BA00271P/00/EN/16.14 71254295	BA00274P/00/EN/15.14 71254474
06.2014	02.20.zz	HART7 protocole revision has been implemented.	BA00271P/00/EN/17.14 71260306	BA00274P/00/EN/16.14 71260321
			BA00271P/00/EN/18.14 71270361	BA00274P/00/EN/17.14 71270402

9 Technical data

For technical data, please refer to TI00383P.

Index

Numerics

4...20 mA test signal. 21

A

Alarm messages 49

C

Cable specification 21

Commubox FXA195 anschließen 23

Connecting Commubox FXA291 23

Connecting ToF Adapter FXA291 23

D

Diaphragm seals, installation instructions 12

Diaphragm seals, vacuum application 13

Display. 24

E

Electrical connection 19

Error messages. 49

F

Factory setting 38

FieldCare 36

H

Hazardous areas 4

Heat insulation. 14

HistoROM/M-DAT 32

I

Incoming acceptance 9

Installation instructions for devices with diaphragm seals. . 12

Installation instructions for devices without diaphragm seals 9

L

Language, selection 40

Level measurement 44–45

Level measurement, Quick Setup menu 46

Load 22

Locking operation. 37

M

Measuring arrangement for level measurement. 12

Measuring arrangement for pressure measurement . . . 10–11

Measuring mode, selection. 40

N

Nameplate 6

O

On-site display 24

Operating elements, function, with on-site display 26

Operating elements, position 25

Operating keys, function, without on-site display 26

Operating keys, position 25

Operating menu. 30

Overvoltage protection. 23

P

Pipe mounting 15

Position adjustment 41

Potential matching 22–23

Pressure measurement 42

Pressure measurement, Quick Setup menu 42

Q

Quick Setup menu level 46

Quick Setup menu pressure 42

R

Repair. 60

Repair of Ex-certified devices 60

Reset 38

Returning devices. 60

Rotating the housing. 18

S

Scope of delivery. 8

Screening 22

Separate housing, assemble and mount 16

Service Interface FXA291 23

SIL3 4

Software history 61

Spare Parts 60

Storage. 9

Supply voltage 21

T

Temperature isolator, installation instructions 13

Trouble-shooting 49

U

Unlocking operation 37

W

Wall mounting 15

Warnings 49

Welding recommendation. 17

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation





Level



Pressure



Flow



Temperature



Liquid
Analysis



Registration



Systems
Components



Services



Solutions


Operating Instructions – Description of Instrument Functions

Cerabar S **PMC71, PMP71/75**

Deltabar S **FMD77, FMD78, PMD75**

Deltapilot S **FMB70**

Process pressure / Differential pressure, Flow / Hydrostatic



BA00274P/00/EN/17.14
71270402

valid from Software version:
02.20.zz

Endress+Hauser

People for Process Automation




Table of contents

1	Notes on use	4
1.1	Finding parameter description using ID numbers	4
1.2	Finding function group using graphic representation	4
1.3	Finding parameter description using parameter names (index)	4
2	Finding parameter description using ID numbers	5
3	Graphic representation of function groups	10
4	Pressure measurement	11
4.1	Calibration with reference pressure	11
4.2	Calibration without reference pressure	12
5	Level measurement	14
5.1	Overview of level measurement	14
5.2	"Level Easy Pressure" level selection	15
5.3	"Level Easy Height" level selection	19
5.4	"Level Standard" level selection, "Linear" level type	24
5.5	"Level Standard" level selection, "Pressure Linearized" level type	28
5.6	"Level Standard" level selection, "Height Linearized" level type	33
6	Flow measurement	40
6.1	Calibration	40
6.2	Totalizers	43
7	Description of parameters	44
8	Trouble-shooting	132
8.1	Messages	132
8.2	Response of outputs to errors	141
8.3	Confirming messages	142
9	Appendix	142
9.1	Operating menu for on-site display, Digital communication	142
Index		151

1 Notes on use

Section 7 describes all the parameters in order of how they appear in the menu. Sections 4 to 6 provide typical examples of configuration.

Sections 1.1 to 1.3 describe ways of finding a certain parameter description more easily.

1.1 Finding parameter description using ID numbers

Each parameter is shown on the on-site display with a unique identification number (ID). Section 2 lists all the parameters in numerical order. The page reference/link takes you to the parameter in question.

In the Operating program, additional parameters and, to an extent, other parameters are displayed. These parameters are not listed in Section 2. You can find these parameters by means of the index.

→ See also Section 1.3.

1.2 Finding function group using graphic representation

All the function groups are shown in table form in Section 3. The page reference/link takes you to the function group in question. In Section 7, all the parameters of a function group are compiled in a table.

1.3 Finding parameter description using parameter names (index)

The index lists all the parameters in alphabetical order. The page reference/link takes you to the parameter in question.

2 Finding parameter description using ID numbers

ID number	Parameter name	Description, see page
001	DENSITY UNIT – Level Selection "Level Easy Pressure"	64 or 97
003	HEIGHT UNIT	64
004	FULL CALIB. – QUICK SETUP	51
004	FULL CALIB. – Level Selection "Level Easy Pressure"	61
004	FULL CALIB. – Level Selection "Level Easy Height"	65
005	FULL PRESSURE	61
006	FULL HEIGHT	66
007	ADJUST DENSITY – Level Selection "Level Easy Height"	64 or 97
008	CALIBRATION MODE – Level Selection "Level Easy Pressure"	60
008	CALIBRATION MODE – Level Selection "Level Easy Height"	64
009	EMPTY HEIGHT	65
010	EMPTY CALIB. – QUICK SETUP	50
010	EMPTY CALIB. – Level Selection "Level Easy Pressure"	60 or 61
010	EMPTY CALIB. – Level Selection "Level Easy Height"	65
011	EMPTY PRESSURE	61
012	SET URV – Level Selection "Level Easy Pressure"	61
012	SET URV – Level Selection "Level Easy Height"	66
013	SET LRV – Level Selection "Level Easy Pressure"	61
013	SET LRV – Level Selection "Level Easy Height"	66
014	DOWNLOAD SELECT	126
015	FULL PRESSURE	See ¹⁾
016	EMPTY PRESSURE	See ¹⁾
017	FULL CALIB.	See ¹⁾
018	EMPTY CALIB.	See ¹⁾
020	LEVEL SELECTION	46
021	SET LRV	See ¹⁾
022	SET URV	See ¹⁾
023	OUTPUT UNIT – Level Selection "Level Easy Pressure"	60
023	OUTPUT UNIT – Level Selection "Level Easy Height"	64
025	PROCESS DENSITY – Level Selection "Level Easy Pressure"	97
036	PREAMBLE NUMBER	115
042	CURR. TRIM 20mA	131
043	OFFSET 4mA TRIM	131
044	OFFSET 20mA TRIM	131
045	CURR. TRIM 4mA	131
046	ALARM STATUS	128
047	ENTER RESET CODE	126
048	INSERT PIN No	126
050	LEVEL BEFORE LIN	123
055	CUST. TAG NUMBER	117
060	PRESS. ENG. UNIT	56, 59, 63, 67 or 92
075	CUSTOMER UNIT P	56, 59, 63, 68 or 92
079	LANGUAGE	44
245	SET LRV – "Pressure" measuring mode	48 or 56
246	SET URV – "Pressure" measuring mode	48 or 57
247	DAMPING VALUE	48, 51, 53, 57, 61, 66, 77, 81, 90 or 95
250	SENSOR SER. No.	119
251	Pmin SENS. DAMAGE	120
252	Pmax SENS. DAMAGE	120
254	OUTPUT CURRENT	111
264	SOFTWARE VERSION	117
266	HARDWARE REV.	117
270	SIM. CURRENT	128
271	HART MESSAGE	116
272	ADDITIONAL INFO.	117
301	PRESSURE – "Pressure" measuring mode	122
	PRESSURE – "Level" measuring mode	122
	PRESSURE – "Flow" measuring mode	123
305	LONG TAG NUMBER	117

1) See Safety Manual SD00189P for Deltabar S, SD00190P for Cerabar S and SD00213P for Deltapilot S.

ID number	Parameter name	Description, see page
309	GET LRV	57
310	GET URV	57
311	MAX. FLOW	52 or 95
313	UNIT VOLUME – "Linear" level type UNIT VOLUME – "Pressure Linearized" level type UNIT VOLUME – "Height Linearized" level type	71 or 75 79 84
314	EMPTY CALIB. – QUICK SETUP EMPTY CALIB. – "Linear" level type EMPTY CALIB. – "Height Linearized" level type	50 73 87
315	FULL CALIB. – QUICK SETUP FULL CALIB. – "Pressure Linearized" level type FULL CALIB. – "Height Linearized" level type	51 74 87
316	ADJUST DENSITY – "Linear" level type ADJUST DENSITY – "Height Linearized" level type ADJUST DENSITY – "Level" extended setup	74 88 97
317	CUST. UNIT FACT. P	56, 68 or 93
318	TEMP. ENG. UNIT – "Pressure" measuring mode TEMP. ENG. UNIT – "Level" measuring mode TEMP. ENG. UNIT – "Flow" measuring mode	96 97 99
319	CALIB. OFFSET	54
323	SET. L. FL. CUT-OFF	99
329	FACT. U. U. TOTAL. 1	108
330	FACT. U. U. TOTAL. 2	109
331	RESET TOTALIZER1	109
332	Pmin ALARM WINDOW	130
333	Pmax ALARM WINDOW	130
334	Tmin ALARM WINDOW	130
335	Tmax ALARM WINDOW	130
336	ALARM DELAY	129
339	DISPLAY CONTRAST	111
342	SET MAX. ALARM	113
343	SET MIN. CURRENT	113
345	BUS ADDRESS	115
350	DEVICE DESIGN.	117
351	DEVICE TYPE, Deltabar S	115
352	CONFIG RECORDER	117
354	DEVICE SERIAL No	117
357	PCB TEMPERATURE	117
358	ALLOWED MIN. TEMP	117
359	ALLOWED MAX. TEMP	117
360	MAT. PROC. CONN. +	118
361	MAT. PROC. CONN. –	118
362	SEAL TYPE	118
363	DIP STATUS	117
365	MAT. MEMBRANE	120
366	FILLING FLUID	120
367	SENSOR TEMP.	122 or 123
368	Tmin SENSOR	120
369	Tmax SENSOR	120
370	TANK CONTENT	123
375	SUPPRESSED FLOW	123
378	MEAS. VAL. TREND	122 or 123
380	COUNTER:P > Pmax	124
382	RESET PEAKHOLD	125
383	MAX. MEAS. PRESS.	124
386	ELECTR. SERIAL No	117
388	OUTPUT FAIL MODE	112
389	MEASURING MODE	45
390	LINEAR/SQROOT	113
391	UNIT FLOW	93
392	CALIBRATION MODE – "Linear" level type CALIBRATION MODE – "Height Linearized" level type	73 87
397	LIN. EDIT MODE	101
398	TOTALIZER 1 UNIT – "Volume p. cond." flow type	108
399	TOTALIZER 2 UNIT – "Volume p. cond." flow type	109
400	NEG. FLOW TOT. 1	108
401	ACK. ALARM MODE	128

ID number	Parameter name	Description, see page
404	COUNTER:T > Tmax	124
409	OPERATING HOURS	126
413	SIMULATION MODE	127
414	SIM. PRESSURE	127
416	NEG. FLOW TOT. 2	109
419	MENU DESCRIPTOR	110
423	ALTERNATE DATA	110
432	MANUFACTURER ID	116
434	CORRECTED PRESS. – "Pressure" measuring mode	122
	CORRECTED PRESS. – "Level" measuring mode	122
	CORRECTED PRESS. – "Flow" measuring mode	123
442	LOW FLOW CUT-OFF	99
467	COUNTER:P < Pmin	124
469	MIN. MEAS. PRESS.	124
471	MAX. MEAS. TEMP.	124
472	COUNTER:T < Tmin	124
474	MIN. MEAS. TEMP.	124
476	SIM. ERROR NO.	128
480	ALARM DISPL. TIME	129
481	HART DATE	116
482	PROC. CONN. TYPE	118
484	PRESS. SENS LOLIM	119
485	PRESS. SENS HILIM	119
487	SENS H/WARE REV	120
488	PCB COUNT:T > Tmax	124
490	PCB MAX. TEMP.	124
492	PCB COUNT:T < Tmin	124
494	PCB MIN. TEMP.	124
500	ACK. ALARM	129
052	CURRENT MODE	115
549	MEASURING TABLE (display)	103
549	EDITOR TABLE, LINE-NUMB (enter values)	102
550	EDITOR TABLE, X-VAL. (enter values)	102
551	EDITOR TABLE, Y-VAL. (enter values)	102, 102
563	POS. INPUT VALUE	48, 50 or 54
564	LAST DIAG. CODE	128
570	Pmax PROC. CONN.	117
571	MASS FLOW UNIT	94
581	SENSOR MEAS. TYPE	120
584	SENSOR PRESSURE – "Pressure" measuring mode	122
	SENSOR PRESSURE – "Level" measuring mode	122
	SENSOR PRESSURE – "Flow" measuring mode	123
585	HART VERSION	114
591	MINIMUM SPAN	119
595	SELECT ALARMTYPE	129
597	ALT. CURR. OUTPUT	113
600	SELECT ALARMTYPE	129
603	RESET ALL ALARMS	129
607	CUST. UNIT FACT. V – "Linear" level type	72
	CUST. UNIT FACT. V – "Pressure Linearized" level type	79
	CUST. UNIT FACT. V – "Height Linearized" level type	85
608	CUSTOMER UNIT V – "Linear" level type	71
	CUSTOMER UNIT V – "Pressure Linearized" level type	79
	CUSTOMER UNIT V – "Height Linearized" level type	85
609	CUST. UNIT FACT. F	95
610	CUSTOMER UNIT F	94
627	TOT. 1 USER UNIT	108
628	TOT. 2 USER UNIT	109
634	MAX PRESS. FLOW	53 or 95
637	SET LRV – "Flow" extended setup	99
638	SET URV – "Flow" extended setup	100
639	SIM.FLOW VALUE	127
640	FLOW-MEAS. TYPE	93
652	TOTALIZER 1	124
655	TOTAL. 1 OVERFLOW	124
657	TOTALIZER 2	124
658	TOTAL. 2 OVERFLOW	124
660	STD. FLOW UNIT	94

661	NORM FLOW UNIT	93
ID number	Parameter name	Description, see page
662	TOTALIZER 1 UNIT – "Mass" flow type	108
663	TOTALIZER 2 UNIT – "Mass" flow type	109
664	TOTALIZER 1 UNIT – "Gas. std. conditions" flow type	108
665	TOTALIZER 2 UNIT – "Gas. std. conditions" flow type	109
666	TOTALIZER 1 UNIT – "Gas. norm conditions" flow type	108
667	TOTALIZER 2 UNIT – "Gas. norm conditions" flow type	109
679	MEASURED VALUE – "Pressure"	121
	MEASURED VALUE – "Level"	122
	MEASURED VALUE – "Flow"	123
685	POS. ZERO ADJUST	48, 50, 52 or 54
688	MAIN DATA FORMAT	110
694	CURR. CHARACT. – "Pressure"	112
695	CURR. CHARACT. – "Flow"	112
696	CURR. CHARACT. – "Height"	112
699	DEVICE REVISION	115
703	CUST. UNIT FACT. M – "Linear" level type	73
	CUST. UNIT FACT. M – "Pressure Linearized" level type	80
	CUST. UNIT FACT. M – "Height Linearized" level type	86
704	CUSTOMER UNIT M – "Linear" level type	72
	CUSTOMER UNIT M – "Pressure Linearized" level type	80
	CUSTOMER UNIT M – "Height Linearized" level type	86
705	CUST. UNIT FACT. H – "Linear" level type	71 or 76
	CUST. UNIT FACT. H – "Height Linearized" level type	84 or 89
706	CUSTOMER UNIT H – "Linear" level type	70 or 76
	CUSTOMER UNIT H – "Height Linearized" level type	84 or 89
708	HEIGHT UNIT – "Linear" level type	70 or 76
	HEIGHT UNIT – "Height Linearized" level type	83 or 88
709	MASS UNIT – "Linear" level type	72
	MASS UNIT – "Pressure Linearized" level type	80
	MASS UNIT – "Height Linearized" level type	85
710	EMPTY PRESSURE – "Linear" level type	74
	EMPTY PRESSURE – "Height Linearized" level type	87
711	FULL PRESSURE – "Linear" level type	74
	FULL PRESSURE – "Height Linearized" level type	87
712	LEVEL MAX	86
713	TANK CONTENT MAX	101
714	SIM. LEVEL	127
715	SIM. TANK CONT.	128
717	MEASURING TABLE (selection)	103
718	LEVEL MODE	68
719	SET LRV – "Level" basic setup	77
720	SET URV – "Level" basic setup	77
755	LEVEL MIN	86
759	TANK CONTENT MIN	101
760	ASSIGN CURRENT	113
761	HYDR. PRESS MAX.	81
762	SET LRV – "Level" extended setup	98
763	SET URV – "Level" extended setup	98
764	CURR. CHARACT. – "Tank content"	112
770	EDITOR TABLE (continue entry)	103
775	HYDR. PRESS MIN.	80
802	DEVICE TYPE, Cerabar S	115
804	LIN. MEASURAND	70
805	LINd. MEASURAND	79
806	COMB. MEASURAND	83
808	TABLE SELECTION	101
809	EDITOR TABLE (select table)	102
810	ADJUSTED DENSITY – "Linear" level type	74
	ADJUSTED DENSITY – "Height Linearized" level type	87
811	PROCESS DENSITY	97
812	DENSITY UNIT – "Linear" level type	74
	DENSITY UNIT – "Height Linearized" level type	88
813	100 % POINT – "Linear" level type	77
	100 % POINT – "Height Linearized" level type	89

ID number	Parameter name	Description, see page
814	ZERO POSITION – "Linear" level type	77
	ZERO POSITION – "Height Linearized" level type	90
815	TANK DESCRIPTION	103
831	HistoROM AVAIL.	126
832	HistoROM CONTROL	127
836	SAFETY LOCKSTATE	See ¹⁾
	SAFETY LOCK	
838	SAFETY PASSWORD	See ¹⁾
840	DIGIT SETS	111
841	DIGIT SETS	See ¹⁾
844	ACK. ALARM MODE	See ¹⁾
845	MEASURING MODE	See ¹⁾
847	CALIB. OFFSET	See ¹⁾
848	MAX. FLOW	See ¹⁾
849	MAX PRESS. FLOW	See ¹⁾
850	LOW FLOW CUT-OFF	See ¹⁾
851	SET. L. FL. CUT-OFF	See ¹⁾
852	SET LRV	See ¹⁾
853	SET URV	See ¹⁾
854	LINEAR/SQROOT.	See ¹⁾
855	DAMPING VALUE	See ¹⁾
856	CONF. PASSWORD	See ¹⁾
858	TANK VOLUME	75
859	TANK HEIGHT	76
875	CURRENT OUTPUT	See ¹⁾

1) See Safety Manual SD00189P for Deltabar S, SD00190P for Cerabar S and SD00213P for Deltapilot S.

3 Graphic representation of function groups



Note!

The "Flow" measuring mode is only available for the Deltabar S differential pressure transmitter. The groups marked with "*" are only displayed for Deltabar S.

1st selection level	2nd selection level (groups)	Function groups	Description, see page
LANGUAGE	LANGUAGE (079)	→	44
MEASURING MODE	MEASURING MODE (389)	→	45
QUICK SETUP pressure		→	47
QUICK SETUP level		→	49
QUICK SETUP flow*		→	52
OPERATING MENU (555)	→ SETTINGS (557)	→ POSITION ADJUSTMENT	→ 53
		→ BASIC SETUP pressure	→ 55
		→ BASIC SETUP level, "Level Easy Pressure"	→ 58
		→ BASIC SETUP level, "Level Easy Height"	→ 62
		→ BASIC SETUP level, "Level Easy Standard"	→ 67
		→ BASIC SETUP flow*	→ 91
		→ EXTENDED SETUP pressure	→ 96
		→ EXTENDED SETUP level	→ 96
		→ EXTENDED SETUP flow*	→ 98
		→ LINEARISATION – on-site display	→ 100
		→ LINEARISATION – Digital communication	→ 104
		→ TOTALIZER SETUP *	→ 107
	→ SAFETY CONFIRM.		→ See ¹⁾
	→ DISPLAY (558)		→ 110
	→ OUTPUT (559)		→ 111
	→ TRANSMITTER INFO (560)	→ HART DATA	→ 114
		→ TRANSMITTER DATA	→ 117
		→ PROCESS CONNECTION	→ 117
		→ SENSOR DATA	→ 119
	→ PROCESSINFO (561)	→ PROCESS VALUES pressure	→ 121
		→ PROCESS VALUES level	→ 122
		→ PROCESS VALUES flow*	→ 123
		→ PEAK HOLD INDICATOR	→ 124
	→ OPERATING		→ 126
	→ DIAGNOSTICS (562)	→ SIMULATION	→ 127
		→ MESSAGES	→ 128
		→ USER LIMITS	→ 130
	→ SERVICE (561)	→ SYSTEM 2	→ 131

1) See Safety Manual SD00189P for Deltabar S, SD00190P for Cerabar S and for SD00213P Deltapilot S.

4 Pressure measurement

4.1 Calibration with reference pressure

Example:

In this example, a device with a 500 mbar (7.5 psi) sensor is configured for the 0...+300 mbar (4.5 psi) measuring range, i.e. 0 mbar and 300 mbar (4.5 psi) are assigned to the 4 mA value and 20 mA value respectively.

Prerequisite:



- The pressure values 0 mbar and 300 mbar (4.5 psi) can be specified. The device is already installed, for example.

**Note!**

- See also Operating Instructions Deltabar S (BA00270P), Section 6.6 "Differential pressure measurement", Cerabar S (BA00271P), Section 6.4 "Pressure measurement" or Deltapilot S (BA00332P), Section 6.5 "Pressure measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 55, Table 7: BASIC SETUP.
- For a description of further relevant parameters, see
 - Page 96, Table 15: EXTENDED SETUP
 - Page 121, Table 25: PROCESS VALUES.

**Warning!**

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and filled with fluid. See Operating Instructions BA00270P, Section 6.6.	 <p>P01-PMD75xxx-19-xx-xx-xx-000</p>  <p>P01-xxxxxxx-05-xx-xx-xx-010</p> <p><i>Fig. 1: Calibration with reference pressure</i></p> <p>1 See table, step 6. 2 See table, step 7.</p>
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
3	If necessary, select the "Pressure" measuring mode via the MEASURING MODE parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE	
4	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	
5	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
6	The pressure for the lower range value (4 mA value) is present at the device, here 0 mbar for example. Select GET LRV parameter. Confirm value present. The pressure value present is assigned to the lower current value (4 mA).	
7	The pressure for the upper range value (20 mA value) is present at the device, here 300 mbar (4.5 psi) for example. Select GET URV parameter. Confirm value present. The pressure value present is assigned to the upper current value (20 mA).	
8	Result: The measuring range is set for 0...+300 mbar (4.5 psi).	



Note!

- You can also specify a customer-specific unit. See parameter description for PRESS. ENG. UNIT (→ Page 56).

4.2 Calibration without reference pressure

Example:

In this example, a device with a 400 mbar (6 psi) sensor is configured for the 0...+300 mbar (4.5 psi) measuring range, i.e. 0 mbar and 300 mbar (4.5 psi) are assigned to the 4 mA value and 20 mA value respectively.

Prerequisite:



- This is a theoretical calibration, i.e. the pressure values for the lower range and upper range value are known.

**Note!**

- See also Operating Instructions Deltabar S (BA00270P), Section 6.6 "Differential pressure measurement", Cerabar S (BA00271P), Section 6.4 "Pressure measurement" or Deltapilot S (BA00332P), Section 6.5 "Pressure measurement".
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page 53, Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 55, Table 7: BASIC SETUP.
- For a description of further relevant parameters, see
 - Page 96, Table 15: EXTENDED SETUP
 - Page 121, Table 27: PROCESS VALUES.

**Warning!**

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	<p>If necessary, select the "Pressure" measuring mode via the MEASURING MODE parameter.</p> <p>On-site display: Menu path: GROUP SELECTION → MEASURING MODE</p> <p>Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE</p>	 <p>P01-PMPT1xxx-19-xx-xx-xx-000</p>  <p>P01-xxxxxxx-05-xx-xx-xx-010</p> <p><i>Fig. 2: Calibration without reference pressure</i></p> <p>1 See table, step 4. 2 See table, step 5.</p>
2	<p>On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP</p>	
3	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
4	Select SET LRV parameter.	
	Enter value, here 0 mbar, for the SET LRV parameter and confirm. This pressure value is assigned to the lower current value (4 mA).	
5	Select SET URV parameter.	
	Enter value, here 300 mbar (4.5 psi), for the SET URV parameter and confirm. This pressure value is assigned to the upper current value (20 mA).	
6	<p>Result: The measuring range is set for 0...+300 mbar (4.5 psi).</p>	

**Note!**

- You can also perform calibration without reference pressure by means of the QUICK SETUP menu. → See Page 47 ff, Table 3: QUICK SETUP menu.
- You can also specify a customer-specific unit. See parameter description for PRESS. ENG. UNIT (→ Page 56).

5 Level measurement

5.1 Overview of level measurement

Measuring task	LEVEL SELECTION/ LEVEL MODE	Measured variable options	Description	Comment	Measured value display
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering two pressure-level value pairs.	LEVEL SELECTION: Level Easy Pressure	Via OUTPUT UNIT parameter: %, level, volume or mass units.	<ul style="list-style-type: none"> – Calibration with reference pressure – wet calibration, see Page 15, Section 5.2.1 – Calibration without reference pressure – dry calibration, see Page 17, Section 5.2.2 	<ul style="list-style-type: none"> – Incorrect entries are possible – SIL mode possible – Customised units are not possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is in direct proportion to the measured pressure. Calibration is performed by entering the density and two height-level value pairs.	LEVEL SELECTION: Level Easy Height	Via OUTPUT UNIT parameter: %, level, volume or mass units.	<ul style="list-style-type: none"> – Calibration with reference pressure – wet calibration, see Page 19, Section 5.3.1 – Calibration without reference pressure – dry calibration, see Page 22, Section 5.3.2 	<ul style="list-style-type: none"> – Incorrect entries are possible – SIL mode not possible – Customised units are not possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is in direct proportion to the measured pressure.	LEVEL SELECTION: Level standard/ LEVEL MODE: Linear	Via LIN. MEASURAND parameter: – % (Level) – Level – Volume – Mass	<ul style="list-style-type: none"> – Calibration with reference pressure – wet calibration, see Page 24, Section 5.4.1 – Calibration without reference pressure – dry calibration, see Page 26, Section 5.4.2 	<ul style="list-style-type: none"> – Incorrect entries are rejected by the device – SIL mode not possible – Customised level, volume and mass units are possible 	The measured value display and the LEVEL BEFORE LIN parameter show the measured value.
The measured variable is not in direct proportion to the measured pressure as, for example, with containers with a conical outlet. A linearisation table must be entered for the calibration.	LEVEL SELECTION: Level standard/ LEVEL MODE: Pressure Linearized	Via LIND MEASURAND parameter: – Pressure + % – Pressure + Volume – Pressure + Mass	<ul style="list-style-type: none"> – Calibration with reference pressure: semiautomatic entry of linearisation table, see Page 28, Section 5.5.1 – Calibration without reference pressure: manual entry of linearisation table, see Page 31, Section 5.5.2 	<ul style="list-style-type: none"> – Incorrect entries are rejected by the device – SIL mode not possible – Customised level, volume and mass units are possible 	The measured value display and the TANK CONTENT parameter show the measured value.
<ul style="list-style-type: none"> – Two measured variables are required or – The container shape is given by value pairs, such as height and volume. <p>The 1st measured variable %-height or height must be in direct proportion to the measured pressure. The 2nd measured variable volume, mass or % must not be in direct proportion to the measured pressure. A linearisation table must be entered for the 2nd measured variable. The 2nd measured variable is assigned to the 1st measured variable by means of this table.</p>	LEVEL SELECTION: Level standard/ LEVEL MODE: Height Linearized	Via COMB. MEASURAND parameter: – Height + Volume – Height + Mass – Height + % – %-Height + Volume – %-Height + Mass – %-Height + %	<ul style="list-style-type: none"> – Calibration with reference pressure: wet calibration and semiautomatic entry of linearisation table, see Page 33, Section 5.6.1 – Calibration without reference pressure: dry calibration and manual entry of linearisation table, see Page 37, Section 5.6.2 	<ul style="list-style-type: none"> – Incorrect entries are rejected by the device – SIL mode not possible – Customised level, volume and mass units are possible 	<p>The measured value display and the TANK CONTENT parameter show the 2nd measured value (volume, mass or %).</p> <p>The LEVEL BEFORE LIN parameter displays the 1st measured value (%-height or height).</p>

5.2 "Level Easy Pressure" level selection

5.2.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m (9.8 ft). The pressure range is set to 0 to 300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled or emptied.



Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB. and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 58, Table 8: LEVEL SELECTION "Level Easy Pressure"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.






	Description	
1	Deltabar S: Before you configure the device for your application, the pressure piping must be cleaned and filled with medium. See Operating Instructions BA00270P, Section 6.5.1	 <p style="text-align: right; font-size: small;">P01-PMAP75xxx-19-xx-xx-xx-008</p>
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
3	If necessary, select the "Level" measuring mode via the MEASURING MODE parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE	
4	If necessary, select "Level Easy Pressure" level mode using the LEVEL SELECTION parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION	

Fig. 3: Calibration with reference pressure – wet calibration

- 1 See Table, Step 9.
2 See Table, Step 10.

	Description	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select a level unit via the OUTPUT UNIT parameter, here m for example.	
8	Select the "Wet" option by means of the CALIBRATION MODE parameter.	
9	Hydrostatic pressure for the lower calibration point is present at the device, here 0 mbar for example. Select EMPTY CALIB. parameter. Enter the level value, here 0 m for example. Confirm the value to assign the pressure value present to the lower level value.  Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then press the "E" button to save the value.	 <p style="text-align: right; font-size: small;">P01-xxxxxxx-05-xx-xx-xx-011</p>
10	Hydrostatic pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example. Select FULL CALIB. parameter. Enter the level value, here 3 m (9.8 ft) for example. Confirm the value to assign the pressure value present to the upper level value.  Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then press the "E" button to save the value.	 <p style="text-align: right; font-size: small;">P01-xxxxxxx-05-xx-xx-xx-014</p>
11	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	<p>Fig. 4: Calibration with reference pressure – wet calibration</p> <p>1 See Table, Step 9. 2 See Table, Step 10. 3 See Table, Step 11. 4 See Table, Step 12.</p>
12	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
13	Result: The measuring range is set for 0 to 3 m (9.8 ft).	



Note!

1. You can also perform calibration with reference pressure by means of the QUICK SETUP menu. → See Page 49 ff, Table 4: QUICK SETUP menu.
2. For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT, Page 60.
3. For operation using the on-site display, the parameters EMPTY CALIB. (→ Page 61) and FULL CALIB. (→ Page 61) also show the respective pressure present at the device. For operation using Digital communication, the pressure present at the device is displayed in the PROCESS VALUES group (menu path: OPERATING MENU → PROCESSINFO → PROCESS VALUES).

5.2.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in litres. The maximum volume of 1000 litres (264 US gal) corresponds to a pressure of 450 mbar (6.75 psi). The minimum volume of 0 litres corresponds to a pressure of 50 mbar (0.75 psi), as the device is mounted below the level lower range value. The device is mounted below the level lower range value.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the pressure and volume values for the lower and upper calibration point must be known.




Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB. and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Pressure" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page 53, Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 58, Table 8: LEVEL SELECTION "Level Easy Pressure"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE	 <p style="text-align: right; font-size: small;">P01-PMC71xxx-19-xx-xx-xx-000</p> <p><i>Fig. 5: Calibration without reference pressure – dry calibration</i></p> <p>1 See Table, Steps 7 and 8. 2 See Table, Steps 9 and 10.</p>
2	If necessary, select "Level Easy Pressure" level mode using the LEVEL SELECTION parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION	
3	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
5	Select a volume unit via the OUTPUT UNIT parameter, here l (litres) for example..	
6	Select the "Dry" option by means of the CALIBRATION MODE parameter.	
7	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example.	
8	Enter the pressure value for the lower calibration point via the EMPTY PRESSURE parameter, here 50 mbar (0.75 psi) for example.	
9	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (264 gal) for example.	
10	Enter the pressure value for the upper calibration point via the FULL PRESSURE parameter, here 450 mbar (6.75 psi) for example.	
11	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	
12	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
13	Result: The measuring range is set for 0 to 1000 l (264 gal).	

Fig. 6: Calibration with reference pressure – wet calibration

- 1 See Table, Step 7.
 2 See Table, Step 8.
 3 See Table, Step 9.
 4 See Table, Step 10.
 5 See Table, Step 11.
 6 See Table, Step 12.



Note!

- For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT, Page 60.

5.3 "Level Easy Height" level selection

5.3.1 Calibration with reference pressure – wet calibration

Example:

In this example, the volume in a tank should be measured in litres. The maximum volume of 1000 litres (264 US gal) corresponds to a level of 4.5 m (15 ft). The minimum volume of 0 litres corresponds to a level of 0.5 m (1.6 ft), as the device is mounted below the level lower range value. The density of the medium is 1 kg/dm³.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled or emptied.



Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE, EMPTY HEIGHT/FULL HEIGHT and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Height" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 62, Table 9: LEVEL SELECTION "Level Easy Height"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description
1	Deltabar S: Before you configure the device for your application, the pressure piping must be cleaned and filled with medium. See Operating Instructions BA00270P, Section 6.5.1
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.
3	<p>Select the "Level" measuring mode via the MEASURING MODE parameter.</p> <p>On-site display: Menu path: GROUP SELECTION → MEASURING MODE</p> <p>Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE</p>
4	<p>If necessary, select the "Level Easy Height" level mode using the LEVEL SELECTION parameter.</p> <p>On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION</p> <p>Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION</p>
5	<p>On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP</p>

Fig. 7: Calibration with reference pressure – wet calibration

- 1 See Table, Steps 10 and 11.
- 2 See Table, Step 12.
- 3 See Table, Step 13.

	Description	
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	<p>P01-xxxxxxx-05-xx-xx-xx-029</p>
7	Select a volume unit via the OUTPUT UNIT parameter, here l (litres) for example..	
8	Select a height unit via the HEIGHT UNIT parameter, here m for example.	
9	Select the "Wet" option via the CALIBRATION MODE parameter.	
10	Select a density unit via the DENSITY UNIT parameter, here kg/dm ³ for example.	
11	Enter the density of the fluid using the ADJUST DENSITY parameter, here kg/dm ³ for example.	<p>P01-xxxxxxx-05-xx-xx-xx-030</p>
12	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example. (The currently measured hydrostatic pressure is displayed as height, here 0.5 m (1.6 ft) for example.) Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then press the "E" button to save the value.	
13	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (264 US gal) for example. (The currently measured hydrostatic pressure is displayed as height, here 4.5 m (15 ft) for example.) Note! To accept the value displayed you must first switch to the Edit mode (see the "Editing values" section) and then press the "E" button to save the value.	<p>P01-xxxxxxx-05-xx-xx-xx-031</p>
14	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	
15	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
16	Result: The measuring range is set for 0 to 1000 l (264 US gal).	<p>Fig. 8: Calibration with reference pressure – wet calibration</p> <p>1 See Table, Steps 10 and 11. 2 See Table, Step 12. 3 See Table, Step 13. 4 See Table, Step 14. 5 See Table, Step 15.</p>

**Note!**

- For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT, Page 64.

5.3.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in litres. The maximum volume is 1000 l (264 US gal), and the maximum height is 4.5 m (15 ft). The minimum volume of 0 litres corresponds to a level of 0.5 m (1.6 ft), as the device is mounted below the level lower range value. The density of the fluid is 1 kg/dm³.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration i.e. the height and volume values for the lower and upper calibration point must be known.




Note!




- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE, EMPTY HEIGHT/FULL HEIGHT and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Height" level mode. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly.
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page , Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 62, Table 9: LEVEL SELECTION "Level Easy Height"
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE	 <p style="text-align: right; font-size: small;">P01-PMC71xxx-19-xx-xx-xx-007</p> <p>Fig. 9: Calibration without reference pressure – dry calibration</p> <p>1 See Table, Steps 8 and 9. 2 See Table, Steps 10 and 11. 3 See Table, Steps 12 and 13.</p>
2	If necessary, select "Level Easy Height" level mode using the LEVEL SELECTION parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION	
3	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	 <p>P01-xxxxxxx-05-xx-xx-xx-029</p>
5	Select a volume unit via the OUTPUT UNIT parameter, here l (litres) for example.	
6	Select a height unit via the HEIGHT UNIT parameter, here m for example.	
7	Select the "Dry" option via the CALIBRATION MODE parameter.	
8	Select a density unit via the DENSITY UNIT parameter, here kg/dm ³ for example.	
9	Enter the density of the fluid using the ADJUST DENSITY parameter, here kg/dm ³ for example.	 <p>P01-xxxxxxx-05-xx-xx-xx-032</p>
10	Enter the volume value for the lower calibration point via the EMPTY CALIB. parameter, here 0 l for example.	
11	Enter the height value for the lower calibration point via the EMPTY HEIGHT parameter, here 0.5 m (1.6 ft) for example.	
12	Enter the volume value for the upper calibration point via the FULL CALIB. parameter, here 1000 l (litres) (264 US gal) for example.	 <p>P01-xxxxxxx-05-xx-xx-xx-033</p>
13	Enter the height value for the upper calibration point via the FULL HEIGHT parameter, here 4.5 m (15 ft) for example.	
14	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	
15	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	<p>Fig. 10: Calibration with reference pressure – wet calibration</p> <p>1 See Table, Steps 8 and 9. 2 See Table, Step 10. 3 See Table, Step 11. 4 See Table, Step 12. 5 See Table, Step 13. 6 See Table, Step 14. 7 See Table, Step 15.</p>
16	Result: The measuring range is set for 0 to 1000 l (litres) (264 US gal).	



Note!

- For this level mode, the measured variables %, level, volume and mass are available. → See also parameter description for OUTPUT UNIT, Page 64.

5.4 "Level Standard" level selection, "Linear" level type

5.4.1 Calibration with reference pressure – wet calibration

Example:

In this example, the level in a tank should be measured in m. The maximum level is 3 m (9.8 ft). The pressure range is set to 0 to 300 mbar (4.5 psi).

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- The tank can be filled or emptied.



Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
 - Page 70, Table 11: BASIC SETUP – "Linear" level type.
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.




	Description	
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00270P, Section 6.5.1	 <p style="text-align: right; font-size: small;">P01-PMC71xxx-19-xx-xx-xx-000</p>
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
3	If necessary, select the "Level" measuring mode via the MEASURING MODE parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE	
4	If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION	

Fig. 11: Calibration with reference pressure – wet calibration

- 1 See table, step 11.
- 2 See table, step 12.

	Description	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	 <p>P01-xxxxxxx-05-xx-xx-xx-014</p>
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Linear" option by means of the LEVEL MODE parameter.	
8	Select the "Level" option by means of the LIN. MEASURAND parameter.	
9	Select a level unit via the HEIGHT UNIT parameter, here m for example.	
10	Select the "Wet" option by means of the CALIBRATION MODE parameter.	 <p>P01-xxxxxxx-05-xx-xx-xx-014</p>
11	The pressure for the lower calibration point is present at the device, here 0 mbar for example. Select EMPTY CALIB. parameter. Enter the level value, here 0 m for example. Confirm the value to assign the pressure value present to the lower level value.	
12	The pressure for the upper calibration point is present at the device, here 450 mbar (6.75 psi) for example. Select FULL CALIB. parameter. Enter the level value, here 3 m (9.8 ft) for example. Confirm the value to assign the pressure value present to the upper level value.	
13	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	
14	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
15	Result: The measuring range is set for 0...3 m (9.8 ft).	<p>Fig. 12: Calibration with reference pressure – wet calibration</p> <p>1 See table, step 11. 2 See table, step 12. 3 See table, step 13. 4 See table, step 14.</p>

**Note!**

1. You can also perform calibration with reference pressure by means of the QUICK SETUP menu. → See Page 49 ff, Table 4: QUICK SETUP menu.
2. You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 70), UNIT VOLUME (→ Page 71) and MASS UNIT (→ Page 72).
3. For this level type, the measured variables %, level, volume and mass are available. → See Page 70 ff.
4. The EMPTY PRESSURE (→ Page 74) and FULL PRESSURE (→ Page 74) parameters display the pressure values belonging to the EMPTY CALIB. and FULL CALIB. parameters.

5.4.2 Calibration without reference pressure – dry calibration

Example:

In this example, the volume in a tank should be measured in m³. The maximum volume is 5 m³ and the maximum height 4 m (13 ft). The density of the fluid is 1 kg/dm³. The device is mounted below the level lower range value.

Prerequisite:

- The measured variable is in direct proportion to the pressure.
- This is a theoretical calibration, i.e. the tank volume, tank height and density of the fluid are known.




Note!


- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero. → To perform a position adjustment see also Page , Table 6: Position adjustment.
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 67, Table 10: BASIC SETUP
 - Page 70, Table 11: BASIC SETUP – "Linear" level type.
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 26: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Select the "Level" measuring mode via the MEASURING MODE parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE	 <p style="text-align: right; font-size: small;">P01-PMF75xxx-19-xx-xx-xx-003</p> <p>Fig. 13: Calibration without reference pressure – dry calibration</p> <p>1 See table, step 9. 2 See table, step 10. 3 See table, step 11. 4 See table, step 12.</p>
2	If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION	
3	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	

	Description	
4	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	 <p style="text-align: right; font-size: small;">P01-xxxx-xxxx-19-xx-xx-xx-012</p> <p><i>Fig. 14: Current output calibration</i></p> <p>5 See table, step 13. 6 See table, step 14.</p>
5	Select the "Linear" option by means of the LEVEL MODE parameter.	
6	Select the "Volume" option by means of the LIN. MEASURAND parameter.	
7	Select a volume unit via the UNIT VOLUME parameter, here m ³ for example.	
8	Select the "Dry" option by means of the CALIBRATION MODE parameter. See also the following note, point 3.	
9	Enter the value for density via the ADJUST DENSITY parameter, here 1 kg/dm ³ for example.	
10	Enter the tank volume via the TANK VOLUME parameter, here 5 m ³ for example.	
11	Enter the tank height via the TANK HEIGHT parameter, here 4 m (13 ft) for example.	
12	Enter the level offset via the ZERO POSITION parameter, here -0.5 m (-1,6 ft) for example.	
13	Set the value for the lower current value (4 mA) by means of the SET LRV parameter.	
14	Set the value for the upper current value (20 mA) by means of the SET URV parameter.	
15	Result: The measuring range is set for 0...5 m ³ .	



Note!

- For this level type, the measured variables %, level, volume and mass are available.
→ See Page 70 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 70), UNIT VOLUME (→ Page 71) and MASS UNIT (→ Page 72).
- A level value is assigned to the lower and upper current value by means of the SET LRV (→ Page 77) and SET URV (→ Page 77) parameters respectively. Once you have selected the "Dry" calibration mode, the error message A711 "LRV or URV out of edit limits" can appear. The error message goes out as soon as level values which are within the editing limits are entered for the SET LRV and SET URV parameters.
By means of the ENTER RESET CODE parameter (→ Page 126), you can use the code 2710 to automatically set the SET LRV and SET URV parameters to level values which are within the editing limits.

5.5 "Level Standard" level selection, "Pressure Linearized" level type

5.5.1 Semiautomatic entry of the linearisation table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.

Prerequisite:

- The tank can be filled. The linearisation characteristic must rise continuously.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.




Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
 - Page 78, Table 11: BASIC SETUP – "Pressure Linearized" level type
 - Page 100, Table 18: LINEARISATION – on-site operation
 - Page 104, Table 19: LINEARISATION – Digital communication.
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 26: PROCESS VALUES.





Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and filled with fluid. See Operating Instructions BA00270P, Section 6.5.1.	 <p>P01-PM75xxx-19-xx-xx-xx-002</p>
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
Carry out basic setup:		
3	<p>If necessary, select the "Level" measuring mode via the MEASURING MODE parameter.</p> <p>On-site display: Menu path: GROUP SELECTION → MEASURING MODE</p> <p>Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE</p>	
4	<p>If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter.</p> <p>On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION</p> <p>Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION</p>	

	Description	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Pressure Linearized" option by means of the LEVEL MODE parameter. See also the following note, point 3.	
8	Select the "Volume" option by means of the LINd. MEASURAND parameter.	
9	Select a volume unit via the UNIT VOLUME parameter, here m ³ for example.	
10	Select HYDR. PRESS MIN. parameter. Enter the minimum hydrostatic pressure to be expected, here 0 mbar for example.	
11	Select HYDR. PRESS MAX . Enter the maximum hydrostatic pressure to be expected.	
Carry out linearisation:		
12	Change the function group: Menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION	
13	Select TANK CONTENT MIN parameter. Specify the minimum tank contents to be expected, here 0 m ³ for example.	
14	Select TANK CONTENT MAX parameter. Specify the maximum tank contents to be expected, here 3.5 m ³ for example.	
15	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.	
16	Select the "Semiautomatic" option by means of the LIN. EDIT MODE parameter.	
17	Select the "New table" option by means of the EDITOR TABLE parameter.	

	Description	
18	<div>Enter linearisation table (min. 2 points, max. 32 points).</div> <div>Fill the tank to the height of the 1st point.</div> <div>LINE-NUMB: confirm value displayed.</div> <div>X-VAL.: the hydrostatic pressure present is displayed. On-site display, Digital communication: The X-VAL. displayed is saved by confirming the Y-value. See following line, Y-VAL. HART handheld terminal: Confirm X-VAL. displayed.</div> <div>Y-VAL.: enter the volume value, here 0 m³ for example, and confirm the value.</div>	<div></div> <div></div> <div><p>Fig. 15: Semiautomatic entry of the linearisation table</p><p>1 See table, step 10. 2 See table, step 11. 3 See table, step 13. 4 See table, step 14. 5 See table, steps 15 – 19. 6 See the following note, point 4. 7 See the following note, point 4</p></div>
19	<div>On-site display: If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 18. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option.</div> <div>Digital communication: You can enter further points for the linearisation table as explained in step 18. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.</div>	
19	<div>Result: The linearisation table has been entered.</div>	



- Note!
1.

For this level type, the measured variables %, volume and mass are available.
→ See Page 78 ff.
2.

You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 79), UNIT VOLUME (→ Page 79) and MASS UNIT (→ Page 80).

3. Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (→ MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.
4. A level value is assigned to both the lower and upper current value with the SET LRV (→ Page 98) and SET URV (→ Page 98) parameters. If you enter values for TANK CONTENT MIN (→ Page 101 or 104) and TANK CONTENT MAX (→ Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5.5.2 Manual entry of the linearisation table

Example:

In this example, the volume in a tank with a conical outlet should be measured in m³.

Prerequisite:

- This is a theoretical calibration, i.e. the points for the linearisation table are known.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.




Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
 - Page 78, Table 12: BASIC SETUP – "Pressure Linearized" level type
 - Page 100, Table 18: LINEARISATION – on-site operation
 - Page 104, Table 19: LINEARISATION – Digital communication.
- For a description of further relevant parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.




Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Perform basic setup as per Section 5.3.1, steps 2 to 10.	
Carry out linearisation:		
2	Change the function group: Menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION	
3	Select TANK CONTENT MIN parameter . Specify the minimum tank contents to be expected, here 0 m ³ for example.	
4	Select TANK CONTENT MAX parameter . Specify the maximum tank contents to be expected, here 3.5 m ³ for example.	

P01-PM175xxx-19-xx-xx-xx-002

	Description	
5	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.	
6	Select the "Manual" option by means of the LIN. EDIT MODE parameter.	
7	Select the "New table" option by means of the EDITOR TABLE parameter.	
8	Enter linearisation table (min. 2 points, max. 32 points).	
	LINE-NUMB: confirm value displayed.	
	X-VAL.: enter the pressure value and confirm.	
	Y-VAL.: enter the volume value, here 0 m ³ for example, and confirm.	
9	On-site display If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 8. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option. Digital communication: You can enter further points for the linearisation table as explained in step 8. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	
10	Result: The linearisation table has been entered.	<p>Fig. 16: Manual entry of the linearisation table</p> <p>1 See Section 5.3.1, table, step 9. 2 See Section 5.3.1, table, step 10. 3 See table, step 3. 4 See table, step 4. 5 See table, steps 5 – 9. 6 See the following note, point 4. 7 See the following note, point 4.</p>

**Note!**

- For this level type, the measured variables %, volume and mass are available.
→ See Page 78 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 79), UNIT VOLUME (→ Page 79) and MASS UNIT (→ Page 80).
- Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (→ MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.
- A level value is assigned to both the lower and upper current value with the SET LRV (→ Page 98) and SET URV (→ Page 98) parameters. If you enter values for TANK CONTENT MIN (→ Page 101 or 104) and TANK CONTENT MAX (→ Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5.6 "Level Standard" level selection, "Height Linearized" level type

5.6.1 Wet calibration and semiautomatic entry of the linearisation table

Example:

In this example, the height and the volume should be measured at the same time.

Prerequisite:

- The tank can be filled. The linearisation characteristic must rise continuously.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.



Note!



- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 67, Table 10: BASIC SETUP
 - Page 83, Table 13: BASIC SETUP – "Height Linearized" level type
 - Page 100, Table 18: LINEARISATION – on-site operation
 - Page 104, Table 19: LINEARISATION – Digital communication.
- For a description of further parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.



Warning!

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Deltabar S: before configuring the device for your application, the pressure piping must be cleaned and filled with fluid. See Operating Instructions BA00270P, Section 6.5.1	
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
Perform calibration for the 1st measured variable:		
3	<p>If necessary, select the "Level" measuring mode via the MEASURING MODE parameter.</p> <p>On-site display: Menu path: GROUP SELECTION → MEASURING MODE</p> <p>Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE</p>	
4	<p>If necessary, select "Level Standard" level mode using the LEVEL SELECTION parameter.</p> <p>On-site display: Menu path: GROUP SELECTION → MEASURING MODE "Level" → LEVEL SELECTION</p> <p>Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE "Level" → LEVEL SELECTION</p>	

	Description	
5	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	 <p>P01-PMP75xxx-19-xx-xx-xx-004</p>
6	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
7	Select the "Height Linearized" option by means of the LEVEL MODE parameter.	
8	Select the "Height + Volume" option by means of the COMB. MEASURAND parameter.	
9	Select the unit for the 1st measured value via the HEIGHT UNIT parameter, here m for example.	
10	Select the unit for the 2nd measured variable via the UNIT VOLUME parameter, here m3 for example.	 <p>P01-xxxxxxx-05-xx-xx-xx-017</p>
11	Select LEVEL MIN parameter. Enter the minimum level to be expected, here 0 m for example.	
12	Select LEVEL MAX parameter. Enter the maximum level to be expected, here 3 m (9.8 ft) for example.	
13	Select the "Wet" option via the CALIBRATION MODE parameter (calibration mode for the 1st measured variable).	
14	The pressure for the lower calibration point is present at the device, here 0 mbar for example. Select EMPTY CALIB. parameter. Enter the level value, here 0 m for example. Confirm the value to assign the pressure value present to the lower level value.	
15	The pressure for the upper calibration point is present at the device, here 300 mbar (4.5 psi) for example. Select FULL CALIB. parameter. Enter the level value, here 3 m (9.8 ft) for example. Confirm the value to assign the pressure value present to the upper level value.	<p>Fig. 17: Calibrating the 1st measured variable</p> <p>1 See table, step 11. 2 See table, step 12. 3 See table, step 14. 4 See Table, step 15.</p>
16	Result: The calibration for the 1st measured variable is carried out.	




	Description	
	Perform linearisation (calibration for the 2nd measured variable)	
17	Change the function group. Menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION	 <p>P01-PM75xxx-19-xx-xx-xx-005</p>
18	Select TANK CONTENT MIN parameter. Specify the minimum tank contents to be expected, here 0 m³ for example.	
19	Select TANK CONTENT MAX parameter. Specify the maximum tank contents to be expected, here 5 m³ for example.	
20	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.	
21	Select the "Semiautomatic" option by means of the LIN. EDIT MODE parameter.	 <p>P01-xxxxxxx-05-xx-xx-xx-018</p>
22	Select the "New table" option by means of the EDITOR TABLE parameter.	
23	Enter linearisation table (min. 2 points, max. 32 points). Fill the tank to the height of the 1st point. LINE-NUMB: confirm value displayed. X-VAL.: the hydrostatic pressure present is measured and converted to the corresponding level and displayed. On-site display, Digital communication: The X-VAL. displayed is saved by confirming the Y-value. See following line, Y-VAL. HART handheld terminal: Confirm X-VAL. displayed. Y-VAL.: enter the volume value, here 0 m³ for example, and confirm the value.	
24	On-site display If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 23. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option. Digital communication: You can enter further points for the linearisation table as explained in step 23. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.	
25	Result: – The linearisation table has been entered. – The measured value display and the TANK CONTENT parameter display the 2nd measured value (here the volume). – The LEVEL BEFORE LIN parameter displays the 1st measured value (here the height). See also the following note, point 5.	 <p>P01-xxxxxxx-05-xx-xx-xx-019</p>

Fig. 18: Calibrating the 2nd measured variable

- 5 See table, step 18.
6 See table, step 19.
7 See table, steps 20 – 24.
8 See the following note, point 4.
9 See the following note, point 4.



Note!

1. For this level type, the measured variables "Height + %", "Height + Volume", "Height + Mass", "%-Height + %", "%-Height + Volume" and "%-Height + Mass" are available. → See Page 79 ff.
2. You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 83), UNIT VOLUME (→ Page 84) and MASS UNIT (→ Page 85).
3. Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (→ MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.
4. A level value is assigned to both the lower and upper current value with the SET LRV (→ Page 98) and SET URV (→ Page 98) parameters.
You can use the ASSIGN CURRENT parameter (→ Page 113) to specify whether the current output should depict the 1st or 2nd measured variable. Depending on the setting of the ASSIGN CURRENT parameter, enter the following values for SET LRV and SET URV:
 - ASSIGN CURRENT = tank content (factory setting) ⇒ %-value, volume value or mass value
 - ASSIGNMENT = height ⇒ level value

The following applies for the setting ASSIGN CURRENT "Tank content":

If you enter values for TANK CONTENT MIN (→ Page 101 or 104) and TANK CONTENT MAX (→ Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

The following applies for the setting ASSIGN CURRENT "Height":

If you enter values for LEVEL MIN (→ Page 86) and LEVEL MAX (→ Page 86), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for LEVEL MIN and LEVEL MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5. You can use the MENU DESCRIPTOR parameter (→ Page 110) to specify which measured value should be displayed on the on-site display.

5.6.2 Dry calibration and manual entry of the linearisation table

Example:

In this example, the height and the volume should be measured at the same time.

Prerequisite:

- This is a theoretical calibration, i.e. the points for the linearisation table are known.
- A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN.




Note!

- See also Operating Instructions for Deltabar S (BA00270P) or Cerabar S (BA00271P), Section 6.5 "Level measurement" or Deltapilot S (BA00332P), Section 6.4 "Level measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 67, Table 10: BASIC SETUP
 - Page 83, Table 12: BASIC SETUP – "Height Linearized" level type
 - Page 100, Table 18: LINEARISATION – on-site operation
 - Page 104, Table 19: LINEARISATION – Digital communication.
- For a description of further parameters, see
 - Page 96, Table 16: EXTENDED SETUP
 - Page 122, Table 28: PROCESS VALUES.




Warning!


If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
	Perform calibration for the 1st measured variable:	 <p>P01-PMPT75xxx-19-xx-xx-xx-005</p>
1	Perform calibration as per Section 5.4.1, steps 3 to 12.	
2	Select the "Dry" option via the CALIBRATION MODE parameter (calibration mode for the 1st measured variable).	
3	Enter the density of the fluid via the ADJUST DENSITY parameter, here 1 kg/dm ³ for example.	
4	If necessary, enter a level offset via the ZERO POSITION parameter, here 0 m for example.	
5	Result: The calibration for the 1st measured variable is carried out.	

Description	
Perform linearisation (calibration for the 2nd measured variable)	
6	Change the function group. Menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION
7	Select TANK CONTENT MIN parameter. Specify the minimum tank contents to be expected, here 0 m ³ for example.
8	Select TANK CONTENT MAX parameter. Specify the maximum tank contents to be expected, here 5 m ³ for example.
9	On-site display: Select the "Editor table" option by means of the TABLE SELECTION parameter.
10	Select the "Manual" option by means of the LIN. EDIT MODE parameter.
11	Select the "New table" option by means of the EDITOR TABLE parameter.
12	Enter linearisation table (min. 2 points, max. 32 points). LINE-NUMB: confirm value displayed. X-VAL.: enter the height value and confirm. Y-VAL.: enter the volume value, here 0 m ³ for example, and confirm.
13	On-site display If you want to enter another point for the linearisation table, select the "Next point" option and enter the point as described in step 12. If you want to finish entering the values and activate the linearisation table, select the "Accept input table" option. Digital communication: You can enter further points for the linearisation table as explained in step 12. Once all the points have been entered, the table must be activated by means of the TAB. ACTIVATE parameter.
14	Result: – The linearisation table has been entered. – The measured value display and the TANK CONTENT parameter display the 2nd measured value (here the volume). – The LEVEL BEFORE LIN parameter displays the 1st measured value (here the height). See also the following note, point 5.



P01-xxxxxxx-05-xx-xx-xx-018



P01-xxxxxxx-05-xx-xx-xx-019

Fig. 19: Calibrating the 2nd measured variable

- 5 See table, step 7.
6 See table, step 8.
7 See table, steps 9 – 13.
8 See the following note, point 4.
9 See the following note, point 4.

**Note!**

- For this level type, the measured variables "Height + %", "Height + Volume", "Height + Mass", "%-Height + %", "%-Height + Volume" and "%-Height + Mass" are available. → See Page 79 ff.
- You can also specify customer-specific units. See parameter description for PRESS. ENG. UNIT (→ Page 67), HEIGHT UNIT (→ Page 83), UNIT VOLUME (→ Page 84) and MASS UNIT (→ Page 85).
- Once you have selected the "Pressure Linearized" level type, the warning message "W710 Set span too small. Not allowed." can appear. At this stage the linearisation table already consists of two points as standard. It could be the case that the 2nd value, and thus the highest X-VAL. of the linearisation table, is smaller than the minimum span permitted (→ MINIMUM SPAN, Page 119). The message goes out as soon as the highest X-VAL. is larger than the minimum span.

4. A level value is assigned to both the lower and upper current value with the SET LRV (→ Page 98) and SET URV (→ Page 98) parameters.
You can use the ASSIGN CURRENT parameter (→ Page 113) to specify whether the current output should depict the 1st or 2nd measured variable. Depending on the setting of the ASSIGN CURRENT parameter, enter the following values for SET LRV and SET URV:
 - ASSIGN CURRENT = tank content (factory setting) ⇒ %- value, volume value or mass value
 - ASSIGNMENT = height ⇒ level value

The following applies for the setting ASSIGN CURRENT "Tank content":

If you enter values for TANK CONTENT MIN (→ Page 101 or 104) and TANK CONTENT MAX (→ Page 101 or 105), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for TANK CONTENT MIN and TANK CONTENT MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

The following applies for the setting ASSIGN CURRENT "Height":

If you enter values for LEVEL MIN (→ Page 86) and LEVEL MAX (→ Page 86), the SET LRV and SET URV parameters are also changed. If you want to assign values other than those for LEVEL MIN and LEVEL MAX to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5. You can use the MENU DESCRIPTOR parameter (→ Page 110) to specify which measured value should be displayed on the on-site display.

6 Flow measurement

6.1 Calibration

Example:

In this example, a volume flow should be measured in m³/s.

**Note!**

- The "Flow measurement" measuring mode is only available for the Deltabar S differential pressure transmitter.
- See also Operating Instructions BA00270P Deltabar S, Section 6.4 "Flow measurement".
- For a description of the parameters mentioned, see
 - Page 45, Table 2: MEASURING MODE
 - Page 53, Table 6: POSITION ADJUSTMENT
 - Page 91 ff, Table 12: BASIC SETUP
 - Page 98 ff, Table 15: EXTENDED SETUP.
- For a description of further parameters, see
 - Page 98, Table 15: EXTENDED SETUP
 - Page 123, Table 29: PROCESS VALUES.

**Warning!**

If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.

	Description	
1	Before configuring the device for your application, the pressure piping must be cleaned and the device filled with fluid. See Operating Instructions BA00270P, Section 6.4.1.	<p>P01-xxxxxxx-19-xx-xx-xx-013</p>
2	Carry out position adjustment if necessary. See Page 53, Table 6: POSITION ADJUSTMENT.	
3	If necessary, select the "Flow" measuring mode via the MEASURING MODE parameter. On-site display: Menu path: GROUP SELECTION → MEASURING MODE Digital communication: Menu path: OPERATING MENU → SETTINGS → BASIC SETUP → MEASURING MODE	
4	On-site display: Select BASIC SETUP function group. Menu path: GROUP SELECTION → OPERATING MENU → SETTINGS → BASIC SETUP	
5	Select a pressure unit via the PRESS. ENG. UNIT parameter, here mbar for example.	
6	Select the "Volume p. cond." option by means of the FLOW-MEAS. TYPE parameter.	
7	Select a flow unit via the UNIT FLOW parameter, here m ³ /h for example.	
8	Select MAX. FLOW parameter. Enter the maximum flow value of the primary element, here 6000 m ³ /h for example. See also layout sheet of primary element.	
9	Select MAX PRESS. FLOW parameter. Enter the maximum pressure, here 400 mbar (6 psi) for example. See also layout sheet of primary element.	
10	Result: The device is configured for flow measurement.	

Fig. 20: Flow measurement calibration

- 1 See table, step 8.
- 2 See table, step 9.
- 3 See the following note, point 4.
- 4 See the following note, point 4.

**Note!**

1. You can also perform calibration by means of the QUICK SETUP menu. → See Page 52 ff, Table 5: QUICK SETUP menu.
2. Using the FLOW-MEAS. TYPE parameter, you can choose between the following flow types:
 - Volume p. cond. (volume under operating conditions)
 - Gas norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0°C))
 - Gas std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288.15 K (15°C/59°F))
 - Mass
3. Depending on the flow type selected, you can choose between various units. You can also specify a customer-specific unit.
See parameter description for PRESS. ENG. UNIT (→ Page 92), UNIT FLOW (→ Page 93), NORM FLOW UNIT (→ Page 93), STD. FLOW UNIT (→ Page 94) and MASS FLOW UNIT (→ Page 94).
4. A flow value or a pressure value is assigned to both the lower and upper current value with the SET LRV (→ Page 99) and SET URV (→ Page 100) parameters.

You can use the LINEAR/SQROOT parameter (→ Page 113) to specify whether the current output should depict the linear pressure signal or the Flow (square root) flow signal. Depending on the setting of the LINEAR/SQROOT parameter, enter the following values for SET LRV and SET URV:

- LINEAR/SQROOT = Flow (square root) (factory setting) ⇒ flow value
- LINEAR/SQROOT = Differential pres. ⇒ pressure value

The following applies for the setting LINEAR/SQROOT "Flow (square root)":

As per the factory settings, the lower current value is set to equal zero and the upper current value is set to the MAX. FLOW value. If you enter a value for MAX. FLOW, the SET URV parameter is also changed. If you want to assign values other than zero and MAX. FLOW to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

The following applies for the setting LINEAR/SQROOT "Differential pres.":

As per the factory settings, the lower current value is set to equal zero and the upper current value is set to the MAX. PRESS. FLOW value. If you enter a value for MAX PRESS. FLOW, the SET URV parameter is also changed. If you want to assign values other than zero and MAX PRESS. FLOW to the lower and upper current values, the desired values must be entered for SET LRV and SET URV.

5. In the lower measuring range, small flow quantities (creepages) can lead to large measured value fluctuations. You can activate low flow cut-off via the LOW FLOW CUT-OFF parameter (→ Page 99).

6.2 Totalizers

Example:

In this example, the volume flow should be totalised and displayed in the unit m^3E^3 . Negative flows should be added to the flow rate.



Note!

- For a description of the parameters mentioned, see
 - Page 107 ff, Table 18: TOTALIZER SETUP
 - Page 123 ff, Table 29: PROCESS VALUES
- Totalizer 1 can be reset. Totalizer 2 cannot be reset.

	Description
1	Calibrate the device as per Section 6.1.
2	Change the function group: (GROUP SELECTION →) OPERATING MENU → SETTINGS → TOTALIZER SETUP
3	Select a flow unit via the TOTALIZER 1 UNIT parameter, here m^3E^3 for example.
4	Use the NEG. FLOW TOT. 1 parameter to specify the totalising mode for negative flows, here the "Positive" option for example.
5	Reset totalizer 1 to zero via the RESET TOTALIZER parameter.
6	Result: The TOTALIZER 1 and TOTAL. 1 OVERFLOW parameters display the totalised volume flow.



Note!

- You can also specify a customer-specific unit. → See parameter description for TOTALIZER 1 UNIT (→ Page 108) and TOTALIZER 2 UNIT (→ Page 109).
- The TOTALIZER 1 and TOTAL. 1 OVERFLOW parameters display the totalised flow value of the first totalizer. The TOTALIZER 2 and TOTAL. 2 OVERFLOW parameters display the totalised flow value of the second totalizer. → See Page 123 ff, PROCESS VALUES function group.
- You can use the MENU DESCRIPTOR parameter (→ Page 110) to specify which measured value should be displayed on the on-site display.

7 Description of parameters



- Note!
- The following tables list all the parameters as per the menu structure. Each table corresponds to a function group in the menu tree. The overall menu structure is illustrated in Section 9.1.
 - The menu structure for on-site operation and the digital communication are slightly different. The differences mainly affect the MEASURING MODE and LANGUAGE parameters and the LINEARISATION function group.
 - In the operating program or HART handheld terminal, additional parameters are displayed. These parameters are marked accordingly.
 - The menu path is indicated in the header of each table. You can use this path to get to the parameters in question.
 - The menu has a different structure depending on the measuring mode selected. This means that some function groups are only displayed for one measuring mode, e.g. the "LINEARISATION" function group for the "Level" measuring mode. If certain requirements have to be met for a function group, these are listed in the first row of the table.
 - Some parameters are only displayed if other parameters are appropriately configured. For example, the EMPTY CALIB. parameter is not displayed in the Quick Setup menu ("Level" measuring mode) unless the "Linear" option was selected for the LEVEL MODE parameter and the "Wet" option was selected for the CALIBRATION MODE parameter. There is a comment in the parameter description here stating: Note: prerequisite: LEVEL MODE = Linear and CALIBRATION MODE = Wet.
 - Parameter names are written in upper case in the text.
 - In the "Parameter name" column, the unique identification number (ID) of the parameter is indicated in brackets. This ID only appears on the on-site display.




Fig. 21: 1st selection level in menu, LANGUAGE (→ see Page 44, Table 1) and MEASURING MODE (→ see Page 45, Table 2)

Table 1: GROUP SELECTION → LANGUAGE – on-site operation	
Parameter name	Description
LANGUAGE (079) Selection	<div>Select the menu language for the on-site display.</div> <div>Note!<ul style="list-style-type: none">■ In the operating program and in the HART handheld terminal, the LANGUAGE parameter is arranged in the DISPLAY function group.■ Select the menu language for FieldCare via the "Options" menu → "Settings" → "Language" tab → "Tool language" field.</div> <div>Factory setting: English</div>





Fig. 22: "Level" measuring mode, LEVEL SELECTION parameter

Table 2: GROUP SELECTION → MEASURING MODE – on-site operation	
Parameter name	Description
MEASURING MODE (389) Selection	<p>Select the measuring mode. The operating menu is structured according to the selected measuring mode.</p> <p> Note! ■ The MEASURING MODE parameter is displayed in the operating program and in the HART handheld terminal in the QUICK SETUP menus and in the BASIC SETUP function group (OPERATING MENU → SETTINGS → BASIC SETUP).</p> <p> Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Pressure ■ Level ■ Deltabar S: Flow <p>Factory setting:</p> <ul style="list-style-type: none"> ■ Cerabar S and Deltabar S: Pressure ■ Deltapilot S: Level

Table 2: GROUP SELECTION → MEASURING MODE – on-site operation	
Parameter name	Description
LEVEL SELECTION (020) Options	<p>Select level mode.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> MEASURING MODE = Level <p> Note!</p> <ul style="list-style-type: none"> In the "Level Easy Pressure" and "Level Easy Height" level modes, the values entered are not tested as extensively as in the "Level Standard" level mode. The values entered for EMPTY CALIB./FULL CALIB., EMPTY PRESSURE/FULL PRESSURE, EMPTY HEIGHT/FULL HEIGHT and SET LRV/SET URV must have a minimum interval of 1% for the "Level Easy Pressure" and "Level Easy Height" level modes. The value will be rejected with a warning message if the values are too close together. Further limit values are not checked; i.e. the values entered must be appropriate for the sensor and the measuring task so that the measuring device can measure correctly. → For an overview of the different level modes and types, see Page 14, Section 5.1 "Overview of level measurement". The "Level Easy Pressure" and "Level Easy Height" level modes encompass fewer parameters than the "Level Standard" mode and are used for quick and easy configuration of a level application. Customer-specific units of fill level, volume and mass or a linearization table may only be entered in the "Level Standard" level mode. Where the device is intended for use as a subsystem in a safety function (SIL), a "Device configuration with enhanced parameter security" (SAFETY CONFIRM.) is only possible for the "Level" operating mode in the "Level Easy Pressure" level mode. All parameters previously entered are checked after a password is entered. Once the "Level Easy Height" or "Level Standard" has been selected, the configuration will first have to be reset to the ex-works setting using the RESET parameter (menu path: (GROUP SELECTION →) OPERATING MENU → OPERATION) using the reset code "7864". → For additional information, see the Safety Manual for Deltabar S (SD00189), Cerabar S (SD00190) or Deltapilot S (SD00213P). <p>Options:</p> <ul style="list-style-type: none"> Level Easy Pressure Specify two pressure-level value pairs for this level mode. The pressure measured value is converted directly to the unit which is selected via the OUTPUT UNIT parameter (→ Page 60). Two calibration modes, "Wet" and "Dry", are available. <ul style="list-style-type: none"> Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time. Dry calibration is a theoretical calibration. For this calibration, specify two pressure-level value pairs via the EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE parameters. → Parameter descriptions see Page 61 ff. Level Easy Height For this level mode, specify a height unit, density and two height-level value pairs. The pressure measured value is converted to a height value using the density entered and the height unit. Two calibration modes, "Wet" and "Dry", are available. <ul style="list-style-type: none"> Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the converted height value. Dry calibration is a theoretical calibration. For this calibration, specify two height-level value pairs via the EMPTY CALIB., EMPTY HEIGHT, FULL CALIB. and FULL HEIGHT parameters. → Parameter descriptions see Page 65 ff. Level standard Once you have selected this level mode, you can use the LEVEL MODE parameter (→ Page 68) to choose between "Linear", "Pressure Linearized" and "Height Linearized". <p>Factory setting: Level Easy Pressure</p> <p>→ For LEVEL SELECTION = "Level Easy Pressure" see Page 58, Table 8. → For LEVEL SELECTION = "Level Easy Height" see Page 62, Table 9. → For LEVEL SELECTION = "Level standard" see Page 67, Table 10.</p>




Fig. 23: Quick Setup menu for the "Pressure" measuring mode

Table 3: (GROUP SELECTION →) QUICK SETUP "Pressure"	
Parameter name	Description
<p>This menu displays the most important parameters for the "Pressure" measuring mode.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> MEASURING MODE = Pressure (→ see also Page 45). <p>Note:</p> <p>See also</p> <ul style="list-style-type: none"> Page 55 ff, Table 7: BASIC SETUP Page 96, Table 15: EXTENDED SETUP Page 121 ff, Table 27: PROCESS VALUES Page 11 ff, Section 4 "Pressure measurement". 	
MEASURING MODE Selection	<p>Select the measuring mode.</p> <p>The operating menu is structured according to the selected measuring mode.</p> <p>Warning!</p> <p>If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> Digital communication <p>Options:</p> <ul style="list-style-type: none"> Pressure Level Deltabar S: Flow <p>Factory setting:</p> <ul style="list-style-type: none"> Cerabar S and Deltabar S: Pressure Deltapilot S: Level

Table 3: (GROUP SELECTION →) QUICK SETUP "Pressure"	
Parameter name	Description
POS. ZERO ADJUST (685) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 2.2 mbar (0.033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar – The current value is also corrected. <p>The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ This parameter is displayed for Deltabar S, Cerabar S with gauge pressure sensor and Deltapilot S. <p>Options:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm <p>Factory setting: 0.0</p>
POS. INPUT VALUE (563) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e. g. from a reference device). Due to the orientation of the device, there may be a shift in the measured value, i.e. for example, when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero or the desired value.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 0.5 mbar (0.0075 psi) – For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2 mbar. (MEASURED VALUE_{new} = POS. INPUT VALUE) – MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) – The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. CALIB. OFFSET = MEASURED VALUE_{old} – POS. INPUT VALUE, here: CALIB. OFFSET = 0.5 mbar (0.0075 psi) – 2.0 mbar (0.03 psi) = – 1.5 mbar (0.0225 psi) – The current value is also corrected. <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ This parameter is displayed for Cerabar S with absolute pressure sensors. <p>Factory setting: 0.0</p>
SET LRV (245) Entry	<p>Set lower range value – without reference pressure. Enter pressure value for the lower current value (4 mA).</p> <p>Factory setting: 0.0 or as per order specifications</p>
SET URV (246) Entry	<p>Set upper range value – without reference pressure. Enter pressure value for the upper current value (20 mA).</p> <p>Factory setting: High sensor limit (→ see PRESS. SENS HILIM, Page 119) or as per order specifications</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>




Fig. 24: Quick Setup menu for the "Level" measuring mode

Table 4: (GROUP SELECTION →) QUICK SETUP "Level"

Parameter name	Description
<p>This menu displays the most important parameters for the "Level" measuring mode.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> MEASURING MODE = Level (→ see also Page 45). <p>Note:</p> <p>See also</p> <ul style="list-style-type: none"> Page 67 ff, Tables 10 to 13: BASIC SETUP Page 96 ff, Table 16: EXTENDED SETUP Page 100 ff, Table 18: LINEARISATION – on-site operation Page 104 ff, Table 19: LINEARISATION – Digital communication Page 122 ff, Table 28: PROCESS VALUES Page 14 ff, Section 5 "Level measurement". 	
MEASURING MODE Selection	<p>Select the measuring mode.</p> <p>The operating menu is structured according to the selected measuring mode.</p> <p>Warning!</p> <p>If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> Digital communication <p>Options:</p> <ul style="list-style-type: none"> Pressure Level Deltabar S: Flow <p>Factory setting:</p> <ul style="list-style-type: none"> Cerabar S and Deltabar S: Pressure Deltapilot S: Level
LEVEL SELECTION (020) Options	<p>Select level mode.</p> <p>→ Parameter description, see Page 46.</p> <p>Factory setting:</p> <p>Level Easy Pressure</p>




Table 4: (GROUP SELECTION →) QUICK SETUP "Level"	
Parameter name	Description
POS. ZERO ADJUST (685) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 2.2 mbar (0.033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar – The current value is also corrected. <p>The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ This parameter is displayed for Deltabar S, Cerabar S with gauge pressure sensor and Deltapilot S. <p>Options:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm <p>Factory setting: 0.0</p>
POS. INPUT VALUE (563) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e. g. from a reference device). Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero or the desired value.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 0.5 mbar (0.0075 psi) – For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.03 psi). (MEASURED VALUE_{new} = POS. INPUT VALUE) – MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) – The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. CALIB. OFFSET = MEASURED VALUE_{old} – POS. INPUT VALUE, here: CALIB. OFFSET = 0.5 mbar (0.0075 psi) – 2.0 mbar (0.03 psi) = – 1.5 mbar (0.0225 psi) – The current value is also corrected. <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ This parameter is displayed for Cerabar S with absolute pressure sensors. <p>Factory setting: 0.0</p>
EMPTY CALIB. (314)/(010) Entry	<p>Enter level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LEVEL SELECTION = Level Easy Pressure (→ see also Page 46), CALIBRATION MODE = Wet (→ see also Page 60) ■ LEVEL SELECTION = Level Standard (→ see also Page), LEVEL MODE = Linear (→ see also Page 68), CALIBRATION MODE = Wet (→ see also Page 73) <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 0.0</p>

Table 4: (GROUP SELECTION →) QUICK SETUP "Level"

Parameter name	Description
FULL CALIB. (315)/(004) Entry	<p>Enter level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LEVEL SELECTION = Level Easy Pressure (→ see also Page 46), CALIBRATION MODE = Wet (→ see also Page 60) ■ LEVEL SELECTION = Level Standard, LEVEL MODE = Linear (→ see also Page 68), CALIBRATION MODE = Wet (→ see also Page 73) <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 100.0</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>



P01-xxxxxxx-19-xx-xx-xx-082

Fig. 25: Quick Setup menu, "Flow" measuring mode

Table 5: (GROUP SELECTION →) QUICK SETUP "Flow"





Parameter name	Description
<p>This menu displays the most important parameters for the "Flow" measuring mode.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Deltabar S differential pressure transmitter ■ MEASURING MODE = Flow (→ see also Page 45). <p>Note:</p> <p>See also</p> <ul style="list-style-type: none"> – Page 91, Table 14: BASIC SETUP – Page 98, Table 17: EXTENDED SETUP – Page 107, Table 20: TOTALIZER SETUP – Page 40 ff, Section 6 "Flow measurement". 	
MEASURING MODE Selection	<p>Select the measuring mode.</p> <p>The operating menu is structured according to the selected measuring mode.</p> <p> Warning!</p> <p>If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.</p> <p>Prerequisites:</p> <ul style="list-style-type: none"> ■ Digital communication <p>Options:</p> <ul style="list-style-type: none"> ■ Pressure ■ Level ■ Deltabar S: Flow <p>Factory setting:</p> <ul style="list-style-type: none"> ■ Cerabar S and Deltabar S: Pressure ■ Deltapilot S: Level
POS. ZERO ADJUST (685) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. (A reference pressure is present at the device.)</p> <p>Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the MEASURED VALUE parameter does not display zero.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 2.2 mbar (0,033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar – The current value is also corrected. <p>The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.</p> <p>Selection:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm <p>Factory setting:</p> <p>0.0</p>
MAX. FLOW (311) Entry	<p>Enter maximum flow of primary element.</p> <p>See also layout sheet of primary element. The maximum flow is assigned to the maximum pressure which you enter via MAX PRESS. FLOW.</p> <p> Note!</p> <p>Use the LINEAR/SQROOT parameter (→ Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Flow (square root)" setting:</p> <p>If you enter a new value for MAX. FLOW, the value for SET URV is also changed. Use SET URV to assign a flow to the upper current value. If you want to assign the upper current value a value other than that for MAX. FLOW, you must enter the desired value for SET URV. (→ SET URV, Page 100).</p> <p>Factory setting:</p> <p>1.0</p>


Table 5: (GROUP SELECTION →) QUICK SETUP "Flow"

Parameter name	Description
MAX PRESS. FLOW (634) Entry	<p>Enter maximum pressure of primary element. → See layout sheet of primary element. This value is assigned to the maximum flow value (→ see MAX. FLOW).</p> <p> Note! Use the LINEAR/SQROOT parameter (→ Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Differential pres." setting: If you enter a new value for MAX PRESS. FLOW, the value for SET URV is also changed. Use SET URV to assign a pressure value to the upper current value. If you want to assign the upper current value a value other than that for MAX PRESS. FLOW, you must enter the desired value for SET URV. (→ SET URV, Page 100).</p> <p>Factory setting: High sensor limit (→ See PRESS. SENS HILIM, Page 119)</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>

**Fig. 26: POSITION ADJUSTMENT function group****Table 6: (GROUP SELECTION →) OPERATING MENU → SETTINGS → POSITION ADJUSTMENT**

Parameter name	Description
<p>Due to the orientation of the device, there may be a shift in the measured value, i.e. when the container is empty or partly filled, the measured value does not display zero. Deltabar S and Cerabar S offer three different ways of performing a position adjustment.</p> <p>Recommendation:</p> <ul style="list-style-type: none"> ■ The pressure difference between zero (set point) and the measured pressure need not be known. <ul style="list-style-type: none"> – POS. ZERO ADJUST: Deltabar S or Cerabar S with gauge pressure sensor or Deltapilot S. – POS. INPUT VALUE: Cerabar S with absolute pressure sensor. ■ The pressure difference between zero (set point) and the measured pressure is known. <ul style="list-style-type: none"> – CALIB. OFFSET: Deltabar S, Cerabar S with gauge pressure sensor, Cerabar S with absolute pressure sensor or Deltapilot S. 	

Table 6: (GROUP SELECTION →) OPERATING MENU → SETTINGS → POSITION ADJUSTMENT	
Parameter name	Description
POS. ZERO ADJUST (685) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 2.2 mbar (0.033 psi) – Correct the MEASURED VALUE via the POS. ZERO ADJUST parameter with the "Confirm" option. This means that you are assigning the value 0.0 to the pressure present. – MEASURED VALUE (after pos. zero adjust) = 0.0 mbar – The current value is also corrected. <p>The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected.</p> <p>Selection:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm <p>Factory setting: 0.0</p>
POS. INPUT VALUE (563) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure need not be known. To correct the pressure difference, you need a reference measurement value (e. g. from a reference device).</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 0.5 mbar (0.0075 psi) – For the POS. INPUT VALUE parameter, specify the desired set point for the MEASURED VALUE, e.g. 2.0 mbar (0.03 psi). (MEASURED VALUE_{new} = POS. INPUT VALUE) – MEASURED VALUE (after entry for POS. INPUT VALUE) = 2.0 mbar (0.03 psi) – The CALIB. OFFSET parameter displays the resulting pressure difference (offset) by which the MEASURED VALUE was corrected. CALIB. OFFSET = MEASURED VALUE_{old} – POS. INPUT VALUE, here: CALIB. OFFSET = 0.5 mbar (0.0075 psi) – 2.0 mbar (0.03 psi) = – 1.5 mbar (0.0225 psi) – The current value is also corrected. <p>Factory setting: 0.0</p>
CALIB. OFFSET (319) Entry	<p>Position adjustment – the pressure difference between zero (set point) and the measured pressure is known.</p> <p>Example:</p> <ul style="list-style-type: none"> – MEASURED VALUE = 2.2 mbar (0.033 psi) – Via the CALIB. OFFSET parameter, enter the value by which the MEASURED VALUE should be corrected. To correct the MEASURED VALUE to 0.0 mbar, you must enter the value 2.2 here. (MEASURED VALUE_{new} = MEASURED VALUE_{old} – CALIB. OFFSET) – MEASURED VALUE (after entry for calib. offset) = 0.0 mbar – The current value is also corrected. <p>Factory setting: 0.0</p>



P01-xxxxxxx-19-xx-xx-xx-084

Fig. 27: BASIC SETUP function group for the "Pressure" measuring mode

Table 7: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Pressure"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Pressure (→ see also Page 45).	
Note: See also – Page 47, Table 3: QUICK SETUP – Page 96, Table 15: EXTENDED SETUP – Page 121 ff, Table 27: PROCESS VALUES – Page 11 ff, Section 4 "Pressure measurement".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode. <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Warning!</p> <p>If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.</p> </div> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Digital communication <p>Options:</p> <ul style="list-style-type: none"> ■ Pressure ■ Level ■ Deltabar S: Flow <p>Factory setting:</p> <ul style="list-style-type: none"> ■ Cerabar S and Deltabar S: Pressure ■ Deltapilot S: Level


Table 7: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Pressure"	
Parameter name	Description
PRESS. ENG. UNIT (060) Selection	<p>Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ¹⁾ ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ²⁾ ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. <p>1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F).</p> <p>Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications</p>
CUSTOMER UNIT P (075) Entry	<p>Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. P (317) Entry	<p>Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 10000 Pa ≈ 1 PU – Entry CUSTOMER UNIT P: PU – Entry CUST. UNIT FACT. P: 0.0001 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>
SET LRV (245) Entry	<p>Set lower range value – without reference pressure. Enter pressure value for the lower current value (4 mA).</p> <p>Factory setting: 0.0 or as per order specifications</p>

Table 7: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Pressure"	
Parameter name	Description
SET URV (246) Entry	<p>Set upper range value – without reference pressure. Enter pressure value for the upper current value (20 mA).</p> <p>Factory setting: High sensor limit (→ See PRESS. SENS HILIM, Page 119)</p>
GET LRV (309) Entry	<p>Set lower range value – reference pressure is present at device. The pressure for the lower current value (4 mA) is present at device. With the "Confirm" option, you assign the lower current value to the pressure value present. On-site display: the pressure value present is displayed in the bottom line.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm
GET URV (310) Entry	<p>Set upper range value – reference pressure is present at device. The pressure for the upper current value (20 mA) is present at device. With the "Confirm" option, you assign the upper current value to the pressure value present. On-site display: the pressure value present is displayed in the bottom line.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>




Fig. 28: BASIC SETUP function group for the "Level" measuring mode and "Level Easy Pressure" level selection

Table 8: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Pressure"
The following parameters are displayed if you have selected the "Level Easy Pressure" option for the LEVEL SELECTION parameter. Specify two pressure-level value pairs for this level mode. Two calibration modes, "Wet" and "Dry", are available.
Prerequisite:
■ MEASURING MODE = Level (→ see also Page 45.)
■ LEVEL SELECTION = Level Easy Pressure (→ See also Page 46.)


Table 8: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Pressure"	
PRESS. ENG. UNIT (060) Selection	<p>Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ¹⁾ ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ²⁾ ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. <p>1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F).</p> <p>Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications</p>
CUSTOMER UNIT P (075) Entry	<p>Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. P (317) Entry	<p>Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 10000 Pa ≙ 1 PU – Entry CUSTOMER UNIT P: PU – Entry CUST. UNIT FACT. P: 0.0001 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>




Table 8: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Pressure"	
OUTPUT UNIT (023) Selection	<p>Select unit for measured value display and MEASURED VALUE parameter (→ Page 122).</p> <p> Note! The selected unit is used only to describe the measured value. This means that when selecting a new output unit, the measured value is not converted.</p> <p>Example:</p> <ul style="list-style-type: none"> ■ current measured value: 0.3 ft ■ new output unit: m ■ new measured value: 0.3 m (9.8 ft) <p>Options</p> <ul style="list-style-type: none"> ■ % ■ mm, cm, dm, m ■ ft, inch ■ cm³, dm³, m³, m³ E³ ■ l, hl ■ ft³, ft³ E³ ■ gal, bbl, lgal ■ g, kg, t ■ lb, ton, oz <p>Factory setting: %</p>
CALIBRATION MODE (008) Selection	<p>Select calibration mode.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Wet Wet calibration takes place by filling and emptying the container. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the pressure measured at this point in time. (→ See also this table, parameter descriptions for EMPTY CALIB. and FULL CALIB.) ■ Dry Dry calibration is a theoretical calibration. For this calibration, specify two pressure-level value pairs via the following parameters: EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. <p>Factory setting: Wet</p>
EMPTY CALIB. (010) Entry	<p>Enter level, volume, mass or percentage value for the lower calibration point (container empty).</p> <p>The container is either empty or part full. By entering a value for this parameter, you assign a level, volume, mass or percentage value to the pressure present at the device. The unit is selected via the OUTPUT UNIT parameter (→ Page 60).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 0.0</p>
FULL CALIB. (004) Entry	<p>Enter height, volume or mass value for the upper calibration point (container full).</p> <p>The container is either completely or almost full. By entering a value for this parameter, you assign a height, volume or mass value to the pressure present at the device. The unit is selected via the OUTPUT UNIT parameter (→ Page 60).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 100.0</p>

Table 8: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Pressure"	
EMPTY CALIB. (010) Entry	<p>Enter level, volume, mass or percentage value for the lower calibration point (container empty). The values entered for the EMPTY CALIB. and EMPTY PRESSURE parameters form the pressure-level value pair for the lower calibration point. The unit is selected via the OUTPUT UNIT parameter (→ Page 60).</p> <p>Prerequisite: ■ CALIBRATION MODE = Dry</p> <p>Factory setting: 0.0</p>
EMPTY PRESSURE (011) Entry	<p>Enter pressure value for the lower calibration point (container empty). → See also EMPTY CALIB.</p> <p>Prerequisite: ■ CALIBRATION MODE = Dry</p> <p>Factory setting: 0.0</p>
FULL CALIB. (004) Entry	<p>Enter height, volume, mass or percentage value for the upper calibration point (container full). The values entered for the FULL CALIB. and FULL PRESSURE parameters form the pressure-level value pair for the upper calibration point. The unit is selected via the OUTPUT UNIT parameter (→ Page 60).</p> <p>Prerequisite: ■ CALIBRATION MODE = Dry</p> <p>Factory setting: 100.0</p>
FULL PRESSURE (005) Entry	<p>Enter pressure value for the upper calibration point (container full). → See also FULL CALIB.</p> <p>Prerequisite: ■ CALIBRATION MODE = Dry</p> <p>Factory setting: 100.0</p>
SET LRV (013) Entry	<p>Enter value for the lower current value (4 mA). The unit is selected via the OUTPUT UNIT parameter (→ Page 60).</p> <p>Factory setting: 0.0</p>
SET URV (012) Entry	<p>Enter value for the upper current value (20 mA). The unit is selected via the OUTPUT UNIT parameter (→ Page 60).</p> <p>Factory setting: 100.0</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0 to 999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>




Fig. 29: BASIC SETUP function group for "Level" measuring mode and "Level Easy Height" level selection

Table 9: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"
The following parameters are displayed if you have selected the "Level Easy Height" option for the LEVEL SELECTION parameter. For this level mode, specify a height unit, density and two height-level value pairs. The pressure measured value is converted to a height value using the density entered and the height. Two calibration modes, "Wet" and "Dry", are available.
Prerequisite: <ul style="list-style-type: none">■ MEASURING MODE = Level (→ see also Page 45.)■ LEVEL SELECTION = Level Easy Height (→ See also Page 46.)

Table 9: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"


<p>PRESS. ENG. UNIT (060) Options</p>	<p>Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ¹⁾ ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ²⁾ ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. <p>1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F).</p> <p>Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications</p>
<p>CUSTOMER UNIT P (075) Entry</p>	<p>Enter text (unit) for customised pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customised unit is displayed only in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
<p>CUST. UNIT FACT. P (317) Entry</p>	<p>Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 10000 Pa $\hat{=}$ 1 PU – Entry CUSTOMER UNIT P: PU – Entry CUST. UNIT FACT. P: 0.0001 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>


Table 9: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"	
OUTPUT UNIT (023) Options	<p>Select unit for measured value display and MEASURED VALUE parameter (→ Page 122).</p> <p> Note! The selected unit is used only to describe the measured value. This means that when selecting a new output unit, the measured value is not converted.</p> <p>Example:</p> <ul style="list-style-type: none"> ■ current measured value: 0.3 ft ■ new output unit: m ■ new measured value: 0.3 m (9.8 ft) <p>Options:</p> <ul style="list-style-type: none"> ■ % ■ mm, cm, dm, m ■ ft, inch ■ cm³, dm³, m³, m³ E³ ■ l, hl ■ ft³, ft³ E³ ■ gal, bbl, lgal ■ g, kg, t ■ lb, ton, oz <p>Factory setting: %</p>
HEIGHT UNIT (003) Options	<p>Select height unit. The measured pressure is converted to the chosen height unit using the DENSITY UNIT and ADJUST DENSITY parameters.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ mm ■ cm ■ dm ■ m ■ inch ■ ft <p>Factory setting: m</p>
CALIBRATION MODE (008) Options	<p>Select calibration mode.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Wet Wet calibration takes place by filling and emptying the container. The measured pressure is converted to the chosen height unit using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters. In the case of two different levels, the level, volume, mass or percentage value entered is assigned to the converted height value. ■ Dry Dry calibration is a theoretical calibration. For this calibration, specify two height-level value pairs via the EMPTY CALIB., EMPTY HEIGHT, FULL CALIB. and FULL HEIGHT parameters. <p>Factory setting: Dry</p>
DENSITY UNIT (001) Options	<p>Select density unit. The measured pressure is converted to a height using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ <p>Factory setting: kg/dm³</p>
ADJUST DENSITY (007) Entry	<p>Enter density of fluid. The measured pressure is converted to a height using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters.</p> <p>Factory setting: 1.0</p>

Table 9: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"



EMPTY CALIB. (010) Entry	<p>Enter level, volume, mass or percentage value for the lower calibration point (container empty). The container is either empty or part full. The measured pressure is converted to a height value using the HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY parameters and displayed. Using the parameter EMPTY CALIB., you assign a level, volume, mass or percentage value to the height value. The unit is selected via the OUTPUT UNIT parameter (→ Page 64).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 0.0</p>
FULL CALIB. (004) Entry	<p>Enter level, volume, mass or percentage value for the upper calibration point (container full). The container is either completely or almost full. Using the parameters HEIGHT UNIT, DENSITY UNIT and ADJUST DENSITY, the measured pressure is converted to a height value and displayed. Using the parameter FULL CALIB., you assign a level, volume, mass or percentage value to the height value. The unit is selected via the OUTPUT UNIT parameter (→ Page 64).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 100.0</p>
EMPTY CALIB. (010) Entry	<p>Enter level, volume, mass or percentage value for the lower calibration point (container empty). The values entered for the EMPTY CALIB. and EMPTY HEIGHT parameters form the height-level value pair for the lower calibration point. The unit is selected via the OUTPUT UNIT parameter (→ Page 64).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Dry <p>Factory setting: 0.0</p>
EMPTY HEIGHT (009) Entry	<p>Height value for the lower calibration point (container empty). The unit is selected via the HEIGHT UNIT parameter (→ Page 64). → See also EMPTY CALIB.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Dry <p>Factory setting: Upper range limit (URL) converted to an height unit</p>
FULL CALIB. (004) Entry	<p>Enter level, volume, mass or percentage value for the upper calibration point (container full). The values entered for the FULL CALIB. and FULL HEIGHT parameters form the height-level value pair for the upper calibration point. The unit is selected via the OUTPUT UNIT parameter (→ Page 64).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Dry <p>Factory setting: 100.0</p>

Table 9: (GROUP SELECTION→) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL SELECTION "Level Easy Height"	
FULL HEIGHT (006) Entry	Enter height value for the upper calibration point (container full). The unit is selected via the HEIGHT UNIT parameter (→ Page 64). → See also FULL CALIB. Prerequisite: ■ CALIBRATION MODE = Dry Factory setting: 0.0
SET LRV (013) Entry	Enter level, volume, mass or percentage value for the lower current value (4 mA). The unit is selected via the OUTPUT UNIT parameter (→ Page 64). Factory setting: 0.0
SET URV (012) Entry	Enter level, volume, mass or percentage value for the upper current value (20 mA). The unit is selected via the OUTPUT UNIT parameter (→ Page 64). Factory setting: 100.0
DAMPING VALUE (247) Entry	Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure. Input range: 0.0 to 999.0 s Factory setting: 2.0 s or as per order specifications




Fig. 30: BASIC SETUP function group for the "Level" measuring mode, depending on the setting for the LEVEL MODE parameter
→ See Page 69, Fig. 31 for LEVEL MODE = Linear,
→ See Page 78, Fig. 33 for LEVEL MODE = Pressure Linearized,
→ See Page 82, Fig. 34 for LEVEL MODE = Height Linearized



Table 10: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = level (→ see also Page 45). Note: See also – Page 70 ff, Tables 11 to 13: BASIC SETUP – contd. – Page 96 ff, Table 16: EXTENDED SETUP – Page 100 ff, Table 18: LINEARISATION – on-site operation – Page 104 ff, Table 19: LINEARISATION – Digital communication – Page 122 ff, Table 28: PROCESS VALUES – Page 14 ff, Section 5 "Level measurement".	
MEASURING MODE Selection	Select the measuring mode. The operating menu is structured according to the selected measuring mode.  Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured. Prerequisite: ■ Digital communication Options: ■ Pressure ■ Level ■ Deltabar S: Flow Factory setting: Pressure
PRESS. ENG. UNIT (060) Selection	Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit. Options: ■ mbar, bar ■ mmH2O, mH2O, inH2O, ftH2O ¹⁾ ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ²⁾ ■ Torr ■ g/cm ² , kg/cm ² ■ lb/ft ² ■ atm ■ gf/cm ² , kgf/cm ² ■ User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. 1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F). Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications

Table 10: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level"	
Parameter name	Description
CUSTOMER UNIT P (075) Entry	<p>Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. P (317) Entry	<p>Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 10000 Pa $\hat{=}$ 1 PU – Entry CUSTOMER UNIT P: PU – Entry CUST. UNIT FACT. P: 0.0001 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>
LEVEL MODE (718) Selection	<p>Select level type.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Linear: the measured variable (level, volume, mass or %) is in direct proportion to the measured pressure. → See also Page 70 ff, Table 9. ■ Pressure Linearized: the measured variable (volume, mass or %) is not in direct proportion to the measured pressure such as in the case of containers with a conical outlet. For the calibration, enter a linearisation table with at least 2 and not more than 32 points. → See also Page 78 ff, Table 10. ■ Height Linearized: select this level type if you require two measured variables or if the container shape is given with value pairs, e.g. height and volume. The following combinations are possible: <ul style="list-style-type: none"> – Height + Volume – Height + Mass – Height + % – %-Height + Volume – %-Height + Mass – %-Height + % <p>Perform two calibrations for this level type. First for the measured variable height or %-height like for the "Linear" option and then for the measured variable volume, mass or % like for the "Pressure Linearized" option. → See also Page 83 ff, Table 11.</p> <p>Factory setting: Linear</p>
<p>→ For LEVEL MODE = Linear, see Page 70, Table 9. → For LEVEL MODE = Pressure Linearized, see Page 78, Table 10. → For LEVEL MODE = Height Linearized, see Page 83, Table 11.</p>	




Fig. 31: BASIC SETUP function group for the "Level" measuring mode and "Linear" level type

Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"


Parameter name	Description
<p>The following parameters are displayed if you selected the "Linear" option for the LEVEL MODE parameter. For this level type, the measured variable (level, volume, mass or %) is in direct proportion to the measured pressure.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Level (→ see also Page 45). ■ LEVEL SELECTION = Level Standard (→ see also Page 46). ■ LEVEL MODE = Linear (→ see also Page 68). <p>Note:</p> <p>See also</p> <ul style="list-style-type: none"> – Page 67 ff, Table 10: BASIC SETUP – general – Page 96 ff, Table 16: EXTENDED SETUP – Page 122 ff, Table 28: PROCESS VALUES – Page 14 ff, Section 5 "Level measurement". 	
LIN. MEASURAND (804) Selection	<p>Select measured variable.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Level ■ Volume ■ Mass ■ % (Level) <p>Factory setting:</p> <p>% (Level)</p>
HEIGHT UNIT (708) Selection	<p>Select level unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Level <p>Options:</p> <ul style="list-style-type: none"> ■ mm ■ cm ■ dm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H. <p>Factory setting:</p> <p>m</p>
CUSTOMER UNIT H (706) Entry	<p>Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Level, HEIGHT UNIT = User unit <p> Note!</p> <p>Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed.</p> <p>If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed.</p> <p>In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting:</p> <p>-----</p>

Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"


Parameter name	Description
CUST. UNIT FACT. H (705) Entry	<p>Enter conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Level, HEIGHT UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 0.5 m (1.6 ft) \approx 1 PU – Entry CUSTOMER UNIT H: PU – Entry CUST. UNIT FACT. H: 2 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>
UNIT VOLUME (313) Selection	<p>Select volume unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume <p>Options:</p> <ul style="list-style-type: none"> ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V. <p>Factory setting: m³</p>
CUSTOMER UNIT V (608) Entry	<p>Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>


Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
CUST. UNIT FACT. V (607) Entry	<p>Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 0.01 m³ ≈ 1 bucket – Entry CUSTOMER UNIT V: bucket – Entry CUST. UNIT FACT. V: 100 – Result: MEASURED VALUE = 1 bucket <p>Factory setting: 1.0</p>
MASS UNIT (709) Selection	<p>Select mass unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Mass <p>Options:</p> <ul style="list-style-type: none"> ■ g ■ kg ■ t ■ oz ■ lb ■ ton ■ User unit, → see also the following parameter description for CUSTOMER UNIT M and CUST. UNIT FACT. M. <p>Factory setting: kg</p>
CUSTOMER UNIT M (704) Entry	<p>Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. M.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Mass, MASS UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT M parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>

Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"



Parameter name	Description
CUST. UNIT FACT. M (703) Entry	<p>Enter conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also CUSTOMER UNIT M.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Mass, MASS UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 10 kg $\hat{=}$ 1 bucket – Entry CUSTOMER UNIT M: bucket – Entry CUST. UNIT FACT. M: 0.1 – Result: MEASURED VALUE = 1 bucket <p>Factory setting: 1.0</p>
CALIBRATION MODE (392) Selection	<p>Select calibration mode.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Wet Wet calibration takes place by filling and emptying the container. This calibration mode requires two pressure-level value pairs to be entered. In the case of two different levels, the level value is entered and the pressure measured at this moment is assigned to the level value. → See also the following parameter description for EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. ■ Dry Dry calibration is a theoretical calibration which you can carry out even if the device is not mounted or the container is empty. <ul style="list-style-type: none"> – For the "Level" measured variable, the density of the fluid (→ see Page 74, ADJUST DENSITY) must be entered. – For the "Volume" measured variable, the density of the fluid and the tank volume and tank height must be entered (→ see Page 74, ADJUST DENSITY, TANK VOLUME and TANK HEIGHT). – For the "Mass" measured variable, the tank volume and the tank height must be entered (→ see Page 75, TANK VOLUME and TANK HEIGHT). The density must also be entered in the case of a zero point shift (level offset) (→ see Page 74, ADJUST DENSITY). – For the "%" measured variable, the density of the fluid must be entered and a level assigned to the 100 % point (→ see Page 74 and 77, ADJUST DENSITY and 100% POINT). <p>If the measurement should not start at the mounting location of the device, a level offset must be entered (→ see Page 77, ZERO POSITION).</p> <p> Note! LIN. MEASURAND: "% (Level)", "Mass" and "Volume": If the change to dry calibration is made after a wet calibration, the density must be entered correctly using the ADJUST DENSITY and DENSITY PROCESS parameter before changing the calibration mode. → See also Page 97.</p> <p>Factory setting: Wet</p>
EMPTY CALIB. (314) Entry	<p>Enter level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also EMPTY PRESSURE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 0.0</p>


Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
EMPTY PRESSURE (710) Display	<p>Displays the pressure value for the lower calibration point (container empty). → See also EMPTY CALIB.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p>Factory setting: 0.0</p>
FULL CALIB. (315) Entry	<p>Enter level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also FULL PRESSURE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p> Note! For this parameter, the on-site display shows the level value to be entered and the pressure present at the device. In order for the level value to be saved together with the pressure present at the device, the entry field for the level value must first be activated using the "+"- or "-" key before confirming with the "E" key. This applies also if the level value is to remain unchanged.</p> <p>Factory setting: 100.0</p>
FULL PRESSURE (711) Display	<p>Displays the pressure value for the upper calibration point (container full). → See also FULL CALIB.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p>Factory setting: High sensor limit (→ see PRESS. SENS HILIM, Page 119)</p>
ADJUSTED DENSITY (810) Display	<p>Displays the density calculated from the upper and lower level point.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet, LIN. MEASURAND = Level
DENSITY UNIT (812) Selection	<p>Select density unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Level, CALIBRATION MODE = Dry ■ LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry <p>Options:</p> <ul style="list-style-type: none"> ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ <p>Factory setting: kg/dm³</p>
ADJUST DENSITY (316) Entry	<p>Enter density of fluid.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Level, CALIBRATION MODE = Dry ■ LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry <p>Factory setting: 1000.0</p>

Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"


Parameter name	Description
UNIT VOLUME (313) Selection	<p>Select volume unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume <p>Options:</p> <ul style="list-style-type: none"> ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V. <p>Factory setting: m³</p>
CUSTOMER UNIT V (608) Entry	<p>Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. V (607) Entry	<p>Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume, UNIT VOLUME = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 0.01 m³ ≈ 1 bucket – Entry CUSTOMER UNIT V: bucket – Entry CUST. UNIT FACT. V: 100 – Result: MEASURED VALUE = 1 bucket <p>Factory setting: 1.0</p>
TANK VOLUME (858) Entry	<p>Enter tank volume.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry <p>Factory setting: 1.0 m³</p>


Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"	
Parameter name	Description
HEIGHT UNIT (708) Selection	<p>Select level unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry <p>Options:</p> <ul style="list-style-type: none"> ■ mm ■ dm ■ cm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H. <p>Factory setting:</p> <p>m</p>
CUSTOMER UNIT H (706) Entry	<p>Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry, HEIGHT UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting:</p> <p>-----</p>
CUST. UNIT FACT. H (705) Entry	<p>Enter conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry, HEIGHT UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 0.5 m (1.6 ft) $\hat{=}$ 1 PU – Entry CUSTOMER UNIT H: PU – Entry CUST. UNIT FACT. H: 2 – Result: MEASURED VALUE = 1 PU <p>Factory setting:</p> <p>1.0</p>
TANK HEIGHT (859) Entry	<p>Enter tank height.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = Volume, CALIBRATION MODE = Dry ■ LIN. MEASURAND = Mass, CALIBRATION MODE = Dry <p>Factory setting:</p> <p>1.0 m</p>

Table 11: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Linear"

Parameter name	Description
100% POINT (813) Entry	<p>Enter level value for 100% point.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LIN. MEASURAND = % (Level), CALIBRATION MODE = Dry <p>Example:</p> <ul style="list-style-type: none"> – The 100 %-point should correspond to 4 m (13 ft). – Select the "m" unit via the HEIGHT UNIT parameter. – Enter the value "4" for this parameter (100% POINT). <p>Factory setting: 1.0</p>
ZERO POSITION (814) Entry	<p>Enter value for level offset.</p> <p>If the measurement should not start at the mounting location of the device, e.g. for containers with a sump, carry out zero point shift (level offset).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Dry <p>Factory setting: 0.0</p> <div data-bbox="938 814 1339 1136"> </div> <p><small>P01-PMP75xxx-19-xx-xx-xx-001</small></p> <p><i>Fig. 32: Zero point shift</i></p> <ol style="list-style-type: none"> 1 Device is mounted above the level lower range value: a positive value has to be entered for ZERO POSITION. 2 Device is mounted below the level lower range value: a negative value has to be entered for ZERO POSITION.
SET LRV (719) Entry	<p>Enter level value for the lower current value (4 mA).</p> <p>Factory setting: 0.0</p>
SET URV (720) Entry	<p>Enter level value for the upper current value (20 mA).</p> <p>Factory setting: 100.0</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ).</p> <p>The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>




Fig. 33: BASIC SETUP function group for the "Level" measuring mode and the "Pressure Linearized" level type, continue calibration with LINEARISATION function group
→ See Page 100 ff for on-site operation and Page 104 ff for operation with digital communication.

Table 12: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"

Parameter name	Description
<p>The following parameters are displayed if you selected the "Pressure Linearized" option for the LEVEL MODE parameter. For this level type, the measured variable (volume, mass or %) is not in direct proportion to the measured pressure. For the calibration, enter a linearisation table with at least 2 and not more than 32 points.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Level (→ see also Page 45). ■ LEVEL SELECTION = Level Standard (→ see also Page 46). ■ LEVEL MODE = Pressure Linearized (→ see also Page 68). <p>Note:</p> <p>See also</p> <ul style="list-style-type: none"> – Page 67 ff, Table 10: BASIC SETUP – general – Page 96 ff, Table 16: EXTENDED SETUP – Page 100 ff, Table 18: LINEARISATION – on-site operation – Page 104 ff, Table 19: LINEARISATION – Digital communication – Page 122 ff, Table 28: PROCESS VALUES – Page 14 ff, Section 5 "Level measurement". 	

Table 12: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"


Parameter name	Description
LINd. MEASURAND (805) Selection	<p>Select measured variable.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Pressure and Volume ■ Pressure and Mass ■ Pressure and % <p>Factory setting: Pressure and %</p>
UNIT VOLUME (313) Selection	<p>Select volume unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LINd. MEASURAND = Pressure and Volume <p>Options:</p> <ul style="list-style-type: none"> ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V. <p>Factory setting: m³</p>
CUSTOMER UNIT V (608) Entry	<p>Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LINd. MEASURAND = Pressure and Volume, UNIT VOLUME = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT V parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. V (607) Entry	<p>Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LINd. MEASURAND = Pressure and Volume, UNIT VOLUME = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 0.01 m³ ≈ 1 bucket – Entry CUSTOMER UNIT V: bucket – Entry CUST. UNIT FACT. V: 100 – Result: MEASURED VALUE = 1 bucket <p>Factory setting: 1.0</p>


Table 12: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"	
Parameter name	Description
MASS UNIT (709) Selection	<p>Select mass unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LInD. MEASURAND = Pressure and Mass <p>Options:</p> <ul style="list-style-type: none"> ■ g ■ kg ■ t ■ oz ■ lb ■ ton ■ User unit, → see also the following parameter description for CUSTOMER UNIT M and CUST. UNIT FACT. M. <p>Factory setting: kg</p>
CUSTOMER UNIT M (704) Entry	<p>Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. M.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LInD. MEASURAND = Pressure and Mass, MASS UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT M parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. M (703) Entry	<p>Enter conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also CUSTOMER UNIT M.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LInD. MEASURAND = Pressure and Mass, MASS UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 10 kg $\hat{=}$ 1 bucket – Entry CUSTOMER UNIT M: bucket – Entry CUST. UNIT FACT. M: 0.1 – Result: MEASURED VALUE = 1 bucket <p>Factory setting: 1.0</p>
HYDR. PRESS MIN. (775) Entry	<p>Enter the minimum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum hydrostatic pressure to be expected, the more accurate the measurement result.</p> <p>Factory setting: 0.0</p>

Table 12: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Pressure Linearized"	
Parameter name	Description
HYDR. PRESS MAX. (761) Entry	<p>Enter the maximum hydrostatic pressure to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum hydrostatic pressure to be expected, the more accurate the measurement result.</p> <p>Factory setting: High sensor limit (→ See PRESS. SENS HILIM, Page 119)</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>




Fig. 34: BASIC SETUP function group for the "Level" measuring mode and the "Height Linearized" level type, continue calibration with LINEARISATION function group → See Page 100 ff for on-site operation and Page 104 ff for operation with digital communication.

Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"	
Parameter name	Description
<p>The following parameters are displayed if you selected the "Height Linearized" option for the LEVEL MODE parameter. Select this level type if you require two measured variables or if the container shape is given with value pairs, e.g. height and volume.</p> <p>The following combinations are possible:</p> <ul style="list-style-type: none"> ■ Height + Volume ■ Height + Mass ■ Height + % ■ %-Height + Volume ■ %-Height + Mass ■ %-Height + % <p>The 1st measured variable (%-Height or Height) must be in direct proportion to the measured pressure. The 2nd measured variable (Volume, Mass or %) must not be in direct proportion. A linearisation table must be entered for the 2nd measured variable. The 2nd measured variable is assigned to the 1st measured variable by means of this table.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Level (→ see also Page 45). ■ LEVEL SELECTION = Level Standard (→ see also Page 46). ■ LEVEL MODE = Height Linearized (→ see also Page 68). <p>Note:</p> <p>See also</p> <ul style="list-style-type: none"> – Page 67 ff, Table 10: BASIC SETUP – general – Page 96 ff, Table 16: EXTENDED SETUP – Page 100 ff, Table 18: LINEARISATION – on-site operation – Page 104 ff, Table 19: LINEARISATION – Digital communication – Page 122 ff, Table 28: PROCESS VALUES – Page 14 ff, Section 5 "Level measurement". 	
COMB. MEASURAND (806) Selection	<p>Select measured variable.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Height and Volume ■ Height and Mass ■ Height and % ■ %-Height and Volume ■ %-Height and Mass ■ %-Height and % <p>Factory setting:</p> <p>%-Height and %</p>
HEIGHT UNIT (708) Selection	<p>Select level unit for the 1st measured variable.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Volume, Height and Mass or Height and % <p>Options:</p> <ul style="list-style-type: none"> ■ mm ■ dm ■ cm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H. <p>Factory setting:</p> <p>m</p>


Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"	
Parameter name	Description
CUSTOMER UNIT H (706) Entry	<p>Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and Mass, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and %, HEIGHT UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. H (705) Entry	<p>Enter conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and Mass, HEIGHT UNIT = User unit ■ COMB. MEASURAND = Height and %, HEIGHT UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 0.5 m (1,6 ft) $\hat{=}$ 1 PU – Entry CUSTOMER UNIT H: PU – Entry CUST. UNIT FACT. H: 2 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>
UNIT VOLUME (313) Selection	<p>Select the volume unit for the 2nd measured value.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Volume or %-Height and Volume <p>Options:</p> <ul style="list-style-type: none"> ■ l ■ hl ■ cm³ ■ dm³ ■ m³ ■ m³ E³ ■ ft ■ ft³ E³ ■ gal ■ lgal ■ bbl ■ User unit, → see also the following parameter description for CUSTOMER UNIT V and CUST. UNIT FACT. V. <p>Factory setting: m³</p>

Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"


Parameter name	Description
CUSTOMER UNIT V (608) Entry	<p>Enter text (unit) for customer-specific volume unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. V</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-Height and Volume, HEIGHT UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT V parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. V (607) Entry	<p>Enter conversion factor for a customer-specific volume unit. The conversion factor must be entered in relation to the SI unit "m³". → See also CUSTOMER UNIT V.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Volume, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-Height and Volume, HEIGHT UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 0.01 m³ ≈ 1 bucket – Entry CUSTOMER UNIT V: bucket – Entry CUST. UNIT FACT. V: 100 – Result: MEASURED VALUE = 1 bucket <p>Factory setting: 1.0</p>
MASS UNIT (709) Selection	<p>Select the mass unit for the 2nd measured value.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Mass or %-Height and Mass <p>Options:</p> <ul style="list-style-type: none"> ■ g ■ kg ■ t ■ oz ■ lb ■ ton ■ User unit, → see also the following parameter description for CUSTOMER UNIT M and CUST. UNIT FACT. M. <p>Factory setting: kg</p>




Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"	
Parameter name	Description
CUSTOMER UNIT M (704) Entry	<p>Enter text (unit) for customer-specific mass unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. M.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Mass, MASS UNIT = User unit ■ COMB. MEASURAND = %-Height and Mass, MASS UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT M parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. M (703) Entry	<p>Enter conversion factor for a customer-specific mass unit. The conversion factor must be entered in relation to the SI unit "kg". → See also CUSTOMER UNIT M.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Mass, MASS UNIT = User unit ■ COMB. MEASURAND = %-Height and Mass, MASS UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "buckets". – MEASURED VALUE = 10 kg \approx 1 bucket – Entry CUSTOMER UNIT M: bucket – Entry CUST. UNIT FACT. M: 0.1 – Result: MEASURED VALUE = 1 bucket <p>Factory setting: 1.0</p>
LEVEL MIN (755) Entry	<p>Enter the minimum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum level to be expected, the more accurate the measurement result.</p> <p> Note! ■ The following applies for the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear": If you enter a new value for LEVEL MIN, the value for SET LRV is also changed. Use SET LRV to assign a height to the lower current value. If you want to assign the lower current value a value other than that for LEVEL MIN, you must enter the desired value for SET LRV. (→ SET LRV, Page 98 and ASSIGN CURRENT, Page 113)</p> <p>Factory setting: 0.0</p>
LEVEL MAX (712) Entry	<p>Enter the maximum level to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum level to be expected, the more accurate the measurement result.</p> <p> Note! ■ The following applies for the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear": If you enter a new value for LEVEL MAX, the value for SET URV is also changed. Use SET URV to assign a height to the upper current value. If you want to assign the upper current value a value other than that for LEVEL MAX, you must enter the desired value for SET URV. (→ SET URV, Page 98 and ASSIGN CURRENT, Page 113)</p> <p>Factory setting: 100.0</p>

Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"


Parameter name	Description
CALIBRATION MODE (392) Selection	<p>Select the calibration mode for the calibration of the 1st measured variable.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Wet Wet calibration takes place by filling the container. This calibration mode requires two pressure-level value pairs to be entered. In the case of two different levels, the level value is entered and the pressure measured at this moment is assigned to the level value. → See also the following parameter description for EMPTY CALIB., EMPTY PRESSURE, FULL CALIB. and FULL PRESSURE. ■ Dry Dry calibration is a theoretical calibration which you can carry out even if the device is not mounted or the container is empty. <ul style="list-style-type: none"> – For the "Level" measured variable, the density of the fluid (→ see Page 88, ADJUST DENSITY) must be entered. – For the "%" measured variable, the density of the fluid must be entered and a level assigned to the 100 % point (→ see Page 88, ADJUST DENSITY and 100% POINT). If the measurement should not start at the mounting location of the device, a level offset must be entered (→ see Page 90, ZERO POSITION). <p> Note! If the change to dry calibration is made after a wet calibration, the density must be entered correctly using the ADJUST DENSITY and DENSITY PROCESS parameter before changing the calibration mode. → See also Page 97.</p> <p>Factory setting: Wet</p>
EMPTY CALIB. (314) Entry	<p>Enter level value for the lower calibration point (container empty). The container is either empty or part full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also EMPTY PRESSURE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p>Factory setting: 0.0</p>
EMPTY PRESSURE (710) Display	<p>Displays the pressure value for the lower calibration point (container empty). → See also EMPTY CALIB.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet
FULL CALIB. (315) Entry	<p>Enter level value for the upper calibration point (container full). The container is either completely or almost full. By entering a value for this parameter, you are assigning a level value to the pressure present at the device. → See also FULL PRESSURE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p>Factory setting: 100.0</p>
FULL PRESSURE (711) Display	<p>Displays the pressure value for the upper calibration point (container full). → See also FULL CALIB.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Wet <p>Factory setting: High sensor limit (→ see PRESS. SENS HILIM, Page 119)</p>
ADJUSTED DENSITY (810) Display	<p>Displays the density calculated from the upper and lower level point.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Wet ■ COMB. MEASURAND = Height and Mass, CALIBRATION MODE = Wet ■ COMB. MEASURAND = Height and %, CALIBRATION MODE = Wet

Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"	
Parameter name	Description
DENSITY UNIT (812) Selection	<p>Select density unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and Mass, CALIBRATION MODE = Dry <p>Options:</p> <ul style="list-style-type: none"> ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ <p>Factory setting: kg/dm³</p>
ADJUST DENSITY (316) Entry	<p>Enter density of fluid.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and %, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and Volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = Height and Mass, CALIBRATION MODE = Dry <p>Factory setting: 1.0</p>
HEIGHT UNIT (708) Selection	<p>Select level unit.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height + %, CALIBRATION MODE = Dry <p>Options:</p> <ul style="list-style-type: none"> ■ mm ■ dm ■ cm ■ m ■ inch ■ ft ■ User unit, → see also the following parameter description for CUSTOMER UNIT H and CUST. UNIT FACT. H. <p>Factory setting: m</p>

Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"



Parameter name	Description
CUSTOMER UNIT H (706) Entry	<p>Enter text (unit) for customer-specific level unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT H parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>
CUST. UNIT FACT. H (705) Entry	<p>Enter conversion factor for a customer-specific level unit. The conversion factor must be entered in relation to the SI unit "m". → See also CUSTOMER UNIT H.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit ■ COMB. MEASURAND = %-Height and %, CALIBRATION MODE = Dry, HEIGHT UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 0.5 m (1.6 ft) \cong 1 PU – Entry CUSTOMER UNIT H: PU – Entry CUST. UNIT FACT. H: 2 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>
100% POINT (813) Entry	<p>Enter level value for 100% point.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ COMB. MEASURAND = %-Height and Volume, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height and Mass, CALIBRATION MODE = Dry ■ COMB. MEASURAND = %-Height + %, CALIBRATION MODE = Dry <p>Example:</p> <ul style="list-style-type: none"> – The 100 %-point should correspond to 4 m (13 ft). – Select the "m" unit via the HEIGHT UNIT parameter. – Enter the value "4" for this parameter (100% POINT). <p>Factory setting: 1.0</p>

Table 13: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Level", LEVEL MODE "Height Linearized"	
Parameter name	Description
ZERO POSITION (814) Entry	<p>Enter value for level offset. If the measurement should not start at the mounting location of the device, e.g. for containers with a sump, carry out zero point shift (level offset).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ CALIBRATION MODE = Dry  <p style="text-align: right;">P01-PMP75xxx-19-xx-xx-xx-001</p> <p><i>Fig. 35: Zero point shift</i></p> <ol style="list-style-type: none"> 1 Device is mounted above the level lower range value: a positive value has to be entered for ZERO POSITION. 2 Device is mounted below the level lower range value: a negative value has to be entered for ZERO POSITION. <p>Factory setting: 0.0</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>




Fig. 36: BASIC SETUP function group for the "Flow" measuring mode

Table 14: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Flow"

Parameter name	Description
Prerequisite: ■ MEASURING MODE = Flow (→ see also Page 45).	
Note: See also – Page 52, Table 5: QUICK SETUP – Page 98, Table 15: EXTENDED SETUP – Page 107, Table 18: TOTALIZER SETUP – Page 123, Table 27: PROCESS VALUES. – Page 40 ff, Section 6 "Flow measurement".	



Table 14: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
MEASURING MODE Selection	<p>Select the measuring mode. The operating menu is structured according to the selected measuring mode.</p> <p> Warning! If the measuring mode is changed, the span setting (URV) must be verified in the "Calibration" → "Basic Setup" operating menu and, if necessary, reconfigured.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Digital communication <p>Options:</p> <ul style="list-style-type: none"> ■ Pressure ■ Level ■ Deltabar S: Flow <p>Factory setting:</p> <ul style="list-style-type: none"> ■ Cerabar S and Deltabar S: Pressure ■ Deltapilot S: Level
PRESS. ENG. UNIT (060) Selection	<p>Select pressure unit. If a new pressure unit is selected, all pressure-specific parameters are converted and displayed with the new unit.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ mbar, bar ■ mmH₂O, mH₂O, inH₂O, ftH₂O ¹⁾ ■ Pa, hPa, kPa, MPa ■ psi ■ mmHg, inHg ²⁾ ■ Torr ■ g/cm², kg/cm² ■ lb/ft² ■ atm ■ gf/cm², kgf/cm² ■ User unit, → See also the following parameter description for CUSTOMER UNIT P and CUST. UNIT FACT. P. <p>1) The conversion factor of the pressure units refers to a reference temperature of 4 °C (39.2 °F). 2) The conversion factor of the pressure units refers to a reference temperature of 0 °C (32 °F).</p> <p>Factory setting: Depends on the sensor nominal measuring range mbar or bar or as per order specifications</p>
CUSTOMER UNIT P (075) Entry	<p>Enter text (unit) for customer-specific pressure unit. You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p> Note! Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed. If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed. In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT P parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>

Table 14: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
CUST. UNIT FACT. P (317) Entry	<p>Enter conversion factor for a customer-specific pressure unit. The conversion factor must be entered in relation to the SI unit "Pa". → See also CUSTOMER UNIT P.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ PRESS. ENG. UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "PU" (PU: packing unit). – MEASURED VALUE = 10000 Pa $\hat{=}$ 1 PU – Entry CUSTOMER UNIT P: PU – Entry CUST. UNIT FACT. P: 0.0001 – Result: MEASURED VALUE = 1 PU <p>Factory setting: 1.0</p>
FLOW-MEAS. TYPE (640) Selection	<p>Select the flow type.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Volume p. cond. (volume under operating conditions) ■ Gas norm. cond. (norm volume under norm conditions in Europe: 1013.25 mbar and 273.15 K (0°C)) ■ Gas std. cond. (standard volume under standard conditions in USA: 1013.25 mbar (14.7 psi) and 288.15 K (15°C/59°F)) ■ Mass (mass under operating conditions) <p>Factory setting: Volume p. cond.</p>
UNIT FLOW (391) Selection	<p>Select volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ FLOW-MEAS. TYPE = Volume p. cond. <p>Options:</p> <ul style="list-style-type: none"> ■ m³/s, m³/min, m³/h, m³/day ■ l/s, l/min, l/h ■ hl/s, hl/min, hl/day ■ ft³/s, ft³/min, ft³/h, ft³/day ■ ACFS, ACFM, ACFH, ACFD ■ ozf/s, ozf/min ■ US Gal/s, US Gal/min, US Gal/h, US Gal/day ■ Imp. Gal/s, Imp. Gal/min, Imp. Gal/h ■ bbl/s, bbl/min, bbl/h, bbl/day ■ User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F <p>Factory setting: m³/s</p>
NORM FLOW UNIT (661) Selection	<p>Select norm volume flow unit. When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ FLOW-MEAS. TYPE = Gas norm conditions <p>Options:</p> <ul style="list-style-type: none"> ■ Nm³/s, Nm³/min, Nm³/h, Nm³/day ■ User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F <p>Factory setting: Nm³/s</p>




Table 14: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
STD. FLOW UNIT (660) Selection	<p>Select standard volume flow unit.</p> <p>When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ FLOW-MEAS. TYPE = Gas std. conditions <p>Options:</p> <ul style="list-style-type: none"> ■ Sm³/s, Sm³/min, Sm³/h, Sm³/day ■ SCFS, SCFM, SCFH, SCFD ■ User unit, → see also this table, parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F <p>Factory setting: Sm³/s</p>
MASS FLOW UNIT (571) Selection	<p>Select mass flow unit.</p> <p>When a new flow unit is selected, all flow-specific parameters are converted and displayed with the new unit within a flow mode (FLOW-MEAS. TYPE). When the flow mode is changed, conversion is not possible.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ FLOW-MEAS. TYPE = Mass <p>Options:</p> <ul style="list-style-type: none"> ■ g/s, kg/s, kg/min, kg/min, kg/h ■ t/s, t/min, t/h, t/day ■ oz/s, oz/min ■ lb/s, lb/min, lb/h ■ ton/s, ton/min, ton/h, ton/day ■ User unit, → see also the following parameter description for CUSTOMER UNIT F and CUST. UNIT FACT. F <p>Factory setting: kg/s</p>
CUSTOMER UNIT F (610) Entry	<p>Enter text (unit) for customer-specific flow unit.</p> <p>You can enter a maximum of eight alphanumeric characters here. → See also CUST. UNIT FACT. F.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ UNIT FLOW = User unit ■ NORM FLOW UNIT = User unit ■ STD. FLOW UNIT = User unit ■ MASS FLOW UNIT = User unit <p> Note!</p> <p>Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed.</p> <p>If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed.</p> <p>In the HART handheld terminal, the customer-specific unit is only displayed in the CUSTOMER UNIT F parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>

Table 14: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP "Flow"	
Parameter name	Description
CUST. UNIT FACT. F (609) Entry	<p>Enter conversion factor for a customer-specific flow unit. The conversion factor must be entered in relation to an appropriate SI unit, e.g. m³/s for the "Volume p. cond." flow mode. → See also CUSTOMER UNIT F.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ UNIT FLOW = User unit ■ NORM FLOW UNIT = User unit ■ STD. FLOW UNIT = User unit ■ MASS FLOW UNIT = User unit <p>Example:</p> <ul style="list-style-type: none"> – You want the measured value to be displayed in "bucket/h". – MEASURED VALUE = 0.01 m³/s ≈ 3600 bucket/h – Entry CUSTOMER UNIT F: bucket/h – Entry CUST. UNIT FACT. F: 360000 – Result: MEASURED VALUE = 3600 bucket/h <p>Factory setting: 1.0</p>
MAX. FLOW (311) Entry	<p>Enter maximum flow of primary element. → See also layout sheet of primary element. The maximum flow is assigned to the maximum pressure which you enter via MAX PRESS. FLOW.</p> <p> Note! Use the LINEAR/SQROOT parameter (→ Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Flow (square root)" setting: If you enter a new value for MAX. FLOW, the value for SET URV is also changed. Use SET URV to assign a flow to the upper current value. If you want to assign the upper current value a value other than that for MAX. FLOW, you must enter the desired value for SET URV. (→ SET URV, Page 100).</p> <p>Factory setting: 1.0</p>
MAX PRESS. FLOW (634) Entry	<p>Enter maximum pressure of primary element. → See layout sheet of primary element. This value is assigned to the maximum flow value (→ see MAX. FLOW).</p> <p> Note! Use the LINEAR/SQROOT parameter (→ Page 113) to specify the current signal for the "Flow" measuring mode. The following applies for the "Differential pres." setting: If you enter a new value for MAX PRESS. FLOW, the value for SET URV is also changed. Use SET URV to assign a pressure value to the upper current value. If you want to assign the upper current value a value other than that for MAX PRESS. FLOW, you must enter the desired value for SET URV. (→ SET URV, Page 100).</p> <p>Factory setting: High sensor limit (→ see PRESS. SENS HILIM, Page 119)</p>
DAMPING VALUE (247) Entry	<p>Enter damping time (time constant τ). The damping affects the speed at which all subsequent elements, such as the on-site display, measured value and current output react to a change in the pressure.</p> <p>Input range: 0.0...999.0 s</p> <p>Factory setting: 2.0 s or as per order specifications</p>




Fig. 37: EXTENDED SETUP function group
→ For the "Pressure" measuring mode, see Page 96, Table 15
→ For the "Level" measuring mode, see Page 96, Table 16
→ For the "Flow" measuring mode, see Page 98, Table 17

Table 15: (GROUP SELECTION →) OPERATING MENU → SETTINGS → EXTENDED SETUP "Pressure"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Pressure (→ see also Page 45).	
Note: ■ See also Page 11 ff, Section 4 "Pressure measurement".	
TEMP. ENG. UNIT (318) Selection	Select the unit for the temperature measured values. → See also PCB TEMPERATURE (Page 117) and SENSOR TEMP. (Page 122). Options: ■ °C ■ °F ■ K ■ R Factory setting: °C

Table 16: (GROUP SELECTION →) OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Level (→ see also Page 45).	
Note: ■ See also Page 14 ff, Section 5 "Level measurement".	



Table 16: (GROUP SELECTION →) OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"	
Parameter name	Description
TEMP. ENG. UNIT (318) Selection	<p>Select the unit for the temperature measured values. → See also PCB TEMPERATURE (Page 117) and SENSOR TEMP. (Page 122).</p> <p>Options:</p> <ul style="list-style-type: none"> ■ °C ■ °F ■ K ■ R <p>Factory setting: °C</p>
DENSITY UNIT (001)/(812) Options	<p>Select density unit.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ g/cm³ ■ kg/dm³ ■ kg/m³ ■ US lb/in³ ■ US lb/ft³ <p>Factory setting: kg/dm³</p>
ADJUST DENSITY (007)/(316) Entry	<p>Enter density of fluid.</p> <p> Note! LIN. MEASURAND: "% (Level)", "Mass" and "Volume" and MEASUAND KOMB.: If a change to dry calibration is made after a wet calibration using the CALIBRATION MODE parameter (→ Page 73 or 87), the density for this parameter must be entered correctly before changing the calibration mode. In the event that the pressure falls with increasing levels (LIN. MEASURED: Volume), such as in the case of a residual volume measurement, a negative value shall be entered for this parameter.</p> <p>Factory setting: 1.0</p>
PROCESS DENSITY (025)/(811) Entry	<p>Enter a new density value for density correction. The calibration was carried out with the medium water, for example. Now the container is to be used for another fluid with another density. The calibration is corrected appropriately by entering the new density value in the PROCESS DENSITY parameter.</p> <p> Note! LIN. MEASURAND: "% (Level)", "Mass" and "Volume" and MEASUAND KOMB.: If a change to dry calibration is made after a wet calibration using the CALIBRATION MODE parameter (→ Page 73 or 87), the density for this parameter must be entered correctly before changing the calibration mode. In the event that the pressure falls with increasing levels (LIN. MEASURED: Volume), such as in the case of a residual volume measurement, a negative value shall be entered for this parameter.</p> <p>Factory setting: 1.0</p>



Table 16: (GROUP SELECTION →) OPERATING MENU → SETTINGS → EXTENDED SETUP "Level"	
Parameter name	Description
SET LRV (762) Entry	<p>Enter value for the lower current value (4 mA).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LEVEL MODE = Pressure Linearized or Height Linearized <p> Note!</p> <ul style="list-style-type: none"> ■ For the LEVEL MODE "Height Linearized", you can use the ASSIGN CURRENT parameter (→ Page 113) to specify whether the current output should depict the 1st or 2nd measured variable (height or tank content). Depending on the setting of the ASSIGN CURRENT parameter, enter the following value for SET LRV: <ul style="list-style-type: none"> – ASSIGN CURRENT = tank content (factory setting) ⇒ %- value, volume value or mass value – ASSIGN CURRENT = height ⇒ level value <p>The following applies for the LEVEL MODE "Pressure Linearized" or LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Tank content":</p> <ul style="list-style-type: none"> ■ If you enter a new value for TANK CONTENT MIN, the value for SET LRV is also changed. If you want to assign the lower current value a value other than that for TANK CONTENT MIN, you must enter the desired value for SET LRV. (→ TANK CONTENT MIN, Page 101 or 104.) <p>The following applies for the LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Height":</p> <ul style="list-style-type: none"> ■ If you enter a new value for LEVEL MIN, the value for SET LRV is also changed. If you want to assign the lower current value a value other than that for LEVEL MIN, you must enter the desired value for SET LRV. (→ LEVEL MIN, Page 86.) <p>Factory setting: 0.0</p>
SET URV (763) Entry	<p>Enter value for the upper current value (20 mA).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LEVEL MODE = Pressure Linearized or Height Linearized <p> Note!</p> <ul style="list-style-type: none"> ■ For the LEVEL MODE "Height Linearized", you can use the ASSIGN CURRENT parameter (→ Page 113) to specify whether the current output should depict the 1st or 2nd measured variable (height or tank content). Depending on the setting of the ASSIGN CURRENT parameter, enter the following value for SET URV: <ul style="list-style-type: none"> – ASSIGN CURRENT = tank content (factory setting) ⇒ %- value, volume value or mass value – ASSIGN CURRENT = height ⇒ level value <p>The following applies for the LEVEL MODE "Pressure Linearized" or LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Tank content":</p> <ul style="list-style-type: none"> ■ If you enter a new value for TANK CONTENT MAX, the value for SET URV is also changed. If you want to assign the upper current value a value other than that for TANK CONTENT MAX, you must enter the desired value for SET URV. (→ TANK CONTENT MAX, Page 101 or 105.) <p>The following applies for the LEVEL MODE "Height Linearized" + ASSIGN CURRENT "Height":</p> <ul style="list-style-type: none"> ■ If you enter a new value for LEVEL MAX, the value for SET URV is also changed. If you want to assign the lower current value a value other than that for LEVEL MAX, you must enter the desired value for SET URV. (→ LEVEL MAX, Page 86.) <p>Factory setting: 100.0</p>

Table 17: (GROUP SELECTION →) OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow"	
Parameter name	Description
<p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Flow (→ see also Page 45). <p>Note:</p> <ul style="list-style-type: none"> ■ See also Page 40 ff, Section 6 "Flow measurement". 	



Table 17: (GROUP SELECTION →) OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow"	
Parameter name	Description
TEMP. ENG. UNIT (318) Selection	<p>Select the unit for the temperature measured value. → See also PCB TEMPERATURE (Page 117) and SENSOR TEMP. (Page 123).</p> <p>Options:</p> <ul style="list-style-type: none"> ■ °C ■ °F ■ K ■ R <p>Factory setting: °C</p>
LOW FLOW CUT-OFF (442) Selection	<p>Switches "low flow cut-off" function on and off. In the lower measuring range, small flow quantities (creepages) can lead to large measured value fluctuations. Switching on this function stops these flow quantities from being recorded. → See also SET. L. FL. CUT-OFF.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Off ■ On <p>Factory setting: Off</p>
SET. L. FL. CUT-OFF (323) Entry	<p>Enter switch-off point of low flow cut-off. The hysteresis between the switch-on point and the switch-off point is always 1 % of the end flow value. → See also LOW FLOW CUT-OFF.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ LOW FLOW CUT-OFF = on <p>Input range: Switch-off point: 0...50 % of end flow value (→ MAX. FLOW).</p> <div style="text-align: center;">  <p style="text-align: right; font-size: small;">P01-PMD7xxxx-05-xx-xx-xx-000</p> </div> <p>Factory setting: 5 % (of end flow value)</p>
SET LRV (637) Entry	<p>Depending on the setting in the LINEAR/SQROOT parameter (→ Page 113), enter a flow value or a pressure value for the lower current value (4 mA) here.</p> <ul style="list-style-type: none"> ■ LINEAR/SQROOT = Flow (square root) (factory setting) ⇒ flow value ■ LINEAR/SQROOT = Differential pres. ⇒ pressure value <p>Factory setting: 0</p>

Table 17: (GROUP SELECTION →) OPERATING MENU → SETTINGS → EXTENDED SETUP "Flow"

Parameter name	Description
SET URV (638) Entry	<p>Depending on the setting in the LINEAR/SQROOT parameter (→ Page 113), enter a flow value or a pressure value for the upper current value (20 mA) here.</p> <ul style="list-style-type: none"> ■ LINEAR/SQROOT = Flow (square root) (factory setting) ⇒ flow value ■ LINEAR/SQROOT = Differential pres. ⇒ pressure value <p>The following applies for the setting LINEAR/SQROOT "Flow (square root)":</p> <ul style="list-style-type: none"> ■ If you enter a new value for MAX. FLOW, the value for SET URV is also changed. If you want to assign the upper current value a value other than that for MAX. FLOW, you must enter the desired value for SET URV. (→ MAX. FLOW, Page 95). <p>The following applies for the setting LINEAR/SQROOT "Differential pres.":</p> <ul style="list-style-type: none"> ■ If you enter a new value for MAX PRESS. FLOW, the SET URV value is also changed. If you want to assign the upper current value a value other than that for MAX PRESS. FLOW, you must enter the desired value for SET URV. (→ MAX PRESS. FLOW, Page 95). <p>Factory setting: MAX. FLOW</p>

**Fig. 38: LINEARISATION function group for on-site operation****Table 18: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION – on-site operation**

Parameter name	Description
<p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Level (→ see also Page 45). ■ LEVEL MODE = Pressure Linearized or Height Linearized (→ see also Page 68). <p>Note:</p> <ul style="list-style-type: none"> – See also Page 14 ff, Section 5 "Level measurement". 	

Table 18: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION – on-site operation



Parameter name	Description
TANK CONTENT MIN (759) Entry	<p>Enter the minimum tank contents to be expected. The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum tank content to be expected, the more accurate the measurement result.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If you enter a new value for TANK CONTENT MIN, the value for SET LRV is also changed. Use SET LRV to assign a %-value, volume value or mass value to the lower current value. If you want to assign the lower current value a value other than that for TANK CONTENT MIN, you must enter the desired value for SET LRV. (→ SET LRV, Page 98). ■ For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MIN parameter does not affect the SET LRV parameter. (→ SET LRV, Page 98 and ASSIGN CURRENT, Page 113) <p>Factory setting: 0.0</p>
TANK CONTENT MAX (713) Entry	<p>Enter the maximum tank contents to be expected. The input limits for the subsequent calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum tank content to be expected, the more accurate the measurement result.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If you enter a new value for TANK CONTENT MAX, the value for SET URV is also changed. Use SET URV to assign a %-value, volume value or mass value to the upper current value. If you want to assign the upper current value a value other than that for TANK CONTENT MAX, you must enter the desired value for SET URV. (→ SET URV, Page 98.) ■ For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MAX parameter does not affect the SET URV parameter. (→ SET URV, Page 98 and ASSIGN CURRENT, Page 113) <p>Factory setting: 100.0</p>
TABLE SELECTION (808) Selection	<p>Select table. The device works with a measuring and an editor table. The measuring table is used to calculate the measured value. To make sure measuring also runs properly when entering a new table, there is another table, the editor table, for entering new values.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ View meas. table ■ Editor table <p>Factory setting: View meas. table</p>
LIN. EDIT MODE (397) Selection	<p>Select the entry mode for the linearisation table.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = Editor table <p>Options:</p> <ul style="list-style-type: none"> ■ Manual: the container neither has to be filled nor emptied for this entry mode. Enter the value pairs for the linearisation table. ■ Semiautomatic: the container is filled or emptied in stages in this entry mode. The device automatically records the hydrostatic pressure. The associated volume, mass or %-value is entered. <p>Factory setting: Manual</p>

Table 18: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION – on-site operation	
Parameter name	Description
EDITOR TABLE (809) Selection	<p>Select table.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> TABLE SELECTION = editor table <p>Options:</p> <ul style="list-style-type: none"> New table: enter new linearisation table. Edit measure table: The measuring table is loaded as an editor table so that changes can be made. → See also TAB. SELECTION Continue edit: Edit an editor table that already exists. → See also TABLE EDITOR (770) <p>Factory setting: New table</p>
EDITOR TABLE Entry ("Semiautomatic" edit mode) – LINE-NUMB (549) – Y-VAL. (551)	<p>Enter table in the "Semiautomatic" editing mode.</p> <p>A linearisation table must have at least 2 points and may not have more than 32 points. A point consists of LINE-NUMB, X-VAL. and Y-VAL. For this editing mode, the container is filled or emptied in stages.</p> <p>Example: Enter point for LEVEL MODE = Pressure Linearized</p> <ul style="list-style-type: none"> LINE-NUMB: confirm value displayed. Y-VAL.: depending on the setting in the LIND. MEASURAND parameter, enter the volume, mass or % value. X-VAL.: the hydrostatic pressure present is displayed and saved by confirming the Y-value. <p>Example: Enter point for LEVEL MODE = Height Linearized</p> <ul style="list-style-type: none"> LINE-NUMB: confirm value displayed. Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the volume, mass or % value. X-VAL.: the hydrostatic pressure present is measured. Depending on the setting in the COMB. MEASURAND parameter, the measured pressure is converted to a level unit or a % and displayed. The value is saved by confirming the Y-value. <p>Factory setting: LINE-NUMB = 1, X-VAL. = 0.0, Y-VAL. = 0.0</p>
EDITOR TABLE Entry ("manual" edit mode) – LINE-NUMB (549) – Y-VAL. (551) – X-VAL. (550)	<p>Enter table in the "manual" editing mode.</p> <p>A linearisation table must have at least 2 points and may not have more than 32 points. A point consists of a line number, X-value and Y-value. The container neither has to be filled nor emptied for this editing mode.</p> <p>Example: Enter point for LEVEL MODE = Pressure Linearized</p> <ul style="list-style-type: none"> LINE-NUMB: confirm value displayed. X-VAL.: enter pressure value. Y-VAL.: depending on the setting in the LIND. MEASURAND parameter, enter the related volume, mass or % value. <p>Example: Enter point for LEVEL MODE = Height Linearized</p> <ul style="list-style-type: none"> LINE-NUMB: confirm value displayed. X-VAL.: the hydrostatic pressure present is measured. Depending on the setting in the COMB. MEASURAND parameter, enter a level value or % value. Y-VAL.: depending on the setting in the COMB. MEASURAND parameter, enter the related volume, mass or % value. <p>Factory setting: LINE-NUMB = 1, X-VAL. = 0.0, Y-VAL. = 0.0</p>

**Table 18: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION
– on-site operation**

Parameter name	Description
EDITOR TABLE (770) Options	<p>Select the function for the editor table.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Next point: enter next point. ■ Last input point: jump back to previous point to correct a mistake for example. ■ Accept input table: save editor table as measuring table. This overwrites the old measuring table. ■ Abort: save values entered up to this point for the editor table and display next parameter. The editor table is not activated as a measuring table. ■ Insert point: see example below. ■ Delete point: the current point is deleted. See example below. <p>Example: Add point, in this case between the 4th and 5th point for example</p> <ul style="list-style-type: none"> – Select point 5 via the EDITOR TABLE/LINE NUMB parameter. – Confirm current X and Y values with Enter. – Using the TABLE EDITOR (770) parameter, select the option "Insert point". – Point 5 is displayed for the TABLE EDITOR/LINE NUMB parameter. New values for the X-VAL and Y-VAL parameters. <p>Example: delete point, in this case the 5th point for example</p> <ul style="list-style-type: none"> – Select point 5 via the EDITOR TABLE/LINE NUMB parameter. – Using the TABLE EDITOR (770) parameter, select the option "Delete point". – The 5th point is deleted. All of the following points are pushed up one number i.e. following deletion, the 6th point becomes Point 5. <p>Factory setting: Next point</p>
MEASURING TABLE (549) Display	<p>A point of the linearisation table saved (measuring table) appears on the display</p> <p>The parameter first displays the first point of the linearisation table. By entering a line number, you can directly display the corresponding point in the linearisation table.</p>
MEASURING TABLE (717) Selection	<p>Select the function for the measuring table.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Next point: view next point of the measuring table. ■ Last input point: view previous point of the measuring table. ■ Abort: cancel measuring table display. Display next parameter. <p>Factory setting: Next point</p>
TANK DESCRIPTION (815) Entry	<p>Enter tank description. (max. 32 alphanumeric characters)</p> <p>Factory setting: -----</p>




Fig. 39: LINEARISATION function group for digital communication

Table 19: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION – Digital communication

Parameter name	Description
Prerequisite: <ul style="list-style-type: none"> MEASURING MODE = Level (→ see also Page 45). LEVEL MODE = Pressure Linearized or Height Linearized (→ see also Page 68). Note: <ul style="list-style-type: none"> See also Page 14 ff, Section 5 "Level measurement". 	
TANK CONTENT MIN Entry	<p>Enter the minimum tank contents to be expected.</p> <p>The input limits for the calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the minimum tank content to be expected, the more accurate the measurement result.</p> <p> Note!</p> <ul style="list-style-type: none"> If you enter a new value for TANK CONTENT MIN, the value for SET LRV is also changed. Use SET LRV to assign a %-value, volume value or mass value to the lower current value. If you want to assign the lower current value a value other than that for TANK CONTENT MIN, you must enter the desired value for SET LRV. (→ SET LRV, Page 98). For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MIN parameter does not affect the SET LRV parameter. (→ SET LRV, Page 98 and ASSIGN CURRENT, Page 113) <p>Factory setting: 0.0</p>



Table 19: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION – Digital communication	
Parameter name	Description
TANK CONTENT MAX Entry	<p>Enter the maximum tank contents to be expected. The input limits for the subsequent calibration (editing limits) are derived from the value entered. The closer the value entered corresponds to the maximum tank content to be expected, the more accurate the measurement result.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ If you enter a new value for TANK CONTENT MAX, the value for SET URV is also changed. Use SET URV to assign a %-value, volume value or mass value to the upper current value. If you want to assign the upper current value a value other than that for TANK CONTENT MAX, you must enter the desired value for SET URV. (→ SET URV, Page 98.) ■ For the setting LEVEL MODE "Height Linearized" and ASSIGN CURRENT "Linear", the TANK CONTENT MAX parameter does not affect the SET URV parameter. (→ SET URV, Page 98 and ASSIGN CURRENT, Page 113) <p>Factory setting: 100.0</p>
TABLE SELECTION Selection	<p>Select table. The device works with a measuring and an editor table. The measuring table is used to calculate the measured value. To make sure measuring also runs properly when entering a new table, there is another table, the editor table, for entering new values.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ View meas. table ■ Editor table <p>Factory setting: View meas. table</p>
LIN. EDIT MODE Selection	<p>Select the entry mode for the linearisation table.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = Editor table <p>Options:</p> <ul style="list-style-type: none"> ■ Manual: The container neither has to be filled nor emptied for this entry mode. Enter the value pairs for the linearisation table. ■ Semiautomatic: the container is filled or emptied in stages in this entry mode. The device automatically records the hydrostatic pressure. The associated volume, mass or %-value is entered. <p>Factory setting: Manual</p>
EDITOR TABLE Selection	<p>Select table.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = Editor table <p>Options:</p> <ul style="list-style-type: none"> ■ New table: Enter new linearisation table. ■ View meas. table: View saved linearisation table and change points if necessary. ■ Continue edit: Edit a linearisation table that already exists. <p> Note!</p> <p>Operating program:</p> <ul style="list-style-type: none"> ■ If you select the "View meas. table" option, the saved measuring table is loaded in the operating program. Use the "Lin.-Tab." window to view the entire table, change values if necessary and write the modified table to the device. ■ If you change a value via the X-VAL. or Y-VAL. parameters, the table in the "Lin.-Tab." window is not updated. To view the table saved in the device, this table must first be read out of the device. <p>Factory setting: New table</p>



Table 19: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION – Digital communication	
Parameter name	Description
LINE-NUMB Entry	<p>Enter the line number for the linearisation table. A linearisation table must have at least 2 points and may not have more than 32 points.</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = View meas. table Via this parameter you can select the point of the linearisation table which should be displayed. ■ TABLE SELECTION = Editor table Enter a point via the LINE-NUMB, X-VAL. and Y-VAL. parameters. → See also this table, parameter description for LIN. EDIT MODE, X-VAL. ("Manual" entry mode), X-VAL. ("Semiautomatic" entry mode) and Y-VAL. <p> Note! In the operating program, you can enter a complete linearisation table in one go via the "Lin.-Tab." window.</p>
X-VAL. ("Manual" entry mode) Entry	<p>Enter the pressure value for the linearisation table. → See also LIN. EDIT MODE, LINE-NUMB and Y-VAL.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = Editor table
X-VAL. ("Semiautomatic" entry mode) Display	<p>In the "Semiautomatic" entry mode, the container is filled or emptied in stages. The X-VAL. displays the measured hydrostatic pressure.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = Editor table <p>Operating program The X-VAL. is saved by confirming the Y-value.</p> <p>HART Handheld Confirm X-VAL. displayed.</p> <p>→ See also LIN. EDIT MODE, LINE-NUMB and Y-VAL.</p>
Y-VAL. Entry	<p>Enter the volume, mass or %-value belonging to the X-VAL. for the linearisation table.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = Editor table <p>Depending on the setting in the LIND. MEASURAND or COMB. MEASURAND parameters, enter a volume, mass or %-value here. → See also this table, parameter description for LIN. EDIT MODE, LINE-NUMB, X-VAL. ("Manual" entry mode), X-VAL. ("Semiautomatic" entry mode).</p>
EDITOR TABLE Options	<p>Select the function for the editor table.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = Editor table <p>Options:</p> <ul style="list-style-type: none"> ■ Next point: without function ■ Last input point: without function ■ Accept input table: save editor table as measuring table. This overwrites the old measuring table. ■ Abort: save values entered up to this point for the editor table and display next parameter. The editor table is not activated as a measuring table. ■ Insert point: see example below. ■ Delete point: the current point is deleted. See example below. <p>Example: Add point, in this case between the 4th and 5th point for example – Select point 5 via the LINE NUMB parameter. – Using the TABLE EDITOR parameter, select the option "Insert point". – Point 5 is displayed for the LINE NUMB parameter. New values for the X-VAL and Y-VAL parameters.</p> <p>Example: delete point, in this case the 5th point for example – Select point 5 via the LINE NUMB parameter. – Using the TABLE EDITOR parameter, select the option "Delete point". – The 5th point is deleted. All of the following points are pushed up one number i.e. following deletion, the 6th point becomes Point 5.</p> <p>Factory setting: Next point</p>

Table 19: (GROUP SELECTION →) OPERATING MENU → SETTINGS → LINEARISATION – Digital communication

Parameter name	Description
ACTIV LIN. TAB. X Display	<p>An X-value of the linearisation table already saved appears on the display You can select a point of the linearisation table via the LINE-NUMB parameter.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = View meas. table <p> Note! In the operating program, you can view the entire saved table in the "Tables" window.</p>
ACTIV LIN. TAB. Y Display	<p>A Y-value of the linearisation table already saved appears on the display You can select a point of the linearisation table via the LINE-NUMB parameter.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ TABLE SELECTION = View meas. table <p> Note! In the operating program, you can view the entire saved table in the "Tables" window.</p>
TANK DESCRIPTION Entry	<p>Enter tank description. (max. 32 alphanumeric characters)</p> <p>Factory setting:</p> <p>-----</p>



P01-xxxxxxx-19-xx-xx-xx-092

Fig. 40: TOTALIZER SETUP function group**Table 20: (GROUP SELECTION →) OPERATING MENU → SETTINGS → TOTALIZER SETUP**

Parameter name	Description
<p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Flow (→ see also Page 45). <p>Note:</p> <ul style="list-style-type: none"> ■ See also Page 40 ff, Section 6 "Flow measurement". 	









Table 20: (GROUP SELECTION →) OPERATING MENU → SETTINGS → TOTALIZER SETUP																	
Parameter name	Description																
TOTALIZER 1 UNIT (398), (666), (664), (662) Selection	<p>Select unit for totalizer 1.</p> <p>Depending on the setting in the FLOW-MEAS. TYPE parameter (→ Page 93) this parameter offers a list of volume, norm volume, standard volume and mass units. When a new volume or mass unit is selected, totalizer-specific parameters are converted and displayed with the new unit within a unit group. When the flow mode is changed, the totalizer value is not converted.</p> <p>The 3-digit ID number on the on-site display depends on the FLOW-MEAS. TYPE selected:</p> <ul style="list-style-type: none">– (398): FLOW-MEAS. TYPE "Volume p. cond."– (662): FLOW-MEAS. TYPE "Mass"– (664): FLOW-MEAS. TYPE "Gas. std. cond."– (666): FLOW-MEAS. TYPE "Gas. norm conditions" <p>Factory setting: m³</p>																
TOT. 1 USER UNIT (627) Entry	<p>Enter text (unit) for customer-specific unit for totalizer 1.</p> <p>You can enter a maximum of eight alphanumeric characters here. → See also FACT. U. U. TOTAL. 1.</p> <p>Prerequisite:</p> <ul style="list-style-type: none">■ TOTALIZER 1 UNIT = User unit <p> Note!</p> <p>Only the first five characters are shown on the on-site display. For example, if "crates" is specified as the customer-specific unit, "crate" is displayed.</p> <p>If the unit contains a slash, up to eight characters can be shown on the on-site display. The maximum number of characters in the counter is again limited to five. For example, if "crates/m2" is specified as the customer-specific unit, "crate/m2" is displayed. In the FieldCare, all eight characters are displayed.</p> <p>In the HART handheld terminal, the customer-specific unit is only displayed in the TOT. 1 USER UNIT parameter. The measured value is displayed with the additional text "User Unit".</p> <p>Factory setting: -----</p>																
FACT. U. U. TOTAL. 1 (329) Entry	<p>Enter conversion factor for a customer-specific unit for totalizer 1.</p> <p>The conversion factor must be entered in relation to an appropriate SI unit, e.g. m³ for the "Volume p. cond." FLOW-MEAS. TYPE. → See also TOT. 1 USER UNIT.</p> <p>Prerequisite:</p> <ul style="list-style-type: none">■ TOTALIZER 1 UNIT = User unit <p>Example: You want the measured value to be displayed in "buckets".</p> <ul style="list-style-type: none">– MEASURED VALUE = 1 m³ ≈ 100 buckets– Entry TOT. 1 USER UNIT: bucket– Entry FACT. U. U. TOTAL. 1: 100– Result: MEASURED VALUE = 100 buckets <p>Factory setting: 1.0</p>																
NEG. FLOW TOT. 1 (400) Selection	<p>Specify way of counting negative flows for totalizer 1.</p> <table><tr><td></td><td><p>positive flow</p></td><td><p>negative flow</p></td></tr><tr><td>Options</td><td></td><td></td></tr><tr><td>Inc. on neg. flow</td><td>Total increases</td><td>Total increases</td></tr><tr><td>Dec. on neg. flow</td><td>Total increases</td><td>Total decreases</td></tr><tr><td>Stop on neg. flow</td><td>Total increases</td><td>Total remains constant</td></tr></table> <p><small>P01-xMD7xxxx-16-xx-xx-xx-003</small></p> <p>Factory setting: Inc. on neg. flow</p>			<p>positive flow</p> 	<p>negative flow</p> 	Options			Inc. on neg. flow	Total increases	Total increases	Dec. on neg. flow	Total increases	Total decreases	Stop on neg. flow	Total increases	Total remains constant
	<p>positive flow</p> 	<p>negative flow</p> 															
Options																	
Inc. on neg. flow	Total increases	Total increases															
Dec. on neg. flow	Total increases	Total decreases															
Stop on neg. flow	Total increases	Total remains constant															

Table 20: (GROUP SELECTION →) OPERATING MENU → SETTINGS → TOTALIZER SETUP	
Parameter name	Description
RESET TOTALIZER1 (331) Selection	You reset totalizer 1 to zero with this parameter. Options: <ul style="list-style-type: none"> ■ Abort (do not reset) ■ Reset Factory setting: Abort
TOTALIZER 2 UNIT (399), (663), (665), (667) Selection	Select unit for totalizer 2. → See also TOTAL 1. ENG. UNIT. The 3-digit ID number on the on-site display depends on the FLOW-MEAS. TYPE selected: <ul style="list-style-type: none"> – (399): FLOW-MEAS. TYPE "Volume p. cond." – (663): FLOW-MEAS. TYPE "Mass" – (665): FLOW-MEAS. TYPE "Gas. std. cond." – (667): FLOW-MEAS. TYPE "Gas. norm conditions" Factory setting: m ³
TOT. 2 USER UNIT (628) Entry	Enter text (unit) for customer-specific unit for totalizer 2. → See also TOT. 1 USER UNIT. Prerequisite: <ul style="list-style-type: none"> ■ TOTALIZER 2 UNIT = User unit Factory setting: -----
FACT. U. U. TOTAL. 2 (330) Selection	Enter conversion factor for a customer-specific unit for totalizer 2. → See also FACT. U. U. TOTAL. 1. Prerequisite: <ul style="list-style-type: none"> ■ TOTALIZER 2 UNIT = User unit Factory setting: 1.0
NEG. FLOW TOT. 2 (416) Selection	Specify way of counting negative flows for totalizer 2. → See NEG. FLOW TOT. 1. Factory setting: Positive



P01-xxxxxxx-19-xx-xx-xx-093

Fig. 41: DISPLAY group


Table 21: (GROUP SELECTION →) OPERATING MENU → DISPLAY	
Parameter name	Description
MENU DESCRIPTOR (419) Selection	<p>Specify contents for the main line of the on-site display in the measuring mode. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.1 "On-site display".</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Main measured value (PV) ■ Main measured value (%) ■ Pressure ■ Flow ■ Level ■ Tank content ■ Current ■ Temperature ■ Error number ■ Totalizer 1 ■ Totalizer 2 <p>The selection depends on the measuring mode chosen.</p> <p>Factory setting: Main measured value (PV)</p>
MAIN DATA FORMAT (688) Selection	<p>Specifies the number of places after the decimal point for the value displayed in the main line. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or (BA00332P) Deltapilot S, Section 5.1 "On-site display".</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Auto ■ x.x ■ x.xx ■ x.xxx ■ x.xxxx ■ x.xxxxx <p>Factory setting: Auto</p>
ALTERNATE DATA (423) Selection	<p>Switch on "Alternating display" mode.</p> <p>In this display mode, the on-site display alternates between the following measured values depending on the measuring mode selected.</p> <ul style="list-style-type: none"> – Pressure: Main measured value (PV), Pressure, Temperature and Current – Level Standard: Main measured value (PV), Pressure, Level, Tank content, Temperature and Current – Level Easy: Main measured value (PV), Pressure, Temperature and Current – Flow: Main measured value (PV), Pressure, Flow, Temperature, Current, Totalizer 1 and Totalizer 2 <p>Options:</p> <ul style="list-style-type: none"> ■ Off ■ On <p>Factory setting: Off</p>
LANGUAGE Selection	<p>Select the menu language for the on-site display.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ For on-site operation, the LANGUAGE parameter is arranged directly under GROUP SELECTION (menu path: GROUP SELECTION → LANGUAGE, see also Page 44). ■ Select the menu language for FieldCare via the "Options" menu → "Settings" → "Language" tab → "Tool language" field. <p>Factory setting: English</p>

Table 21: (GROUP SELECTION →) OPERATING MENU → DISPLAY

Parameter name	Description
DISPLAY CONTRAST (339) Entry	<p>Adjust contrast of on-site display.</p> <p>You specify the contrast of the display with a number. Changes are only accepted as single steps, i.e. to change the value from "8" to "4", you need to save four times. You can also adjust the contrast of the display by means of the keys on the electronic insert or at the device.</p> <p>→ See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.2.3 "Function of operating keys".</p> <p>Input range: 4...13, 4: contrast weaker (brighter), 13: contrast stronger (darker).</p> <p>Factory setting: 8</p>
DIGITS SETS (840) Display	<p>This parameter is used to check the correct display of characters and digits on the user interface. If the characters and digits are displayed correctly, this parameter displays the string "0123456789.-".</p>




Fig. 42: OUTPUT group

Table 22: (GROUP SELECTION →) OPERATING MENU → OUTPUT

Parameter name	Description
OUTPUT CURRENT (254) Display	Displays the current current value.

Table 22: (GROUP SELECTION →) OPERATING MENU → OUTPUT

Parameter name	Description
CURR. CHARACT. (694), (695), (696), (764) Selection	<p>Select curve of current output.</p> <p>Options:</p> <p>Fig. 43: Illustration of current output curves</p> <p>1 Linear: lower range value = 4 mA, upper range value = 20 mA 2 Bi-linear: lower range value = 4 mA, centre or zero = 20 mA, upper range value = 4 mA 3 Linear inverse: lower range value = 20 mA, upper range value = 4 mA 4 Bi-linear inverse: lower range value = 20 mA, centre or zero = 4 mA, upper range value = 20 mA</p> <p>LRV Lower range value URV Upper range value I Current X Measured value (Pressure/Level/Flow)</p> <p>The "CURR. CHARACT." function refers to the operating mode previously selected.</p> <p>The 3-digit ID number on the on-site display depends on the MEASURING MODE selected:</p> <ul style="list-style-type: none"> – (694): MEASURING MODE "Pressure" or MEASURING MODE "Flow" with the setting for LINEAR/SQROOT "Differential pres." – (695): MEASURING MODE "Flow" with the setting LINEAR/SQROOT "Flow (square root)" – (696): MEASURING MODE "Level", LEVEL MODE "Linear" or "Pressure Linearized" and LEVEL MODE "Height Linearized" with the setting for ASSIGN CURRENT "Level" – (764): MEASURING MODE "Level", LEVEL MODE "Height Linearized" with the setting for ASSIGN CURRENT "Tank content" <p>Factory setting: Linear</p>
OUTPUT FAIL MODE (388) Entry	<p>Select the current value in the event of an alarm.</p> <p>In the event of an alarm, the current and the bargraph assume the current value specified with this parameter.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Max. alarm (110%): can be set between 21...23 mA ■ Hold meas. value: last measured value is kept. ■ Min. alarm (–10%): 3.6 mA <p>→ See also this table SET MAX. ALARM and Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 8.2.1. "Setting current output for alarm".</p> <p>Factory setting: Max. alarm 110% (22 mA)</p>

Table 22: (GROUP SELECTION →) OPERATING MENU → OUTPUT	
Parameter name	Description
ALT. CURR. OUTPUT (597) Selection	<p>Set current output if sensor limits undershot or overshoot.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Normal: the current output assumes the value set via the OUTPUT FAIL MODE and SET MAX. ALARM parameters. ■ Special: <ul style="list-style-type: none"> – Lower sensor limit undershot (E120): Current output = 3.6 mA – Upper sensor limit overshoot (E115): current output assumes the value set via the SET MAX. ALARM parameter. <p>Attention : when using the case "special", the behavior is limited to an over/underpressure in a range LRL -10%, URL +10%.</p> <p>Factory setting: Normal</p>
SET MAX. ALARM (342) Entry	<p>Enter current value for maximum alarm current. → See also OUTPUT FAIL MODE.</p> <p>Input range: 21...23 mA</p> <p>Factory setting: 22 mA</p>
SET MIN. CURRENT (343) Entry	<p>Enter lower current limit. Some switching units sometimes do not accept currents less than 4.0 mA.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ 3.8 mA ■ 4.0 mA <p>Factory setting: 3.8 mA</p>
ASSIGN CURRENT (760) Selection	<p>Specify current signal for the "Level" measuring mode. See also SET LRV (→ Page 98) and SET URV (→ Page 98).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Level, LEVEL MODE = Height Linearized <p>Options:</p> <ul style="list-style-type: none"> ■ Height ■ Tank content <p>Factory setting: Tank content</p>
LINEAR/SQROOT (390) Selection	<p>Specify current signal for the "Flow" measuring mode. See also SET LRV (→ Page 99) and SET URV (→ Page 100).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Flow <p>Options:</p> <ul style="list-style-type: none"> ■ Differential pres.: the linear pressure signal is used for the current output. ■ Flow (square root): the root flow signal is used for the current output. The "Flow (square root)" current signal is indicated on the on-site display with a root symbol. <p>Factory setting: Flow (square root)</p>




Fig. 44: TRANSMITTER INFO group

→ For the HART DATA function group, see Page 114, Table 23

→ For the TRANSMITTER DATA function group, see Page 117, Table 24

→ For the PROCESS CONNECTION function group, see Page 117, Table 25

→ For the SENSOR DATA function group, see Page 119, Table 26

Table 23: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → HART DATA

Parameter name	Description
HART VERSION (585) Display	Displays the HART Version.

Table 23: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → HART DATA	
Parameter name	Description
CURRENT MODE (052) Selection	<p>Set the current mode for HART communication.</p> <p>Selection via on-site display and FieldCare:</p> <ul style="list-style-type: none"> ■ Signaling Measured value transmission by the current value ■ Fixed Fixed current 4.0 mA (multidrop mode) (Measured value transmission only via HART digital communication) <p>Factory setting: Signaling</p> <p>Selection via HART Handheld Terminal:</p> <ul style="list-style-type: none"> ■ enabled Measured value transmission by the current value ■ disabled Fixed current 4.0 mA (multidrop mode) (Measured value transmission only via HART digital communication) <p>Factory setting: enabled</p>
BUS ADDRESS (345) Entry	<p>Enter the address for the exchange of data with the HART protocol. (HART 5.0: range 0 to 15, wherein if the address = 0 this produces the "Signaling" setting; HART 6.0/7.0: range 0 to 63)</p> <p>Factory setting: 0</p>
DEVICE TYPE (351) Display	<p>Displays the device type in decimal numerical format, here Deltabar S: 23 The extended device type is a composition of the manufacturer number (17) and the device type (23).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Deltabar S differential pressure transmitter
DEVICE TYPE (802) Display	<p>Displays the device type in decimal numerical format, here Cerabar S: 24 The extended device type is a composition of the manufacturer number (17) and the device type (24).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Pressure transmitter Cerabar S
DEVICE TYPE (002) Display	<p>Displays the device type in decimal numerical format, here Deltapilot S: 26 The extended device type is a composition of the manufacturer number (17) and the device type (26).</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Pressure transmitter Deltapilot S
DEVICE REVISION (699) Display	Displays the device revision
BURST MODE Selection	<p>Switches "Burst Mode" function on and off.</p> <p>Selection:</p> <ul style="list-style-type: none"> ■ On ■ Off <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Digital communication
BURST OPTION Entry	<p>Use this parameter to specify which command is sent to the master.</p> <p>Voraussetzung:</p> <ul style="list-style-type: none"> ■ Digital communication <p>Factory setting: 3 (HART commando 3)</p>
PREAMBLE NUMBER (036) Entry	<p>Enter the number of preambles in the HART protocol. (Synchronisation of the modem modules along a transmission path, each modem module could "swallow" a byte - at least 2 bytes must arrive.)</p> <p>Input range: 2...20</p> <p>Factory setting: 5</p>

Table 23: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → HART DATA	
Parameter name	Description
MANUFACTURER ID (432) Display	Displays the manufacturer number in a decimal numerical format. Here: 17 Endress+Hauser
HART MESSAGE (271) Entry	Enter message (max. 32 alphanumeric characters). On command from the master, this message is sent via the HART protocol. Factory setting: ----- or as per order specifications
HART DATE (481) Entry	Enter the date of the last configuration change. Factory setting: DD.MM.YY (date of final test)
PRIMARY VALUE IS Display	This parameter displays the following measured value depending on the measuring mode selected: <ul style="list-style-type: none"> – Measuring mode "Pressure": PRESSURE – "Level" measuring mode, "Linear" or "Pressure Linearized" level type: LEVEL BEFORE LIN – Measuring mode "Level", level type "Height Linearized": TANK CONTENT – Measuring mode "Flow": SUPPRESSED FLOW → See also PRIMARY VALUE. Prerequisite: <ul style="list-style-type: none"> ■ Digital communication
PRIMARY VALUE Display	Displays the primary value. → See also PRIMARY VALUE IS. Prerequisite: <ul style="list-style-type: none"> ■ Digital communication
SECONDARY VAL. IS	Select second process value. You can choose between the following process values depending on the measuring mode selected: <ul style="list-style-type: none"> – PRESSURE – CORRECTED PRESS. – SENSOR PRESSURE – SENSOR TEMP. – PCB TEMPERATURE – SUPPRESSED FLOW – TOTALIZER 1 – TOTALIZER 2 – LEVEL BEFORE LIN – TANK CONTENT Prerequisite: <ul style="list-style-type: none"> ■ Digital communication
SECONDARY VALUE	Display second process value. → See also SECONDARY VAL. IS. Prerequisite: <ul style="list-style-type: none"> ■ Digital communication
THIRD VALUE IS	Select third process value. → See also SECONDARY VAL. IS. Prerequisite: <ul style="list-style-type: none"> ■ Digital communication
THIRD VALUE	Display third process value. → See also SECONDARY VAL. IS. Prerequisite: <ul style="list-style-type: none"> ■ Digital communication
4TH VALUE IS	Select fourth process value. → See also SECONDARY VAL. IS. Prerequisite: <ul style="list-style-type: none"> ■ Digital communication
4TH VALUE	Display fourth process value. → See also SECONDARY VAL. IS. Prerequisite: <ul style="list-style-type: none"> ■ Digital communication

Table 24: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → TRANSMITTER DATA	
Parameter name	Description
DEVICE SERIAL No (354) Display	Displays the serial number of the device (11 alphanumeric characters).
ELECTR. SERIAL No (386) Display	Displays the serial number of the main electronics (11 alphanumeric characters).
CUST. TAG NUMBER (055) Entry	Enter TAG number (max. 8 alphanumeric characters). Factory setting: _____ or as per order specifications
LONG TAG NUMBER (305) Entry	Enter TAG number (max. 32 alphanumeric characters). Factory setting: _____ or as per order specifications
ADDITIONAL INFO. (272) Entry	Enter tag description (max. 16 alphanumeric characters). Factory setting: _____ or as per order specifications
DEVICE DESIGN. (350) Display	Displays the device designation and order code.
HARDWARE REV. (266) Display	Displays the revision number of the main electronics e.g.: V02.00
SOFTWARE VERSION (264) Display	Displays the software version e.g.: V02.10
CONFIG RECORDER (352) Display	Displays the configuration counter. This counter is increased by one with each change to a parameter or group. The counter counts to 65535 and then starts again at zero. Changes in the parameters of the DISPLAY function group do not increase the counter.
PCB TEMPERATURE (357) Display	Displays the measured temperature of the main electronics.
ALLOWED MIN. TEMP (358) Display	Displays the lower temperature limit of the main electronics.
ALLOWED MAX. TEMP (359) Display	Displays the upper temperature limit of the main electronics.
DIP STATUS (363) Display	Displays the status of DIP switch 1 on the electronic insert. You can lock or unlock parameters relevant to the measured value with DIP switch 1. If operation is locked by means of the INSERT PIN No. parameter, you can only unlock operation again by means of this parameter. (→ INSERT PIN NO, see Page 126.) → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.9 "Locking/unlocking operation". Display: ■ On (locking switched on) ■ Off (locking switched off) Factory setting: Off (locking switched off)

Table 25: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → PROCESS CONNECTION	
Parameter name	Description
Pmax PROC. CONN. (570) Entry	For entering and displaying the maximum permitted pressure of the process connection. Factory setting: In accordance with nameplate data (→ see also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 2.1.1 nameplate)

Table 25: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → PROCESS CONNECTION	
Parameter name	Description
PROC. CONN. TYPE (482) Selection	<p>For selecting and displaying the process connection type.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Not used ■ Unknown ■ Special ■ Oval flange ■ Thread female ■ Thread male ■ Flange ■ Remote seal
MAT. PROC. CONN. + (360) Selection	<p>For selecting and displaying the material of the process connection (P+). → See also parameter description for MAT. PROC. CONN. -</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Not used ■ Unknown ■ Special ■ Steel ■ 304 st. steel ■ 316 st. steel ■ Alloy C ■ Monel ■ Tantalum ■ Titanium ■ PTFE (Teflon) ■ 316L st. steel ■ PVC ■ Inconel ■ PVDF ■ ECTFE <p>Factory setting: As per order specifications</p>
MAT. PROC. CONN. - (361) Selection	<p>For selecting and displaying the material of the process connection (P-). → See also parameter description for MAT. PROC. CONN. +</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Deltabar S differential pressure transmitter
SEAL TYPE (362) Selection	<p>For selecting and displaying the material of the process seal.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Not used ■ Unknown ■ Special ■ FKM Viton ■ NBR ■ EPDM ■ Urethane ■ IIR ■ Kalrez ■ FKM Viton oxyg ■ CR ■ MVQ ■ PTFE glass ■ PTFE graphite ■ PTFE oxygen ■ Copper ■ Copper f. oxygen <p>Factory setting: As per order specifications</p>
BOLTS MATERIAL	<p>For selecting and displaying the material of the bolts.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Digital communication

Table 25: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → PROCESS CONNECTION	
Parameter name	Description
NUTS MATERIAL	For selecting and displaying the material of the nuts. Prerequisite: ■ Digital communication
DRAIN VENT MAT.	For selecting and displaying the material of the vent valves. Prerequisite: ■ Digital communication
DRAIN VENT POS.	For selecting and displaying the position of the vent valves. Prerequisite: ■ Digital communication
THREAD	For selecting and displaying the process connection thread. Prerequisite: ■ Digital communication
MOUNTING THREAD	For selecting and displaying the ways of securing the device. Prerequisite: ■ Digital communication
REMOTE SEAL +	For selecting and displaying the diaphragm seal type on the positive side. Prerequisite: ■ Digital communication
REMOTE SEAL –	For selecting and displaying the diaphragm seal type on the negative side. Prerequisite: ■ Digital communication
DIAPHRAG. MAT. +	For selecting and displaying the material of the process isolating diaphragm on the positive side. Prerequisite: ■ Digital communication
DIAPHRAG. MAT. –	For selecting and displaying the material of the process isolating diaphragm on the negative side. Prerequisite: ■ Digital communication
NR OF REMOTE SEAL	For selecting and displaying the number of diaphragm seals. Prerequisite: ■ Digital communication
FILL FLUID	For selecting and displaying the diaphragm seal fill fluid. Prerequisite: ■ Digital communication

Table 26: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → SENSOR DATA (all measuring modes)	
Parameter name	Description
SENSOR SER. No. (250) Display	Displays the serial number of the sensor (11 alphanumeric characters).
PRESS. SENS LOLIM (484) Display	Displays the lower measuring limit of the sensor.
PRESS. SENS HILIM (485) Display	Displays the upper measuring limit of the sensor.
MINIMUM SPAN (591) Display	Displays the smallest possible span.

Table 26: (GROUP SELECTION →) OPERATING MENU → TRANSMITTER INFO → SENSOR DATA (all measuring modes)	
Parameter name	Description
SENSOR MEAS.TYPE (581) Display	Displays the sensor type. <ul style="list-style-type: none"> ■ Deltabar S = differential ■ Cerabar S with gauge pressure sensor = relative ■ Cerabar S with absolute pressure sensor = absolute ■ Deltapilot S = relative
Pmin SENS. DAMAGE (251) Display	Displays the minimum permissible absolute pressure of the sensor (vacuum-proofing).
Pmax SENS. DAMAGE (252) Display	Displays the maximum permissible absolute pressure of the sensor (overpressure-proofing).
MAT. MEMBRANE (365) Display	Displays the material of the process isolating diaphragm. Factory setting: As per version in the order code → For Deltabar S, see Technical Information TI00382P, for Cerabar S, see Technical Information TI00383P or for Deltapilot S, see Technical Information TI00416P, "Ordering information" section.
FILLING FLUID (366) Display	Displays the filling fluid.
Tmin SENSOR (368) Display	Displays the lower nominal temperature limit of the sensor.
Tmax SENSOR (369) Display	Displays the upper nominal temperature limit of the sensor.
SENS H/WARE REV (487) Display	Displays the revision number of the sensor hardware. e.g.: 1




Fig. 45: PROCESSINFO group

→ For the PROCESS VALUES function group, "Pressure" measuring mode, see Page 121, Table 27

→ For the PROCESS VALUES function group, "Level" measuring mode, see Page 122, Table 28

→ For the PROCESS VALUES function group, "Flow" measuring mode, see Page 123, Table 29

→ For the PEAK HOLD INDICATOR function group, see Page 124, Table 30

Table 27: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure"

Parameter name	Description
Prerequisite: ■ MEASURING MODE = pressure (→ see also Page 45).	
MEASURED VALUE (679)	Displays the measured value In the "Pressure" measuring mode, this value corresponds to the PRESSURE parameter. Prerequisite: ■ Digital communication On-site operation: ■ For on-site operation, the MEASURED VALUE parameter is displayed on the 1st level.

Table 27: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PROCESS VALUES "Pressure"


Parameter name	Description
PRESSURE (301) Display	<p>Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.</p>  <p style="text-align: right;">P01-zMa7xxxx-05-xx-xx-xx-009</p>
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. → See also PRESSURE diagram.
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. → See also PRESSURE diagram.
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This temperature can deviate from the process temperature.
MEAS. VAL. TREND (378) Display	Displays the trend of the pressure measured value. Possibilities: increasing, decreasing, constant

Table 28: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level"


Parameter name	Description
Prerequisite: ■ MEASURING MODE = Level (→ see also Page 45).	
MEASURED VALUE (679) Display	<p>Displays the measured value</p> <p>In the "Level" measuring mode with "Linear" or "Pressure Linearized" level type, this value corresponds to the LEVEL BEFORE LIN parameter</p> <p>In the "Level" measuring mode with "Height Linearized" level type, this value corresponds to the TANK CONTENT parameter.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Digital communication <p>On-site operation:</p> <ul style="list-style-type: none"> ■ For on-site operation, the MEASURED VALUE parameter is displayed on the 1st level.
PRESSURE (301) Display	<p>Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode.</p>  <p style="text-align: right;">P01-zMa7xxxx-05-xx-xx-xx-010</p>
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. → See also PRESSURE diagram.
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. → See also PRESSURE diagram.
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This temperature can deviate from the process temperature.

Table 28: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PROCESS VALUES "Level"	
Parameter name	Description
MEAS. VAL. TREND (378) Display	Displays the trend of the pressure measured value. Possibilities: increasing, decreasing, constant
LEVEL BEFORE LIN (050) Display	Displays the level value prior to linearisation. Prerequisite: ■ LEVEL MODE = Linear or Height Linearized Depending on the setting for the LIN. MEASURAND or COMB. MEASURAND parameter, this parameter displays the current level in % or in a unit of level.
TANK CONTENT (370) Display	Displays the level value after linearisation. Prerequisite: ■ LEVEL MODE = Pressure Linearized or Height Linearized Depending on the settings for the LINd. MEASURAND or COMB. MEASURAND parameter, the current tank content is displayed in % or in a unit of volume or mass. This value corresponds to the MEASURED VALUE.

Table 29: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow"	
Parameter name	Description
Prerequisite: ■ MEASURING MODE = Flow (→ see also Page 45).	
MEASURED VALUE (679) Display	Displays the measured value In the "Flow" measuring mode, this value corresponds to the SUPPRESSED FLOW parameter. Prerequisite: ■ Digital communication On-site operation: ■ For on-site operation, the MEASURED VALUE parameter is displayed on the 1st level.
PRESSURE (301) Display	Displays the measured pressure after sensor recalibration, position adjustment and damping. This value corresponds to the MEASURED VALUE parameter in the "Pressure" measuring mode. <div style="text-align: center;"> <pre> graph LR Sensor[Sensor] --> ST[Sensor trim] ST --> PA[Position adjustment] PA --> D[Damping] D --> P((P)) P --> Level[Level] Level --> Flow[Flow] Flow --> CO[Current output] Sensor --> SP[SENSOR PRESSURE] PA --> CP[CORRECTED PRESS.] P --> PR[PRESSURE] </pre> </div> <p style="text-align: right; font-size: small;">P01-aMx7xxxx-05-xx-xx-xx-011</p>
CORRECTED PRESS. (434) Display	Displays the measured pressure after sensor trim and position adjustment and before damping. → See also PRESSURE diagram.
SENSOR PRESSURE (584) Display	Displays the measured pressure before sensor trim, position adjustment and damping. → See also PRESSURE diagram.
SENSOR TEMP. (367) Display	Displays the temperature currently measured in the sensor. This temperature can deviate from the process temperature.
MEAS. VAL. TREND (378) Display	Displays the trend of the pressure measured value. Possibilities: increasing, decreasing, constant
SUPPRESSED FLOW (375) Display	Displays the current flow. Depending on the flow mode selected (→ FLOW-MEAS. TYPE), a volume flow, mass flow, standard volume flow or corrected volume flow is displayed.

Table 29: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PROCESS VALUES "Flow"	
Parameter name	Description
TOTALIZER 1 (652) Display	Displays the total flow value of totalizer 1. You can reset the value with the RESET TOTALIZER 1 parameter. The TOTAL. 1 OVERFLOW parameter displays the overflow. Example: The value 123456789 m ³ is displayed as follows: – TOTALIZER 1: 3456789 m ³ – TOTAL. 1 OVERFLOW: 12 E7
TOTAL. 1 OVERFLOW (655) Display	Displays the overflow value of totalizer 1. → See also TOTALIZER 1.
TOTALIZER 2 (657) Display	Displays the total flow value of totalizer 2. You cannot reset totalizer 2. The TOTAL. 2 OVERFLOW parameter displays the overflow. → See also example for TOTALIZER 1.
TOTAL. 2 OVERFLOW (658) Display	Displays the overflow value of totalizer 2. → See also TOTALIZER 2 and example for TOTALIZER 1.

Table 30: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PEAK HOLD INDICATOR	
Parameter name	Description
COUNTER:P > Pmax (380) Display	Displays the overpressure counter of the sensor The limit value is: upper nominal pressure limit of sensor + 10 % of upper nominal pressure limit of sensor. You can reset this counter by means of the RESET PEAKHOLD parameter.
MAX. MEAS. PRESS. (383) Display	Displays the largest measured pressure value (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
COUNTER P < Pmin (467) Display	Displays the vacuum pressure counter of the sensor The limit value is: lower nominal pressure limit of sensor – 10 % of upper nominal pressure limit of sensor. You can reset this counter by means of the RESET PEAKHOLD parameter.
MIN. MEAS. PRESS. (469) Display	Displays the smallest measured pressure value (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
COUNTER:T > Tmax (404) Display	Displays the number of times the specified temperature range of the sensor has been overshoot. You can reset this counter by means of the RESET PEAKHOLD parameter.
MAX. MEAS. TEMP. (471) Display	Displays the largest measured temperature in the sensor (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
COUNTER:T < Tmin (472) Display	Displays the number of times the specified temperature range of the sensor has been undershot. You can reset this counter by means of the RESET PEAKHOLD parameter.
MIN. MEAS. TEMP. (474) Display	Displays the smallest measured temperature in the sensor (peak hold indicator). You can reset this indicator by means of the RESET PEAKHOLD parameter.
PCB COUNT:T > Tmax (488) Display	Displays the number of times the specified temperature range of the electronics has been overshoot.
PCB MAX. TEMP. (490) Display	Displays the largest electronics temperature measured.
PCB COUNT:T < Tmin (492) Display	Displays the number of times the specified temperature range of the electronics has been undershot.
PCB MIN. TEMP. (494) Display	Displays the smallest electronics temperature measured.

Table 30: (GROUP SELECTION →) OPERATING MENU → PROCESSINFO → PEAK HOLD INDICATOR

Parameter name	Description
RESET PEAKHOLD (382) Selection	<p>This parameter lists all the peak hold indicator parameters that can be reset. You can select the peak hold indicators you want to reset.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ None ■ Max. pressure ■ Min. pressure ■ Pmax history ■ Pmin history ■ Max. temp. ■ Min. temp. ■ Tmax history ■ Tmin history ■ Reset all <p>Factory setting: None</p>




Fig. 46: OPERATING and DIAGNOSTICS group
→ For the OPERATING group, see Page 126, Table 31
→ For the SIMULATION function group, see Page 127, Table 32
→ For the MESSAGES function group, see Page 128, Table 33
→ For the USER LIMITS function group, see Page 130, Table 34



Table 31: (GROUP SELECTION →) OPERATING MENU → OPERATING	
Parameter name	Description
ENTER RESET CODE (047) Entry	<p>Reset parameters completely or partially to factory values or delivery status. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.10 "Factory setting" (reset).</p> <p>Factory setting: 0</p>
OPERATING HOURS (409) Display	<p>Displays the hours of operation. This parameter cannot be reset.</p>
INSERT PIN NO (048) Entry	<p>For entering a code to lock or unlock operation.</p> <p> Note!</p> <ul style="list-style-type: none"> ■ The -symbol on the on-site display indicates that operation is locked. Parameters which refer to how the display appears, e.g. LANGUAGE and DISPLAY CONTRAST can still be altered. ■ If operation is locked by means of the DIP-switch, you can only unlock operation again by means of the DIP-switch. If operation is locked by means of the on-site display or remote operation e.g. FieldCare, you can unlock operation again by means of the on-site display or using remote operation. <p>→ See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.9 "Locking/unlocking operation".</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Lock: enter a number between 0...9999 which is ≠100. ■ Unlock: enter the number 100. <p>Factory setting: 100</p>
HistoROM AVAIL. (831) Display	<p>Indicates whether the optional HistoROM®/M-DAT memory module is connected to the electronic insert. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.5 "HistoROM®/M-DAT (optional)".</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Yes (HistoROM®/M-DAT is attached to the electronic insert) ■ No (HistoROM®/M-DAT is not attached to the electronic insert)
DOWNLOAD SELECT (014) Options	<p>Select download function from HistoROM to device. The selection has no effect on an upload from the device to the HistoROM.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ A HistoROM®/M-DAT is attached to the electronic insert (HistoROM AVAIL. = yes) <p>Options:</p> <ul style="list-style-type: none"> ■ Configuration copy: For this option, all parameters apart from the DEVICE SERIAL No, DEVICE DESIGN., CUST. TAG NUMBER, LONG TAG NUMBER, ADDITIONAL INFO., BUS ADDRESS, CURRENT MODE and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION group are overwritten. ■ Device replacement: With this option, all parameters except for DEVICE SERIAL No, DEVICE DESIGN. and the parameters of the POSITION ADJUSTMENT and PROCESS CONNECTION group are overwritten. ■ Electronics replace: With this option, all parameters except for the parameters of the POSITION ADJUSTMENT group are overwritten. <p>Factory setting: Copy config. (if HistoROM®/M-DAT is attached to the electronic insert)</p>

Table 31: (GROUP SELECTION →) OPERATING MENU → OPERATING

Parameter name	Description
HistoROM CONTROL (832) Selection	<p>For selecting the direction for copying the data. → See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.5. "HistoROM®/M-DAT (optional)".</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ A HistoROM®/M-DAT is attached to the electronic insert (HistoROM AVAIL. = yes) <p>Options:</p> <ul style="list-style-type: none"> ■ Abort ■ HistoROM → Device ■ Device → HistoROM <p>Factory setting: Abort (if HistoROM®/M-DAT is connected to the electronic insert)</p>

Table 32: (GROUP SELECTION →) OPERATING MENU → DIAGNOSTICS → SIMULATION

Parameter name	Description
SIMULATION MODE (413) Selection	<p>Switch on simulation and select simulation type. Any simulation running is switched off if the measuring mode or level type is changed.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ None ■ Pressure, → see also this table parameter description for SIM. PRESSURE ■ Flow (only differential pressure transmitter), → see also this table parameter description for SIM. FLOW VALUE ■ Level, → see also this table parameter description for SIM. LEVEL ■ Tank content, → see also this table parameter description for SIM. TANK CONT. ■ Current, → see also this table parameter description for SIM. CURRENT <p>Note: The "Flow" measuring mode has to be selected in the LINEAR/SQROOT parameter to ensure the current output corresponds to the simulated flow value.</p> <ul style="list-style-type: none"> ■ Alarm/warning, → see also this table parameter description for SIM. ERROR NO. <div style="text-align: center;"> <p style="text-align: right; font-size: small;">P01-xMx7xxx-05-xr-xx-xx-012</p> </div> <p>Factory setting: None</p>
SIM. PRESSURE (414) Entry	<p>Enter simulation value. → See also SIMULATION MODE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ SIMULATION MODE = Pressure <p>Factory setting: Current pressure measured value</p>
SIM. FLOW VALUE (639) Entry	<p>Enter simulation value. → See also SIMULATION MODE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ MEASURING MODE = Pressure and SIMULATION MODE = Flow ■ MEASURING MODE = Flow and SIMULATION MODE = Flow


Table 32: (GROUP SELECTION →) OPERATING MENU → DIAGNOSTICS → SIMULATION	
Parameter name	Description
SIM. LEVEL (714) Entry	<p>Enter simulation value. → See also SIMULATION MODE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> MEASURING MODE = Level and SIMULATION MODE = Level
SIM. TANK CONT. (715) Entry	<p>Enter simulation value. → See also SIMULATION MODE.</p> <p>Prerequisites:</p> <ul style="list-style-type: none"> MEASURING MODE = Level, LEVEL MODE = Pressure Linearized and SIMULATION MODE = Tank content MEASURING MODE = Level, LEVEL MODE = Height Linearized and SIMULATION MODE = Tank content
SIM. CURRENT (270) Entry	<p>Enter simulation value. → See also SIMULATION MODE.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> SIMULATION MODE = Current value <p>Factory setting: Current current value</p>
SIM. ERROR NO. (476) Entry	<p> Warning! The SIMULATION parameter overwrites fault states (alarm/warning) that are actually present. When the simulation is ended, the fault states (alarm/warning) still persist but are no longer displayed! When the device is restarted it returns to its fault state.</p> <p>Enter message number. → See also SIMULATION MODE. → See also these Operating Instructions, Section 8.1 "Messages", "Code" table column.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> SIMULATION MODE = Alarm/Warning <p>Factory setting: 613 (simulation active)</p>






Table 33: (GROUP SELECTION →) OPERATING MENU → DIAGNOSTICS → MESSAGES	
Parameter name	Description
ALARM STATUS (046) Display	<p>Displays the current messages present. → See also these Operating Instructions, Section 8.1. "Messages" and Section 8.3 "Confirming messages".</p> <p>On-site display</p> <ul style="list-style-type: none"> The measured value display shows the message with the highest priority. The ALARM STATUS parameter shows all the messages in descending order of priority. You can scroll through all the messages present with the  or  key. <p>Operating program</p> <ul style="list-style-type: none"> The "Status" field and the ALARM STATUS parameter show the message with the highest priority.
LAST DIAG. CODE (564) Display	<p>Displays the last messages that occurred and were eliminated.</p> <p> Note!</p> <ul style="list-style-type: none"> On-site display: you can scroll through the last 15 messages with the  or  key. Digital communication: the last message appears on the display. Use the RESET ALL ALARMS parameter to delete the messages listed in the LAST DIAG. CODE parameter.
ACK. ALARM MODE (401) Selection	<p>Switch on acknowledge alarm mode. → See also ACK. ALARM.</p> <p>Options:</p> <ul style="list-style-type: none"> On Off <p>Factory setting: Off</p>




Table 33: (GROUP SELECTION →) OPERATING MENU → DIAGNOSTICS → MESSAGES	
Parameter name	Description
ACK. ALARM (500) Selection	<p>Acknowledge alarm.</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ ACK. ALARM MODE = on <p>Options:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm <p>The cause of the alarm must be eliminated, the message must be acknowledged via the ACK. ALARM parameter and, where applicable, the ALARM DISPL. TIME (→ Page 129) has to have elapsed before the device starts measuring again following an alarm.</p> <p>→ See also these Operating Instructions, Section 8.3 "Confirming messages".</p> <p>Factory setting: Abort</p>
RESET ALL ALARMS (603) Selection	<p>Use this parameter to reset all the messages of the LAST DIAG. CODE parameter.</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Abort ■ Confirm <p>Factory setting: Abort</p>
ERROR No. Entry	<p>For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). Enter the corresponding message number for this parameter. → See also SELECT ALARMTYPE.</p> <p>→ See also these Operating Instructions, Section 8.1 "Messages" and Section 8.2 "Response of outputs to errors".</p> <p>Prerequisite:</p> <ul style="list-style-type: none"> ■ Digital communication
SELECT ALARMTYPE (595) – Entry (600) – Selection	<p>For "Error"-type messages, you can decide whether the device should behave as in the event of an alarm (A) or as in the event of a warning (W). → See also ERROR No.</p> <p>→ See also these Operating Instructions, Section 8.2 "Response of outputs to errors".</p> <p>Options:</p> <ul style="list-style-type: none"> ■ Alarm (A): output current assumes a defined value. ■ Warning (W): device continues measuring <p>On-site operation:</p> <ol style="list-style-type: none"> 1. Enter the corresponding message number for ERROR No. field. 2. Select "Alarm" or "Warning" option. <p>Digital communication:</p> <ol style="list-style-type: none"> 1. Enter the corresponding message number via the ERROR No. parameter. 2. Use the SELECT ALARMTYPE parameter to select the "Alarm" or "Warning" option.
ALARM DELAY (336) Entry	<p>Enter alarm response time for all "Error" messages.</p> <p> Note! There is no alarm if the cause of the error is eliminated within the alarm delay time.</p> <p>Input range: 0...100 s</p> <p>Factory setting: 0.0 s</p>
ALARM DISPL. TIME (480) Entry	<p>Enter alarm display time for all "Error" messages. Once the cause of the error is rectified, the alarm display time starts running.</p> <p> Note! The following applies if the setting for ACK. ALARM MODE = on: If an alarm appears and the alarm display time elapses before the alarm has been acknowledged, the message will be cleared once it has been acknowledged.</p> <p>→ See also these Operating Instructions, Section 8.3 "Confirming messages".</p> <p>Input range: 0...999.9 s</p> <p>Factory setting: 0.0 s</p>

Table 34: (GROUP SELECTION →) OPERATING MENU → DIAGNOSTICS → USER LIMITS	
Parameter name	Description
Pmin ALARM WINDOW (332) Entry	Customer-specific process monitoring – enter lower pressure limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E730 and Section 8.2. "Response of outputs to errors". Factory setting: Low sensor limit ■ 1.1 (→ For the low sensor limit, see PRESS. SENS LOLIM.)
Pmax ALARM WINDOW (333) Entry	Customer-specific process monitoring – enter upper pressure limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E731 and Section 8.2. "Response of outputs to errors". Factory setting: High sensor limit ■ 1.1 (→ For the high sensor limit, see PRESS. SENS HILIM.)
Tmin ALARM WINDOW (334) Entry	Customer-specific process monitoring – enter lower temperature limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E732 and Section 8.2. "Response of outputs to errors". Factory setting: Lower sensor temperature application limit – 10 K (→ For the lower temperature application limit, see Tmin SENSOR)
Tmax ALARM WINDOW (335) Entry	Customer-specific process monitoring – enter upper temperature limit. You can use the SELECT ALARMTYPE parameter to enter how the device responds if the operating pressure undershoots the specified value. → See also these Operating Instructions, Section 8.1 "Messages", table, Code E733 and Section 8.2. "Response of outputs to errors". Factory setting: Upper sensor temperature application limit +10 K (→ For the upper temperature application limit, see Tmax SENSOR)



P01-xxxxxxx-19-xx-xx-xx-144

Fig. 47: SYSTEM 2 group

Table 35: (GROUP SELECTION →) OPERATING MENU → SERVICE → SYSTEM 2	
Parametername	Beschreibung
CURR. TRIM 4mA (045) Entry	<p>Enter current value for the lower point (4 mA) of the current output trim line. You can adapt the current output to the transmission conditions with this parameter and CURR. TRIM 20mA.</p> <p>Perform current trim for the lower point as follows:</p> <ol style="list-style-type: none"> 1. Select SIMULATION group. (Menu path: (GROUP SELECTION) → OPERATING MENU → DIAGNOSTICS → SIMULATION) 2. Select option "Current" via SIMULATION parameter. 3. Enter "4 mA" for SIM. CURRENT parameter. 4. Select SYSTEM 2 group. (Menu path: (GROUP SELECTION) → OPERATING MENU → SERVICE) 5. Enter the current value measured with the switching unit for the CURR. TRIM 4mA parameter. <p>Input range: Measured current ± 0.2 mA</p> <p>Factory setting: 4 mA</p>
CURR. TRIM 20mA (042) Entry	<p>Enter current value for the upper point (20 mA) of the current output trim line. You can adapt the current output to the transmission conditions with this parameter and CURR. TRIM 4mA.</p> <p>Perform current trim for the upper point as follows:</p> <ol style="list-style-type: none"> 1. Select SIMULATION group. (Menu path: (GROUP SELECTION) → OPERATING MENU → DIAGNOSTICS → SIMULATION) 2. Select option "Current" via SIMULATION parameter. 3. Enter "20 mA" for SIM. CURRENT parameter. 4. Select SYSTEM 2 group. (Menu path: (GROUP SELECTION) → OPERATING MENU → SERVICE) 5. Enter the current value measured with the switching unit for the CURR. TRIM 20mA parameter. <p>Input range: Measured current ± 0.2 mA</p> <p>Factory setting: 20 mA</p>
OFFSET 4mA TRIM (043) Display	<p>Displays the difference between 4 mA and the value entered for the CURRENT TRIM 4mA parameter.</p> <p>Factory setting: 0</p>
OFFSET 20mA TRIM (044) Display	<p>Displays the difference between 20 mA and the value entered for the CURRENT TRIM 20mA parameter.</p> <p>Factory setting: 0</p>

8 Trouble-shooting

8.1 Messages

The following table lists all the possible messages that can occur.



The device differentiates between the error types "Alarm", "Warning" and "Error". You may specify whether the instrument should react as if for an "Alarm" or "Warning" for "Error" messages.

→ See "Error type/NA 64" column and parameter descriptions for ERROR No. and SELECT ALARMTYPE (→ Page 129).

In addition, the "Error type/NA 64" column classifies the messages in accordance with NAMUR Recommendation NA 64:

- Break down: indicated with "B"
- Maintenance need: indicated with "C" (check request)
- Function check: indicated with "I" (in service)

Error message display on the on-site display:

- The measured value display shows the message with the highest priority. → See "Priority" column.
- The ALARM STATUS (→ Page 128) parameter shows all the messages present in descending order of priority. You can scroll through all the messages present with the -key or -key.

Message display via the digital communication:

- The ALARM STATUS (→ Page 128) parameter shows the message with the highest priority. → See "Priority" column.




Note!

- If the device detects a defect in the on-site display during initialization, special error messages are generated. → For the error messages, see Page 139, Section 8.1.1 "On-site display error messages".
- For support and further information, please contact Endress+Hauser Service.
- → See also Section 8.4, 8.5 and 8.6.

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
101 (A101)	Alarm B	Failure (F)	B>Sensor electronic EEPROM error	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). This message normally only appears briefly. – Sensor defect. 	<ul style="list-style-type: none"> – Wait a few minutes. – Restart the device. Perform reset (Code 62). – Block off electromagnetic effects or eliminate source of disturbance. – Replace sensor. 	17
102 (W102)	Warning C	Maintenance request (M)	C>Checksum error in EEPROM: peakhold segment	<ul style="list-style-type: none"> – Main electronics defect. Correct measurement can continue as long as you do not need the peak hold indicator function. 	<ul style="list-style-type: none"> – Replace main electronics. 	53
106 (W106)	Warning C	Funktion check (C)	C>Downloading - please wait	<ul style="list-style-type: none"> – Downloading. 	<ul style="list-style-type: none"> – Wait for download to complete. 	52

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
110 (A110)	Alarm B	Failure (F)	B>Checksum error in EEPROM: configuration segment	<ul style="list-style-type: none"> – The supply voltage is disconnected when writing. – Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). – Main electronics defect. 	<ul style="list-style-type: none"> – Reestablish supply voltage. Perform reset (Code 7864) if necessary. Carry out calibration again. – Block off electromagnetic effects or eliminate sources of disturbance. – Replace main electronics. 	6
113 (A113)	Alarm B	Failure (F)	B>ROM failure in transmitter electronic	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	1
115 (E115)	Error B factory setting; Warning C	Out of specification (S)	B>Sensor overpressure	<ul style="list-style-type: none"> – Overpressure present. – Sensor defect. 	<ul style="list-style-type: none"> – Reduce pressure until message disappears. – Replace sensor. 	29
116 (W116)	Warning C	Maintenance request (M)	C>Download error, repeat download	<ul style="list-style-type: none"> – The file is defect. – During the download, the data are not correctly transmitted to the processor, e.g. because of open cable connections, spikes (ripple) on the supply voltage or electromagnetic effects. 	<ul style="list-style-type: none"> – Use another file. – Check cable connection PC – transmitter. – Block off electromagnetic effects or eliminate sources of disturbance. – Perform reset (Code 7864) and carry out calibration again. – Repeat download. 	36
120 (E120)	Error B factory setting; Warning C	Out of specification (S)	B>Sensor low pressure	<ul style="list-style-type: none"> – Pressure too low. – Sensor defect. 	<ul style="list-style-type: none"> – Increase pressure until message disappears. – Replace sensor. 	30
121 (A121)	Alarm B	Failure (F)	B>Checksum error in factory segment of EEPROM	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	5
122 (A122)	Alarm B	Failure (F)	B>Sensor not connected	<ul style="list-style-type: none"> – Cable connection sensor –main electronics disconnected. – Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). – Main electronics defect. – Sensor defect. 	<ul style="list-style-type: none"> – Check cable connection and repair if necessary. – Block off electromagnetic effects or eliminate source of disturbance. – Replace main electronics. – Replace sensor. 	13
130 (A130)	Alarm B	Failure (F)	B>EEPROM is defect.	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	10
131 (A131)	Alarm B	Failure (F)	B>Checksum error in EEPROM: min/max segment	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	9
132 (A132)	Alarm B	Failure (F)	B>Checksum error in totalizer EEPROM	<ul style="list-style-type: none"> – Main electronics defect. 	<ul style="list-style-type: none"> – Replace main electronics. 	7
133 (A133)	Alarm B	Failure (F)	B>Checksum error in History EEPROM	<ul style="list-style-type: none"> – An error occurred when writing. – Main electronics defect. 	<ul style="list-style-type: none"> – Perform reset (Code 7864) and carry out calibration again. – Replace electronics. 	8
602 (W602)	Warning C	Funktion check (C)	C>Linearisation curve not monotone	<ul style="list-style-type: none"> – The linearisation table is not monotonic increasing or decreasing. 	<ul style="list-style-type: none"> – Add to linearisation table or perform linearisation again. 	57

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
604 (W604)	Warning C	Funktion check (C)	C>Linearisation table not valid. Less than 2 points or points too close	 Note! From software version "02.10.xx" onwards, there is no min. span for the Y-points.		58
				<ul style="list-style-type: none"> – The linearisation table consists of less than 2 points. – At least 2 points in the linearisation table are too close together. A minimum gap of 0.5 % of the distance between two points must be maintained. Spans for the "Pressure linearized" option: HYDR. PRESS MAX. – HYDR. PRESS MIN.; TANK CONTENT MAX. – TANK CONTENT MIN. Spans for the "Height linearized" option: LEVEL MAX – LEVEL MIN; TANK CONTENT MAX. – TANK CONTENT MIN. 	<ul style="list-style-type: none"> – Add to linearisation table. If necessary, perform linearisation again. – Correct linearisation table and accept again. 	
613 (W613)	Warning I	Funktion check (C)	I>Simulation is active	– Simulation is switched on, i.e. the device is not measuring at present.	– Switch off simulation.	60
620 (E620)	Error C Factory setting: Warning C	Out of specification (S)	C>Current output out of range	The current is outside the permitted range 3.8 to 20.5 mA. <ul style="list-style-type: none"> – The pressure applied is outside the set measuring range (but within the sensor range). – Loose connection at sensor cable 	<ul style="list-style-type: none"> – Check pressure applied, reconfigure measuring range if necessary (→ See also these Operating Instructions, chapter 4 to 6.) – Perform reset (Code 7864) and carry out calibration again. – Wait a short period of time and tighten the connection, or avoid loose connection. 	49
700 (W700)	Warning C	Maintenance request (M)	C>Last configuration not stored	<ul style="list-style-type: none"> – An error occurred when writing or reading configuration data or the power supply was disconnected. – Main electronics defect. 	<ul style="list-style-type: none"> – Perform reset (Code 7864) and carry out calibration again. – Replace main electronics. 	54
701 (W701)	Warning C	Funktion check (C)	C>Measuring chain config. exceeds sensor range	– The calibration carried out would result in the sensor nominal operating range being undershot or overshoot.	– Carry out calibration again.	50
702 (W702)	Warning C	Maintenance request (M)	C>HistoROM data not consistent.	<ul style="list-style-type: none"> – Data were not written correctly to the HistoROM, e.g. if the HistoROM was detached during the writing process. – HistoROM does not have any data. 	<ul style="list-style-type: none"> – Repeat upload. – Perform reset (Code 7864) and carry out calibration again. – Copy suitable data to the HistoROM. (→ See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S) or BA00332P (Deltapilot S), Section 5.5.1 "Copying configuration data".) 	55
703 (A703)	Alarm B	Failure (F)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	22

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
704 (A704)	Alarm B	Funktion check (C)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	12
705 (A705)	Alarm B	Failure (F)	B>Measurement error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	21
706 (W706)	Warning C	Maintenance request (M)	C>Configuration in HistoROM and device not identical	<ul style="list-style-type: none"> – Configuration (parameters) in the HistoROM and in the device is not identical. 	<ul style="list-style-type: none"> – Copy data from the device to the HistoROM. – Copy data from the HistoROM to the device. The message remains if the HistoROM and the device have different software versions. The message goes out if you copy the data from the device to the HistoROM. – Device reset codes such as 7864 do not have any effect on the HistoROM. That means that if you do a reset, the configurations in the HistoROM and in the device may not be the same. <p>→ See also Operating Instructions BA00270P (Deltabar S), BA00271P (Cerabar S), BA00332P (Deltapilot S) Section 5.5.1 "Copying configuration data".</p>	59
707 (A707)	Alarm B	Funktion check (C)	B>X-VAL. of lin. table out of edit limits.	<ul style="list-style-type: none"> – At least one X-VALUE in the linearisation table is either below the value for HYDR. PRESS. MIN. or MIN. LEVEL or above the value for HYDR. PRESS. MAX. or LEVEL MAX. 	<ul style="list-style-type: none"> – Carry out calibration again. (→ See also these Operating Instructions, chapter 5.) 	38
710 (W710)	Warning C	Funktion check (C)	B>Set span too small. Not allowed.	<ul style="list-style-type: none"> – Values for calibration (e.g. lower range value and upper range value) are too close together. – The sensor was replaced and the customer-specific configuration does not suit the sensor. – Unsuitable download carried out. 	<ul style="list-style-type: none"> – Adjust calibration to suit sensor. (→ See also Page 119, parameter description MINIMUM SPAN.) – Adjust calibration to suit sensor. – Replace sensor with a suitable sensor. – Check configuration and perform download again. 	51
711 (A711)	Alarm B	Funktion check (C)	B>LRV or URV out of edit limits	<ul style="list-style-type: none"> – Lower range value and/or upper range value undershoot or overshoot the sensor range limits. – The sensor was replaced and the customer-specific configuration does not suit the sensor. – Unsuitable download carried out. 	<ul style="list-style-type: none"> – Reconfigure lower range value and/or upper range value to suit the sensor. Pay attention to position factor. – Reconfigure lower range value and/or upper range value to suit the sensor. Pay attention to position factor. – Replace sensor with a suitable sensor. – Check configuration and perform download again. 	37
713 (A713)	Alarm B	Funktion check (C)	B>100% POINT level out of edit limits	<ul style="list-style-type: none"> – The sensor was replaced. 	<ul style="list-style-type: none"> – Carry out calibration again. 	39

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
715 (E715)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor over temperature	<ul style="list-style-type: none"> – The temperature measured in the sensor is greater than the upper nominal temperature of the sensor. (→ See also Page 120, parameter description Tmax SENSOR.) – Unsuitable download carried out. 	<ul style="list-style-type: none"> – Reduce process temperature/ ambient temperature. – Check configuration and perform download again. 	32
716 (E716)	Error B Factory setting: Alarm B	Failure (F)	B>Process isolating diaphragm broken	<ul style="list-style-type: none"> – Sensor defect. 	<ul style="list-style-type: none"> – Replace sensor. – Reduce pressure. 	24
717 (E717)	Error C Factory setting: Warning C	Out of specification (S)	C>Transmitter over temperature	<ul style="list-style-type: none"> – The temperature measured in the electronics is greater than the upper nominal temperature of the electronics (+88 °C). – Unsuitable download carried out. 	<ul style="list-style-type: none"> – Reduce ambient temperature. – Check configuration and perform download again. 	34
718 (E718)	Error C Factory setting: Warning C	Out of specification (S)	C>Transmitter under temperature	<ul style="list-style-type: none"> – The temperature measured in the electronics is smaller than the lower nominal temperature of the electronics (–43 °C). – Unsuitable download carried out. 	<ul style="list-style-type: none"> – Increase ambient temperature. Insulate device if necessary. – Check configuration and perform download again. 	35
719 (A719)	Alarm B	Funktion check (C)	B>Y-VAL of lin. table out of edit limits	<ul style="list-style-type: none"> – At least on Y-VALUE in the linearisation table is below the MIN. TANK CONTANT or above the MAX. TANK CONTENT. 	<ul style="list-style-type: none"> – Carry out calibration again. (→ See also Operating Instructions BA00274P, chapter 5 or these Operating Instructions, Page 2.) 	40
720 (E720)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor under temperature	<ul style="list-style-type: none"> – The temperature measured in the sensor is smaller than the lower nominal temperature of the sensor. (→ See also Page 120, parameter description Tmin SENSOR.) – Unsuitable download carried out. – Loose connection at sensor cable 	<ul style="list-style-type: none"> – Increase process temperature/ ambient temperature. – Check configuration and perform download again. – Wait a short period of time and tighten the connection, or avoid loose connection. 	33
721 (A721)	Alarm B	Funktion check (C)	B>ZERO POSITION level out of edit limits	<ul style="list-style-type: none"> – LEVEL MIN or LEVEL MAX has been changed. 	<ul style="list-style-type: none"> – Perform reset (Code 2710) and carry out calibration again. 	41
722 (A722)	Alarm B	Funktion check (C)	B>EMPTY CALIB. or FULL CALIB. out of edit limits	<ul style="list-style-type: none"> – LEVEL MIN or LEVEL MAX has been changed. 	<ul style="list-style-type: none"> – Perform reset (Code 2710) and carry out calibration again. 	42
723 (A723)	Alarm B	Funktion check (C)	B>MAX. FLOW out of edit limits	<ul style="list-style-type: none"> – FLOW-MEAS. TYPE has been changed. 	<ul style="list-style-type: none"> – Carry out calibration again. 	43

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
725 (A725)	Alarm B	Failure (F)	B>Sensor connection error, cycle disturbance	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). – Setscrew loose. – Sensor or main electronics defect. 	<ul style="list-style-type: none"> – Block off electromagnetic effects or eliminate source of disturbance. – Retighten setscrew with 1 Nm (0,74 lbf ft) (see chapter "Rotating the housing" in BA00270P (Deltabar S), BA00271P (Cerabar S), BA00332P (Deltapilot S). – Replace sensor or main electronics. 	25
726 (E726)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor temperature error - overrange	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). – Process temperature is outside permitted range. – Sensor defect. 	<ul style="list-style-type: none"> – Block off electromagnetic effects or eliminate source of disturbance. – Check temperature present, reduce or increase if necessary. – If the process temperature is within the permitted range, replace sensor. 	31
727 (E727)	Error C Factory setting: Warning C	Out of specification (S)	C>Sensor pressure error - overrange	<ul style="list-style-type: none"> – Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). – Pressure is outside permitted range. – Sensor defect. 	<ul style="list-style-type: none"> – Block off electromagnetic effects or eliminate source of disturbance. – Check pressure present, reduce or increase if necessary. – If the pressure is within the permitted range, replace sensor. 	28
728 (A728)	Alarm B	Failure (F)	B>RAM error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	2
729 (A729)	Alarm B	Failure (F)	B>RAM error	<ul style="list-style-type: none"> – Fault in the main electronics. – Main electronics defect. 	<ul style="list-style-type: none"> – Briefly disconnect device from the power supply. – Replace main electronics. 	3
730 (E730)	Error C Factory setting: Warning C	Out of specification (S)	C>LRV user limits exceeded	<ul style="list-style-type: none"> – Pressure measured value has undershot the value specified for the Pmin ALARM WINDOW parameter. – Loose connection at sensor cable 	<ul style="list-style-type: none"> – Check system/pressure measured value. – Change value for Pmin ALARM WINDOW if necessary. (→ See also Page 130, parameter description Pmin ALARM WINDOW.) – Wait a short period of time and tighten the connection, or avoid loose connection. 	46

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
731 (E731)	Error C Factory setting: Warning C	Out of specification (S)	C>URV user limits exceeded	– Pressure measured value has overshot the value specified for the Pmax ALARM WINDOW parameter.	– Check system/pressure measured value. – Change value for Pmax ALARM WINDOW if necessary. (→ See also Page 130, parameter description Pmax ALARM WINDOW.)	45
		Out of specification (S)		– Loose connection at sensor cable	– Wait a short period of time and tighten the connection, or avoid loose connection.	
732 (E732)	Error C Factory setting: Warning C		C>LRV Temp. User limits exceeded	– Temperature measured value has undershot the value specified for the Tmin ALARM WINDOW parameter.	– Check system/temperature measured value. – Change value for Tmin ALARM WINDOW if necessary. (→ See also Page 130, parameter description Tmin ALARM WINDOW.)	48
733 (E733)	Error C Factory setting: Warning C	Out of specification (S)	C>URV Temp. User limits exceeded	– Temperature measured value has overshot the value specified for the Tmax ALARM WINDOW parameter.	– Check system/temperature measured value. – Change value for Tmax ALARM WINDOW if necessary. (→ See also Page 130, parameter description Tmax ALARM WINDOW.)	47
736 (A736)	Alarm B	Failure (F)	B>RAM error	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	4
737 (A737)	Alarm B	Failure (F)	B>Measurement error	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	20
738 (A738)	Alarm B	Failure (F)	B>Measurement error	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	19
739 (A739)	Alarm B	Failure (F)	B>Measurement error	– Fault in the main electronics. – Main electronics defect.	– Briefly disconnect device from the power supply. – Replace main electronics.	23
740 (E740)	Error C Factory setting: Warning C	Maintenance request (M)	C>Calculation overflow, bad configuration	– Level measuring mode: the measured pressure has undershot the value for HYDR. PRESS. MIN. or overshot the value for HYDR. PRESS MAX. – Level measuring mode: The measured level did not reach the LEVEL MIN value or exceeded the LEVEL MAX value. – Flow measuring mode: the measured pressure has undershot the value for MAX. PRESS FLOW.	– Check configuration and carry out calibration again if necessary. – Select a device with a suitable measuring range. – Check configuration and carry out calibration again if necessary. (→ See also parameter description LEVEL MIN., Page 86.) – Check configuration and carry out calibration again if necessary. – Select a device with a suitable measuring range.	27
741 (A741)	Alarm B	Funktion check (C)	B>TANK HEIGHT out of edit limits	– LEVEL MIN or LEVEL MAX has been changed.	– Perform reset (Code 2710) and carry out calibration again.	44

Code	Error type/ NA 64	Corresponds NE 107	Message/description	Cause	Measure	Prio rity
742 (A742)	Alarm B	Failure (F)	B>Sensor connection error (upload)	<ul style="list-style-type: none"> Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). This message normally only appears briefly. Cable connection sensor – main electronics disconnected. Sensor defect. 	<ul style="list-style-type: none"> Wait a few minutes. Perform reset (Code 7864) and carry out calibration again. Check cable connection and repair if necessary. Replace sensor. 	18
743 (E743)	Alarm B	Failure (F)	B>Electronic PCB error during initialisation	<ul style="list-style-type: none"> This message normally only appears briefly. Main electronics defect. 	<ul style="list-style-type: none"> Wait a few minutes. Restart the device. Perform reset (Code 62). Replace main electronics. 	14
744 (A744)	Alarm B	Failure (F)	B>Main electronic PCB error	<ul style="list-style-type: none"> Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). Main electronics defect. 	<ul style="list-style-type: none"> Restart the device. Perform reset (Code 62). Block off electromagnetic effects or eliminate source of disturbance. Replace main electronics. 	11
745 (W745)	Warning C	Maintenance request (M)	C>Sensor data unknown	<ul style="list-style-type: none"> Sensor does not suit the device (electronic sensor nameplate). Device continues measuring. 	<ul style="list-style-type: none"> Replace sensor with a suitable sensor. 	56
746 (W746)	Warning C	Funktion check (C)	C>Sensor connection error - initialising	<ul style="list-style-type: none"> Electromagnetic effects are greater than specifications in the technical data. This message normally only appears briefly. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). Overpressure or low pressure present. 	<ul style="list-style-type: none"> Wait a few minutes. Restart the device. Perform reset (Code 7864). Block off electromagnetic effects or eliminate source of disturbance. Reduce or increase pressure. 	26
747 (A747)	Alarm B	Failure (F)	B>Sensor software not compatible to electronics	<ul style="list-style-type: none"> Sensor does not suit the device (electronic sensor nameplate). 	<ul style="list-style-type: none"> Replace sensor with a suitable sensor. 	16
748 (A748)	Alarm B	Failure (F)	B>Memory failure in signal processor	<ul style="list-style-type: none"> Electromagnetic effects are greater than specifications in the technical data. → See Technical Information TI00382P (Deltabar S), TI00383P (Cerabar S) or TI00416P (Deltapilot S). Main electronics defect. 	<ul style="list-style-type: none"> Block off electromagnetic effects or eliminate source of disturbance. Replace main electronics. 	15

8.1.1 On-site display error messages



If the device detects a defect in the on-site display during initialization, the following error messages can be displayed:

Message	Measure
Initialization, VU Electr. Defect A110	Exchange on-site display.
Initialization, VU Electr. Defect A114	
Initialization, VU Electr. Defect A281	
Initialization, VU Checksum Err. A110	
Initialization, VU Checksum Err. A112	
Initialization, VU Checksum Err. A171	

8.2 Response of outputs to errors

The device differentiates between the error types Alarm, Warning and Error.

→ See also Section 8.1 "Messages" und Page 111 ff, Table 20: OUTPUT and Page 111 ff, Table 31: MESSAGES the following table and Page 132, Section 8.1 "Messages".

Output	A (Alarm)	W (Warning)	E (Error: Alarm/Warning)
Current output	Assumes the value specified via the OUTPUT FAIL MODE ¹⁾ , ALT. CURR. OUTPUT ¹ and SET MAX. ALARM ¹ parameter. → See also the following section "Configuring current output for an alarm".	Device continues measuring.	For this error, you can enter whether the device should react as in the event of an alarm or as in the event of a warning. See corresponding "Alarm" or "Warning" column. (→ See also these Operating Instructions, parameter description SELECT ALARM TYPE.)
Bargraph (on-site display)	The bargraph adopts the value defined by the OUTPUT FAIL MODE ¹ parameter.	The bargraph adopts the value which corresponds to the current value.	→ See this table, column "Alarm" or "Warning".
On-site display	<ul style="list-style-type: none"> – The measured value and message are displayed alternately – Measured value display: -symbol is permanently displayed. <p>Message display</p> <ul style="list-style-type: none"> – 3-digit number such as A122 and description 	<ul style="list-style-type: none"> – The measured value and message are displayed alternately – Measured value display: -symbol flashes. <p>Message display:</p> <ul style="list-style-type: none"> – 3-digit number such as W613 and description 	<ul style="list-style-type: none"> – The measured value and message are displayed alternately – Measured value display: see corresponding "Alarm" or "Warning" column <p>Message display:</p> <ul style="list-style-type: none"> – 3-digit number such as E731 and description
Remote operation (Digital communication)	In the case of an alarm, the ALARM STATUS ²⁾ parameter displays a 3-digit number such as 122 for "Sensor not connected".	In the case of a warning, the ALARM STATUS ²⁾ parameter displays a 3-digit number such as 613 for "Simulation is active".	In the case of an error, the ALARM STATUS ²⁾ parameter displays a 3-digit number such as 731 for "URV user limits exceeded".

1) Menu path: (GROUP SELECTION →) OPERATING MENU → OUTPUT

2) Menu path: (GROUP SELECTION →) OPERATING MENU → MESSAGES



8.3 Confirming messages

Depending on the settings for the ALARM DISPL. TIME (→ Page 129) and ACK. ALARM MODE (→ Page 128) parameters, the following measures should be taken to clear a message:

Settings ¹⁾	Measures
– ALARM DISPL. TIME = 0 s – ACK. ALARM MODE = off	– Rectify cause of the message (see also Section 8.1).
– ALARM DISPL. TIME > 0 s – ACK. ALARM MODE = off	– Rectify cause of the message (see also Section 8.1). – Wait for the alarm display time to elapse.
– ALARM DISPL. TIME = 0 s – ACK. ALARM MODE = on	– Rectify cause of the message (see also Section 8.1). – Confirm message using ACK. ALARM parameter.
– ALARM DISPL. TIME > 0 s – ACK. ALARM MODE = on	– Rectify cause of the message (see also Section 8.1). – Confirm message using ACK. ALARM parameter. – Wait for the alarm display time to elapse. If a message appears and the alarm display time elapses before the message has been acknowledged, the message will be cleared once it has been acknowledged.

1) Menu path for ALARM DISPL. TIME and ACK. ALARM MODE: (GROUP SELECTION →) OPERATING MENU → DIAGNOSTICS → MESSAGES

If the on-site display displays a message, you can delete it with the -key.

If there are several messages, the on-site display shows the message which has the highest priority (see also Section 8.1). Once you have deleted this message using the -key, the message with the next highest priority is displayed. You can use the -key to delete each message, one after the other. The ALARM STATUS parameter continues to display all the messages present.


9 Appendix

9.1 Operating menu for on-site display, Digital communication



Note!

- The entire menu is depicted on the following pages.
- The menu has a different structure depending on the measuring mode selected. This means that some function groups are only displayed for one measuring mode, e.g. "LINEARISATION" function group for the Level measuring mode (Menu path: (GROUP SELECTION →) OPERATING MENU → SETTINGS → BASIC SETUP).
- In addition, there are also parameters that are only displayed if other parameters are appropriately configured. For example the Customer Unit P parameter is only displayed if the "User unit" option was selected for the PRESS. ENG. UNIT parameter. These parameters are indicated with a "*".
- For a description of the parameters, please refer to chapter 7 "Description of parameters". The exact dependency of individual parameters on one another is explained here.




1) Display via on-site display only


2) Display via digital communication

3) Cerabar S with gauge pressure sensor, Deltabar S or Deltapilot S

4) Cerabar S with absolute pressure sensor


There are parameters that are only displayed if other parameters are appropriately configured.
For example the CUSTOMER UNIT P parameter is only displayed if the "User unit" option was selected for the PRESS. ENG. UNIT parameter.
These parameters are indicated with a "***".






There are parameters that are only displayed if other parameters are appropriately configured.
For example the CUST. UNIT FACT. H parameter is only displayed if the "User unit" option was selected for the HEIGHT UNIT parameter.
These parameters are indicated with a "*".

P01-xxxxxxx-19-xx-xx-xx-140



There are parameters that are only displayed if other parameters are appropriately configured.
 For example the TOT. 1 USER UNIT parameter is only displayed if the "User unit" option was selected for the TOTALIZER 1 UNIT parameter.
 These parameters are indicated with a "*".



2) Display via digital communication


3) Level measuring mode only

4) Flow measuring mode only

5) only LEVEL SELECTION = Level Easy Pressure


There are parameters that are only displayed if other parameters are appropriately configured.
These parameters are indicated with a "".

** See Safety Manual SD190P for Cerabar S, SD189P for Deltabar S or SD213P for Deltapilot S.



2) Display via digital communication

* There are parameters that are only displayed if other parameters are appropriately configured.
These parameters are indicated with a "".



* There are parameters that are only displayed if other parameters are appropriately configured.
These parameters are indicated with a "*".

Index

Numerics

100% POINT (813), "Height linearized" level type	89
100% POINT (813), "Linear" level type	77
4TH VALUE	116
4TH VALUE IS	116

A

ACK. ALARM (500)	129
ACK. ALARM MODE (401)	128
ACK. ALARM MODE (844), "Safety confirm." group	9
ACTIV LIN. TAB. X.	107
ACTIV LIN. TAB. Y.	107
ADDITIONAL INFO. (272)	117
ADJUST DENSITY (007), "Level Easy Height" level selection	64
ADJUST DENSITY (007)/(316), "Level" extended setup	97
ADJUST DENSITY (316), "Height linearized" level type	88
ADJUST DENSITY (316), "Linear" level type	74
ADJUSTED DENSITY (810), "Height linearized" level type	87
ADJUSTED DENSITY (810), "Linear" level type	74
ALARM DELAY (336)	129
ALARM DISPL. TIME (480)	129
ALARM STATUS (046)	128
ALLOWED MAX. TEMP (359)	117
ALLOWED MIN. TEMP (358)	117
ALT. CURR. OUTPUT (597)	113
ALTERNATE DATA (423)	110
ASSIGN CURRENT (760)	113

B

BOLTS MATERIAL	118
BURST MODE	115
BURST OPTION	115
BUS ADDRESS (345)	115

C

CALIB. OFFSET (319)	54
CALIB. OFFSET (847), "Safety confirm." group	9
CALIBRATION MODE (008), "Level Easy Height" level selection	64
CALIBRATION MODE (008), "Level Easy Pressure" level selection	60
CALIBRATION MODE (392), "Height linearized" level type	87
CALIBRATION MODE (392), "Linear" level type	73
COMB. MEASURAND (806)	83
CONF. PASSWORD (856)	9
CONFIG RECORDER (352)	117
CORRECTED PRESS. (434), "Flow" measuring mode	123
CORRECTED PRESS. (434), "Level" measuring mode	122
CORRECTED PRESS. (434), "Pressure" measuring mode	122
COUNTER P > Pmax (380)	124
COUNTER P Pmin (467)	124
COUNTER T > Tmax (404)	124
COUNTER T Tmin (472)	124
CURR. CHARACTER. (694), (695), (696), (764)	112
CURR. TRIM 20mA (042)	131
CURR. TRIM 4mA (045)	131

CURRENT MODE (052)	115
CURRENT OUTPUT (875)	9
CUST. TAG NUMBER (055)	117
CUST. UNIT FACT. F (609)	95
CUST. UNIT FACT. H (705), "Height linearized" level type	84, 89
CUST. UNIT FACT. H (705), "Linear" level type	71, 76
CUST. UNIT FACT. M (703), "Height linearized" level type	86
CUST. UNIT FACT. M (703), "Linear" level type	73
CUST. UNIT FACT. M (703), "Pressure linearized" level type	80
CUST. UNIT FACT. P (317)	56, 59, 63, 68, 93
CUST. UNIT FACT. V (607), "Height linearized" level type	85
CUST. UNIT FACT. V (607), "Linear" level type	72, 75
CUST. UNIT FACT. V (607), "Pressure linearized" level type	79
CUSTOMER UNIT F (610)	94
CUSTOMER UNIT H (706), "Height linearized" level type	84, 89
CUSTOMER UNIT H (706), "Linear" level type	70, 76
CUSTOMER UNIT M (704), "Height linearized" level type	86
CUSTOMER UNIT M (704), "Linear" level type	72
CUSTOMER UNIT M (704), "Pressure linearized" level type	80
CUSTOMER UNIT P (075)	56, 59, 63, 68, 92
CUSTOMER UNIT V (608), "Height linearized" level type	85
CUSTOMER UNIT V (608), "Linear" level type	71, 75
CUSTOMER UNIT V (608), "Pressure linearized" level type	79

D

DAMPING VALUE (247)	48, 51, 53, 57, 61, 66, 77, 81, 90, 95
DAMPING VALUE (855), "Safety confirm." group	9
DENSITY UNIT (001), "Level Easy Height" level selection	64
DENSITY UNIT (001)/(812), "Level" extended setup	97
DENSITY UNIT (812), "Height linearized" level type	88
DENSITY UNIT (812), "Linear" level type	74
DEVICE DESIGN. (350)	117
DEVICE REVISION (699)	115
DEVICE SERIAL No (354)	117
DEVICE TYPE (002), Deltapilot S	115
DEVICE TYPE (351), Deltabar S	115
DEVICE TYPE (802), Cerabar S	115
DIAPHRAG. MAT. -	119
DIAPHRAG. MAT. +	119
DIGIT SETS (841)	9
DIGITS SETS (840)	111
DIP STATUS (363)	117
DISPLAY CONTRAST (339)	111
DOWNLOAD SELECT (014)	126
DRAIN VENT MAT.	119
DRAIN VENT POS.	119

E

EDITOR TABLE (770), on-site operation	103
EDITOR TABLE (809), on-site operation	102
EDITOR TABLE, digital communication	105–106
ELECTR. SERIAL No (386)	117

EMPTY CALIB. (010), "Level Easy Height" level selection .	65
EMPTY CALIB. (010), "Level Easy Pressure" level selection .	60–61
EMPTY CALIB. (314), "Height linearized" level type	87
EMPTY CALIB. (314), "Linear" level type	73
EMPTY CALIB. (314)/(010), QUICK SETUP	50
EMPTY HEIGHT. (009), "Level Easy Height" level selection	65
EMPTY PRESSURE (011), "Level Easy Pressure" level selection	61
EMPTY PRESSURE (710), "Height linearized" level type. . .	87
EMPTY PRESSURE (710), "Linear" level type.	74
ENTER RESET CODE (047)	126
ERROR No.	129

F

FACT. U. U. TOTAL. 1 (329)	108
FACT. U. U. TOTAL. 2 (330)	109
FILL FLUID	119
FILLING FLUID (366)	120
FLOW-MEAS. TYPE (640)	93
FULL CALIB. (004), "Level Easy Height" level selection . .	65
FULL CALIB. (004), "Level Easy Pressure" level selection.	60–61
FULL CALIB. (315), "Height linearized" level type	87
FULL CALIB. (315), "Linear" level type	74
FULL CALIB. (315)/(004), QUICK SETUP	51
FULL HEIGHT (006), "Level Easy Height" level selection . .	66
FULL PRESSURE (005), "Level Easy Pressure" level selection .	61
FULL PRESSURE (711), "Height linearized" level type . . .	87
FULL PRESSURE (711), "Linear" level type	74

G

GET LRV (309), "Pressure" measuring mode	57
GET URV (310), "Pressure" measuring mode	57

H

HARDWARE REV. (266)	117
HART DATE (481)	116
HART MESSAGE (271)	116
HART VERSION (585)	114
HEIGHT UNIT (011), "Level Easy Height" level selection. .	64
HEIGHT UNIT (708), "Height linearized" level type. . .	83, 88
HEIGHT UNIT (708), "Linear" level type	70, 76
HistoROM AVAIL. (831)	126
HistoROM CONTROL (832)	127
HYDR. PRESS MAX. (761)	81
HYDR. PRESS MIN. (775)	80

I

INSERT PIN NO (048)	126
-------------------------------	-----

L

LANGUAGE (079)	44
LANGUAGE, display group	110
LAST DIAG. CODE (564)	128
LEVEL BEFORE LIN (050)	123
LEVEL MAX (712)	86
LEVEL MIN (755)	86
LEVEL MODE (718)	68

LEVEL SELECTION (020)	46, 49
LIN. EDIT MODE (397), on-site operation	101
LIN. EDIT MODE, digital communication	105
LIN. MEASURAND (804)	70
LINd. MEASURAND (805)	79
LINEAR/SQROOT (390)	113
LINEAR/SQROOT (854), "Safety confirm." group	9
LINE-NUMB (549), on-site operation	102
LINE-NUMB, digital communication	106
LONG TAG NUMBER (305)	117
LOW FLOW CUT-OFF (442)	99
LOW FLOW CUT-OFF (850), "Safety confirm." group	9

M

MAIN DATA FORMAT (688)	110
MANUFACTOR ID (432)	116
MASS FLOW UNIT (571)	94
MASS UNIT (709), "Height linearized" level type	85
MASS UNIT (709), "Linear" level type.	72
MASS UNIT (709), "Pressure linearized" level type	80
MAT. MEMBRANE (365)	120
MAT. PROC. CONN. – (361)	118
MAT. PROC. CONN. + (360)	118
MAX PRESS. FLOW (634)	53, 95
MAX PRESS. FLOW (849), "Safety confirm." group	9
MAX. FLOW (311)	52, 95
MAX. FLOW (848), "Safety confirm." group	9
MAX. MEAS. PRESS. (383)	124
MAX. MEAS. TEMP. (471)	124
MEAS. VAL. TREND (378)	122–123
MEASURED VALUE, "Flow" measuring mode	123
MEASURED VALUE, "Level" measuring mode	122
MEASURED VALUE, "Pressure" measuring mode	121
MEASURING MODE (389), on-site display	45
MEASURING MODE (845), "Safety confirm" group	9
MEASURING MODE, digital communication	47, 49, 52, 55, 67, 92
MEASURING TABLE (549)	103
MEASURING TABLE (717)	103
MENU DESCRIPTOR (419)	110
MIN. MEAS. PRESS. (469)	124
MIN. MEAS. TEMP. (474)	124
MINIMUM SPAN (591)	119
MOUNTING THREAD	119

N

NEG. FLOW TOT. 1 (400)	108
NEG. FLOW TOT. 2 (416)	109
NORM FLOW UNIT (661)	93
NR OF REMOTE SE	119
NUTS MATERIAL	119

O

OFFSET 20mA TRIM (044)	131
OFFSET 4mA TRIM (043)	131
OPERATING HOURS (409)	126
OUTPUT CURRENT (254)	111
OUTPUT FAIL MODE (388)	112
OUTPUT UNIT (023), "Level Easy Height" level selection .	64
OUTPUT UNIT (023), "Level Easy Pressure" level selection	60

P

PASSWORD (836).....	9
PCB COUNT	
T Tmin (492).....	124
PCB COUNT T.....	124
PCB COUNT T > Tmax (488).....	124
PCB MAX. TEMP. (490).....	124
PCB MIN. TEMP. (494).....	124
PCB TEMPERATURE (357).....	117
Pmax ALARM WINDOW (333).....	130
Pmax PROC. CONN. (570).....	117
Pmax SENS. DAMAGE (252).....	120
Pmin ALARM WINDOW (332).....	130
Pmin SENS. DAMAGE (251).....	120
POS. INPUT VALUE (563).....	48, 50, 54
POS. ZERO ADJUST (685).....	48, 50, 52, 54
PREAMBLE NUMBER (036).....	115
PRESS. ENG. UNIT (060).....	56, 59, 63, 67, 92
PRESS. SENS. HILIM (485).....	119
PRESS. SENS. LOLIM (484).....	119
PRESSURE (301), "Flow" measuring mode.....	123
PRESSURE (301), "Level" measuring mode.....	122
PRESSURE, "Pressure" measuring mode.....	122
PRIMARY VALUE.....	116
PRIMARY VALUE IS.....	116
PROC. CONN. TYPE (482).....	118
PROCESS DENSITY (025)/(811).....	97

Q

Quick Setup "Flow" menu.....	52
Quick Setup "Level" menu.....	49
Quick Setup "Pressure" menu.....	47

R

REMOTE SEAL -.....	119
REMOTE SEAL +.....	119
RESET ALL ALARMS (603).....	129
RESET PEAKHOLD (382).....	125
RESET TOTALIZER1 (331).....	109

S

SAFETY LOCK (836).....	9
SAFETY LOCKSTATE (836).....	9
SEAL TYPE (362).....	118
SECONDARY VAL. IS.....	116
SECONDARY VALUE.....	116
SELECT ALARMTYPE (595), (600).....	129
SENS H/WARE REV (487).....	120
SENSOR MEAS. TYPE (581).....	120
SENSOR PRESSURE (584), "Pressure" measuring mode..	122
SENSOR PRESSURE (584), "Safety confirm." group.....	123
SENSOR SER. No. (250).....	119
SENSOR TEMP. (367).....	122–123
SET LRV (013), "Level Easy Height" level selection.....	66
SET LRV (013), "Level Easy Pressure" level selection.....	61
SET LRV (245), "Pressure" measuring mode.....	48, 56
SET LRV (637), "Flow" extended setup.....	99
SET LRV (719), "Level" basic setup.....	77
SET LRV (762), "Level" extended setup.....	98

SET LRV (852), "Safety confirm." group.....	9
SET MAX. ALARM (342).....	113
SET MIN. CURRENT (343).....	113
SET URV (012), "Level Easy Height" level selection.....	66
SET URV (012), "Level Easy Pressure" level selection.....	61
SET URV (246), "Pressure" measuring mode.....	48, 57
SET URV (638), "Flow" extended setup.....	100
SET URV (720), "Level" basic setup.....	77
SET URV (763), "Level" extended setup.....	98
SET URV (853), "Safety confirm." group.....	9
SET. L. FL. CUT-OFF (323).....	99
SET. L. FL. CUT-OFF (851), "Safety confirm." group.....	9
SIM. CURRENT (270).....	128
SIM. ERROR NO. (476).....	128
SIM. LEVEL (714).....	128
SIM. PRESSURE (414).....	127
SIM. TANK CONT. (715).....	128
SIM.FLOW VALUE (639).....	127
SIMULATION MODE (413).....	127
SOFTWARE VERSION (264).....	117
STD. FLOW UNIT (660).....	94
SUPPRESSED FLOW (375).....	123

T

TABLE SELECTION (808), on-site operation.....	101
TABLE SELECTION, digital communication.....	105
TANK CONTENT (370).....	123
TANK CONTENT MAX (713).....	101, 105
TANK CONTENT MIN (759).....	101, 104
TANK DESCRIPTION (815).....	103, 107
TANK HEIGHT (859).....	76
TANK VOLUME (858).....	75
TEMP. ENG. UNIT (318), "Flow" measuring mode.....	99
TEMP. ENG. UNIT (318), "Level" measuring mode.....	97
TEMP. ENG. UNIT (318), "Pressure" measuring mode.....	96
THIRD VALUE.....	116
THIRD VALUE IS.....	116
THREAD.....	119
Tmax ALARM WINDOW (335).....	130
Tmax SENSOR (369).....	120
Tmin ALARM WINDOW (334).....	130
Tmin SENSOR (368).....	120
TOT. 1 USER UNIT (627).....	108
TOT. 2 USER UNIT (628).....	109
TOTAL. 1 OVERFLOW (655).....	124
TOTAL. 2 OVERFLOW (658).....	124
TOTALIZER 1 (652).....	124
TOTALIZER 1 UNIT (398), (662), (664), (666).....	108
TOTALIZER 2 (657).....	124
TOTALIZER 2 UNIT (399), (663), (665), (667).....	109

U

UNIT FLOW (391).....	93
UNIT VOLUME (313), "Height linearized" level type.....	84
UNIT VOLUME (313), "Linear" level type.....	71, 75
UNIT VOLUME (313), "Pressure linearized" level type.....	79

X

X-VAL. (550), on-site operation.....	102
X-VAL., digital communication.....	106

Y

Y-VAL. (551), on-site operation 102

Y-VAL., digital communication 106

Z

ZERO POSITION (814), "Height linearized" level type 90

ZERO POSITION (814), "Linear" level type 77

www.endress.com/worldwide

Endress+Hauser 
People for Process Automation





MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL
AMARUQ WTP – NUNAVUT
VEOLIA PROJECT: 5000 218 009

ENVIREQUIP
SERIES EVG/EVGX, MIXERS

LEFT BLANK

ENVIREQUIP (Division 6445772 Canada Inc)

MIX-TECH DYNAMIC MIXERS

490, Bord du Lac - Suite 2

Dorval, Quebec, Canada

H9S 2A8

mobile: 514.386.1043

710 Cotton Mill Road

tel: 613.703.7930

Cornwall, Ontario, Canada

K6H 7L3

Cell: 514.349.3116

e-mail: envirequip@cogeco.ca

internet: <http://www.envirequip.com>

INSTRUCTION & OPERATING MANUAL

ENVIREQUIP - MIX-TECH MIXERS

SEE SECTION FOR AGITATOR / GEAR REDUCER DESIGN: (at end of Manual)

EVG	(Parallel Shafts with Hollow Output Shafts & Tapered Roller Bearings)
EVGX	(Parallel Shafts with Hollow Output Shafts & High Capacity Upper Cylindrical & Lower (2) - Row Spherical Roller Bearings)
EHG	(Worm drives for Small Top Entry & Portable Mixers with Hollow Output Shafts)
EHGB	Helical / Bevel gearing with Hollow Output Shafts & Tapered Roller Bearings)
EVGFS	Helical in-line gears with Solid Output Shaft Tapered Roller or Spherical Roller Bearings - Refer to Nord Installation & Operation Manual

NOTE: For Units with Solid Output Shafts, Refer to the Nord Manual

Env-IOM.EngJuly.2015.wpd

ENVIREQUIP / MIX-TECH MIXERS - INDEX I.O.M.

- For mixer(s) installed in OPEN TANKS -
 - See Section for Mechanical seals & Packing (Stuffing boxes) at end of I.O.M. PAGE (S)
-

PAGE / DRAWING	MIX-TECH MIXER (SECTION)	Rev 0
SECTION 1	INSPECTION	1
SECTION 2	INSTALLATION	1, 2, 3 & 4
SECTION 3	MIXER ASSEMBLY	4
SECTION 4	MOTORS	5 & 6
SECTION 5	PEDESTALS: <u>SHAFT & GEAR REDUCER REMOVAL</u>	6 & 7
SECTION 6	SHAFTS, IMPELLERS & COUPLINGS Note: <u>Shaft & Gear Reducer Removal - Section/Page 7</u>	7, 8 & 9
SECTION 7	GEAR DRIVE MAINTENANCE	9, 10 & 11
SECTION 8	BOLTS	11 & 12
SECTION 9	OPERATION	12
SECTION 10	MOTOR REMOVAL & INSTALLATION	13
SECTION 11	TROUBLE-SHOOTING / MIXER PERFORMANCE	13 & 14
SECTION 12	WARRANTY	15
PAGE	USEFUL CONVERSIONS	16
PAGE	MAINTENANCE LOG	19
PAGES	IMPELLER BLADE INSTALLATION	A, B C & D
NORD	BIM 1020 I.O.M. PARALLEL SHAFT REDUCERS	(pdf)
NORD	DM 006 DIS-ASSEMBLY MANUAL SK6282 to SK11282 for <u>DOUBLE</u> reduction)	(pdf)
NORD	DM 007 as above but for <u>TRIPPLE</u> reduction drives.	(pdf)
PARTS LIST(S)	(to suit)	(Pdf)

MIX-TECH DYNAMIC MIXERS

490 Bord du Lac - Suite 2,
Dorval, QC, Canada H9S 2A8
RR1, (21494 Little Russia Rd),
Glen Robertson, ON, Canada K0B 1H0

toll free: 1.866.819.6123

mobile: 514.386.1043

tel: 613.874.2616

fax: 613.874.2629

e-mail: envireqp@glen-net.ca

internet: <http://www.envirequip.com>

INSTALLATION & OPERATION MANUAL

MIX-TECH MIXERS

Page 1

SECTION 1 - INSPECTION

- Make sure that all mixer parts have been removed from the crate(s) before discarding.
 - Each mixer should be carefully checked for any possible shipping damage. Any shipping damage should be reported to the TRANSPORT COMPANY immediately.
 - Check the paint and make any necessary touch-ups.
-

SECTION 2 - INSTALLATION

- Most mixer problems can be avoided by following proper installation and operation instructions. The following is a list of hints to help insure proper installation and therefore satisfactory mixer service.
- Please read all appropriate instruction manuals prior to proceeding with the installation of the mixers.

CAUTION

- Lock-out the motor starter if any person is in the tank.
- Remove wick from the breather vent plug.
- DO NOT Paint breather / vent plug

MOST COMMON PROBLEMS: Mixer Shaft(s) not vertical; Impeller going through liquid level

- Make sure the impeller blades have been installed onto the hubs in the proper position with regards Rotation and Direction of flow. Please also note that the impellers blades are installed with the hubs ears always backing the blade into the flow. Also be sure that the leading edge and not the trailing edge is presented into the flow and that the angle at the impeller tip (angle of attack) from the horizontal is closer to 15° rather than to 75°.

CAUTION

- If the angle of attack (at the impeller tip is closer to 75°, either an incorrect hub in combination with the correct impeller blade (OR VICE VERSA) has been incorrectly assembled to make an incorrect matching of possible hub and blade combinations. For help in determining what the correct combination should be, Please refer to the mixer nameplate that will have the Rotation and direction of thrust written. Once you know the combination, refer to the pictorial guide of impeller / hub installation positions A, B, C or D.
- Depending on whether the concave or the convex surface is facing the fluid, if the angle of attach at the impeller is closer to 75°, the HP drawn will be 2 to 3 times greater than what it should be. This could result in overloading the motor and damaging the mixer.
- Make sure that the impeller blades are installed in the correct position for the required rotation. e.g. if the impeller blades are installed up-side-down, the pumping capacity will be reduced by about 65%. Check the mixer nameplate for the flow direction and install the impeller blades to suit.

CAUTION

POTENTIALLY DAMAGING SITUATIONS FOR MIXERS

- Prolonged operation of the mixer (impeller) at the liquid interface causes increased stress on the shaft & impeller for which the system was not designed to accommodate. Damage could result.
- Installations where there is a large hydraulic flow (or Velocity) in the mixer reservoir. : Make sure that if should such a flow is present, that the flow is baffled or dispersed over a larger area (as opposed to directed flow via a pipe), or that the flow be re-directed away form the impeller/shaft assembly, or is introduced evenly e.g via a weir. If this cannot be done, this external hydraulic flow will exert additional un-designed for stress loads and deflection on the mixer shaft and impeller which could result in component failure.

CAUTION

- Before permanently wiring the motor, check for the correct rotation of the low speed shaft. Normal is Clock-wise looking down from the top of the tank, although the reverse may also be required. Please check mixer nameplate for other instructions. (e.g. Letters A, B, C or D)

- Read and follow the instructions of all tags and nameplates before operating.
- Check the mixer full load motor amperage and voltage before operating any mixer.
- It is recommended that the mixer impeller be rotated by hand in order to check for smooth operation. **N.B:** For crown & worm drives, remove the fan cover and rotate the fan manually.
- Always operate the mixer in a fluid which had a specific gravity and viscosity less than or equal to the design specific gravity and viscosity.
- Do not dump the contents of large bags of chemicals directly onto the rotating mixer impeller(s); but add the contents into the reservoir gradually. This will also promote better mixing.
- Before starting the mixer, make sure the impeller is not buried in solids or a "set-up" fluid
Note: If solids have settled-out, then dilute or jog the mixer clockwise then counterclockwise
- Please check that there is no directed flow from an external source at the impeller or shaft unless the mixer was specifically designed to accommodate these additional stress loads, as mixers could be damaged.
- During START-UP, please listen for unusual noises and check for excessive vibration.
- Check the temperature of the motor and gear reducer. The temperature should not exceed 180° F. (82°C) If they are too hot, please stop the operation of the mixer and contact MIX-TECH immediately.
- Measure the motor amperage. The measured amperage must be less than the nameplate rating nameplate value. If the amps are over, please check the rotational speed of the gear reducer/mixer output shaft. Place a piece of tape onto the shaft (or use an RPM counter if available, and count the number of revolutions for a period of e.g. 10 seconds using your watch second hand. Multiply the result by (6) for 60 Hz operation and this will provide you with the rotational speed of the mixer. Check Rotation, & impeller blade installation to be sure they are correct. If the power draw remains high, please check with MIX-TECH

Note: - Record the full load motor amperage (FLA) and measure them every (3) months.
- Some motor amperage readings are poor indicators at low loads

CAUTION:

- **DO NOT STAY IN THE TANK DURING MIXER ROTATION**
- Never use the mixer impeller as a foot stand or support for body weight - as such actions could damage the mixer as well as result in serious bodily injury.

- As with any rotating equipment, in order to avoid injury, extreme care should be taken to avoid contacting the rotating parts including not connecting the motors to the electrical power source until the mixer is completely assembled. Then, vacate the tank prior to operating the mixer.
 - Before making field changes of motor horsepower, mixer speed, shaft length, impeller diameter or width, etc. be sure to consult with ENVIREQUIP, MIX TECH DIVISION.
 - After any plant electrical work has been done, check that the mixer(s) rotation(s) are correct as power lines may have been reversed.
-

SECTION 3 - MIXER ASSEMBLY: - Closed tanks are Flange Mounted

- Open tank models usually are mounted on a steel structure. Level the drive as closely as possible. This assures that the shaft will turn in a true vertical position. Incorrect mounting is often a cause of mechanical difficulty with a mixer. Unless specified on the mixer assembly drawing, the mixer extension shaft is designed to run in a true vertical position. Never angle or side mount the mixers.
- While operating, there is random fluid motion in the vessel that exerts great forces on the extension shaft of the mixer. The mixer accommodates these forces since they are transmitted directly to the support mounting(s). Therefore, the mounting system must be rigid. It must support the static mixer weight as well as live mixer reactions that result from Torque and Bending Moment. It is not enough to design the support system for acceptable levels of stress. It must be rigid enough to take care of Start-up torque load (2.5 times the Torque), and preclude large deflections that may result in mixer vibration.
- When designing the support structure to accommodate bending moments, be sure that the structure is sufficiently rigid so that the mixer extension shaft will not move more than 1/32" per (10) feet (0.8 m per 3.05 meters) of shaft length due to deflection of the support structure.
- After the gear drive (with the motor already flange mounted onto the drive) has been properly installed, the mixer extension shaft should be installed into the gear drive's hollow output shaft (quill shaft) and fastened in the quill shaft with the thrust plate and secured in position with the threaded bolt provided - use Locktite Blue (or equivalent), or in the case of an output shaft coupling, bolt the mating flanges together.
- Mixer blades over 20" in diameter are generally bolted to a welded hub. Check the welds on the hub on your yearly overall inspection.

- These mixers are supplied with the finest electric motors available. They are manufactured by a nationally known manufacturer, (e.g. NORD, WEG, Brook etc). Under normal operating conditions, within specified temperatures, proper installation and maintenance, these motors are guaranteed to deliver rated output.
- In order to get top performance from any electric motor, be sure that there is plenty of air circulation and a minimum of obstructions. On fan cooled motors, be sure not to choke off the suction inlets, also be sure to check the allowable temperature that's indicated on the motor nameplate. Don't decrease the service life of a motor by operating it at excessively high ambient temperature.
- In order to avoid damage to the motor during temporary overloads, jams, etc. be sure that correctly sized overload protection is provided. Starter overload heater elements can be sized from the full load current of the motor as shown on the motor nameplate. It is advisable to consult a supplier of motor control equipment when selecting thermal overload heaters.
- Before the motor is permanently wired, check to be sure that the output shaft rotation is correct (Normally clockwise looking down from the mixer drive, but sometimes counterclockwise depending on the process requirements)

CAUTION:

- Make sure to check rotation of the mixer before it is operated. To reverse the rotation of standard 3 phase electric motors, simply switch any two power leads.

MOTOR SPECIFICATIONS: 1800 RPM - (4) pole

- NORD motors carry the CE mark in accordance with the Low Voltage Directive
- NORD motors are designed to operate at elevations up to 1000 m (3300 ft) above sea level

<u>Altitude:</u> up to 1000 m	= 100% output	Ambient Temp = 40° C
Above 1000 up to 2000 m	= 92% output	Ambient Temp.= 32° C
Above 2000 up to 3000 m	= 83% output	Ambient Temp = 24° C
Above 3000 up to 4000 m	= 74% output	Ambient Temp = 16° C
- NORD motors are designed to operate with a maximum ambient temperature of 40° C (104°F) - for higher temperatures, motors have to be de-rated or an upgraded insulation used.

<u>Ambient Temperature:</u>	(104°F) 40° C = 100%
	45° C = 95%
	50° C = 89%
	55° C = 83%
	60° C = 67%
	70° C = 64%

EXAMPLE: A motor designed for an output of 100 HP to operate in the mining area of Bolivia (altitude 4000 m above sea level). **NOTE:** 1000 meters = 3281 Feet
Output reduction: the maximum allowable output of the motor would be 74% (74 HP)

Ambient temperature limit: the motor may operate at its rated output of 100 HP provided that the ambient temperature does not exceed 16° C

Note: You can operate over 3300 feet, but you have to de-rate the motor

- Voltages: Canada 575/3/60, TEFC; USA 460/3/60, TEFC; Europe 400/3/50, IP55 ; Australia 415/3/50
 - **Tolerances Voltage & Frequency:** $\pm 10\%$ based on rated voltage; Line frequency tolerance $\pm 5\%$. Combined **MAXIMUM** variation in voltage and frequency $\pm 10\%$
 - MG1 Part 31 suitable for inverter service
 - Insulation Class is Class F (non organic)
 - High-efficiency design for motors 1 HP and up
 - Service Factor 1.15
 - The Standard Nord motor fan is a non-sparking
 - Each Nord motor uses a terminal block
 - Integral Nord motor (unless Nema motor with “C” flange)
-

SECTION 5 - Pedestals: Shaft & Gearbox Removal - EVG SERIES

- Series EVG standard design of the dry-well pedestal and shaft catcher is one where the flinger (for the dry well) and the shaft catcher are one-in-the-same part serving both purposes.

SHAFT REMOVAL AND /OR TO REMOVE THE GEAR REDUCER:- See assembly dwg

- i) Lock-out electrical power to the electric motor.
- ii) If the electrical wiring is not long enough to allow removal of the gear reducer, dis-connect the motor wiring.
- iii) Remove the safety cover located on top of the gear reducer exposing the bolt (# 3) and top plate (# 4) which holds the shaft (# 12).
- iv) Slowly remove the top bolt.(# 3).
- v) As the bolt is loosened, the shaft and impeller assembly will be lowered a distance of about 0.125" (3.175 mm).
- vi) After the bolt has been loosened sufficiently, the flinger (# 8) will come into contact with the Pedestal to the inner support pipe (# 11) and stop there.
- vii) Remove the bolts holding together the Adaptor plate Reducer to Pedestal top plate (# 7).
- viii) Lift-off the complete gear reducer unit the gearbox clears the shaft.
- ix) Inside of the Pedestal (# 10), you can now see the flinger (#8) which rests on the Collar / Clamp (2) Bolts / Shaft catcher (# 9).
- x) Prior to un-doing the set screws on the collar / Clamp, make preparation to handle the shaft which will now fall through the dry well (# 11) and into the tank.
- xi) Once the shaft is secured loosen the set screws on the Flinger assembly or Clamp bolts (# 9).
- xii) **To Reinstall the shaft** (et al) follow the above procedure in Reverse.

Note: In older designs, the flinger was welded-onto the shaft. In that case, the shaft can only be removed vertically through the top of the Pedestal.

SECTION 5 - Pedestals: Shaft & Gearbox Removal Page 7

CAUTION:

- Prior to loosening the (3) set screws on the flinger/shaft-catcher, please ensure that there is some means of holding the shaft in-place (if no Clamp supplied, use (2) pieces of wood 4" x 4" or 6" x 6" with tightening bolts to hold the shaft in place via friction) IF NOT, THE SHAFT WILL DROP INTO THE TANK possible causing damage to the equipment or vessel and bodily injury. Shafts are often of sufficient weight to cause serious bodily injury or even death were it not properly secured.
- You may want to install a plastic hose in the pedestal so that you can monitor if the gear reducer is losing oil and collecting in the dry-well pedestal.

A Split Collar is used to prevent the shaft from accidentally falling from the gear reducer:

NOTE: On older Series EVG, there may not be a Split Ring but rather a flinger that rests on the dry well seal to hold the shaft in-place

- (i) Insert eye-bolt in top centre of the impeller shaft.
- (ii) Slowly lift up the complete impeller shaft assembly a distance of 6 mm (0.25").
- (iii) Remove the split collar that rests against the top of the quill shaft of the gearbox.
- (iv) Slowly lower the complete shaft/impeller assembly a distance of 10 to 12 mm (0.375" to 0.50").
- (v) At this point, the flinger/clamp ass'y will come into contact with the pedestal top inner support pipe/Dry-well
- (vi) Remove bolts.
- (vii) Lift off the complete gear reducer until the gearbox clears the shaft and eye-bolt.
- (viii) The reinstall the gear drive, follow the above procedure in reverse

SECTION 5 - SHAFTS, IMPELLERS & FLANGED COUPLINGS

SHAFT - STRAIGHTNESS:

- When shipped, the mixer extension shaft was straight to within 0.003" per foot (0.25 mm per meter) of shaft length for mixers equipped with centre-less ground shafts (Special Order/ uncommonly used). If the shaft does not appear to be damaged, but the run-out is greater than the above standard, the shafting supplied may have been "smooth-turn" (more commonly used), which might not be dimensionally the same over the entire length of the shaft. This is probably still acceptable. In such cases, or where it might be difficult to obtain an accurate shaft run-out value, we may apply another rule: 0.25 to 0.50% of the impeller diameter = the maximum shaft run-out at the bottom of the shaft. e.g:
- | | |
|------------------------|---------------|
| 50" diameter impeller | 0.14 to 0.28" |
| 100" diameter impeller | 0.26 to 0.53" |
| 150" diameter impeller | 0.40 to 0.67" |

SECTION 5 - SHAFTS, IMPELLERS & FLANGED COUPLINGS

- Flanges are used as shaft couplings when shaft extensions exceed approx 12'-0" (3.65 m)
Ensure that the bolts are tightened and that a product like Never Seize (or equivalent) is used.
Refer to the table (in this manual) for torque tightening values

Recheck bolt tightness after 1500 hours (or (3 months)

These couplings are welded onto the shafts with (4 to 6) gussets and are not removable.

CAUTION:

- Handle the shaft carefully to be sure that it is not bent.
- After the shaft has been installed, check it for straightness. Storage and handling may have resulted in a bend. To check it, an indicator is placed at the end of the shaft, and the high speed shaft is then rotated by hand. Runout of the total shaft should not be greater than the above \references values. If the runout is greater than the above values, the shaft can be re-straightened in the field. To re-straighten the shaft, follow this procedure:
- Where the maximum, positive readout is found, place the indicator on that side of the shaft.
- Heat the shaft at a point of 180° from the indicator, (and just below the first in-tank coupling if applicable), apply heat just below the mounting nozzle.
- The shaft will grow toward the indicator as heat is applied to it. However, DO NOT permit the surface temperature to go over 500° F (260° C). Use Tempilstics or equivalent
- The shaft will straighten since it will draw more than it grows.
- After each heating process, rotate the shaft and recheck until the straightness is within tolerance to meet the allowable tolerance
- To install any impeller, simply slide the impeller hub onto the extension shaft above the shaft keyway. Install Hook type (Gib) key into the keyway making sure that the pin is inserted into the correct hole for proper impeller location. Lower the hub (with or without blades bolted-on) down onto the key. Tighten set screw. Bolt -on blades if not already done.

NOTE: All MIX-TECH Portable mixers operate at least 35% below the 1st Critical speed or harmonic frequency - There is no danger of “hitting-on” or approaching the 1st Critical speed - (Unless specifically mentioned otherwise)

- Please refer to the specific manufacturer's installation and operating manual.
- Correct lubrication practices are essential to long life and satisfactory performance of a gear drive. Be sure to use the right lubricants as recommended. With proper lubrication

maintenance, the gear drive will carry its rated design load and provide years of satisfactory operation.

SECTION 6 - SHAFTS, IMPELLERS & COUPLINGS Page 9

IMPELLERS

- Make sure that the impeller blades have been installed onto the hubs in the proper position with regard Rotation and Direction of flow. Please also note that the impellers blades are installed with the hubs ears always backing the blade into the flow. Also be sure that the leading edge and not the trailing edge is presented into the flow and that the angle at the impeller tip (angle of attack) from the horizontal is closer to 15° rather than to 75°.

CAUTION

- If the angle of attack (at the impeller tip is closer to 75°, either an incorrect hub in combination with the correct impeller blade (OR VICE VERSA) has been incorrectly assembled to make an incorrect matching of possible hub and blade combinations. For help in determining what the correct combination should be, please refer to the mixer nameplate that will have the Rotation and direction of thrust written. Once you know the combination, refer to the pictorial guide of impeller / hub installation positions A, B, C or D.
- Depending on whether the concave or the convex surface is facing the fluid, if the angle of attach at the impeller is closer to 75°, the HP drawn will be 2 to 3 times greater than what it should be. This could result in overloading the motor and damaging the mixer.
- Make sure that the impeller blades are installed in the correct position for the required rotation. e.g. if the impeller blades are installed up-side-down, the pumping capacity will be reduced by about 65%. Check the mixer nameplate for the flow direction and install the blades to suit.

SECTION 7 - GEAR DRIVE MAINTENANCE

CAUTION:

- By following instructions, many premature gear and bearing failures can be avoided.
- Keeping a maintenance log is highly recommended.
- Lubricant used in the gear case must be free of dirt, metal particles and other contaminants. Use only new oil. Strain the oil if there is any possibility that it contains contaminants.
- To equalize pressure inside and outside the gear case, a breather vrnt is installed on top of the unit. This breather normally requires no maintenance, and must not be blocked. Check hole for free breathing.

PORTABLE MIXERS:

Lubrication For PORTABLE MIXERS (Series “EHG”), the Crown & worm gear reducers are filled for life (20,000 hours or (4) years) with synthetic oil

CAUTION:

- For shipment, the gear-case is drained of oil (EXCEPT FOR NORD drives) - Be sure to fill the gear case with the proper lubricant to the proper level. Install breather. DO NOT OVERFILL - N.B: if the reducer is already filled, (as is the case with NORD drives), Do not forget to install the breather(s) or the seals may fail.
 - **RECOMMENDED LUBRICANTS FOR NORD HELICAL GEARING:**
These Nord Gear reducers are factory-filled with Shell Omala 220 mineral oil or with Chevron ISO FM 220 food grade oil (if required), or equivalent:
or with Shell Omala 220 regular mineral oil fill when the mixer is provided with a dry well seal unless otherwise specified:

N.B: A reducer previously filled with Shell Omala 220 mineral can be drained (as much as practical to achieve), and Chevron ISO FM 220 substituted without any harmful chemical reactions or reduction to the lubricating quality of the new (or old) oil.
 - Please note that the gear reducers for MIX-TECH’S “EVG” series are Nord Parallel shaft drives. The top output bearing is grease packed although there is not grease nipple. Please remove the seal and re-pack the bearing with grease. (please refer to NORD instruction attached)
 - The output shaft seals are “Quadrilip” having (2) discrete grease filled pockets
-

SECTION 7 - GEAR DRIVE MAINTENANCE FOR SERIES EVG & EVGX parallel Shaft design gear reducers:

- **RECOMMENDED OIL CHANGE INTERVALS IN NORD IOM: -**
Synthetic lubricants should be changed every 20,000 service hours or (4) years;
Mineral oils should be changed every 10,000 service hours or after (2) years. See gear reducer service manual (IOM).

CAUTION:

Units should be checked out periodically for increased noise, surface temperature, vibration, shaft

movement, and amperage draw. Units with inspection covers should not be operated with the inspection covers removed.

PROCEDURE FOR RE-GREASING THE UPPER OUTPUT BEARING equipped with Tapered roller bearing option:

- Remove upper output shaft seal(s).
- Inspect bearing cavity for presence of grease. The bearing cavity should be packed to approximately 1/3 full with grease.
- If required, inject grease into the taper roller bearing until the cavity is filled to 1/3. A Needle Nozzle is generally required on the grease gun, because the shim(s) partially cover the access to the bearing cavity.
- Install new upper output seals.

Note: The other bearings in these gearboxes are open and are submerged in oil.

The recommended interval for changing the gearbox oil is every 10,000 hours of operation.

- The standard ambient temperature selected is 15 to 125° F (9 to 52° C) for the gear reducer.
 - Some Gear reducers are equipped with bulls-eye oil level indicators, **others have a plug.**
-

SECTION 8 - BOLTS

- Impeller blades & other in-tank fasteners are supplied as standard with lock-washers.

CAUTION:

- Extreme care should be taken to see that locking devices are properly installed and to be sure that the bolts/studs are properly tightened and lubricated.

It is recommended that all in-tank fasteners (and all other bolts), be rechecked for tightness after the first 1500 hours of operation and subsequently, at each scheduled shut-down and that a suitable lubricant be used e.g. Never seize or equivalent.

RECOMMENDED BOLT TORQUE VALUES:

BOLT SIZE TIGHTENING TORQUE

		(Foot Pounds)		
½" - 13	50		1.25" - 7	580
5/8" - 11	100		7/8" - 9	190
¾" - 10	190		1.50" - 6	1000
1" - 8	290			

NOTE: Tighten all bolts as specified. Lubricate all fasteners with an anti-seize product. If no lubrication is used when tightening the bolts as specified, multiply the table values by 1.3

GEAR REDUCER & MOUNTING PLATE BOLTS:

These bolts are also subject to high loads and should be properly torqued to prevent bolt stretch and/or reducer wobble. For situations with large reducers or long shafts with large reducers, use additional care to make sure that these bolts are installed and torqued properly

This "Turn of the nut Method" can be summed up in one sentence: "Turn the Nut ½ to 2/3 turns beyond the snug tight position, "this applies to any bolt of any size. However, fasteners should be clean, rust free and lightly oiled.

In cases where the nut is not accessible, the bolt may be turned ½ to ¾ turn beyond snug tight.

LEVER ARM SYSTEM

<u>Bolt size</u>	<u>Lever Arm</u>
1/4 - 3/8"	6" handle
7/16" - 5/8"	12" handle
¾" - 1.125"	24" handle
1.25" and over	36" handle

Note: This lever arm system should be used with or without lock-washers. If lock-washers show sign of splitting or fatigue, they must be replaced

SECTION 9 - OPERATION

- The mixers that you have purchased have been designed to accommodate all the loads that will be encountered in the normal course of operation.

CAUTION:

- Care must be taken to avoid prolonged operation of the mixer impeller(s) at liquid interface. These mixers were not designed to operate under those severe conditions and could become damaged.

SECTION 10 - MOTOR REMOVAL & INSTALLATION OF MOTORS:

Page 13

- For Nema “C ” Flanged motors (not integral motors)
The motors supplied have been installed onto the reducers. In the event of motor maintenance, remove the bolts which hold the gear reducer’s Nema “C” flange adaptor to the motor’s “C” face. Remove the coupling half and service the standard NEMA motor as required. INSTALLATION: reverse the procedure. Please refer to **“COUPLING ENCLOSED”** cross sectional drawing which shows the mounting distance 1 13/16" (46.03 mm). Note that the coupling is keyed onto the motor shaft (key provided).
 - In the case of NORD integral motors, remove the bolts. The motor can then be removed exposing the high speed pinion gear mounted on the motor shaft. The motor can then be serviced as required.
-

SECTION 11 - TROUBLE-SHOOTING / MIXER PERFORMANCE

- **PERFORMANCE**: If you find that the mixer is not performing according to your expectations, one of the things that directly affects mixer performance is Baffles (or lack thereof)
- Note**: Also check that the impeller blades are in the correct configuration A, B, C or D, that the correct blades are matched to the correct hubs and that the rotation is correct.(Please refer to Section 6 Pages 7, 8 & 9 for more information.

N.B: Baffles always help any mixer application by providing the means to convert rotational motion into to top-to-bottom- pumping/mixing.

- If the viscosity of the fluid is over 25,000 cp, then baffles are not necessary.
- If the vessel is rectangular in shape, baffles may not be necessary.
- In circular or square vessels, the use of baffles is mandatory.
- OTHER METHODS of achieving top-to-bottom motion without using baffles:
 - Off-centering the mixer by 20% (uses the vessel as a baffle)
 - Angle mounting (into a quadrant)- often seen on Portable mixers. If you want to angle-mount a larger mixer, please check to be sure that the shaft was designed to accept these additional stress loads.
- **OIL LEAK(S)** problems with Nord Gear reducers: In order to be able to address the

- **OIL LEAK(S)** For Series EVG supplied with a flinger / shaft Catcher & dry well seal:

NOTE: For Series **EVGX**, There is an oil overflow plastic pipe indicating oil leak>

- If one of the (2) output oil seals were to fail (very rare), then the oil would migrate down the output shaft, and be pumped by the flinger into the moat surrounding the dry well pipe. Any such leak would be contained by our sealed pedestal. (access to it is by a plug). Any other oil leak will be visible on the outside of the gear reducer

<u>SYMPTOM</u>	<u>REASON(S)</u>	<u>SOLUTION</u>
Oil leak on the reducer	Vent plug not installed Vent plug painted over Vent plug failure	Clean up oil and remove the vent plug If this stops the leak, change the vent plug
Oil leak on top of the reducer	Motor and/or top bolts not tightened	Use Teflon tape and tighten bolts
Oil leak on top of reducer	Too much oil in the reducer will be forced out of the vent	Check oil level and adjust to site glass
Oil leak on end plate	Bolts loose	Tighten bolts
Oil leak on top of the reducer	Gasket between motor and the reducer failed	Replace gasket and silicone dealant
Sign of oil on the reducer	Drain pipe & valve damaged	Use Teflon tape /sealant to try to reseal
Oil leaking on reducers with “C” flanged motor(s)	if the vent was not installed, plugged or faulty, the oil presure in the reducer might have exceeded 2 psi causing the input oil seal to “blow-out”	Change the input oil seal

- **NOISE:** Under normal circumstances, Mix-Tech mixers operate quietly and without vibration. If there is a metal-on-metal noise, check to see if the top bolt # 3 is properly tightened to the shaft. If the bolt is not, the shaft will lower than it should be and the flinger/shaft catcher may be touching the dry well pipe
- **HEAT:** Check the temperature of the Reducer and motor. If hot, check the oil level.

NOTE: On Series EVG & EVGX, an oil expansion chamber is supplied to minimize problems with over-filling of oil into the gearcase

- These mixers should provide long and satisfactory service. Only the finest materials were employed in their manufacture. However, if any defects in materials or workmanship occur, the defective part(s) must be returned to ENVIREQUIP (div 6335772 Canada Inc), **MIX TECH Division**, freight prepaid. ENVIREQUIP reserves the right to repair or replace, at its discretion, any part that proves to have been defective in materials or workmanship.
- ENVIREQUIP is not responsible for the warranties on components purchased, e.g. motors, but will endeavour to help to obtain resolution of any problem(s) with any of our sub-supplier(s) as regards their warranties.
- ENVIREQUIP specifically excludes any liability as to loss of production, improper use of the equipment, abuse, any other liability expressed or implied that exceed the limited warranty given as applies to the equipment being free of defects in materials and/or workmanship.
- ENVIREQUIP's warranty is for (2) years against defects in materials or workmanship and also includes a process warranty.
- This Process warranty only applies to the actual conditions that were specified at the time of bidding.
- Please refer to the terms and conditions as well as to the warranty for complete details.

Call toll free 1-866-819-6123

CONVERSION FACTORS

1 inch	=	25.4 mm
1 kilogram	=	2.205 lbs
1 U.S. gallon	=	3.785 litres
U.S. gallons x 0.2642	=	litres
1 m ³	=	264.2 U.S. gal
1 ft ³	=	7.481 usg
1 ft ³ of water	=	62.4 lbs
1 foot	=	0.3048 meters
1 psi	=	6.895 Kpa
1 Kpa	=	0.145 psi
1 K Cal	=	3.967 BTU
1 HP	=	0.7457 kW
1 kW	=	1.341 HP
1 Bar	=	14.5 psi
1 kg /m ²	=	14.22 psi
1 Newton	=	0.2248 pounds (force)
1 lb in	=	0.1129 Newton-meter (Nm) force
1 lb in	=	1.1519 kg-cm
1 kg/cm ²	=	14.23 psi

ENVIREQUIP / MIX-TECH MIXERS**Page 17****MAINTENANCE LOG**BY:
DATE:

Signed

TASK

CHECK OIL

CHANGE OIL

CHECK PEDESTAL for OIL LEAKAGE

CHECK FOR HEAT

CHECK FOR NOISE

CHECK FOR VIBRATION

CHECK BOLT TIGHTNESS:

Top bolt & Pedestal bolts

Base bolts

Clamp

Coupling

Hub & blades

Reducer end cover bolts

CHECK MOTOR AMPERAGE

CHECK ROTATION AFTER
ELECTRICAL WORK

OTHER

LEFT BLANK



MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL
AMARUQ WTP – NUNAVUT
VEOLIA PROJECT: 5000 218 009

FLOWROX

SERIES PVE, PINCH VALVE

LEFT BLANK

Installation, operation, and maintenance instructions for Flowrox valves Open Valve (PV) & Enclosed Valve (PVE)



These instructions must be read carefully and understood prior to the installation, use, and servicing of this product.

FLOWROX OY
P.O. Box 338
FI-53101 Lappeenranta, Finland
Tel. +358 (0)201 113 311, fax +358 (0)201 113 300
E-mail: sales@flowrox.com
Web: www.flowrox.com







TABLE OF CONTENTS

1	GENERAL	1
1.1	General safety instructions for PV & PVE valves	1
2	INTRODUCTION TO DEVICE	2
2.1	Intended use	2
2.2	Construction of device	2
2.2.1	Open body valve PV	3
2.2.2	Enclosed body valve PVE	3
2.3	Valve function	4
3	TRANSPORTATION, STORAGE AND LIFTING	5
3.1	Receiving	5
3.2	Storing	5
3.3	Lifting	5
4	INSTALLATION	6
4.1	Open body model (PV)	6
4.2	Enclosed body model (PVE)	7
4.3	Both models (PV and PVE)	7
5	OPERATION	8
5.1	First use	8
5.2	During operation	8
6	MAINTENANCE	9
6.1	Schedule	9
6.2	Changing the valve sleeve	9
6.2.1	Changing the valve sleeve in open model valve (PV)	9
6.2.2	Changing valve sleeve with enclosed model valve PVE	10
6.3	Adjusting the valve	11
6.4	Troubleshooting	13
7	TECHNICAL DATA	14
7.1	Model and spare part codes	14
7.1.1	Valve model selection	14
7.1.2	Sleeve model selection	15
7.1.3	Sleeve materials for Flowrox valves	15
8	APPENDIXES	18
8.1	APPENDIX A: PV- Open Body Assembled	18
8.2	APPENDIX B: PVE-Enclosed Body Assembled	19

1 GENERAL

1.1 General safety instructions for PV & PVE valves

In this manual, the following symbols are used to highlight the parts requiring particular attention:

SYMBOL	DESCRIPTION
	Risk to personal safety: Neglecting the safety measures can cause serious personal injury or death.
	Electrical safety: Neglecting the safety measures can cause serious personal injury or death.
	Machinery or environmental risk: Incorrect maintenance or operation of the product can harm the environment or the product.
	Read the operation and maintenance instructions: Read and understand the operation and maintenance instructions before using the product.

2 INTRODUCTION TO DEVICE

2.1 Intended use

Open type PV.

The open body is available in diameters starting from 80mm.

The open body construction is designed for applications with:

- Low pressures
- Low temperatures
- Non-hazardous media

The open body construction is light and simple, which makes it easy to access for service.

The open body also tolerates misalignment and vibration.

Enclosed type PVE.

The valve sleeve is covered by the body housing and thus protected from the environmental impacts and sunlight.

- Body construction prevents leakage of flowing media to the environment
- The valve body can be equipped with a gauge indicating pressure changes inside the body

2.2 Construction of device

Flowrox valves are made of three main components:

- flanged valve sleeve
- valve body, either open PV or enclosed PVE
- actuator and actuator control components, if applicable

The valve sleeve is the only part of the valve which is in contact with the medium flowing in the pipeline.

All valve bodies are flange ended. The standard flange drillings can be made to meet all standards (e.g. DIN, ANSI, BS, AS, JIS).

The face to face dimensions of Flowrox valves are according to ANSI/ISA 75.10.02:

- 165 mm for valves DN25...DN65
- 2 ½ times the nominal diameter for valves DN80 and bigger

2.2.1 Open body valve PV

In the open body model the body and the actuator are connected only to one of the end flanges (Fig. 1.). The construction allows a slight deviation in the pipe angle and the valve can act as a vibration absorber.




Fig. 1.



Note that in case of a sleeve breakage, the flowing liquid will leak to the environment.

2.2.2 Enclosed body valve PVE

The body of the enclosed model prevents leakage of flowing media to the environment (Fig. 2.). The lower part of the body has a plug, which can be opened to check for sleeve failure.




Fig. 2. plug






In case of a sleeve failure, slight leakage will occur through the bushings.
If you open the plug for checking, be careful as the medium may flow out.




Changing the sleeve at appropriate intervals prevents leakages.

2.3 Valve function

	<p>When the valve closes the actuator moves. Do not put tools or parts of your body between the moving valve parts. Note the injury risks (see drawings 3A and 3B).</p>
---	---

<p>Note the dangerous places (see drawings 3A and 3B)!</p> <p>When the pinch valve closes, two pinch bars, moved by the actuator, squeeze the sleeve, closing on the center line. As the valve is fully closed, the actuator has raised one half of the valve diameter.</p> <p>The actuator raises in both models (PV and PVE) 0.5 x valve nominal diameter (measure X).</p> <p>In the open model the space between the pinch bars, the space between the upper pinch bar and fixing plate of the actuator and the space below the lower pinch bar.</p>	
	<p>Fig. 3A - PV open model</p>
<p>In the enclosed model the space between the valve body and the fixing plate of the actuator and the ends of the guide bars of lower pinch bar below the valve body.</p>	
	<p>Fig. 3B - PVE enclosed model</p>

Regarding the actuators, follow the instructions of the manufacturer.

	<p>Note the possible remote control of automatic valves and turn it off before starting maintenance.</p>
---	--

3 TRANSPORTATION, STORAGE AND LIFTING

3.1 *Receiving*

Check the condition of the valve package on arrival. If it shows signs of transport damage, check the operation of the valve carefully. Normally, a visual inspection of the valve is sufficient. However, if valve has been damaged during transport, contact your nearest Flowrox sales office immediately.

3.2 *Storage*

The sleeves must be stored as follows:

- The storing temperature should not exceed +25°C, preferably below +15°C but not under +5 °C. Keep the storage temperature as constant as possible.
- Store the sleeves in a dry place. Prevent water from condensing on sleeve surfaces.
- Avoid ultraviolet light. Protect the sleeves against straight sunlight. Use warehouse instead of storing outside.
- Remove all equipment generating ozone from the room where sleeves are stored. Minimize the store room ventilation.
- Store sleeves so that they are free from tension. Sleeves should be stored in vertical position on smooth support. Do not store sleeves one on top of another.
- Keep the sleeves off the chemical effect of solutions, semi-solids, impurities and solvent vapours during storing.
- Try to keep the storing time of sleeves as short as possible. Always use first the material which has been longest in stock.

3.3 *Lifting*

When lifting the valve, fasten the ropes to the valve body or around it. Note the center of gravity and support the valve to avoid it turning around. In some models the center of gravity is located towards the actuator.

4 INSTALLATION

4.1 Open body model (PV)

The sleeve has not been designed to withstand axial forces. The pipes must therefore be supported properly so that neither tension nor compression is caused. Use cross-tightening for flange bolts. Do not overtighten bolts.

Make sure that no inappropriate items get between the pinch bars and the sleeve.

If possible, protect the sleeve from direct sunlight. Direct sunlight and UV light deteriorate certain rubber qualities; this must also be considered during normal use.




Fig. 4.

A lengthwise angle deviation of max. 5° in the pipe is allowed (Fig. 5).




Fig. 5.




Fig. 6.

Deviation in the center line of the pipe (C), (Fig. 6):

PV 80...100	max. 5 mm
PV 125...250	max. 10 mm
PV 300...500	max. 15 mm
PV 550...1000	max. 20 mm

4.2 Enclosed body model (PVE)

Make sure that no inappropriate items get between the valve body and the actuator.

4.3 Both models (PV and PVE)

The valve nominal size means the inner diameter of the sleeve. The pipe inner diameter should match this diameter as closely as possible. Whenever possible, install the actuator in a vertical position. Valve can be assembled either way in terms of flow direction.

If you have to install the actuator horizontally, it has to be supported to ensure the operation, especially if the actuator is heavy. Install a sliding surface under the actuator (Fig 7).

The support can be fixed on the wall (1), on the floor (2) or the pipeline (3).

The valve can be installed in either way depending on the flow direction.




Fig. 7.

When installing the valve to the pipeline, it has to be in the open position. Tighten the flange bolts smoothly crosswise



Do not fasten actuator or any part of it to the support.

5 OPERATION

5.1 First use

Flowrox valves are normally delivered fully assembled and ready to use. Check the condition of the valve visually.


After installation to the pipeline, check that all connections are leak-proof.

5.2 During operation

During the operation the valve does not normally require any maintenance. The sleeve change is described in 6.2.

To ensure smooth operation, it is recommended to change the valve sleeve regularly.

Regarding the actuators, follow the instructions of the manufacturer.

 NOTE	Note the valve functions, see 2.3.
---	------------------------------------

6 MAINTENANCE

6.1 Schedule

The sleeve is the only part of the valve which is in contact with the medium flowing in the pipeline. With regular sleeve changing, the likelihood of malfunctions in the process decreases. Wear resistance of the sleeve depends on the circumstances of the process and may vary a lot.

If there is a flow through closed valve or leakage through bushings (PVE) or through damaged sleeve (PV), change the sleeve immediately.



PVE: In case of a sleeve failure, slight leakage can occur through bushings.

PV: In case of a sleeve breakage, the flowing liquid will leak into the environment.

6.2 Changing the valve sleeve



Control the valve functions (see 2.3) and follow the instructions for adjusting of valve (6.3) to prevent accidents and to ensure the correct operation of the valve.

6.2.1 Changing the valve sleeve in open model valve (PV)

See appendix A. Open the valve and detach it from the pipeline. If the valve is equipped with opening tags, loosen the fixing screws (8 pcs) at the pinch bars and pull out the opening tags (Fig. 8).

Remove the broken sleeve by bending the rubber flange of the sleeve and by wrenching it e.g. with a pry bar / bending iron.





Fig. 8.

Put in the new sleeve by pressing the rubber flange on the opposite sides together, pushing its edge as far as possible through the steel flange and wrenching the rest of the sleeve through the flange e.g. with a pry bar / bending iron (see Fig. 9).

 NOTE	The rubber flange of the sleeve allows bending. Do not damage the sleeve with a sharp tool.
--	---






Fig. 9.

After putting in the new sleeve, fix the opening tags to the pinch bars. The excessive length of the tags can be cut away. Adjust the pinch bars before installing to the pipeline.

 NOTE	At sleeve change, it is always important to check and adjust the position of the pinch bars. See 6.3.
--	---


6.2.2 Changing valve sleeve with enclosed model valve PVE

See appendix B. (Part numbers refer to drawing number 410006 in appendix A). Open the valve and detach it from the pipeline. Open the bolts (6.) between the valve body halves and detach the lower part of the body. If the valve has opening tags, detach them (16.) from upper (2.) and lower pinch bars (3.), 8 pcs screws (Fig.8). Take out the damaged sleeve and put in a new one. If the sleeve is stiff, detach the lower pinch bar. Remember to fix the opening tags if applicable. Check the body sealing (15.) between the body halves and the condition of the bushings (4.). A worn sealing and/or worn bushings may cause leakage to the environment in the event of a sleeve breakage. Assemble the valve and adjust the pinch bars before installing the valve to the pipeline.

 NOTE	At sleeve change, it is always important to check and adjust the position of the pinch bars. See 6.3.
--	---

6.3 Adjusting the valve

After every sleeve change, the closing of the valve has to be checked and adjusted. A wrong adjustment may shorten the lifetime of the sleeve and cause leakage from the valve when the actuator is in the closed position.

	<p>Control the valve functions (see 2.3). Do not put tools or parts of your body between the moving valve parts.</p>
---	--

Before reinstallation of the valve into the pipeline:

- Close the valve by using the actuator. Adjust the pinch bars parallel to each other with the nuts, which are on both sides of actuator fixing plate (Fig. 10, nuts 1 and 2), so that from one end of the sleeve an even, narrow light strip (appr. 0.5 mm) is shown on the whole squeezed point of the sleeve or symmetrically on both sides (Fig. 10.1).
- Tighten both nuts (1) equally so, that the strip of light disappears.
- Unscrew the lower nuts (Fig. 10.2, nut 2) X mm from the attachment plate (see the dimension X in the table, Fig. 11).
- When the nuts (Fig. 10.3, nut 1) on the upper side of the attachment plate are tightened, the lower pinch bar rises and causes a sufficient squeeze on the sleeve to close the flow against the pressure in the pipeline. After this has been done, open the valve and it is ready to be installed to the pipeline.

If the valve is hand wheel operated, it is enough to check that the pinch bars are parallel and the light slit is shown (Fig. 10.1). A sufficient squeeze is achieved by turning the hand wheel 1/3...3/4 rounds after the valve feels tight: if the pressure in the pipeline is 1 bar - appr. 1/3 of a hand wheel rotation; PN 10 bar - appr. 1/2 of a hand wheel rotation; PN 25 bar - appr. 3/4 of a hand wheel rotation. If the valve is supplied with a reduction gear, the number of rotations is multiplied by the gear ratio.

- A. Attachment plate
- B. Upper pinch bar
- C. Sleeve
- D. Lower pinch bar




Fig. 10.

6.4 Troubleshooting

PROBLEM	POSSIBLE REASON	ACTION
Valve leaks into the environment.	1. Sleeve breakage. 2. End flanges loosely tightened.	1. Change and make adjustment of sleeve 2. Tighten the flange end screws
Leakage or flow through the valve when valve should be closed.	Sleeve breakage.	(models PVE, PVS): check by the plug - change and make adjustment of sleeve
	Sleeve is not closed with sufficient squeeze.	Manual valves - turn the hand wheel more tight. Pneum. and hydr. actuators - check the supply pressure for cylinder; if the pressure is too low, the sufficient squeeze for the sleeve cannot be reached. Check the compactness of the cylinder seals.
	Wrong adjustment of the sleeve.	Make the adjustment
Shorter lifetime of the sleeve than before.	Sleeve is not closed with sufficient squeeze.	Manual valves - turn the hand wheel more tight. Pneum. and hydr. actuators - check the supply pressure for cylinder; if the pressure is too low, the sufficient squeeze for the sleeve cannot be reached. Check the compactness of the cylinder sealings.
	Wrong adjustment of the sleeve.	Make the adjustment.
	1. Pneum. valves: wrong adjustment of the end cushioning in front end-block of cylinder. 2. Wrong adjustment of the pneum. spring.	1. End cushioning in front end-block of cylinder should be fully open. 2. Check adjustment of pneumatic spring .
	Changes in customer process e.g. * composition of medium / temperature * flow capacity	Check the best rubber qualityl with FLOWROX. Select another valve size with FLOWROX (particularly valves with positioners).
Sleeve is flapping and/or flow capacity is not sufficient.	Vacuum or pressure shocks in pipeline, rubber has hardened and does not open totally.	Check that the opening tags are fixed.

In case you cannot find the solution to your problem in the above table, please turn to the nearest Flowrox representative. The serial number and type identification of the valve in question will help getting the prompt answer.

7 TECHNICAL DATA

7.1 Model and spare part codes

7.1.1 Valve model selection

PVE	100	AK	10	-	2	0	3	L	R	
TYPE	SIZE (DN)	ACTUATOR	PRESSURE CLASSES (PN)	-	FLANGE DRILLINGS	BODY MATERIAL	SHAPE OF FLANGE	OPENING TAGS	AUXILIARIES	
PV = open	25-1000	M=handwheel	1= 1bar		1 = -	0 = Cast iron / Welded steel	types 1 - 4	L = opening tags	Q = quick exhaust valve	
PVE = enclosed		A=pneumatic	6= 6 bar		2 = DIN PN 10	1 = - 2 = AISI 316 3 = aluminium 4 = other 5 = plastic	Determined by the valve manufacturer		R= inductive limits	
PVS = sealed		AB=with manual override	10= 10 bar		3 = DIN PN 16					
PVE/S = enclosed/sealed		AK=with el.pneum. positioner	16= 16 bar		4 = DIN PN 25					
			25= 25 bar		5 = DIN PN 40					
			40= 40bar		6 = ANSI 150					
			AN=with pneum. positioner		64= 64 bar					7 = ANSI 300
			AU=with pneum. spring		100 =100bar					8 = BS TABLE D
			AV=with mech. spring							9A = AS TABLE D
			H=hydraulic							9B = AS TABLE E
HP=with hydraulic positioner		9C = JIS 10								
			9D = JIS 16							
		E=electro mechanical			Other on request			X = must be specified		
		EO=electric for control								

7.1.2 Sleeve model selection

SBRT	10	100	/	250	/	3	L	2
SLEEVE MATERIALS	PRESSURE CLASSES (PN)	SLEEVE INNER DIA (mm)		SLEEVE LENGTH (mm)		SHAPE OF FLANGE	OPENING TAGS	FLANGE DRILLINGS
SBRT = styrene butadiene	1= 1bar	25-1000		Depend on the sleeve inner diameter according to ANSI/ISA 75.10.02;		type 1 - 4	L = yes	1 = -
EPDM=ethylene propylene	6= 6 bar							2 = DIN PN 10
CR = chloroprene	10= 10 bar					Determined by the valve manufacturer		3 = DIN PN 16
CSM = chloro-sulphone-ethene	16= 16 bar							4 = DIN PN 25
FPM = fluorine rubber	25= 25 bar							5 = DIN PN 40
HNBR = hydrogenated nitrile	40= 40bar					(depending on the valve diameter / pressure class)		6 = ANSI 150
IIR = butyl	64= 64 bar							7 = ANSI 300
NBR = nitrile	100 =100bar							8 = BS TABLE D
NBRF = nitrile foodstuff quality								9A = AS TABLE D
NR = natural rubber								9B = AS TABLE E
NRF = natural rubber foodstuff quality								9C = JIS 10
PU = polyurethane								9D = JIS 16
_ /PU = PU-coating inside the sleeve								X = Other, must be specified
_ /M = Flowrox SensoMate sleeve								
_ /VAC = Vacuum sleeve								
In spare sleeve orders, please use 4- or 5- figure code marked on the sleeve.								

7.1.3 Sleeve materials for Flowrox valves


STANDARD SLEEVE MATERIALS FOR FLOWROX VALVES

RUBBER QUALITY	APPLICATION EXAMPLES	TEMPERATURE RANGE	TYPICAL MEDIA
SBRT Styrene Butadiene, Flowrox Blend	Heavy wearing High cycle frequency	-40°C - +110°C	Abrasive materials Diluted acid, alkali and chemical applications
EPDM Ethylene Propylene	Chemical applications • Applicable to 75% of all industrial chemical applications	-40°C - +120°C	Concentrated and oxidizing chemicals

OTHER SLEEVE MATERIAL OPTIONS


RUBBER QUALITY	APPLICATION EXAMPLES	TEMPERATURE RANGE	TYPICAL MEDIA
NBR Nitrile Rubber	Applications involving oils, fats and hydrocarbons	-30°C - +100°C	Oils, Fats, Fuels Hydrocarbon, Lubricants
NR Natural Rubber	High wear applications	-40°C - +75°C	Abrasive materials Diluted acids, alkali and chemicals
HNBR Hydrogenated Nitrile	High temperature Applications	-30°C - +160°C	Oils, Fats, Fuels Hydrocarbon, Lubricants
NRF Natural Rubber Foodstuff Quality White inner lining	Foodstuff applications Fulfil FDA (Food and Drug Administration) requirements	-40°C - +75°C	Media used in food and other CIP (clean-in-place) processes Alcohols
NBRF Nitrile Rubber White inner lining	Applications involving fatty foodstuff Fulfil FDA (Food and Drug Administration) requirements	-30°C - +100°C	Vegetable and animal oils and fats
EPDM/B Ethylene Propylene, Flowrox Blend	Pulp and paper industry's green liquor applications	-40°C - +100°C	Green liquor Alkaline and extraneous matter in green liquor processes
CR Chloroprene Rubber	Special-purpose chemical applications • Resilient to ozone and averse weather	-40°C - +100°C	Chemicals, Acids Several solvents Aliphatic oils Fats, Lubricants
FPM Fluorine Rubber (Viton®)	Special-purpose chemical applications • Resilient to ozone and averse weather	-20°C +120°C	Chemicals Aliphatic oils Aromatic and halogenated hydrocarbon
CSM Chloro-sulphone-ethylene (Hypalon®)	Special-purpose chemical applications • Resilient to ozone and averse weather	-40°C - +100°C	Chemicals, Acids Several solvents Aliphatic oils Fats, Lubricants
IIR Butyl	Special-purpose chemical applications • Impermeable to gas	-40°C - +100°C	Concentrated and acidic chemicals Vegetable oils
PU Polyurethane • With PU lining or solid PU	Abrasive media applications	-10°C - +80°C	Abrasive materials Diluted chemicals Hydrocarbons Oils, Lubricants

For more information on sleeve materials for Flowrox valves, contact your nearest Flowrox representative.



8 APPENDIXES

8.1 APPENDIX A: PV- Open Body Assembled




FLOWROX

PV-OPEN BODY ASSEMBLED

Dwg. no. 410158b

- | | |
|--------------------|--------------------------------|
| 1. Valve body | 6. Allen screw |
| 2. Flange | 7. Valve plate |
| 3. Upper pinch bar | 8. Drive screw |
| 4. Lower pinch bar | 9. Fix. parts for opening tags |
| 5. Hex. nut | |

8.2 APPENDIX B: PVE-Enclosed Body Assembled



FLOWROX

PVE- ENCLOSED BODY ASSEMBLED

Dwg. no. 410006a

- | | | |
|--------------------|-----------------|---------------------------------|
| 1. Valve body | 7. Allen screw | 13. Drive screw |
| 2. Upper pinch bar | 8. Hex nut | 14. Sticker open-closed |
| 3. Lower pinch bar | 9. Hex nut | 15. Sealing |
| 4. RCH-bushing | 10. Washer | 16. Fix. parts for opening tags |
| 5. Guide | 11. Plug | |
| 6. Hex screw | 12. Valve plate | |

LEFT BLANK



MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL
AMARUQ WTP – NUNAVUT
VEOLIA PROJECT: 5000 218 009

FLSMIDTH KREBS
MODEL U10-GMAX-9.5 SQIN, HYDROCYCLONE

LEFT BLANK

FLSmidth

5505 W Gillette Rd • Tucson, AZ 85743-9501 • USA

Tel +1 520 744 8200 • Fax +1 520 744 8300

www.flsmidth.com



INSTALLATION, OPERATION AND MAINTENANCE MANUAL

**4 MODEL U10-GMAX-3037 KREBS® CYCLONES
SERIAL NUMBERS: g169408U – g169411U
EQUIPMENT TAG NUMBERS: C2-011, C2-012, C2-021, C2-022**

**FOR
VEOLIA WATER TECHNOLOGIES OF CANADA
PO NUMBER: 18000759 HD 05000
PROJECT NUMBER: 5000218009**

This page is intentionally left blank

FLSMIDTH KREBS
URETHANE IOM

GENERAL

FLSmidth Krebs Cyclones are the result of an intensive research and development program initiated in 1950. Each unit represents a product of advanced design, careful engineering, quality materials and the finest workmanship.

The information in the following pages is directed toward a better understanding of cyclone principles and operation, so that the potential for every FLSmidth Krebs Cyclone is realized.

FLSmidth Krebs engineers cyclone installations by studying the operating data and customer objectives. The cyclone selections are based on the large amount of operating data accumulated by our staff of engineers and our continuing research. When data is not available or is incomplete, studies in our laboratory and pilot plant are recommended. The pilot plant is equipped for complete, full-scale cyclone classification studies. Predictable performances resulting from these studies have been proven in numerous subsequent field installations. An important part of this service is the analysis of the test results by our staff of metallurgical and chemical engineers as related to the overall plant operation.

You are invited to avail yourself of these facilities and services for the study of your classification problems.



Cyclone Identification

FLSmidth Krebs cyclones are designated by Model Numbers, Serial Numbers, size and style. This information is stamped on an identification plate.

Permanent records for this cyclone are kept by the serial number; therefore, the serial number must be used with all correspondence and spare parts orders.

Receiving Instructions

Smaller FLSmidth Krebs Urethane Cyclones are crated and shipped completely assembled. Larger units are generally shipped dismantled as two pieces in order to reduce the size of the shipping crate. When removing the cyclone from the shipping crate, care should be taken to account for all of the parts. This can be checked against the packing slip.

Storage Requirements

FLSmidth Krebs Cyclones, any items with elastomer or polymer components, and auxiliary equipment such as valves, should always be stored:

- out of direct sunlight;
- away from heat and;
- protected from extreme weather conditions.

The preferred storage area will be a cool, well-ventilated building.

If outside storage is mandatory, the equipment should be totally covered over with heavy, opaque, plastic weather covering. It is essential that the plastic be opaque so as to cut out direct sunlight. In addition, a light color opaque material is desirable, to avoid heat build-up under the covering.

The covering should be spread over the equipment with allowance for underside ventilation to avoid excessive heat build-up and moisture condensation. Elevating the equipment a minimum of 2 inches above ground level should ensure adequate ventilation and prevention of moisture condensation.

The polyurethane employed in the manufacture of the cyclones is adversely affected by heat. However, if stored exactly as described above, ambient temperatures of less than 120°F (preferably less than 100°F) can be maintained.

The equipment will not be damaged by freezing conditions as long as it is kept dry. If below freezing conditions are involved, care should be taken when handling to avoid damage to urethane components as they become brittle at very low temperatures.

Installation

Cyclone Mounting

Each cyclone should be securely mounted on a soundly constructed frame so that stresses on the overflow/underflow piping are minimized.

During assembly, care must be taken such that the urethane flanges are not stressed. Assemble the inlet flange to its mating piping without over torqueing to the point of urethane deformation. Follow the same procedure for the overflow connection and lastly the cyclone mounting plate. Do not force the urethane cyclone into an unnatural position.

Sump

Correct design of the pump sump is probably the most important factor in establishing an efficient cyclone operation.

Conversion of flow and velocity to kinetic energy in a cyclone is derived from the energy supplied from the pump. Each adjustment of the cyclone variables will influence the pumping to some degree. This will be discussed in the section entitled "Operation". A constant volume to the cyclone is important. Momentary fluctuations are generally the result of entrained air in the slurry.

A constant level in the sump is critical, but by no means an indication that the cyclone is receiving a constant and uniform volume of feed. If the needle of the cyclone inlet pressure gauge fluctuates rapidly, it is a definite indication that there is entrained air in the pump discharge slurry. To correct this problem, the entering stream should be prevented from carrying entrapped air to the suction of the pump. This can be done by mounting a sloping plate in the sump, well below the normal level of the slurry. An annular opening between the plate and the edges of the sump of about one inch around its entire periphery will generally be sufficient to allow the total volume of slurry to pass from the upper compartment to the lower section.

It is permissible to return part or the entire overflow product to the sump to maintain a constant level. It should be noted that the greater the slime content of the feed slurry to a cyclone, the more difficult it becomes to make a given separation. The use of recycled overflow product should be handled with caution, as there is always a danger of recirculating an excess quantity and consequently increasing the slime content of the feed slurry.

Where water is available and the overflow product is an important consideration, fresh water should

be added to the feed as a means of volume control.

The overflow product should discharge to atmosphere as close to the cyclone as possible. If the overflow pipe is carried directly to an elevation below the inlet of the cyclone, a siphoning action can be created. This will cause coarser particles to be carried to the cyclone overflow product.

The underflow discharge should be open for visual inspection, as it is important to be able to observe the characteristics of this flow. The underflow should be maintained with a 20-30 degree spray discharge. A "rope" discharge is an indication that there is excess crowding of solids at the apex orifice. This will cause coarse oversize solids to be carried into the overflow product.

Both the overflow and underflow should be available for sampling.

Pumping

Pumping to a cyclone, or battery of cyclones, must be carefully engineered to the job both as to size and type of the pump, and to size and length of the pipe line. Wear results in a much higher pump maintenance cost than cyclone maintenance cost.

Wear on a pump varies approximately proportionately to the cube of the velocity. In order to minimize the pump speed and pump maintenance, the cyclone

should be as near to the pump as possible. A certain inlet pressure at the cyclone will be required, so there is also a power saving by having the static and friction head as low as possible.

If adequate pressure is available in the cyclone feed line, a pump may not be required.

Piping

When designing cyclone piping, the most important consideration is to establish a velocity that will prevent particle segregation in the pipe line, and at the same time hold the velocity to a minimum to reduce wear, which increases rapidly with increase in velocity.

With a large majority of installations for pumping slurries, the velocity range falls between a low of 5 ft/s and a high of 15 ft/s.

Major factors in determining the optimum velocity in a pipeline are:

- particle size
- angularity of the coarser fractions
- specific gravity of solids
- slimes content
- pulp density
- viscosity

Multiple Installations

FLSmidth Krebs has the ability to design and fabricate cyclone manifolds as per the project

requirements, with various styles including: radial, "spider", and inline.

A radial manifold system assures an even feed distribution to each cyclone. The take-offs should be equally spaced around the perimeter of the central distribution pot. The overflow and underflow launders must be properly sized to allow for collection and distribution of the streams.

An inline manifold system can be used if the feed is very dilute and not subject to segregating in the system. An inline system is generally easier to design and build than a radial system and consequently is less expensive. However, an inline system does not assure equal feed to each cyclone.

Operation

The FLSmidth Krebs Urethane Cyclones are chemical resistant in some cases. The maximum recommended operating temperature is 140 °F. Available sizes include: ½" up to 15" diameter.

The primary consideration in selecting the proper size and design of cyclone is the classification objective, not the capacity. The proper relationship between the inlet orifice size, the vortex finder diameter, and the apex diameter is engineered by the staff of FLSmidth Krebs for each specific classification objective.

There is seldom any necessity for changing the size of these orifices unless the classification objectives or plant operating conditions are altered.

Numerous factors influence the operation of a cyclone. Following is a brief discussion of some factors influencing cyclone operation (which the operator is normally able to control while the cyclone is operating).

Feed Dilution

Feed dilution is the most effective control available. The use of additional dilution water will always result in a finer and sharper separation. The dilution water can also be adjusted to maintain a constant level in the sump,

although the operator must be aware of the potential change in the separation. For very dilute feeds, the change in the separation will be minimal.

Pressure Management

Pressure drop across the cyclone is the pressure differential between the cyclone inlet and overflow. When the cyclone discharges to atmosphere, a condition we usually recommend, the inlet pressure (gauge reading) is equal to the pressure drop.

The pressure drop is merely an indication of the energy required to force a given volume through the cyclone fitted with a certain combination of orifices. It is not an indication of a developed force-pattern or throughput, except as related to that one particular set of operating conditions. Excessive pressure results in high pump operating and maintenance costs and should be avoided. We generally do not recommend pressure drops above 40 psi.

In general, the higher the pressure drop, the greater the throughput capacity of the cyclone. A higher pressure drop will also produce a finer separation.

Cyclone Orifices

The following describes the effect the various orifices have on the cyclone performance. Changing

the orifice requires shutting down the system.

Inlet Orifice

The main function of the inlet orifice is to provide a smooth flow pattern at the point of entry into the cyclone. All FLSmidth Krebs Cyclones are designed with an involute entry that pre-oriens the solids prior to reaching the tangential point of contact with the cylinder wall. This minimizes turbulence and allows FLSmidth Krebs Cyclones to produce finer and sharper separations.

An increase in the inlet area will increase the capacity of the cyclone. It will also coarsen the separation slightly. All of FLSmidth Krebs Urethane Cyclones, four inches and smaller in diameter, have fixed inlet areas. For larger diameter urethane cyclones, various inlet head sizes are available for each size cyclone. If a different inlet area is required, the complete inlet head can be replaced as the inlet area is integral to the part.

Vortex Finder

The vortex finder has the greatest impact on the operating results of all the orifices. The vortex finder size has a major effect on the cyclone capacity at a fixed pressure drop and also affects the cyclone separation significantly.

The larger the vortex finder diameter, the greater the cyclone capacity at a given pressure drop. A larger diameter vortex finder will also coarsen the cyclone separation and send a larger proportion of solids to the overflow. Various vortex finder sizes are available and the entire part can be replaced.

Apex Orifice

The main function of the apex orifice is to discharge the coarse solids in such a manner that the maximum underflow density and smoothness of discharge are obtained. The apex should be large enough to produce a 20-30 degree conical-shaped discharge, but should not be used to control the cyclone separation. The apex should never be so small that a "rope" discharge exists. A "rope" discharge is an indication that the apex is not allowing all of the coarse solids to exit out the underflow and consequently some are being forced out the cyclone overflow.

Both fixed and manually adjustable apexes are available on FLSmidth Krebs Urethane Cyclones, although fixed apexes are more common. Various apex sizes are available and the entire part can be easily replaced to optimize the underflow solids.

Maintenance

It is important to maintain smooth surfaces on the interior of the cyclone. If possible, the cyclones should be inspected on a regular basis. When the interior surfaces become worn or uneven, the part should be replaced. After experience has been gained in operating the cyclones under given conditions, a regular maintenance schedule can be determined.

Once the apex opens more than 10% of its original size, it should be replaced. Once worn, these urethane parts are 'disposable'.

Please note that for urethane cyclones, the entire part (i.e. cone section, vortex finder, and apex) can be replaced. This is opposed to the replaceable elastomer or ceramic liners used by standard cyclones with steel housing.

The FLSmidth Krebs Urethane cyclones are very lightweight which makes maintenance easier. For cyclone sizes 6" and smaller, the cone sections are generally connected by SS clamps for ease of connection by operators.

FLSmidth Krebs Urethane Cyclones are available in various materials of construction which include:

- Urethane (RU)
- Food-grade Urethane (RT90)
- High-Temp. Urethane (RI)
- Ultrane (RW)*

- Royal Cast (RC)*
- Natural Gum Rubber (apex liner and adjustable apex only)

*Multi-component urethane used for gMAX cyclone sizes 10" and larger

**Other urethane materials are available upon special request

Common Problems and Solutions

Problem 1:

There are very coarse solids in the cyclone overflow.

Solution:

This is normally an indication that the apex is too small and coarse solids are being forced to the cyclone overflow. The apex diameter should be increased until a constant 30 degree cone angle is obtained on the discharge. Certain styles of the urethane fixed apexes can be cut to increase the diameter. An adjustable apex will have to be replaced with a larger one if it is in the full open position.

Another possible solution is to reduce the pressure drop by reducing the flow to the cyclone or by operating additional cyclones (for multiple installations).

Problem 2:

The cyclone pressure drop fluctuates wildly.

Solution:

This is an indication that a constant level in the sump is not being maintained or that air is entrained in the slurry. If the pump is pumping more feed volume than is going to the slump, the sump level will go down. Eventually the pump will cavitate and the pressure drop across the cyclone will be very

erratic. Slowing the pump down or increasing the dilution water to the sump will maintain a constant sump level.

Air usually enters the pump suction because the feed to the sump is pointing directly down into the pump suction. Change the feed so that it angles against a side wall of the sump or install a baffle plate as described in the installation section.

Problem 3:

The separation is not fine enough.

Solution:

Increase the dilution water to the feed. If the feed is already dilute or if diluting the feed is not possible, increase the cyclone pressure drop. This will require speeding up the pump and installing a smaller diameter vortex finder. If the separation is still not fine enough, smaller diameter cyclones will probably be required.

Problem 4:

The underflow is too dilute.

Solution:

This is an indication that the apex is too large. Decrease the apex diameter until a 30 degree cone discharge is obtained. Do not decrease the apex diameter to the point of "roping" the discharge. The adjustable apexes can be decreased by tightening the worm

driven clamp. The fixed apexes will have to be replaced with a smaller size.

If smaller apexes are not readily available, another option is to increase the pressure drop by increasing the flow to the cyclone or by operating fewer cyclones (for multiple installations).

Calculations

TONNAGE:

1) Solids:
$$\text{TPH} = \frac{\text{GPM SLURRY} \times \text{S.G. SLURRY} \times \% \text{ SOLIDS}}{100}$$

Slurry:
$$\frac{\text{TPH SOLIDS}}{\% \text{ SOLIDS}}$$

2) PULP SPECIFIC GRAVITY:

S.G. PULP =

$$\frac{100 \times \text{S.G. SOLIDS} \times \text{S.G. LIQUID}}{100 \times \text{S.G. SOLIDS} - \% \text{ SOLIDS} (\text{S.G. SOLIDS} - \text{S.G. LIQUID})}$$

3) PERCENT SOLIDS IN PULP

$$\% = \frac{\text{TPH SOLIDS}}{\text{TPH SLURRY}} \times 100$$

4) GALLONS PER MINUTE:

$$\text{GPM SLURRY} = \frac{\text{TPH SOLIDS} \times 4}{\text{S. G. SLURRY} \times \% \text{ SOLIDS}}$$



5)
$$\% \text{ SOLIDS BY VOLUME} = \frac{\% \text{ SOLIDS BY WEIGHT} \times \text{S.G. PULP}}{\text{S.G. SOLIDS}}$$

6)
$$\frac{\text{GPM}}{\text{ONE TPH SOLIDS}} = \frac{4}{\% \text{ SOLIDS} \times \text{S.G. PULP}}$$

FASTENER REQUIREMENTS				
CONNECTION	DESCRIPTION	SIZE	LENGTH	QTY
1, 4 TO 6, 7	HEX BOLT & NUT	1/2-13	2 3/4"	8
7, 8 TO 10, 11	HEX BOLT & NUT	1/2-13	3"	4
	WASHER	1/2		24

FASTENER NOTES:

1. ALL BOLTS AND NUTS, TO BE SAE IMPERIAL 304 STAINLESS STEEL. (OTHER GRADE/PLATING CAN BE OFFERED)
2. NUTS SUPPLIED TO BE FINISH NUTS.
3. WASHERS TO BE USED ON ALL SLOTTED HOLES.
4. PLEASE NOTIFY CUSTOMER SERVICES OF ANY DEVIATION IN THIS LIST.
5. NO PAYMENT FOR CUSTOMER MODIFICATIONS, BACK CHARGES, OR ANY OTHER CHANGES WILL BE ACCEPTED, UNLESS PREVIOUSLY AUTHORIZED BY FLSMIDTH KREBS.
6. QUANTITIES SHOWN ARE FOR THE ASSEMBLY OF ONE CYCLONE.



VEOLIA WATER TECHNOLOGIES OF CANADA
PROJECT NO: 5000218009 / SERIAL NO: G169408U - G169411U

PART No : UIO-G169408

ITEM No.	PART NUMBER	DESCRIPTION
1.	C2293-RU-9.5	INLET HEAD WITH 4" VICTAULIC INLET CONNECTION, 9.5 SQUARE INCH INLET NOZZLE ORIFICE SIZE, URETHANE.
2.	C2294-RU-3	VORTEX FINDER, 3" SIZE, URETHANE.
3.	VIC-75-6	VICTAULIC COUPLING, 6" SIZE, STEEL.
4.	G7-1004-RN	GASKET, NEOPRENE.
5.	C2176-ST	BACKING PLATE HALF RING, STEEL. (2-SET)
6.	C2175-ST-MF	BACKING PLATE / MOUNTING PLATE, STEEL.
7.	G65-209560-RCS	CONE SECTION, ROYAL CAST / ULTRANE II.
8.	C1846-ST	BACKING FLANGE HALF RING, STEEL. 2 - SET.
9.	G7-1005-RN	GASKET, NEOPRENE.
10.	G63-066130A-ST	BACKING FLANGE, STEEL.
11.	G65-066130-RCS	CONE SECTION, ROYAL CAST / ULTRANE II.
12.	G7-1006-RN	GASKET, NEOPRENE.
13.	C7712-SS	CLAMP WITH HAND WHEEL, STAINLESS STEEL.
14.	G85-30ARCS-1.75	APEX, 1.75" SIZE, ROYAL CAST / ULTRANE II.
15.	C7728-SS	CLAMP, STAINLESS STEEL.
16.	C8135R-RS-8	SPLASH SKIRT, 3.25" I.D. X 8" LONG, ULTRANE II.

TAG NO.
C2-O11
C2-O12
C2-O21
C2-O22

TOLERANCE SCHEDULE: UNLESS OTHERWISE SPECIFIED.

-24" = ±1/4"	+24" thru 100" = ±1/2"	+100" = ±1"
(-600mm = ±6mm)	(+600mm thru 2500mm = ±12mm)	(+2500mm = ±25mm)

NOTES:

1. PAINT: EN-SPEC-4-304I (FOR STEEL PARTS ONLY)
2. BARE WEIGHT: 65# [30kg]

THIS DRAWING IS THE EXCLUSIVE PROPERTY OF FLSMIDTH KREBS, TUCSON, ARIZONA, AND CONTAINS INFORMATION WHICH IS PROPRIETARY TO FLSMIDTH KREBS. IT IS NOT TO BE COPIED OR DUPLICATED IN ANY MANNER, OR USED IN CONNECTION WITH THE MANUFACTURE AND/OR SALE OF ANY APPARATUS OR PARTS THEREOF, OR DISSEMINATED TO ANY THIRD PARTY WITHOUT THE PRIOR WRITTEN CONSENT OF FLSMIDTH KREBS. ANY AUTHORIZED REPRODUCTION OF THIS DRAWING, OR ANY PORTION THEREOF, SHALL INCLUDE THIS NOTICE.

FINAL CERTIFICATION

CERTIFIED FOR: Veolia Water Technologies of Canada

P.O. No. 18000759 HD 05000

S.O. No. 0219283

BY: *[Signature]* DATE 31-August-2018


5505 WEST GILLETTE ROAD
TUCSON, ARIZONA 85743
PHONE: (520) 744-8200 FAX: (520) 744-8300

FLSMIDTH KREBS

FLSMIDTH KREBS 5505 WEST GILLETTE ROAD TUCSON, AZ 85743 www.krebs.com		
Rev. Date: 04/27/2018 Appvd. By:	Scale: --- ISN Dwn. By: GS Date Drawn: 04-27-18 Appvd. By: ADG	Sheet: 1 OF 1
GENERAL PARTS ARRANGMENT KREBS CYCLONE MODEL U10-gMAX-3037 WITH FIXED APEX ASSEMBLY NO. G85-30A (SO: 0219283)		
© FLSMIDTH KREBS 2018		DWG. NO. S3037-G169408U

This page is intentionally left blank

9.50 SQ. IN. INLET ORIFICE



CAPACITY IS BASED ON WATER AT AMBIENT TEMPERATURE
AND APEX DIAMETER EQUAL TO ONE HALF THE VORTEX
FINDER DIAMETER, AND MAY VARY AT DIFFERENT RATIOS

LEFT BLANK



MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL
AMARUQ WTP – NUNAVUT
VEOLIA PROJECT: 5000 218 009

FLYGT

ENM-10, LEVEL SWITCH

WATER TECHNOLOGIES

LEFT BLANK



ENM 10

Table of Contents

Introduction and Safety.....	2
Introduction.....	2
Safety.....	2
Safety terminology and symbols.....	2
User safety and health.....	3
Product warranty.....	3
Product Description.....	5
Introduction.....	5
Process description.....	5
Material.....	6
Cable lengths.....	6
Electrical data.....	6
Electrical data for Ex-approved installation.....	7
Approvals.....	7
Ex-approvals.....	7
Mechanical Installation.....	8
Precautions.....	8
General.....	8
Electrical Installation.....	9
Precautions.....	9
Wiring diagrams.....	9
Connection for audible or visible alarm	10
Ex-installation.....	11
Maintenance.....	12
General.....	12

Introduction and Safety

Introduction



CAUTION:

- Read this manual carefully before installing and using the product. Improper use of the product can cause personal injury and damage to property, and may void the warranty.
- Observe accident prevention regulations in force.
- Save this manual for future reference, and keep it readily available at the location of the unit.

Purpose of this manual

The purpose of this manual is to provide the necessary information for:

- Installation
- Operation
- Maintenance

Safety

Precautions



WARNING:

- The operator must be aware of safety precautions to prevent physical injury.
- You must observe the instructions contained in this manual. Failure to do so could result in physical injury, damage, or delays.
- Before starting work on the unit, make sure that the unit and the control panel are isolated from the power supply and cannot be energized. This applies to the control circuit as well.[R]
- A certified electrician must supervise all electrical work. Comply with all local codes and regulations. [R]


Safety terminology and symbols



About safety messages

It is extremely important that you read, understand, and follow the safety messages and regulations carefully before handling the product. They are published to help prevent these hazards:

- Personal accidents and health problems
- Damage to the product
- Product malfunction

Hazard levels

Hazard level	Indication
 DANGER:	A hazardous situation which, if not avoided, will result in death or serious injury

Hazard level	Indication
 WARNING:	A hazardous situation which, if not avoided, could result in death or serious injury
 CAUTION:	A hazardous situation which, if not avoided, could result in minor or moderate injury
NOTICE:	<ul style="list-style-type: none"> • A potential situation which, if not avoided, could result in undesirable conditions • A practice not related to personal injury

Electrical hazards

Electrical hazards are indicated by the following specific symbol. This symbol warns for presence of a dangerous voltage.



Electrical Hazard:

User safety and health

Introduction

All government regulations, local health and safety directives must be observed.

Prevent danger due to electricity

All danger due to electricity must be avoided. Electrical connections must always be carried out in compliance with the following:

- The standard connections shown in the product documentation that is delivered together with the product
- All international, national, state, and local regulations. (For details, consult the regulations of your local electricity supplier.)

For more information about requirements, see sections dealing specifically with electrical connections.

Product warranty

Coverage

Xylem undertakes to remedy faults in products from Xylem under these conditions:

- The fault is due to defects in design, materials, or workmanship.
- The fault is reported to a Xylem representative within the warranty period.
- The product is used only under the conditions described in this manual.
- All service and repair work is done by qualified and authorized personnel. All modifications must be done by qualified technicians.
- Genuine Xylem parts are used.

Limitations

The warranty does not cover faults caused by these situations:

- Deficient maintenance
- Improper installation
- Modifications or changes to the product and installation made without consulting Xylem

- Incorrectly executed repair work
- Normal wear and tear

Xylem assumes no liability for these situations:

- Bodily injury
- Material damage
- Economic loss

Warranty claim

Xylem products are high quality products with expected reliable operation and long life. However, should the need arise for a warranty claim, then contact your Xylem representative.

Qualification of personnel

All work on the product should be carried out by certified electricians or Xylem authorized mechanics.

Xylem disclaims all responsibility for work done by untrained, unauthorized personnel.

Support

Xylem only supports products that have been tested and approved. Xylem does not support unapproved equipment.

Product Description

Introduction

Product description

The ENM-10 is the simplest possible method for level control. A mechanical switch in a plastic casing, freely suspended at the desired height from its own cable. When the liquid level reaches the regulator, the casing will tilt and the mechanical switch will close or break the circuit, thereby starting or stopping a pump or actuating an alarm device. No wear, no maintenance. In sewage pumping stations, for ground water and drainage pumping – in fact, for most level control applications – the ENM-10 is the ideal solution.

Liquid density

The product is available in different versions for different liquid densities.

Temperature limit

The regulator can withstand up to 60°C (140°F).

Manual coverage


This manual is applicable to the following versions:

- Standard version Blue casing of ENM-10
- EX-version Black casing of ENM-10.

Available languages

For manuals in other languages, visit tpi.xyleminc.com

Process description



WS004996A

1. When the pumped media reaches a predetermined level, the upper level regulator tips over to horizontal position and the pump starts to drain the basin.
2. The basin is drained of fluid.
3. The pump stops when the lower level regulator returns to the vertical position.
4. The basin fills up again. The process restarts.

Material

Standard version

Part	Material
Regulator casing	Polypropylene
Cable sheath	PVC or Nitrile/PVC rubber compound

The plastic components are welded and screwed together. Adhesive is never used. Impurities and deposits will not adhere to the smooth casing.

EX-version

The version for Ex-applications has a black casing, made conductive by adding carbon to the polypropylene.

Cable lengths

For liquids with specific density between 0.95 and 1.10 g/cm³, the following cables are available:

Version	Lengths m (ft)
Standard	<ul style="list-style-type: none"> • 6 m (20 ft) • 13 (42) • 20 (65) • 30 (100) • 50 (167)
Ex-version	<ul style="list-style-type: none"> • 6 m (20 ft) • 13 (42) • 20 (65) Nitrile/PVC rubber cable

Electrical data

Country	Electrical data
Canada	5 A, 250 V, DC 10 A, 250 V, AC
Denmark	10 A, 250 V, AC
Switzerland	6 A, 250 V, AC
Sweden	10 A, 230 V, AC Resistive load 3 A, 250 V, AC Inductive load 5 A, 30 V, DC Resistive load *1 mA, 5 V, DC, Gold Contact

* Part no: 594 79 19 and 594 79 20

Micro switch

The level regulator contains a micro switch, max rated 250 VAC/10 A.

Low-voltage supply

In many cases, local codes require that the regulator is connected to a low-voltage supply, even though it is approved for a higher voltage.

It is recommended that the regulator is connected to a low-voltage supply, 48 V or 24 V, and a protective transformer.

Electrical data for Ex-approved installation

Description	Data
Maximum input voltage, U_i	30 V
Maximum input current, I_i	100 mA
Maximum input power, P_i	1.2 W
Depth of immersion	Max 20 m

For cable

Description	Data
Maximum internal capacitance, C_i :	1.8 nF
Maximum internal inductance, L_i :	10 μ H

Installation

There are special rules that apply to installation in an explosive atmosphere. Intrinsically safe circuits are normally required: Ex i. Use a EX-safety barrier, for example, Prod. No. 84 01 07.

Approvals

CE, CSA, SEMKO, NEMKO, DEMKO, EX

LVD approval according to EN61058

CSA approval: Cert No. 1330172

Cl.I Zone 0, Gr. IIC;

CL.I Div.1 Gr A, B, C and D

Cl.II Gr. E, F and G

Cl.III when installed to the certified Intrinsically Safe relay, Ex ia, rated for the locations per submitter control drawing and installation manual.

Ex-approvals

IECEX ia IIC T4 Ga: $-20^{\circ}\text{C} < T_a < 60^{\circ}\text{C}$

IECEX NEMKO 09.008

ATEX II 1G ia IIC T4

NEMKO 10ATEX 1082

Applied standards

- EN 60079-0:2009/IEC 60079-0:2007
- EN 60079-11:2007/IEC 60079-0:2006
- EN 60079-26:2007/IEC 60079-26:2006

Intrinsically safe circuits are required for the automatic control system.

Use a Ex-safety barrier: For example, Prod. No. 84 01 07



Mechanical Installation

Precautions



CAUTION:

- Read this manual carefully before installing and using the product. Improper use of the product can cause personal injury and damage to property, and may void the warranty.
 - The operator must be aware of safety precautions to prevent physical injury.
-

General

To conform to local regulations, the regulators are normally connected through a transformer to a low-tension control circuit.

Make sure that two regulators are used, one for starting and one for stopping.

If an alarm is required at a given level, then connect a third regulator.

Identical regulators can be used for all functions.

Make sure that the cables do not become tangled during the installation.

The regulator cables must hang freely from each other.