

## 4.2 Hydraulic connection



### Warning

#### **Risk of chemical burns!**

**Wear protective clothing (gloves and goggles) when working on the dosing head, connections or lines!**

**The dosing head may contain water from the factory check!**

### Caution

**When dosing media which should not come into contact with water, another medium must be dosed beforehand!**

### Caution

**Faultless function can only be guaranteed in conjunction with lines supplied by Grundfos!**

### Caution


**The lines used must comply with the pressure limits as per section 3.1 Technical data!**

### Important information on installation

- Observe suction lift and line diameter, see section 3.1 Technical data.
- Shorten hoses at right angles.
- Ensure that there are no loops or kinks in the hoses.
- Keep suction line as short as possible.
- Route suction line up towards the suction valve.
- Installing a filter in the suction line protects the entire installation against dirt and reduces the risk of leakage.
- Only control variant FC/FCM: For discharge quantities < 1 l/h we recommend the use of an additional spring-loaded valve (approx. 3 bar) on the discharge side for the safe generation of the necessary differential pressure.

### Hose connection procedure

1. Push union nut and tensioning ring across hose.
2. Push cone part fully into hose, see fig. 8.
3. Attach cone part with hose to corresponding pump valve.
4. Tighten union nut manually.
  - Do not use tools!
5. Tighten up union nuts after 2-5 operating hours if using PTFE gaskets!
6. Attach deaeration hose to the corresponding connection (see fig. 3) and run into a container or a collecting tray.



**Fig. 8** Hydraulic connection

### Note


**Pressure differential between suction and discharge side must be at least 1 bar/14.5 psi!**

### Caution

**Tighten the dosing head screws with a torque wrench once before commissioning and again after 2-5 operating hours at 4 Nm.**

### Installation example

The pump offers various installation options. In the picture below, the pump is installed in conjunction with a suction line, level switch and multifunction valve on a Grundfos tank.



**Fig. 9** Installation example

### 4.3 Electrical connection



**Warning**

The enclosure class (IP65/Nema 4X) is only guaranteed if plugs or protective caps are correctly installed!



**Warning**

The pump can start automatically when the mains voltage is switched on!  
Do not manipulate mains plug or cable!



The mains plug is the separator separating the pump from the mains.

The rated voltage of the pump, see section 2.5 Nameplate, must conform to local conditions.

#### Signal connections



**Warning**

Electric circuits of external devices connected to the pump inputs must be separated from dangerous voltage by means of double or reinforced insulation!






Fig. 10 Wiring diagram of the electrical connections

TM04 1121 0110

## Analog, External stop and pulse input

	Function	Pins				Plug type
		1/brown	2/white	3/blue	4/black	
	Analog	GND/(-) mA	(+) mA			mA signal
	External stop	GND		X		Pulse
	Pulse	GND			X	Pulse


## Level signals: Empty signal and Low-level signal

	Function	Pins				Plug type
		1	2	3	4	
	Low-level signal	X		GND		Pulse
	Empty signal		X	GND		Pulse


## GENIbus, Analog output

**Caution**

*Danger of damage to the product due to short circuit! Pin 1 supplies 30 VDC.  
Never short-circuit pin 1 with any of the other pins!*

	Function	Pins					Plug type
		1/brown	2/white	3/blue	4/black	5/yellow/green	
	GENIbus	+30 V	GENI bus TXD	GENI bus RXD		GND	Bus
	Analog output				(+) mA	GND/(-) mA	mA signal

## Relay outputs

	Function	Pins				Plug type
		1/brown	2/white	3/blue	4/black	
	Relay 1	X			X	Pulse
	Relay 2		X	X		Pulse

## FlowControl signal connection




Fig. 11 FlowControl signal connection


TM04 1158 0110

## 5. Startup


### 5.1 Setting the menu language

For description of control elements, see section 6.


1. Turn click wheel to highlight the cog symbol.




2. Press the click wheel to open the "Setup" menu.




3. Turn the click wheel to highlight the "Language" menu.




4. Press the click wheel to open the "Language" menu.



5. Turn the click wheel to highlight the desired language.



6. Press the click wheel to select the highlighted language.



7. Press the click wheel again to confirm the "Confirm settings?" prompt and apply the setting.




Fig. 12 Set menu language



TM04 1184 1110

## 5.2 Deaerating the pump



### **Warning**

***The deaeration hose must be connected correctly and inserted into a suitable tank!***

1. Open deaeration valve by approximately half a turn.
2. Press and hold down the [100%] key (deaeration key) until liquid flows continuously without any bubbles from the deaeration hose.
3. Close deaeration valve.

***Press the [100%] key and simultaneously turn the click wheel clockwise to increase the duration of the process to up to 300 seconds. After setting the seconds, do not press the key any longer.***

### **Note**

## 5.3 Calibrating the pump

The pump is calibrated in the factory for media with a viscosity similar to water at maximum pump backpressure (see section 3.1 *Technical data*).

If the pump is operated with a backpressure that deviates or if dosing a medium whose viscosity deviates, the pump must be calibrated.


For pumps with FCM control variant, it is not necessary to calibrate the pump if there is deviating or fluctuating backpressure as long as the "AutoFlowAdapt" function has been enabled (see section 6.10 *AutoFlowAdapt*).

### **Requirements**

- The hydraulics and electrics of the pump are connected (see section 4. *Assembly and installation*).
- The pump is integrated into the dosing process under operating conditions.
- The dosing head and suction hose are filled with dosing medium.
- The pump has been deaerated.

**Calibration process - example for DDA 7.5-16**


1. Fill a measuring beaker with dosing medium.  
Recommended filling volumes  $V_1$ :
  - DDA 7.5-16: 0.3 l
  - DDA 12-10: 0.5 l
  - DDA 17-7: 1.0 l
  - DDA 30-4: 1.5 l



2. Read off and note down the fill volume  $V_1$  (e.g. 300 ml).
3. Place the suction hose in the measuring beaker.




4. Start the calibration process in the "Setup > Calibration" menu.




5. The pump executes 200 dosing strokes and displays the factory calibration value (e.g. 125 ml).




6. Remove the suction hose from the measuring beaker and check the remaining volume  $V_2$  (e.g. 170 ml).



7. From  $V_1$  and  $V_2$ , calculate the actual dosed volume  $V_d = V_1 - V_2$  (e.g. 300 ml - 170 ml = 130 ml).



8. Set and apply  $V_d$  in the calibration menu.
  - The pump is calibrated.



## 6. Operation

### 6.1 Control elements

The pump control panel includes a display and the following control elements.




Fig. 13 Control panel

#### Keys

Key	Function
[Start/stop] key	Starting and stopping the pump.
[100%] key	The pump doses at maximum flow regardless of the operation mode.

#### Click wheel

The click wheel is used to navigate through the menus, select settings and confirm them. Turning the click wheel clockwise moves the cursor clockwise in increments in the display. Turning the click wheel counter-clockwise moves the cursor counter-clockwise.

## 6.2 Display and symbols

### 6.2.1 Navigation

In the "Info", "Alarm" and "Setup" main menus, the options and submenus are displayed in the rows below. Use the "Back" symbol to return to the higher menu level. The scroll bar at the right edge of the display indicates that there are further menu items which are not shown.

The active symbol (current cursor position) flashes. Press the click wheel to confirm your selection and open the next menu level. The active main menu is displayed as text, the other main menus are displayed as symbols. The position of the cursor is highlighted in black in the sub-menus.

When you position the cursor on a value and press the click wheel, a value is selected. Turning the click wheel clockwise increases the value, turning the click wheel counter-clockwise reduces the value. When you now press the click wheel, the cursor will be released again.

### 6.2.2 Operating states

The operating state of the pump is indicated by a symbol and display colour.

Display	Fault	Operating state		
White	-	Stop	Standby	
Green	-			Running
Yellow	Warning	Stop	Standby	Running
Red	Alarm	Stop	Standby	

### 6.2.3 Sleep mode (energy-saving mode)

If in the "Operation" main menu the pump is not operated for 30 seconds, the header disappears. After two minutes, the display brightness is reduced.

If in any other menu the pump is not operated for two minutes, the display switches back to the "Operation" main menu and the display brightness is reduced. This state will be cancelled when the pump is operated or a fault occurs.

TM04 1104 2111

### 6.2.4 Overview of display symbols

The following display symbols may appear in the menus.




Fig. 14 Overview of display symbols

TM04 1161 1710




### 6.3 Main menus

The main menus are displayed as symbols at the top of the display. The currently active main menu is displayed as text.

#### 6.3.1 Operation

Status information such as the dosing flow, selected operation mode and operating state is displayed in the "Operation" main menu.



TM04 1157 2011

#### 6.3.2 Info

You can find the date, time and information about the active dosing process, various counters, product data and the service system status in the "Info" main menu. The information can be accessed during operation.

The service system can also be reset from here.



TM04 1106 1010


#### Counters

The "Info > Counters" menu contains the following counters:

Counters	Resettable
<b>Volume</b>	Yes
Total dosed volume [l] or US gallons	
<b>Operating hours</b>	No
Accumulated operating hours (pump switched on) [h]	
<b>Motor runtime</b>	No
Accumulated motor runtime [h]	
<b>Strokes</b>	No
Accumulated number of dosing strokes	
<b>Power on/off</b>	No
Accumulated frequency of switching mains voltage on	

#### 6.3.3 Alarm

You can view errors in the "Alarm" main menu.



TM04 1109 1010

Up to 10 warnings and alarms, together with their date, time and cause, are listed in chronological order. If the list is full, the oldest entry will be overwritten, see section 8. *Faults*.

#### 6.3.4 Setup

The "Setup" main menu contains menus for pump configuration. These menus are described in the following sections.

Note

**Check all pump settings after any change in the "Setup" menu.**

Setup	Section
Language	English > 5.1
Operation mode	Pulse > 6.4
Pulse memory*	> 6.4.2
Analog scaling	> 6.4.3
Batch volume*	1.06 l > 6.4.4
Dosing time[mm:ss]*	7:50 > 6.4.4
Dosing timer cycle*	> 6.4.5
Dosing timer week*	> 6.4.6
Analog output	Actual flow > 6.5
SlowMode	Off > 6.6
FlowControl active*	> 6.7
FlowControl*	> 6.7
Pressure monitoring*	> 6.8
AutoFlowAdapt*	> 6.10
Auto deaeration	> 6.11
Calibration	> 5.3
Key lock	Off > 6.12
Display	> 6.13
Time+date	> 6.14
Bus	> 6.15
Inputs/Outputs	> 6.16
Basic settings	> 6.17

\* These submenus are only displayed for specific default settings and control variants. The contents of the "Setup" menu also vary depending on the operation mode.



TM04 1110 1010

## 6.4 Operation modes

Six different operation modes can be set in the "Setup > Operation mode" menu.

- Manual, see section 6.4.1
- Pulse, see section 6.4.2
- Analog 0-20mA, see section 6.4.3
- Analog 4-20mA, see section 6.4.3
- Batch (pulse-based), see section 6.4.4
- Dosing timer cycle, see section 6.4.5
- Dosing timer week, see section 6.4.6

### 6.4.1 Manual

In this operation mode, the pump constantly doses the dosing flow set with the click wheel. The dosing flow is set in l/h or ml/h in the "Operation" menu. The pump automatically switches between the units. Alternatively, the display can be reset to US units (gph). See section 6.13 *Display Setup*.




Fig. 15 Manual mode

The setting range depends on the pump type:

Type	Setting range*	
	[l/h]	[gph]
DDA 7.5-16	0.0025 - 7.5	0.0007 - 2.0
DDA 12-10	0.012 - 12	0.0031 - 3.1
DDA 17-7	0.017 - 17	0.0045 - 4.5
DDA 30-4	0.03 - 30	0.0080 - 8.0

\* When the "SlowMode" function is active, the maximum dosing flow is reduced, see section 3.1 *Technical data*.

### 6.4.2 Pulse

In this operation mode, the pump doses the set dosing volume for each incoming (potential-free) pulse, e.g. from a water meter. The pump automatically calculates the optimum stroke frequency for dosing the set volume per pulse.

The calculation is based on:

- the frequency of external pulses
- the set dosing volume/pulse.




Fig. 16 Pulse mode

The dosing volume per pulse is set in ml/pulse in the "Operation" menu using the click wheel. The setting range for the dosing volume depends on the pump type:

Type	Setting range [ml/pulse]
DDA 7.5-16	0.0015 - 14.9
DDA 12-10	0.0029 - 29.0
DDA 17-7	0.0031 - 31.0
DDA 30-4	0.0062 - 62.0

The frequency of incoming pulses is multiplied by the set dosing volume. If the pump receives more pulses than it can process at the maximum dosing flow, it runs at the maximum stroke frequency in continuous operation. Excess pulses will be ignored if the memory function is not enabled.

#### Memory function

When the "Setup > Pulse memory" function is enabled, up to 65,000 unprocessed pulses can be saved for subsequent processing.



#### Warning

**Subsequent processing of saved pulses can cause local increase in concentration!**

The contents of the memory will be deleted by:

- Switching off the power supply
- Changing the operation mode
- Interruption (e.g. alarm, External stop).

### 6.4.3 Analog 0/4-20 mA

In this operation mode, the pump doses according to the external analog signal. The dosing volume is proportional to the signal input value in mA.

Operation mode	Input value [mA]	Dosing flow [%]
4-20 mA	$\leq 4.1$	0
	$\geq 19.8$	100
0-20 mA	$\leq 0.1$	0
	$\geq 19.8$	100

If the input value in operation mode 4-20 mA falls below 2 mA, an alarm is displayed and the pump stops. A cable break or signal transmitter error has occurred. The "Cable break" symbol is displayed in the "Signal and error display" area of the display.




Fig. 17 Analog scaling




Fig. 18 Analog operation mode

### Set analog scaling

Analog scaling refers to the assignment of the current input value to the dosing flow.

Changes of analog scaling affect also the analog output signal. See section 6.5 *Analog output*.

Analog scaling passes through the two reference points  $(I_1/Q_1)$  and  $(I_2/Q_2)$ , which are set in the "Setup > Analog scaling" menu. The dosing flow is controlled according to this setting.

#### Example 1 (DDA 7.5-16)

Analog scaling with positive gradient:




Fig. 19 Analog scaling with pos. gradient

In example 1, the reference points  $I_1 = 6$  mA,  $Q_1 = 1.5$  l/h and  $I_2 = 16$  mA,  $Q_2 = 7.5$  l/h have been set.

From 0 to 6 mA analog scaling is described by a line that passes through  $Q = 0$  l/h, between 6 mA and 16 mA it rises proportionally from 1.5 l/h to 7.5 l/h and from 16 mA onwards it passes through  $Q = 7.5$  l/h.

#### Example 2 (DDA 7.5-16)

Analog scaling with negative gradient (Operation mode 0-20 mA):




Fig. 20 Analog scaling with neg. gradient

In example 2, the reference points  $I_1 = 2$  mA,  $Q_1 = 7.5$  l/h and  $I_2 = 16$  mA,  $Q_2 = 1.3$  l/h have been set.

From 0 to 2 mA analog scaling is described by a line that passes through  $Q = 0$  l/h, between 2 mA and 16 mA it drops proportionally from 7.5 l/h to 1.3 l/h and from 16 mA onwards it passes through  $Q = 1.3$  l/h.

### Set analog scaling in the "Operation" menu

Analog scaling can also be modified after a security prompt directly in the "Operation" menu. This is how the dosing flow is directly modified for the current flow input value.

**Caution** Please observe that changes also have a direct effect on point  $I_2/Q_2$  (see fig. 21)!




Fig. 21 Set analog scaling ("Operation" menu)

#### 6.4.4 Batch (pulse-based)

In this operation mode, the pump doses the set batch volume in the set dosing time ( $t_1$ ). A batch is dosed with each incoming pulse.




Fig. 22 Batch (pulse-based)

The setting range depends on the pump type:

Type	Setting range per batch		
	from [ml]	to [l]	Resolution* [ml]
DDA 7.5-16	0.74	999	0.0925
DDA 12-10	1.45	999	0.1813
DDA 17-7	1.55	999	0.1938
DDA 30-4	3.10	999	0.3875

\* Thanks to the digital motor control, dosing quantities with a resolution of up to 1/8 of the dosing stroke volume can be dosed.

The batch volume (e.g. 75 ml) is set in the "Setup > Batch volume" menu. The minimum dosing time required for this (e.g. 36 seconds) is displayed and can be increased.




Fig. 23 Batch mode

Signals received during a batch process or an interruption (e.g. alarm, External stop) will be ignored. If the pump is restarted following an interruption, the next batch volume is dosed on the next incoming pulse.




Fig. 24 Batch mode

In the "Operation" menu, the total batch volume (e.g. 75 ml) and the remaining batch volume still to be dosed (e.g. 43 ml) are shown in the display.

#### 6.4.5 Dosing timer cycle

In this operation mode, the pump doses the set batch volume in regular cycles. Dosing starts when the pump is started after a singular start delay. The setting range for the batch volume corresponds to the values in section 6.4.4 *Batch (pulse-based)*.

**Warning**  
**When time or date is changed in "Time+date" menu, timer dosing and timer relay output functions (Relay 2) are stopped!**  
**Timer dosing and timer relay output functions must be restarted manually!**  
**Changing time or date can cause increase or decrease in concentration!**




Fig. 25 Dosing timer cycle diagram

$t_1$	Dosing time
$t_2$	Start delay
$t_3$	Cycle time

In the event of an interruption (e.g. interruption of the mains voltage, External stop), the dosing will be stopped while the time continues running. After suspending the interruption, the pump will continue to dose according to the actual timeline position.

The following settings are required in the "Setup > Dosing timer cycle" menu:

Timer	
Batch volume	125ml
Dosing time[mm:ss]	1:54
Cycle time[mm:ss]	3:00
Start delay[mm:ss]	2:00

Fig. 26 Dosing timer cycle

The batch volume to be dosed (e.g. 125 ml) is set in the "Setup > Dosing timer cycle" menu. The dosing time required for this (e.g. 1:54) is displayed and can be changed.

The total batch volume (e.g. 125 ml) and the remaining batch volume still to be dosed are displayed in the "Operation" menu. During breaks in dosing, the time until the next dosing process (e.g. 1:21) is displayed.




Fig. 27 Dosing timer cycle

#### 6.4.6 Dosing timer week

In this operation mode, up to 16 dosing procedures are defined for a week. These dosing procedures may take place regularly on one or several week days. The setting range for the batch volume corresponds to the values in section 6.4.4 *Batch (pulse-based)*.

**Warning**  
**When time or date is changed in "Time+date" menu, timer dosing and timer relay output functions (Relay 2) are stopped!**  
**Timer dosing and timer relay output functions must be restarted manually!**  
**Changing time or date can cause increase or decrease in concentration!**




Fig. 28 Example for Dosing timer week function

**Note**  
**If several procedures overlap, the process with the higher dosing flow has priority!**

In the event of an interruption (e.g. disconnection of the mains voltage, External stop), the dosing is stopped while the time continues running. After suspending the interruption, the pump continues to dose according to the actual timeline position.

The following settings are required in the "Setup > Dosing timer week" menu for each dosing procedure:




Fig. 29 Setting the timer

The batch volume (e.g. 80.5 ml) is set in the "Setup > Dosing timer week" menu. The dosing time required for this (e.g. 39.0) is displayed and can be changed. In the "Operation" menu, the total batch volume (e.g. 80.5 ml) and the remaining batch volume to be dosed is displayed. During breaks in dosing, the time (e.g. 43:32) until the next dosing is displayed.




Fig. 30 Weekly timer dosing (break in dosing)

## 6.5 Analog output




Fig. 31 Configure analog output

The analog output of the pump is parametrised in the "Setup > Analog output" menu. The following settings are possible:

Setting	Description of output signal	Variant		
		FCM	FC	AR
Output = Input	Analog feedback signal (not for master-slave application). The analog input signal is mapped 1:1 to the analog output.	X	X	X
Actual flow**	Current actual flow • 0/4 mA = 0 % • 20 mA = 100 % see section 6.9 <i>Flow measurement</i>	X	X*	X*
Backpressure	Backpressure, measured in the dosing head • 0/4 mA = 0 bar • 20 mA = Max. operating pressure see section 6.8 <i>Pressure monitoring</i>	X	X	
Bus control	Enabled by command in Bus control, see section 6.15 <i>Bus communication</i>	X	X	X

\* Output signal is based on motor speed and pump status (target flow).

\*\* Signal has same analog scaling as the current analog input signal. See 6.4.3 *Analog 0/4-20 mA*.

Wiring diagram see section 4.3 *Electrical connection*.

**In all operation modes, the analog output has a range of 4-20 mA. Exception: Operation mode 0-20 mA. Here, the analog output range is 0-20 mA.**

Note

## 6.6 SlowMode




When the "SlowMode" function is enabled, the pump slows down the suction stroke. The function is enabled in the "Setup > SlowMode" menu and is used to prevent cavitation in the following cases:

- for dosing media with a high viscosity
- for degassing dosing media
- for long suction lines
- for large suction lift.

In the "Setup > SlowMode" menu, the speed of the suction stroke can be reduced to 50 % or 25 %.

**Caution**

***Enabling the 'SlowMode' function reduces the maximum dosing flow of the pump to the set percentage value!***



TM04 1153 1110

**Fig. 32** SlowMode menu

## 6.7 FlowControl

*Applies to DDA-FC/FCM control variant.*

This function is used to monitor the dosing process. Although the pump is running, various influences e.g. air bubbles, can cause a reduced flow or even stop the dosing process. In order to guarantee optimum process safety, the enabled "FlowControl" function directly detects and indicates the following errors and deviations:

- Overpressure
- Damaged discharge line
- Air in the dosing chamber
- Cavitation
- Suction valve leakage > 70 %
- Discharge valve leakage > 70 %.

The occurrence of a fault is indicated by the "eye" symbol flashing. The faults are displayed in the "Alarm" menu (see section 8. *Faults*).



FlowControl works with a maintenance-free sensor in the dosing head. During the dosing process, the sensor measures the current pressure and continuously sends the measured value to the microprocessor in the pump. An internal indicator diagram is created from the current measured values and the current diaphragm position (stroke length). Causes for deviations can be identified immediately by aligning the current indicator diagram with a calculated optimum indicator diagram. Air bubbles in the dosing head reduce e.g. the discharge phase and consequently the stroke volume (see fig. 33).

Requirements for a correct indicator diagram are:

- FlowControl function is active
- pressure difference between suction and discharge side is > 2 bar
- No interruption/pause in discharge stroke
- Pressure sensor and cable are functioning properly
- No leakage > 50 % in suction or discharge valve

If one of these requirements is not met, the indicator diagram cannot be evaluated.




Fig. 33 Indicator diagram

1	Compression phase
2	Discharge phase
3	Expansion phase
4	Suction phase

### Setting FlowControl

The "FlowControl" function is set using the two parameters "Sensitivity" and "Delay" in the "Setup > FlowControl" menu.

### Sensitivity

In "Sensitivity" the deviation in stroke volume, which will result in an error message, is set in percent.

Sensitivity	Deviation
low	approx. 70 %
medium	approx. 50 %
high	approx. 30 %



### Delay

The "Delay" parameter is used to define the time period until an error message is generated: "short", "medium" or "long". The delay depends on the set dosing flow and therefore cannot be measured in strokes or time.

### Air bubbles

The "FlowControl" function identifies air bubbles > 60 % of the stroke volume. After switching to "Air bubble" warning status, the pump adapts the stroke frequency to approximately 30-40 % of max. stroke frequency, and starts a special motor drive strategy. The adaptation of the stroke frequency allows the air bubbles to rise from suction to discharge valve. Due to the special motor drive strategy the air bubbles are displaced from the dosing head into the discharge line.

If the air bubbles have not been eliminated after a maximum of 60 strokes, the pump returns to the normal motor drive strategy.

## 6.8 Pressure monitoring

*Applies to DDA-FC/FCM control variant.*

A pressure sensor monitors the pressure in the dosing head. If the pressure during the discharge phase falls below 2 bar, a warning is generated (pump continues running). If in the "Setup > Pressure monitoring" menu the function "Min. pressure alarm" is activated, an alarm is generated and the pump is stopped.

If the pressure exceeds the "Max. pressure" set in the "Setup > Pressure monitoring" menu, the pump is shut down, enters the standby state and indicates an alarm.

### Caution

**The pump restarts automatically once the backpressure falls below the set "Max. pressure"!**

### 6.8.1 Pressure setting ranges

Type	Fixed min. pressure [bar]	Adjustable max. pressure [bar]
DDA 7.5-16	< 2	3-17
DDA 12-10	< 2	3-11
DDA 17-7	< 2	3-8
DDA 30-4	< 2	3-5



### Warning

**Install a pressure-relief valve in the pressure line to provide protection against impermissibly high pressure!**

**The pressure measured in the dosing head is slightly higher than the actual system pressure.**

### Caution

**Therefore the "Max. pressure" should be set at least 0.5 bar higher than the system pressure.**

### 6.8.2 Calibration of pressure sensor

The pressure sensor is calibrated in the factory. As a rule, it does not need to be re-calibrated. If specific circumstances (e.g. pressure sensor exchange, extreme air pressure values at the location of the pump) necessitate a calibration, the sensor can be calibrated as follows:


1. Set pump to "Stop" operating state.
2. Make system pressureless and flush.
3. Dismantle suction line and suction valve.

### Warning

**Calibrating when the suction valve is installed produces incorrect calibration and can cause personal injuries and damage to property!**

**Only carry out a calibration if this is technically required!**

4. Proceed as described below to calibrate:



If a calibration is not successfully possible, check plug connections, cable and sensor and replace defective parts where necessary.

TM04 1145 2510

## 6.9 Flow measurement

*Applies to DDA-FCM control variant.*

The pump accurately measures the actual flow and displays it. Via the 0/4-20 mA analog output, the actual flow signal can easily be integrated into an external process control without additional measuring equipment (see section 6.5 *Analog output*).

The flow measurement is based on the indicator diagram as described in section 6.7 *FlowControl*. The accumulated length of the discharge phase multiplied by the stroke frequency produces the displayed actual flow. Faults e.g. air bubbles or backpressure that is too low result in a smaller or larger actual flow. When the "AutoFlowAdapt" function is activated (see section 6.10 *AutoFlowAdapt*), the pump compensates for these influences by correction of the stroke frequency.

**Strokes which cannot be analysed (partial strokes, pressure differential which is too low) are provisionally calculated based on the setpoint value and displayed.**

Note

## 6.10 AutoFlowAdapt

*Applies to DDA-FCM control variant.*

The "AutoFlowAdapt" function is activated in the "Setup" menu. It detects changes in various parameters and responds accordingly in order to keep the set target flow constant.

Note

**Dosing accuracy is increased when "AutoFlowAdapt" is activated.**

This function processes information from the pressure sensor in the dosing head. Errors detected by the sensor are processed by the software.

The pump responds immediately regardless of the operation mode by adjusting the stroke frequency or where necessary compensating for the deviations with a corresponding indicator diagram.

If the target flow cannot be achieved by the adjustments, a warning is issued.

"AutoFlowAdapt" operates on the basis of the following functions:

- FlowControl: malfunctions are identified (see section 6.7 *FlowControl*).
- Pressure monitoring: pressure fluctuations are identified (see section 6.8 *Pressure monitoring*).
- Flow measurement: deviations from the target flow are identified (see section 6.9 *Flow measurement*).

## Example of "AutoFlowAdapt"

### Pressure fluctuations

The dosing volume decreases as backpressure increases and conversely the dosing volume increases as the backpressure decreases.

The "AutoFlowAdapt" function identifies pressure fluctuations and responds by adjusting the stroke frequency. The actual flow is thus maintained at a constant level.

## 6.11 Auto deaeration

Dosing degassing media can result in air pockets in the dosing head during breaks in dosing. This can result in no medium being dosed when restarting the pump. The "Setup > Auto deaeration" function performs pump deaeration automatically at regular intervals. Software-controlled diaphragm movements encourage any bubbles to rise and gather at the discharge valve so that they can be removed on the next dosing stroke.

The function works:

- when the pump is not in the "Stop" operating state
- during breaks in dosing (e.g. External stop, no incoming pulses, etc.).

**The diaphragm movements can displace small volumes into the discharge line. When dosing strongly degassing media, this is however virtually impossible.**

Note

## 6.12 Key lock

The key lock is set in the "Setup > Key lock" menu by entering a four-digit code. It protects the pump by preventing changes to settings. Two levels of key lock can be selected:

Level	Description
Settings	All settings can only be changed by entering the lock code. The [Start/stop] key and the [100%] key are not locked.
Settings + keys	The [Start/stop] key and the [100%] key and all settings are locked.

It is still possible to navigate in the "Alarm" and "Info" main menu and reset alarms.

### 6.12.1 Temporary deactivation

If the "Key lock" function is activated but settings need to be modified, the keys can be unlocked temporarily by entering the deactivation code. If the code is not entered within 10 seconds, the display automatically switches to the "Operation" main menu. The key lock remains active.

### 6.12.2 Deactivation

The key lock can be deactivated in the "Setup > Key lock" menu via the "Off" menu point. The key lock is deactivated after the general code "2583" or a pre-defined custom code has been entered.

### 6.13 Display Setup

Use the following settings in the "Setup > Display" menu to adjust the display properties:

- Units (metric/US)
- Display contrast
- Additional display.

#### 6.13.1 Units

Metric units (litres/millilitres/bar) or US units (US gallons/PSI) can be selected. According to the operation mode and menu, the following units of measurement are displayed:

Operation mode / function	Metric units	US units
Manual control	ml/h or l/h	gph
Pulse control	ml/□	ml/□
0/4-20 mA Analog control	ml/h or l/h	gph
Batch (pulse- or timer-controlled)	ml or l	gal
Calibration	ml	ml
Volume counter	l	gal
Pressure monitoring	bar	psi

#### 6.13.2 Additional display

The additional display provides additional information about the current pump status. The value is shown in the display with the corresponding symbol.

In "Manual" mode the "Actual flow" information can be displayed with Q = 1.28 l/h (see fig. 34).




Fig. 34 Display with additional display

The additional display can be set as follows:

Setting	Description
Default display	Depending on the operation mode:
	Q Actual flow (Manual/Pulse) <sup>1), 2)</sup>
	Q Target flow (Pulse)
	→ Input current (analog)
	□ Remaining batch volume (Batch, Timer)
Dosed volume	t□ Period until next dosing (Timer)
	V Dosed vol. since last reset (see <i>Counters</i> on page 21)
Actual flow	Q Current actual flow <sup>1)</sup>
Backpressure	P Current backpressure in the dosing head <sup>3)</sup>

<sup>1)</sup> only DDA-FCM control variant

<sup>2)</sup> only if indicator diagram can be evaluated (see 6.7 *FlowControl*)

<sup>3)</sup> only DDA-FCM/FC control variant

### 6.14 Time+date

The time and date can be set in the "Setup > Time+date" menu.

#### Warning

**When time or date is changed in "Time+date" menu, timer dosing and timer relay output functions (Relay 2) are stopped!**

**Timer dosing and timer relay output functions must be restarted manually! Changing time or date can cause increase or decrease in concentration!**



**The conversion between summer and winter time does not take place automatically!**

Caution

TM04 1151 2011

## 6.15 Bus communication

The bus communication enables remote monitoring and setting of the pump via a fieldbus system.

Further manuals, functional profiles and support files (e.g. GSD-files) are available on the CD delivered with the interface hardware and on [www.grundfos.com](http://www.grundfos.com).

### 6.15.1 GENIbus communication

The pump is supplied with an integrated module for GENIbus communication. The pump identifies the bus control after connecting to the corresponding signal input. The "Activate communication?" prompt is displayed. After confirmation, the corresponding symbol appears in the "Activated functions" area in the "Operation" menu.

In the "Setup > Bus" menu the GENIbus address can be set from 32 to 231 and bus control can be deactivated.



Fig. 35 Bus menu

#### Caution

**The maximum cable length for GENIbus connection is 3 m and must not be exceeded!**

### 6.15.2 Possible industrial bus types

The pump can be integrated into several networks using the additional E-box (Extension-Box).

Bus type	Interface hardware	Retrofitting possible for pump software
Profibus® DP	E-Box 150	V2.0 and higher
Modbus RTU	E-Box 200	V2.5 and higher

The pump can also be connected to a Grundfos CIU unit (CIU = Communication Interface Unit) equipped with one of the following CIM modules (CIM = Communication Interface Module):

- CIM150 Profibus
- CIM200 Modbus
- CIM270 GRM
- CIM500 Ethernet

For internal communication between the E-Box/CIU and the dosing pump, GENIbus is used.

#### Caution

**The maximum cable length for GENIbus connection is 3 m and must not be exceeded!**

#### Caution

**Prior to installation and start-up, read the documentation delivered with the E-Box or CIU unit!**

## BUS

### 6.15.3 Activate communication

1. Set the pump to operating state "Stop" with the [Start/stop] key.
2. Switch off the power supply of the pump.
3. Install and connect the E-Box/CIU as described in the respective separate installation and operating instructions.
4. Switch on the power supply of the pump.

The "Activate communication?" prompt is displayed.

After confirmation, the "Bus" symbol appears in the "Activated functions" area of the "Operation" menu, no matter if the prompt was accepted or refused.

If the prompt has been accepted, the bus control function is activated. If the prompt has been refused, bus control function can be activated in "Setup > Bus" menu.



Fig. 36 Example of submenu for Profibus®

### 6.15.4 Setting the bus address

1. Enter "Setup > Bus" menu and set desired bus address:

Bus type	Address range
Profibus® DP	0 - 126
Modbus RTU	1 - 247

2. The pump needs to be restarted to initialise the new bus address. Switch off the power supply of the pump and wait for approximately 20 seconds.
3. Switch on the power supply of the pump.

The pump is initialised with the new bus address.

TM04 1139 2410

TM04 1139 2410

#### 6.15.5 Characteristics of bus communication

To start and stop the pump via bus, it needs to be in operating state "Running". When the pump is remotely stopped from bus, the "External stop" symbol is displayed and the pump switches to operating state "Standby".

While bus control function is activated, the "Setup" menu only shows the "Bus" and "Key lock" submenus. The other main menus, the "External stop" function and the keys are still available.

All operation modes (see section 6.4 *Operation modes*) can still be used when bus control is activated. This allows to use the bus control only for monitoring and setting the pump. In this case the respective "BusWatchDog" (see functional profile on E-Box/CIU product CD) should be deactivated in bus control, because otherwise faults in communication can stop the pump.

#### Note

**To change any settings manually, the bus control function must be deactivated temporarily.**

The analog output can not be used while the pump is bus-controlled as both functions use the same electrical connection. See section 4.3 *Electrical connection*.

#### 6.15.6 Deactivate communication



#### Warning

**After deactivating the bus control function, the pump can start automatically!**

**Before deactivating the bus control function, set the pump to operating state "Stop"!**

Bus control function can be deactivated in the "Setup > Bus" menu. After deactivation all submenus in "Setup" menu are available.

The "Bus" symbol in the display disappears at next restart of the pump, after the E-Box/CIU plug was disconnected.

#### Caution

**After disconnecting any plug, always refit protective cap!**

#### 6.15.7 Communication faults

Faults are only detected, if the respective "BusWatchDog" (see functional profile on E-Box/CIU product CD) is activated.



#### Warning

**After a communication fault is repaired, the pump can start automatically, depending on current bus control and pump settings!**

**Before repairing any fault, set the pump to operating state "Stop"!**

In case of bus communication faults (e.g. communication cable break), the pump stops dosing and switches to operating state "Standby" approximately 10 seconds after the fault was detected. An alarm is triggered, detailing the cause of the fault. See section 8. *Faults*.

## 6.16 Inputs/Outputs

In the "Setup > Inputs/Outputs" menu, you can configure the two outputs "Relay 1+Relay 2" and the signal inputs "External stop", "Empty signal" and "Low-level signal".




Fig. 37 Inputs/Outputs menu



### Warning

**When time or date is changed in "Time+date" menu, timer dosing and timer relay output functions (Relay 2) are stopped!**

**Timer dosing and timer relay output functions must be restarted manually!**

**Changing time or date can cause increase or decrease in concentration!**

### 6.16.1 Relay outputs

The pump can switch two external signals using installed relays. The relays are switched by potential-free pulses. The connection diagram of the relays is shown in section 4.3 *Electrical connection*. Both relays can be allocated with the following signals:

Relay 1 signal	Relay 2 signal	Description
Alarm*	Alarm	Display red, pump stopped (e.g. empty signal, etc.)
Warning*	Warning	Display yellow, pump is running (e.g. low-level signal, etc.)
Stroke signal	Stroke signal	Each full stroke
Pump dosing	Pump dosing*	Pump running and dosing
Pulse input**	Pulse input**	Each incoming pulse from pulse input
Bus control	Bus control	Activated by a command in the bus communication
	Timer Cycle	See following sections
	Timer Week	See following sections
<b>Contact type</b>		
NO*	NO*	Normally open contact
NC	NC	Normally closed contact

\* Factory setting

\*\* The correct transmission of incoming pulses can only be guaranteed up to a pulse frequency of 5 Hz.

TM04 1152 1110

### Timer Cycle (Relay 2)

For the "Relay 2 > Timer Cycle" function, set the following parameters:

- On ( $t_1$ )
- Start delay ( $t_2$ )
- Cycle time ( $t_3$ )




Fig. 38 Diagram

### Timer Week (Relay 2)

This function saves up to 16 relay on-times for a week. The following settings can be made for each relay switching operation in the "Relay 2 > Timer Week" menu:

- Procedure (No.)
- On time (duration)
- Start time
- Weekdays.

#### 6.16.2 External stop

The pump can be stopped via an external pulse, e.g. from a control room. When activating the external stop pulse, the pump switches from the operating state "Running" into the operating state "Standby". The corresponding symbol appears in the "Signal/error display" area of the display.

**Frequent disengagement from the mains voltage, e.g. via a relay, can result in damage to the pump electronics and in the breakdown of the pump. The dosing accuracy is also reduced as a result of internal start procedures.**

**Caution**



**Do not control the pump via the mains voltage for dosing purposes!**

**Only use the "External stop" function to start and stop the pump!**

The contact type is factory-set to normally open contact (NO). In the "Setup > Inputs/Outputs > External stop" menu, the setting can be changed to normally closed contact (NC).

#### 6.16.3 Empty and Low level signals

In order to monitor the filling level in the tank, a dual-level sensor can be connected to the pump. The pump responds to the signals as follows:

Sensor signal	Pump status
Low level	<ul style="list-style-type: none"> <li>• Display is yellow</li> <li>•  Flashes</li> <li>• Pump continues running</li> </ul>
Empty	<ul style="list-style-type: none"> <li>• Display is red</li> <li>•  Flashes</li> <li>• Pump stops</li> </ul>

**Caution** *When the tank is filled up again, the pump restarts automatically!*

Both signal inputs are allocated to the normally open contact (NO) in the factory. They can be re-allocated in the "Setup > Inputs/Outputs" menu to normally closed contact (NC).

#### 6.17 Basic settings

All settings can be reset to the settings default upon delivery in the "Setup > Basic settings" menu.

Selecting "Save customer settings" saves the current configuration to the memory. This can then be activated using "Load customer settings".

The memory always contains the previously saved configuration. Older memory data is overwritten.

## 7. Service



In order to ensure a long service life and dosing accuracy, wearing parts such as diaphragms and valves must be regularly checked for signs of wear. Where necessary, replace worn parts with original spare parts made from suitable materials.

Should you have any questions, please contact your service partner.



### Warning

**Maintenance work must only be carried out by qualified staff.**

### 7.1 Regular maintenance

Interval	Task
Daily	Check, if liquid leaks from the drain opening (fig. 41, pos. 11) and if the drain opening is blocked or soiled. If so, follow the instructions given in section 7.6 <i>Diaphragm breakage</i> .
	Check, if liquid leaks from the dosing head or valves. If necessary, tighten dosing head screws with a torque wrench at 4 Nm. If necessary, tighten valves and cap nuts, or perform service (see 7.4 <i>Perform service</i> ).
	Check, if a service requirement is present at the pump display. If so, follow the instructions given in section 7.3 <i>Service system</i> .
Weekly	Clean all pump surfaces with a dry and clean cloth.
Every 3 months	Check dosing head screws. If necessary, tighten dosing head screws with a torque wrench at 4 Nm. Replace damaged screws immediately.

### 7.2 Cleaning

If necessary, clean all pump surfaces with a dry and clean cloth.

### 7.3 Service system

According to the motor runtime or after a defined period of operation, service requirements will appear. Service requirements appear regardless of the current operating state of the pump and do not affect the dosing process.

Service requirement	Motor runtime [h]*	Time interval [months]*
Service soon!	7500	23
Service now!	8000	24

\* Since the last service system reset




Fig. 39 Service soon!




Fig. 40 Service now!

#### Caution

**For media which result in increased wear, the service interval must be shortened.**

The service requirement signals when the replacement of wearing parts is due and displays the number of the service kit. Press the click wheel to temporarily hide the service prompt.

When the "Service now!" message appears (displayed daily), the pump must be serviced immediately. The symbol appears in the "Operation" menu.

The number of the service kit required is also displayed in the "Info" menu.

TM04 1131 1110

TM04 1131 1110



## 7.4 Perform service

Only spare parts and accessories from Grundfos should be used for maintenance. The usage of non-original spare parts and accessories renders any liability for resulting damages null and void. Further information about carrying out maintenance can be found in the service kit catalogue on our homepage. See [www.grundfos.com](http://www.grundfos.com).

**Warning**  
**Risk of chemical burns!**  
**When dosing dangerous media, observe the corresponding precautions in the safety data sheets!**  
**Wear protective clothing (gloves and goggles) when working on the dosing head, connections or lines!**  
**Do not allow any chemicals to leak from the pump. Collect and dispose of all chemicals correctly!**



Caution

**Before any work to the pump, the pump must be in the "Stop" operating state or be disconnected from the power supply. The system must be pressureless!**

### 7.4.1 Dosing head overview




Fig. 41 Changing the diaphragm and valves

1	Safety diaphragm
2	Flange
3	O-ring
4	Diaphragm
5	Valve on discharge side
6	Valve on suction side
7	Dosing head
8	Screws with discs
9	Cover
10	Deaeration valve
11	Drain opening

### 7.4.2 Dismantling the diaphragm and valves

**Warning**  
**Danger of explosion, if dosing liquid has entered the pump housing!**  
**If the diaphragm is possibly damaged, don't connect the pump to the power supply! Proceed as described in section 7.6 Diaphragm breakage!**




This section refers to fig. 41.

1. Make system pressureless.
  2. Empty dosing head before maintenance and flush it if necessary.
  3. Set pump to "Stop" ■ operating state using the [Start/stop] key.
  4. Press the [Start/stop] and [100%] keys at the same time to put the diaphragm into "out" position.  
– Symbol (– must be displayed (see fig. 14).
  5. Take suitable steps to ensure that the returning liquid is safely collected.
  6. Dismantle suction, pressure and deaeration hose.
  7. Dismantle valves on suction and discharge side (5, 6).
  8. Remove the cover (9).
  9. Loosen screws (8) on the dosing head (7) and remove with discs.
  10. Remove the dosing head (7).
  11. Unscrew diaphragm (4) counter-clockwise and remove with flange (2).
  12. Make sure the drain opening (11) is not blocked or soiled. Clean if necessary.
  13. Check the safety diaphragm (1) for wear and damage. Replace if necessary.
- If nothing indicates that dosing liquid has entered the pump housing, go on as described in section 7.4.3 Reassembling the diaphragm and valves. Otherwise proceed as described in section 7.6.2 Dosing liquid in the pump housing.

### 7.4.3 Reassembling the diaphragm and valves

The pump must only be reassembled, if nothing indicates that dosing liquid has entered the pump housing. Otherwise proceed as described in section 7.6.2 *Dosing liquid in the pump housing*.

This section refers to fig. 41.

1. Attach flange (2) correctly and screw on new diaphragm (4) clockwise.
  - Make sure that the O-ring (3) is seated correctly!
2. Press the [Start/stop] and [100%] keys at the same time to put the diaphragm into "in" position.
  - Symbol  must be displayed (see fig. 14).
3. Attach the dosing head (7).
4. Install screws with discs (8) and cross-tighten with a torque wrench.
  - Torque: 4 Nm.
5. Attach the cover (9).
6. Install new valves (5, 6).
  - Do not interchange valves and pay attention to direction of arrow.
7. Connect suction, pressure and deaeration hose (see section 4.2 *Hydraulic connection*)
8. Press the [Start/stop] key to leave the service mode.

***Tighten the dosing head screws with a torque wrench once before commissioning and again after 2-5 operating hours at 4 Nm.***

**Caution**

9. Deaerate dosing pump (see section 5.2 *Deaerating the pump*).
10. Please observe the notes on commissioning in section 5. *Startup!*

### 7.5 Resetting the service system

After performing the service, the service system must be reset using the "Info > Reset service system" function.

### 7.6 Diaphragm breakage

If the diaphragm leaks or is broken, dosing liquid escapes from the drain opening (fig. 41, pos. 11) on the dosing head.

In case of diaphragm breakage, the safety diaphragm (fig. 41, pos. 1) protects the pump housing against ingress of dosing liquid.

When dosing crystallising liquids the drain opening can be blocked by crystallisation. If the pump is not taken out of operation immediately, a pressure can build up between the diaphragm (fig. 41, pos. 4) and the safety diaphragm in the flange (fig. 41, pos. 2). The pressure can press dosing liquid through the safety diaphragm into the pump housing.

Most dosing liquids don't cause any danger when entering the pump housing. However a view liquids can cause a chemical reaction with inner parts of the pump. In the worst case, this reaction can produce explosive gases in the pump housing.

#### **Warning**

***Danger of explosion, if dosing liquid has entered the pump housing!***

***Operation with damaged diaphragm can lead to dosing liquid entering the pump housing.***

***In case of diaphragm breakage, immediately separate the pump from the power supply!***

***Make sure the pump cannot be put back into operation by accident!***

***Dismantle the dosing head without connecting the pump to the power supply and make sure no dosing liquid has entered the pump housing.***

***Proceed as described in section 7.6.1 Dismantling in case of diaphragm breakage.***



To avoid any danger resulting from diaphragm breakage, observe the following:

- Perform regular maintenance. See section 7.1 *Regular maintenance*.
- Never operate the pump with blocked or soiled drain opening.
  - If the drain opening is blocked or soiled, proceed as described in section 7.6.1 *Dismantling in case of diaphragm breakage*.
- Never attach a hose to the drain opening. If a hose is attached to the drain opening, it is impossible to recognise escaping dosing liquid.
- Take suitable precautions to prevent harm to health and damage to property from escaping dosing liquid.
- Never operate the pump with damaged or loose dosing head screws.

### 7.6.1 Dismantling in case of diaphragm breakage



**Warning**

***Danger of explosion, if dosing liquid has entered the pump housing!***

***Do not connect the pump to the power supply!***

This section refers to fig. 41.

1. Make system pressureless.
2. Empty dosing head before maintenance and flush it if necessary.
3. Take suitable steps to ensure that the returning liquid is safely collected.
4. Dismantle suction, pressure and deaeration hose.
5. Remove the cover (9).
6. Loosen screws (8) on the dosing head (7) and remove with discs.
7. Remove the dosing head (7).
8. Unscrew diaphragm (4) counter-clockwise and remove with flange (2).
9. Make sure the drain opening (11) is not blocked or soiled. Clean if necessary.
10. Check the safety diaphragm (1) for wear and damage. Replace if necessary.

If nothing indicates that dosing liquid has entered the pump housing, go on as described in section 7.4.3 *Reassembling the diaphragm and valves*.

Otherwise proceed as described in section 7.6.2 *Dosing liquid in the pump housing*.

### 7.6.2 Dosing liquid in the pump housing



**Warning**

***Danger of explosion!***

***Immediately separate the pump from the power supply!***

***Make sure the pump cannot be put back into operation by accident!***

If dosing liquid has entered the pump housing:

- Send the pump to Grundfos for repair, following the instructions given in section 7.7 *Repairs*.
- If a repair isn't economically reasonable, dispose of the pump observing the information in section 9. *Disposal*.

### 7.7 Repairs



**Warning**

***The pump housing must only be opened by personnel authorised by Grundfos!***

***Repairs must only be carried out by authorised and qualified personnel!***

***Switch off the pump and disconnect it from the voltage supply before carrying out maintenance work and repairs!***

After consulting Grundfos, please send the pump, together with the safety declaration completed by a specialist, to Grundfos. The safety declaration can be found at the end of these instructions. It must be copied, completed and attached to the pump.

***The pump must be cleaned prior to dispatch!***

**Caution**

***If dosing liquid has possibly entered the pump housing, state that explicitly in the safety declaration! Observe section 7.6 Diaphragm breakage.***

If the above requirements are not met, Grundfos may refuse to accept delivery of the pump. The shipping costs will be charged to the sender.

## 8. Faults



In the event of faults in the dosing pump, a warning or an alarm is triggered.


The corresponding fault symbol flashes in the "Operation" menu, see section 8.1 *List of faults*. The cursor jumps to the "Alarm" main menu symbol. Press the click wheel to open the "Alarm" menu and, where necessary, faults to be acknowledged will be acknowledged.

A yellow display indicates a warning and the pump continues running.

A red display indicates an alarm and the pump is stopped.

The last 10 faults are stored in the "Alarm" main menu. When a new fault occurs, the oldest fault is deleted.

The two most recent faults are shown in the display, you can scroll through all the other faults. The time and cause of the fault are displayed.



TM04 1109 1010







The list of faults can be deleted at the end of the list.

If there is a service requirement, this appears when the "Alarm" menu is opened. Press the click wheel to temporarily close the service prompt (see section 7.3 *Service system*).

## 8.1 List of faults

### 8.1.1 Faults with error message

Display in the "Alarm" menu	Possible cause	Possible remedy
▼ Empty (Alarm)	<ul style="list-style-type: none"> <li>Dosing medium tank empty</li> </ul>	<ul style="list-style-type: none"> <li>Fill tank.</li> <li>Check contact setting (NO/NC).</li> </ul>
▼ Low level (Warning)	<ul style="list-style-type: none"> <li>Dosing medium tank almost empty</li> </ul>	
Overpressure (Alarm)	<ul style="list-style-type: none"> <li>Discharge valve blocked</li> <li>Isolating valve in discharge line closed</li> <li>Pressure peaks due to high viscosity</li> <li>Max. pressure set too low (see section 6.8 <i>Pressure monitoring</i>)</li> </ul>	<ul style="list-style-type: none"> <li>Replace valve if necessary (see section 7.4 <i>Perform service</i>).</li> <li>Check flow direction of valves (arrow) and correct if necessary.</li> <li>Open the isolating valve (on the discharge side).</li> <li>Enlarge diameter of discharge line.</li> <li>Change pressure setting (see section 6.8 <i>Pressure monitoring</i>).</li> </ul>
Low backpressure (Warning/alarm*)	<ul style="list-style-type: none"> <li>Faulty diaphragm</li> <li>Broken discharge line</li> <li>Pressure differential between suction and discharge side too low</li> <li>Leakage in the pressure loading valve at <math>Q &lt; 1 \text{ l/h}</math></li> <li>Deaeration valve open</li> </ul>	<ul style="list-style-type: none"> <li>Change the diaphragm (see section 7.4 <i>Perform service</i>).</li> <li>Check discharge line and repair if necessary.</li> <li>Install additional spring-loaded valve (approx. 3 bar) on the discharge side.</li> <li>Close the deaeration valve.</li> </ul>
Air bubble (Warning)	<ul style="list-style-type: none"> <li>Broken/leaky suction line</li> <li>Strongly degassing medium</li> <li>Tank dosing medium empty</li> </ul>	<ul style="list-style-type: none"> <li>Check suction line and repair if necessary.</li> <li>Provide positive inlet pressure (place dosing medium tank above the pump).</li> <li>Enable "SlowMode" (see section 6.6 <i>SlowMode</i>).</li> <li>Fill tank.</li> </ul>
👁 Cavitation (Warning)	<ul style="list-style-type: none"> <li>Blocked/constricted/squeezed suction line</li> <li>Blocked/constricted suction valve</li> <li>Suction lift too high</li> <li>Viscosity too high</li> </ul>	<ul style="list-style-type: none"> <li>Enable "SlowMode" (see section 6.6 <i>SlowMode</i>).</li> <li>Reduce suction lift.</li> <li>Increase suction hose diameter.</li> <li>Check suction line and open isolating valve if necessary.</li> </ul>
Suct. valve leak (Warning)	<ul style="list-style-type: none"> <li>Leaky/dirty suction valve</li> <li>Deaeration valve open</li> </ul>	<ul style="list-style-type: none"> <li>Check valve and tighten it up.</li> <li>Flush system.</li> <li>Replace valve if necessary (see section 7.4 <i>Perform service</i>).</li> <li>Check O-ring position.</li> <li>Install filter in suction line.</li> <li>Close the deaeration valve.</li> </ul>
Disch. valve leak (Warning)	<ul style="list-style-type: none"> <li>Leaky/dirty discharge valve</li> <li>Leakage in the pressure loading valve</li> <li>Deaeration valve open</li> </ul>	<ul style="list-style-type: none"> <li>Check valve and tighten it up.</li> <li>Flush system.</li> <li>Replace valve if necessary (see section 7.4 <i>Perform service</i>).</li> <li>Check O-ring position.</li> <li>Install screen in suction line.</li> <li>Close the deaeration valve.</li> <li>Install spring-loaded valve on the discharge side.</li> </ul>
Flow deviation (Warning)	<ul style="list-style-type: none"> <li>Considerable deviation between target and actual flow</li> <li>Pump not or incorrectly calibrated</li> </ul>	<ul style="list-style-type: none"> <li>Check installation.</li> <li>Calibrate the pump (see section 5.3 <i>Calibrating the pump</i>).</li> </ul>

Display in the "Alarm" menu	Possible cause	Possible remedy
 Pressure sensor (Warning)	<ul style="list-style-type: none"> <li>Broken "FlowControl" cable (see fig. 11)</li> <li>Sensor defect</li> <li>Pressure sensor not correctly calibrated.</li> </ul>	<ul style="list-style-type: none"> <li>Check plug connection.</li> <li>Change sensor if necessary.</li> <li>Calibrate pressure sensor correctly (see section 6.8.2 <i>Calibration of pressure sensor</i>).</li> </ul>
 Motor blocked (Alarm)	<ul style="list-style-type: none"> <li>Backpressure greater than nominal pressure</li> <li>Damage to gears</li> </ul>	<ul style="list-style-type: none"> <li>Reduce backpressure.</li> <li>Arrange for repair of gears, if necessary.</li> </ul>
 Bus error (Alarm)	<ul style="list-style-type: none"> <li>Fieldbus communication error</li> </ul>	<ul style="list-style-type: none"> <li>Check cables for correct specification and damage; replace if necessary.</li> <li>Check cable routing and shielding; correct if necessary.</li> </ul>
 E-Box (Alarm)	<ul style="list-style-type: none"> <li>E-Box connection error</li> <li>Faulty E-Box</li> </ul>	<ul style="list-style-type: none"> <li>Check plug connection.</li> <li>Replace E-Box if necessary.</li> </ul>
 Cable break (Alarm)	<ul style="list-style-type: none"> <li>Defect in analog cable 4-20 mA (input current &lt; 2 mA)</li> </ul>	<ul style="list-style-type: none"> <li>Check cable/plug connections and replace, if necessary.</li> <li>Check signal transmitter.</li> </ul>
 Service now (Warning)	<ul style="list-style-type: none"> <li>Time interval for service expired</li> </ul>	<ul style="list-style-type: none"> <li>Perform service (see section 7.4 <i>Perform service</i>).</li> </ul>

\* Depending on setting

### 8.1.2 General faults

Fault	Possible cause	Possible remedy
Dosing flow too high	Inlet pressure greater than backpressure	Install additional spring-loaded valve (approx. 3 bar) on the discharge side.
		Increase pressure differential.
	Incorrect calibration	Calibrate the pump (see section 5.3 <i>Calibrating the pump</i> ).
No dosing flow or dosing flow too low	Air in dosing head	Deaerate the pump.
	Faulty diaphragm	Change the diaphragm (see section 7.4 <i>Perform service</i> ).
	Leakage/fracture in lines	Check and repair lines.
	Valves leaking or blocked	Check and clean valves.
	Valves installed incorrectly	Check that the arrow on the valve housing is pointing in the direction of flow. Check whether all O-rings are installed correctly.
	Blocked suction line	Clean suction line/install filter.
		Reduce suction lift.
	Suction lift too high	Install priming aid.
		Enable "SlowMode" (see section 6.6 <i>SlowMode</i> ).
		Enable "SlowMode" (see section 6.6 <i>SlowMode</i> ).
	Viscosity too high	Use hose with larger diameter.
		Install spring-loaded valve on the discharge side.
	Faulty calibration	Calibrate the pump (see section 5.3 <i>Calibrating the pump</i> ).
	Deaeration valve open	Close the deaeration valve.

Fault	Possible cause	Possible remedy
Irregular dosing	Valves leaking or blocked	Tighten up valves, replace valves if necessary (see section 7.4 <i>Perform service</i> ).
	Backpressure fluctuations	Keep backpressure constant. Activate "AutoFlowAdapt" (only DDA-FCM).
Liquid escaping from the drain opening on the flange	Faulty diaphragm	Immediately separate the pump from the power supply! Observe section 7. <i>Service</i> and especially section 7.6 <i>Diaphragm breakage</i> .
Liquid escaping	Dosing head screws not tightened	Tighten up screws (see section 4.2 <i>Hydraulic connection</i> ).
	Valves not tightened	Tighten up valves/union nuts (see section 4.2 <i>Hydraulic connection</i> ).
Pump not sucking in	Suction lift too high	Reduce suction lift; if necessary, provide positive inlet pressure.
	Backpressure too high	Open the deaeration valve.
	Soiled valves	Flush system, replace valves if necessary (see section 7.4 <i>Perform service</i> ).

## 9. Disposal

This product or parts of it must be disposed of in an environmentally sound way.  
Use appropriate waste collection services.  
If this is not possible, contact the nearest Grundfos company or service workshop.



Subject to alterations.

## Appendix

## Safety declaration

Please copy, fill in and sign this sheet and attach it to the pump returned for service.

**Note**

**Fill in this document using English or German language.**

Product type (nameplate)



Model number (nameplate)

Dosing medium

### Fault description

Please make a circle around the damaged parts.

In the case of an electrical or functional fault, please mark the cabinet.



TM04 1185 1110

Please describe the error/cause of the error in brief.

☐

Dosing liquid has possibly entered the pump housing.

The pump must not be connected to the power supply! Danger of explosion!

We hereby declare that the pump has been cleaned and is completely free from chemical, biological and radioactive substances.

Date and signature

Company stamp



## Declaration of conformity

**GB: EC declaration of conformity**

We, Grundfos, declare under our sole responsibility that the products DDA, DDC and DDE, to which this declaration relates, are in conformity with these Council directives on the approximation of the laws of the EC member states:

**BG: EC декларация за съответствие**

Ние, фирма Grundfos, заявяваме с пълна отговорност, че продуктите DDA, DDC и DDE, за които се отнася настоящата декларация, отговарят на следните указания на Съвета за уеднаквяване на правните разпоредби на държавите членки на ЕС:

**CZ: ES prohlášení o shodě**

My firma Grundfos prohlašujeme na svou plnou odpovědnost, že výrobky DDA, DDC a DDE, na něž se toto prohlášení vztahuje, jsou v souladu s ustanoveními směrnice Rady pro sblížení právních předpisů členských států Evropského společenství v oblastech:

**DK: EF-overensstemmelseserklæring**

Vi, Grundfos, erklærer under ansvar at produkterne DDA, DDC og DDE som denne erklæring omhandler, er i overensstemmelse med disse af Rådets direktiver om indbyrdes tilnærmelse til EF-medlemsstaternes lovgivning:

**DE: EG-Konformitätserklärung**

Wir, Grundfos, erklären in alleiniger Verantwortung, dass die Produkte DDA, DDC und DDE, auf die sich diese Erklärung bezieht, mit den folgenden Richtlinien des Rates zur Angleichung der Rechtsvorschriften der EU-Mitgliedsstaaten übereinstimmen:

**EE: EL vastavusdeklaratsioon**

Meie, Grundfos, deklareerime enda ainuvastutusel, et tooted DDA, DDC ja DDE, mille kohta käesolev juhend käib, on vastavuses EU Nõukogu direktiividega EMÜ liikmesriikide seaduste ühitamise kohta, mis käsitlevad:

**GR: Δήλωση συμμόρφωσης EC**

Εμείς, η Grundfos, δηλώνουμε με αποκλειστικά δική μας ευθύνη ότι τα προϊόντα DDA, DDC και DDE στα οποία αναφέρεται η παρούσα δήλωση, συμμορφώνονται με τις εξής Οδηγίες του Συμβουλίου περί προσέγγισης των νομοθεσιών των κρατών μελών της ΕΕ:

**ES: Declaración CE de conformidad**

Nosotros, Grundfos, declaramos bajo nuestra entera responsabilidad que los productos DDA, DDC y DDE, a los cuales se refiere esta declaración, están conformes con las Directivas del Consejo en la aproximación de las leyes de los Estados Miembros del EM:

**FR: Déclaration de conformité CE**

Nous, Grundfos, déclarons sous notre seule responsabilité, que les produits DDA, DDC et DDE, auxquels se réfère cette déclaration, sont conformes aux Directives du Conseil concernant le rapprochement des législations des Etats membres CE relatives aux normes énoncées ci-dessous:

**HR: EZ izjava o usklađenosti**

Mi, Grundfos, izjavljujemo pod vlastitom odgovornošću da je proizvod DDA, DDC i DDE, na koji se ova izjava odnosi, u skladu s direktivama ovog Vijeća o usklađivanju zakona država članica EU:

**IT: Dichiarazione di conformità CE**

Grundfos dichiara sotto la sua esclusiva responsabilità che i prodotti DDA, DDC e DDE, ai quali si riferisce questa dichiarazione, sono conformi alle seguenti direttive del Consiglio riguardanti il riavvicinamento delle legislazioni degli Stati membri CE:

**LV: EK atbilstības deklarācija**

Sabiedrība GRUNDFOS ar pilnu atbildību dara zināmu, ka produkti DDA, DDC un DDE, uz kuriem attiecas šīs paziņojums, atbilst šādām Padomes direktīvām par tuvināšanos EK dalībvalstu likumdošanas normām:

**LT: EB atitikties deklaracija**

Mes, Grundfos, su visa atsakomybe pareiškiamo, kad gaminiai DDA, DDC ir DDE, kuriems skirta ši deklaracija, atitinka šias Tarybos Direktyvas dėl Europos Ekonominės Bendrijos šalių narių įstatymų suderinimo:

**HU: EK megfeleléségi nyilatkozat**

Mi, a Grundfos, egyedül felelősséggel kijelentjük, hogy a DDA, DDC és DDC termékek, amelyekre jelen nyilatkozik vonatkozik, megfelelnek az Európai Unió tagállamainak jogi irányelveit összehangoló tanács alábbi előírásainak:

**NL: EC overeenkomstigheidsverklaring**

Wij, Grundfos, verklaren geheel onder eigen verantwoordelijkheid dat de producten DDA, DDC en DDE waarop deze verklaring betrekking heeft, in overeenstemming zijn met de Richtlijnen van de Raad in zake de onderlinge aanpassing van de wetgeving van de EG Lidstaten betreffende:

**NO: EU samsvarserklæring**

Vi, Grundfos, erklærer på eget ansvar at produktene DDA, DDC og DDE, som denne erklæringen gjelder, er i samsvar med disse rådsdirektivene slik de omtrentlig samsvarer med lovene for EU-medlemslandene:

**UA: Декларация відповідності ЄС**

Компанія Grundfos заявляє про свою виключну відповідальність за те, що продукти DDA, DDC та DDE, на які поширюється дана декларація, відповідають таким рекомендаціям Ради з уніфікації правових норм країн - членів ЄС:

**PL: Deklaracja zgodności WE**

My, Grundfos, oświadczamy z pełną odpowiedzialnością, że nasze wyroby DDA, DDC oraz DDE, których deklaracja niniejsza dotyczy, są zgodne z następującymi wytycznymi Rady d/s ujednolicenia przepisów prawnych krajów członkowskich WE:

**PT: Declaração de conformidade CE**

A Grundfos declara sob sua única responsabilidade que os produtos DDA, DDC e DDE, aos quais diz respeito esta declaração, estão em conformidade com as seguintes Directivas do Conselho sobre a aproximação das legislações dos Estados Membros da CE:

**RU: Декларация о соответствии ЕС**

Мы, компания Grundfos, со всей ответственностью заявляем, что изделия DDA, DDC и DDE, к которым относится настоящая декларация, соответствуют следующим Директивам Совета Евросоюза об унификации законодательных предписаний стран-членов ЕС:

**RO: Declarație de conformitate CE**

Noi, Grundfos, declarăm pe propria răspundere că produsele DDA, DDC și DDE, la care se referă această declarație, sunt în conformitate cu aceste Directive de Consiliu asupra armonizării legilor Statelor Membre CE:

**SK: Prehlásenie o konformite ES**

My firma Grundfos prehlasujeme na svoju plnú zodpovednosť, že výrobky DDA, DDC a DDE, na ktoré sa toto prehlásenie vzťahuje, sú v súlade s ustanovením smernice Rady pre zblíženie právnych predpisov členských štátov Európskeho spoločenstva v oblastiach:

**SI: ES izjava o skladnosti**

V Grundfosu s polno odgovornostjo izjavljamo, da so naši izdelki DDA, DDC in DDE, na katere se ta izjava nanaša, v skladu z naslednjimi direktivami Sveta o približevanju zakonodaje za izenačevanje pravnih predpisov držav članic ES:

**RS: EC deklaracija o usaglašenosti**

Mi, Grundfos, izjavljujemo pod vlastitom odgovornošću da je proizvod DDA, DDC i DDE, na koji se ova izjava odnosi, u skladu sa direktivama Saveta za usklađivanje zakona država članica EU:

**FI: EY-vaatimustenmukaisuusvakuutus**

Me, Grundfos, vakuutamme omalla vastuullamme, että tuotteet DDA, DDC ja DDE, joita tämä vakuutus koskee, ovat EY:n jäsenvaltioiden lainsäädännön yhdenmukaistamiseen tähtäävien Euroopan neuvoston direktiivien vaatimusten mukaisia seuraavasti:

**TR: EC uygunluk bildirgesi**

Grundfos olarak bu beyannameye konu olan DDA, DDC ve DDE ürünlerinin, AB Üyesi Ülkelerin kanunlarını birbirine yaklaştırma üzerine Konsey Direktifiyle uyumlu olduğunu yalnızca bizim sorumluluğumuz altında olduğunu beyan ederiz:

**JP: EC 適合宣言**

Grundfos は、その責任の下に、DDA, DDC 製品および DDE 製品が EC 加盟諸国の法規に関連する、以下の評議会指令に適合していることを宣言します：

**SE: EG-försäkran om överensstämmelse**

Vi, Grundfos, försäkrar under ansvar att produkterna DDA, DDC och DDE, som omfattas av denna försäkran, är i överensstämmelse med rådets direktiv om inbördes närmande till EU-medlemsstaternas lagstiftning, avseende:

**CN: EC 产品合格声明书**

我们格兰富在我们的全权责任下声明，产品 DDA, DDC 和 DDE，即该合格证所指之产品，符合欧共体使其成员国法律趋于一致的以下欧共理事会指令：


**KO: EC 적합성 선언**

Grundfos에서는 자사의 단독 책임에 따라 이 선언과 관련된 DDA, DDC 및 DDE 제품이 EC 회원국 법률에 기반한 다음 이사회 지침을 준수함을 선언합니다：

- Machinery Directive (2006/42/EC).  
Standards used: EN 809: 1998, DIN EN ISO 12100:2010.
- Low Voltage Directive (2006/95/EC).  
Standard used: EN 61010-1: 2001 (second edition).
- EMC Directive (2004/108/EC).  
Standards used: EN 61326-1: 2006,  
EN 61000-3-2: 2006+A1: 2009+A2: 2009, EN 61000-3-3: 2008.

This EC declaration of conformity is only valid when published as part of the Grundfos installation and operating instructions.

Pfinztal, 1 December 2014



Ulrich Stemick  
Technical Director  
Grundfos Water Treatment GmbH  
Reetzstr. 85, D-76327 Pfinztal, Germany

Person authorised to compile technical file and  
empowered to sign the EC declaration of conformity.

**This page is intentionally left blank**

**This page is intentionally left blank**

**This page is intentionally left blank**

**Argentina**

Bombas GRUNDFOS de Argentina S.A.  
Ruta Panamericana km. 37.500 Centro  
Industrial Garin  
1619 - Garin Pcia. de B.A.  
Phone: +54-3327 414 444  
Telefax: +54-3327 411 111

**Australia**

GRUNDFOS Pumps Pty. Ltd.  
P.O. Box 2040  
Regency Park  
South Australia 5942  
Phone: +61-8-8461-4611  
Telefax: +61-8-8340 0155

**Austria**

GRUNDFOS Pumpen Vertrieb  
Ges.m.b.H.  
Grundfosstraße 2  
A-5082 Grödig/Salzburg  
Tel.: +43-6246-883-0  
Telefax: +43-6246-883-30

**Belgium**

N.V. GRUNDFOS Bellux S.A.  
Boomsesteenweg 81-83  
B-2630 Aartselaar  
Tél.: +32-3-870 7300  
Télécopie: +32-3-870 7301

**Belarus**

Представительство ГРУНДФОС в  
Минске  
220125, Минск  
ул. Шафарнянская, 11, оф. 56  
Тел.: +7 (375 17) 286 39 72, 286 39 73  
Факс: +7 (375 17) 286 39 71  
E-mail: minsk@grundfos.com

**Bosnia/Herzegovina**

GRUNDFOS Sarajevo  
Trg Heroja 16,  
BiH-71000 Sarajevo  
Phone: +387 33 713 290  
Telefax: +387 33 659 079  
e-mail: grundfos@bih.net.ba

**Brazil**

BOMBAS GRUNDFOS DO BRASIL  
Av. Humberto de Alencar Castelo  
Branco, 630  
CEP 09850 - 300  
São Bernardo do Campo - SP  
Phone: +55-11 4393 5533  
Telefax: +55-11 4343 5015

**Bulgaria**

Grundfos Bulgaria EOOD  
Slatina District  
Iztochna Tangenta street no. 100  
BG - 1592 Sofia  
Tel. +359 2 49 22 200  
Fax. +359 2 49 22 201  
email: bulgaria@grundfos.bg

**Canada**

GRUNDFOS Canada Inc.  
2941 Brighton Road  
Oakville, Ontario  
L6H 6C9  
Phone: +1-905 829 9533  
Telefax: +1-905 829 9512

**China****Grundfos Alldos****Dosing & Disinfection**

ALLDOS (Shanghai) Water Technology  
Co. Ltd.  
West Unit, 1 Floor, No. 2 Building (T 4-2)  
278 Jinhu Road, Jin Qiao Export Pro-  
cessing Zone  
Pudong New Area  
Shanghai, 201206  
Phone: +86 21 5055 1012  
Telefax: +86 21 5032 0596  
E-mail: grundfosalldos-CN@grund-  
fos.com

**China**

GRUNDFOS Pumps (Shanghai) Co. Ltd.  
50/F Maxdo Centre No. 8 Xing Yi Rd.  
Hongqiao Development Zone  
Shanghai 200336  
PRC  
Phone: +86-21 6122 5222  
Telefax: +86-21 6122 5333

**Croatia**

GRUNDFOS CROATIA d.o.o.  
Cebini 37, Buzin  
HR-10010 Zagreb  
Phone: +385 1 6595 400  
Telefax: +385 1 6595 499  
www.hr.grundfos.com

**Czech Republic**

GRUNDFOS s.r.o.  
Čapkovského 21  
779 00 Olomouc  
Phone: +420-585-716 111  
Telefax: +420-585-716 299

**Denmark**

GRUNDFOS DK A/S  
Martin Bachs Vej 3  
DK-8850 Bjerringbro  
Tlf.: +45-87 50 50 50  
Telefax: +45-87 50 51 51  
E-mail: info\_GDK@grundfos.com  
www.grundfos.com/DK

**Estonia**

GRUNDFOS Pumps Eesti OÜ  
Peterburi tee 92G  
11415 Tallinn  
Tel: + 372 606 1690  
Fax: + 372 606 1691

**Finland**

OY GRUNDFOS Pumput AB  
Mestarintie 11  
FIN-01730 Vantaa  
Phone: +358-(0)207 889 900  
Telefax: +358-(0)207 889 550

**France**

Pompes GRUNDFOS Distribution S.A.  
Parc d'Activités de Chesnes  
57, rue de Malacombe  
F-38290 St. Quentin Fallavier (Lyon)  
Tél.: +33-4 74 82 15 15  
Télécopie: +33-4 74 94 10 51

**Germany**

GRUNDFOS Water Treatment GmbH  
Reetzstraße 85  
D-76327 Pfintzal (Söllingen)  
Tel.: +49 7240 61-0  
Telefax: +49 7240 61-177  
E-mail: gwt@grundfos.com

**Germany**

GRUNDFOS GMBH  
Schlüterstr. 33  
40699 Erkrath  
Tel.: +49-(0) 211 929 69-0  
Telefax: +49-(0) 211 929 69-3799  
E-mail: infoservice@grundfos.de  
Service in Deutschland:  
E-mail: kundendienst@grundfos.de

**Greece**

GRUNDFOS Hellas A.E.B.E.  
20th km. Athinon-Markopoulou Av.  
P.O. Box 71  
GR-19002 Peania  
Phone: +0030-210-66 83 400  
Telefax: +0030-210-66 46 273

**Hong Kong**

GRUNDFOS Pumps (Hong Kong) Ltd.  
Unit 1, Ground floor  
Siu Wai Industrial Centre  
29-33 Wing Hong Street &  
68 King Lam Street, Cheung Sha Wan  
Kowloon  
Phone: +852-27861706 / 27861741  
Telefax: +852-27858664

**Hungary**

GRUNDFOS Hungária Kft.  
Park u. 8  
H-2045 Törökbálint,  
Phone: +36-23 511 110  
Telefax: +36-23 511 111

**India**

GRUNDFOS Pumps India Private  
Limited  
118 Old Mahabalipuram Road  
Thoraiakkam  
Chennai 600 097  
Phone: +91-44 4596 6800

**Indonesia**

PT GRUNDFOS Pompa  
Jl. Rawa Sumur III, Blok III / CC-1  
Kawasan Industri, Pulogadung  
Jakarta 13930  
Phone: +62-21-460 6909  
Telefax: +62-21-460 6910 / 460 6901

**Ireland**

GRUNDFOS (Ireland) Ltd.  
Unit A, Merrywell Business Park  
Ballymount Road Lower  
Dublin 12  
Phone: +353-1-4089 800  
Telefax: +353-1-4089 830

**Italy**

GRUNDFOS Pompe Italia S.r.l.  
Via Gran Sasso 4  
I-20060 Truccazzano (Milano)  
Tel.: +39-02-95838112  
Telefax: +39-02-95309290 / 95838461

**Japan**

GRUNDFOS Pumps K.K.  
Gotanda Metalion Bldg. 5F,  
5-21-15, Higashi-gotanda  
Shiagawa-ku, Tokyo,  
141-0022 Japan  
Phone: +81 35 448 1391  
Telefax: +81 35 448 9619

**Korea**

GRUNDFOS Pumps Korea Ltd.  
6th Floor, Aju Building 679-5  
Yeoksam-dong, Kangnam-ku, 135-916  
Seoul, Korea  
Phone: +82-2-5317 600  
Telefax: +82-2-5633 725

**Latvia**

SIA GRUNDFOS Pumps Latvia  
Deglava biznesa centrs  
Augusta Deglava ielā 60, LV-1035, Rīga,  
Tālr.: + 371 714 9640, 7 149 641  
Fakss: + 371 914 9646

**Lithuania**

GRUNDFOS Pumps UAB  
Smolensko g. 6  
LT-03201 Vilnius  
Tel: + 370 52 395 430  
Fax: + 370 52 395 431

**Malaysia**

GRUNDFOS Pumps Sdn. Bhd.  
7 Jalan Peguam U1/25  
Glenmarie Industrial Park  
40150 Shah Alam  
Selangor  
Phone: +60-3-5569 2922  
Telefax: +60-3-5569 2866

**Mexico**

Bombas GRUNDFOS de México S.A. de C.V.  
Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
Apodaca, N.L. 66600  
Phone: +52-81-8144 4000  
Telefax: +52-81-8144 4010

**Netherlands**

GRUNDFOS Netherlands  
Veluwezoom 35  
1326 AE Almere  
Postbus 22015  
1302 CA ALMERE  
Tel.: +31-88-478 6336  
Telefax: +31-88-478 6332  
E-mail: info\_gnl@grundfos.com

**New Zealand**

GRUNDFOS Pumps NZ Ltd.  
17 Beatrice Tinsley Crescent  
North Harbour Industrial Estate  
Albany, Auckland  
Phone: +64-9-415 3240  
Telefax: +64-9-415 3250

**Norway**

GRUNDFOS Pumper A/S  
Strømsveien 344  
Postboks 235, Leirdal  
N-1011 Oslo  
Tlf.: +47-22 90 47 00  
Telefax: +47-22 32 21 50

**Poland**

GRUNDFOS Pompy Sp. z o.o.  
ul. Klonowa 23  
Baranowo k. Poznania  
PL-62-081 Przeźmierowo  
Tel: (+48-61) 650 13 00  
Fax: (+48-61) 650 13 50

**Portugal**

Bombas GRUNDFOS Portugal, S.A.  
Rua Calvet de Magalhães, 241  
Apartado 1079  
P-2770-153 Paço de Arcos  
Tel.: +351-21-440 76 00  
Telefax: +351-21-440 76 90

**Romania**

GRUNDFOS Pompe România SRL  
Bd. Biruintei, nr 103  
Pantelimon county Ilfov  
Phone: +40 21 200 4100  
Telefax: +40 21 200 4101  
E-mail: romania@grundfos.ro

**Russia**

ООО Грундфос  
Россия, 109544 Москва, ул. Школьная  
39  
Тел. (+7) 495 737 30 00, 564 88 00  
Факс (+7) 495 737 75 36, 564 88 11  
E-mail grundfos.moscow@grundfos.com

**Serbia**

GRUNDFOS Predstavništvo Beograd  
Dr. Milutina Ivkovića 2a/29  
YU-11000 Beograd  
Phone: +381 11 26 47 877 / 11 26 47 496  
Telefax: +381 11 26 48 340

**Singapore**

GRUNDFOS (Singapore) Pte. Ltd.  
25 Jalan Tukang  
Singapore 619264  
Phone: +65-6681 9688  
Telefax: +65-6681 9689

**Slovakia**

GRUNDFOS s.r.o.  
Prievozská 4D  
821 09 BRATISLAVA  
Phona: +421 2 5020 1426  
sk.grundfos.com

**Slovenia**

GRUNDFOS d.o.o.  
Šlandrova 8b, SI-1231 Ljubljana-Črnuče  
Phone: +386 1 568 0610  
Telefax: +386 1 568 0619  
E-mail: slovenia@grundfos.si

**South Africa**

Grundfos (PTY) Ltd.  
Corner Mountjoy and George Allen  
Roads  
Wilbart Ext. 2  
Bedfordview 2008  
Phone: (+27) 11 579 4800  
Fax: (+27) 11 455 6066  
E-mail: lsmart@grundfos.com

**Spain**

Bombas GRUNDFOS España S.A.  
Camino de la Fuentequilla, s/n  
E-28110 Algete (Madrid)  
Tel.: +34-91-848 8800  
Telefax: +34-91-628 0465

**Sweden**

GRUNDFOS AB  
(Box 333) Lunnagårdsgatan 6  
431 24 Mölndal  
Tel.: +46 31 332 23 000  
Telefax: +46 31-331 94 60

**Switzerland**

GRUNDFOS ALLDOS International AG  
Schöneggstrasse 4  
CH-4153 Reinach  
Tel.: +41-61-717 5555  
Telefax: +41-61-717 5500  
E-mail: grundfosalldos-CH@grundfos.com

**Switzerland**

GRUNDFOS Pumpen AG  
Bruggacherstrasse 10  
CH-8117 Fällanden/ZH  
Tel.: +41-44-806 8111  
Telefax: +41-44-806 8115

**Taiwan**

GRUNDFOS Pumps (Taiwan) Ltd.  
7 Floor, 219 Min-Chuan Road  
Taichung, Taiwan, R.O.C.  
Phone: +886-4-2305 0868  
Telefax: +886-4-2305 0878

**Thailand**

GRUNDFOS (Thailand) Ltd.  
92 Chaloen Phrakiat Rama 9 Road,  
Dokmai, Pravej, Bangkok 10250  
Phone: +66-2-725 8999  
Telefax: +66-2-725 8998

**Turkey**

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.  
Gebze Organize Sanayi Bölgesi  
İhsan dede Caddesi,  
2. yol 200. Sokak No. 204  
41490 Gebze/ Kocaeli  
Phone: +90 - 262-679 7979  
Telefax: +90 - 262-679 7905  
E-mail: satis@grundfos.com

**Ukraine**

Бізнес Центр Європа  
Столичне шосе, 103  
м. Київ, 03131, Україна  
Телефон: (+38 044) 237 04 00  
Факс: (+38 044) 237 04 01  
E-mail: ukraine@grundfos.com

**United Arab Emirates**

GRUNDFOS Gulf Distribution  
P.O. Box 16768  
Jebel Ali Free Zone  
Dubai  
Phone: +971-4- 8815 166  
Telefax: +971-4-8815 136

**United Kingdom**

GRUNDFOS Pumps Ltd.  
Grovebury Road  
Leighton Buzzard/Beds. LU7 4TL  
Phone: +44-1525-850000  
Telefax: +44-1525-850011

**U.S.A.**

GRUNDFOS Pumps Corporation  
17100 West 118th Terrace  
Olathe, Kansas 66061  
Phone: +1-913-227-3400  
Telefax: +1-913-227-3500

**Uzbekistan**

Grundfos Tashkent, Uzbekistan The Representative Office of Grundfos Kazakhstan in Uzbekistan  
38a, Oybek street, Tashkent  
Телефон: (+998) 71 150 3290 / 71 150 3291  
Факс: (+998) 71 150 3292

Addresses revised 21.05.2014

be think innovate

---

**95724708** 1114

ECM: 1146320

© Copyright Grundfos Holding A/S

The name Grundfos, the Grundfos logo, and **be think innovate** are registered trademarks owned by Grundfos Holding A/S or Grundfos A/S, Denmark. All rights reserved worldwide.

[www.grundfos.com](http://www.grundfos.com)

**GRUNDFOS** 





MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL  
AMARUQ WTP – NUNAVUT  
VEOLIA PROJECT: 5000 218 009

---

**GRUNDFOS**

***CRN SERIES, MULTI-STAGE CENTRIFUGAL PUMP***

*LEFT BLANK*

# CR, CRI, CRN, CRT

Installation and operating instructions



**English (US)**  
Installation and operating instructions. .... 3

## Original installation and operating instructions.

## CONTENTS

	Page	
1. Limited warranty	4	
2. Symbols used in this document	4	
3. Introduction	4	
4. Shipment inspection	5	
4.1 Lifting instructions	5	
4.2 Ensure you have the right pump	5	
4.3 Checking the condition of the pump	5	
4.4 Electrical requirements	5	
5. Identification	6	
5.1 Nameplate data	6	
5.2 Type keys	6	
6. Applications	9	
7. Operating conditions	9	
7.1 Ambient temperature and altitude	9	
7.2 Liquid temperatures	9	
7.3 Minimum inlet pressures	9	
7.4 Maximum inlet pressures	10	
7.5 Maximum operating pressures	11	
8. Installation	12	
8.1 Pump location	12	
8.2 Foundation	12	
8.3 Pump mounting	13	
8.4 Suction pipe	13	
8.5 Discharge pipe	13	
8.6 Bypass	14	
8.7 Flange forces and torques	14	
8.8 Minimum continuous duty flow rates [gpm]	15	
8.9 Check valves	16	
8.10 Temperature rise	16	
8.11 Electrical connection	16	
8.12 Motors	16	
8.13 Position of terminal box	16	
8.14 Field wiring	16	
8.15 Motor protection	17	
9. Commissioning	17	
9.1 Priming	17	
9.2 Startup	18	
10. Operation	18	
10.1 Operating parameters	18	
10.2 Pump cycling	18	
10.3 Boiler feed installations	18	
10.4 Frost protection	18	
11. Maintaining the pump	18	
12. Maintaining the motor	19	
12.1 Motor inspection	19	
12.2 Motor lubrication	19	
12.3 Recommended lubricant	19	
12.4 Lubricating chart (for motors with grease zerks)	19	
12.5 Lubricating procedure	20	
13. Replacing the motor	20	
13.1 Disassembly	20	
13.2 Assembly	20	
14. Parts list	23	
14.1 Spare parts	23	
15. Preliminary electrical tests	23	
15.1 Supply voltage	23	
15.2 Current	24	
15.3 Insulation resistance	24	
16. Startup of pump with air-cooled top (Cool-Top®)	25	
17. Diagnosing specific problems	26	
18. Worksheet for three-phase motors	29	
19. Disposal	29	

**Warning**

*Prior to installation, read these installation and operating instructions. Installation and operation must comply with local regulations and accepted codes of good practice.*

**Warning**

*Electrical work: All electrical work should be performed by a qualified electrician in accordance with the latest edition of national, state, and local codes and regulations.*

**Warning**

*Shock Hazard: A faulty motor or wiring can cause electrical shock that could be fatal, whether touched directly or conducted through standing water. For this reason, proper grounding of the pump to the power supply's grounding terminal is required for safe installation and operation. In all installations, the above-ground metal plumbing should be connected to the power supply ground as described in Article 250-80 of the National Electrical Code.*

## 1. Limited warranty

Products manufactured by GRUNDFOS PUMPS CORPORATION (Grundfos) are warranted to the original user only to be free of defects in material and workmanship for a period of 24 months from date of installation, but not more than 30 months from date of manufacture. Grundfos' liability under this warranty shall be limited to repairing or replacing at Grundfos' option, without charge, F.O.B. Grundfos' factory or authorized service station, any product of Grundfos' manufacture. Grundfos will not be liable for any costs of removal, installation, transportation, or any other charges which may arise in connection with a warranty claim. Products which are sold but not manufactured by Grundfos are subject to the warranty provided by the manufacturer of said products and not by Grundfos' warranty. Grundfos will not be liable for damage or wear to products caused by abnormal operating conditions, accident, abuse, misuse, unauthorized alteration or repair, or if the product was not installed in accordance with Grundfos' printed installation and operating instructions.

To obtain service under this warranty, the defective product must be returned to the distributor or dealer of Grundfos' products from which it was purchased together with proof of purchase and installation date, failure date, and supporting installation data. Unless otherwise provided, the distributor or dealer will contact Grundfos or an authorized service station for instructions. Any defective product to be returned to Grundfos or a service station must be sent freight prepaid; documentation supporting the warranty claim and/or a Return Material Authorization must be included if so instructed.

GRUNDFOS WILL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, LOSSES, OR EXPENSES ARISING FROM INSTALLATION, USE, OR ANY OTHER CAUSES. THERE ARE NO EXPRESS OR IMPLIED WARRANTIES, INCLUDING MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, WHICH EXTEND BEYOND THOSE WARRANTIES DESCRIBED OR REFERRED TO ABOVE.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages and some jurisdictions do not allow limit actions on how long implied warranties may last. Therefore, the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction.

## 2. Symbols used in this document



### **Warning**

*If these safety instructions are not observed, it may result in personal injury.*



### **Warning**

*If these instructions are not observed, it may lead to electric shock with consequent risk of serious personal injury or death.*



*If these safety instructions are not observed, it may result in malfunction or damage to the equipment.*



*Notes or instructions that make the job easier and ensure safe operation.*

## 3. Introduction

The CR range is based on the inline multistage centrifugal pump first pioneered by Grundfos. CR is available in four basic materials and over one million configurations. CR is suitable for pumping water and water-like liquids in industry, petrochemical plants, water treatment plants, commercial buildings, and many other applications. Some of the outstanding characteristics of CR are:

- superior efficiency
- reliability
- easy maintenance
- compact size and small footprint
- quiet operation.

## 4. Shipment inspection

Examine the components carefully to make sure no damage has occurred to the pump during shipment. Ensure that the pump is NOT dropped or mishandled.

### 4.1 Lifting instructions

**Caution** Do not use the lifting eyes of the motor for lifting the entire pump and motor assembly.

Lift pump assembly with lifting straps that pass through the motor stool. Ensure that the load is not applied to the pump shaft.




Fig. 1 Correct lifting of a CR pump

### 4.2 Ensure you have the right pump

Check the pump nameplate to make sure that it is the one you ordered.

- **CR:** Centrifugal pump; all parts in contact with the pumped liquid are made of standard cast iron and AISI 304 stainless steel
- **CRI:** Centrifugal pump; all parts in contact with the pumped liquid are made of AISI 304 stainless steel
- **CRN:** Centrifugal pump; all parts in contact with the pumped liquid are made of AISI 316 stainless steel
- **CRT:** Centrifugal pump; all parts in contact with the pumped liquid are made of titanium
- **CRE:** Centrifugal pump with a Grundfos MLE variable frequency drive motor.

### 4.3 Checking the condition of the pump

The packing in which your pump arrived is specially designed for your pump to prevent damage during shipment. As a precaution, leave the pump in the packing until you are ready to install it. Examine the pump for any damage that may have occurred during shipping. Examine any other parts of the shipment as well for any visible damage.

*If the shipment consists of a complete unit (motor attached to pump end), the position of the coupling connecting the pump shaft to the motor shaft is set to factory specifications. No adjustment is required. If the shipment is a pump end without motor, follow the adjustment procedures in section 13. Replacing the motor.*

**Note**

**Pump without motor (CR, CRI, CRN 1s, 1, 3, 5, 10, 15, and 20 only):**

If you purchased a pump end without motor, the shaft seal has been set from factory. Do not loosen the three set screws on the shaft seal when attaching the motor.

**Pump without motor (CR, CRN 32, 45, 64, 90, 120, and 150 only):**

If you purchased a pump end without motor, you must install the shaft seal. The shaft seal is protected in its own box inside the pump packing crate. To protect the shaft and bearings during shipment, a transport protector is used. Remove the transport protector prior to installation of the shaft seal. Read the seal installation instructions which are included in the pump packing.

### 4.4 Electrical requirements

#### Warning

**Electrical work:** All electrical work should be performed by a qualified electrician in accordance with the current national, state, and local codes and regulations.



#### Warning

**Shock hazard:** A faulty motor or faulty wiring can cause electric shock that could be fatal, whether the motor is touched directly or the current is conducted through standing water. For this reason, safe installation and operation require proper grounding of the pump to the power supply ground (earth) terminal.



**In all installations, connect the above-ground metal plumbing to the power supply ground terminal as described in Article 250-80 of the National Electrical Code.**

Verify the power supply to make sure that the voltage, phases and frequency match those of the pump. The proper operating voltage and other electrical information appear on the motor nameplate. These motors are designed to run on  $-10\% / +10\%$  of the rated nameplate voltage. For dual-voltage motors, the motor should be internally connected to operate on the voltage closest to the 10 % rating, i.e., a 208 V motor should be wired according to the 208 V wiring diagram. The wiring diagram can be found on either a plate attached to the motor or on a label inside the terminal box cover.


**Caution**

**Do not operate the pump if voltage variations are greater than  $-10\% / +10\%$ .**

TM04 0339 0608

5. Identification

5.1 Nameplate data




- 1. Type designation
- 2. Model, material number, production number
- 3. Head in feet at rated flow
- 4. Rated motor hp
- 5. Head at zero flow
- 6. Rated rpm
- 7. Rated flow
- 8. Rated frequency
- 9. Maximum pressure and maximum liquid temperature
- 10. Direction of rotation
- 11. Production country

TM04 3895 2609

Fig. 1 Example of nameplate CR, CRI, CRN, CRT

Specification of the model line in nameplates:



TM04 3904 3913

Fig. 2 Key to model line in nameplates

5.2 Type keys

5.2.1 CR, CRI, CRN 1s, 1, 3, 5, 10, 15, and 20

Example	CR 3- 10 A FG A E HQQE
Type range: CR, CRI, CRN	
Rated flow rate in [m³/h] (x 5 gpm)	
Number of impellers	
Code for pump version	
Code for pipe connection	
Code for materials	
Code for rubber parts	
Code for shaft seal	

5.2.2 CR, CRN 32, 45, 64, 90, 120, and 150

Example	CR 32- 2- 1 A G A E KUBE
Pump range: CR, CRN	
Rated flow rate in [m³/h] (x 5 gpm)	
Number of impellers	
Number of reduced-diameter impellers	
Code for pump version	
Code for pipe connection	
Code for materials	
Code for rubber parts	
Code for shaft seal	

5.2.3 CRT 2, 4, 8, and 16

Example	CRT 16- 30 /2 A G A AUUE
Pump range: CRT	
Rated flow rate in [m³/h] (x 5 gpm)	
Number of stages x 10	
Code for impellers (used only if the pump has fewer impellers than stages)	
Code for pump version	
Code for pipe connection	
Code for materials	
Code for shaft seal and rubber parts	



## 5.2.4 Codes

Example		A	-G	-A	-E	-H	QQ	E
<b>Pump version</b>								
A	Basic version <sup>1)</sup>							
B	Oversize motor							
E	Certificate/approval							
F	CR pump for high temperatures (air-cooled top assembly)							
H	Horizontal version							
HS	High-pressure pump with high-speed MLE motor							
I	Different pressure rating							
J	Pump with different max. speed							
K	Pump with low NPSH							
M	Magnetic drive							
N	Fitted with sensor							
P	Undersize motor							
R	Horizontal version with bearing bracket							
SF	High-pressure pump							
T	Oversize motor (two flange sizes bigger)							
U	NEMA version <sup>1)</sup>							
X	Special version <sup>2)</sup>							
<b>Pipe connection</b>								
A	Oval flange, Rp thread							
B	Oval flange, NPT thread							
CA	FlexiClamp (CRI(E), CRN(E) 1, 3, 5, 10, 15, 20)							
CX	Triclamp (CRI(E), CRN(E) 1, 3, 5, 10, 15, 20)							
F	DIN flange							
G	ANSI flange							
J	JIS flange							
N	Changed diameter of ports							
P	PJE coupling							
X	Special version							
<b>Materials</b>								
A	Basic version							
D	Carbon-graphite filled PTFE (bearings)							
G	Wetted parts, AISI 316							
GI	All parts stainless steel, wetted parts, AISI 316							
I	Wetted parts, AISI 304							
II	All parts stainless steel, wetted parts, AISI 304							
K	Bronze (bearings)							
S	SiC bearings + PTFE neck rings							
X	Special version							
<b>Code for rubber parts</b>								
E	EPDM							
F	FXM							
K	FFKM							
V	FKM							

Example		A	-G	-A	-E	-H	QQ	E
<b>Shaft seal</b>								
A	O-ring seal with fixed driver							
B	Rubber bellows seal							
E	Cartridge seal with O-ring							
H	Balanced cartridge seal with O-ring							
K	Metal bellows cartridge seal							
O	Double seal, back-to-back							
P	Double seal, tandem							
X	Special version							
B	Carbon, synthetic resin-impregnated							
H	Cemented tungsten carbide, embedded (hybrid)							
Q	Silicon carbide							
U	Cemented tungsten carbide							
X	Other ceramics							
E	EPDM							
F	FXM							
K	FFKM							
V	FKM							

- <sup>1)</sup> In August 2003 the NEMA version pump code was discontinued for all material numbers created by Grundfos manufacturing companies in North America. The NEMA version pump code will still remain in effect for existing material numbers. NEMA version pumps built in North America after this change will have either an A or a U as the pump version code depending on the date the material number was created.
- <sup>2)</sup> If a pump incorporates more than two pump versions, the code for the pump version is X. X also indicates special pump versions not listed above.

## 6. Applications

Compare the pump's nameplate data or its performance curve with the application in which you plan to install it. Make sure the application falls within the following limits.


Type	Application/liquid
CR	Hot and chilled water, boiler feed, condensate return, glycols and solar thermal liquids.
CRI/CRN	Deionized, demineralized and distilled water. Brackish water and other liquids unsuitable for contact with iron or copper alloys. (Consult manufacturer for specific liquid compatibilities.)
CRN-SF	High-pressure washdown, reverse osmosis or other high-pressure applications.
CRT	Salt water, chloride based liquids and liquids approved for titanium.

## 7. Operating conditions

### 7.1 Ambient temperature and altitude

If the ambient temperature exceeds the maximum temperature limits of the pump or the pump is installed at an altitude exceeding the altitude values in the chart below, the motor must not be fully loaded due to the risk of overheating.

Overheating may result from excessive ambient temperatures or the low density and consequently low cooling effect of the air at high altitudes. In such cases, it may be necessary to use a motor with a higher rated output ( $P_2$ ).



**Fig. 3** Relationship between motor output ( $P_2$ ) and ambient temperature/altitude

#### Legend

Pos.	Description
1	NEMA standard-efficiency motors
2	NEMA premium-efficiency motors

**Example:** From fig. 3 it appears that  $P_2$  must be reduced to 88 % when a pump with a NEMA premium-efficiency ML motor is installed 15,584 feet above sea level. At an ambient temperature of 167 °F,  $P_2$  of a standard-efficiency motor must be reduced to 74 % of rated output.

In cases where both the maximum temperature and the maximum altitude are exceeded, the derating factors must be multiplied.

Example:  $0.89 \times 0.89 = 0.79$ .

## 7.2 Liquid temperatures

Pump	Liquid temperature
CR, CRI, CRN 1s, 3, 5, 10, 15, and 20	-4 - +248 °F (-20 - +120 °C)
CR, CRN 32, 45, 64, and 90*	-22 - +248 °F (-30 - +120 °C)
CR, CRN 120 and 150* (up to 60 hp)	-22 - +248 °F (-30 - +120 °C)
CR, CRN 120 and 150 (75 and 100 hp)	32-248 °F (0-120 °C)
CRT 2, 4, 8, 16	-4 - +248 °F (-20 - +120 °C)
CRN-SF	-4 - +221 °F (-15 - +105 °C)
Pumps with Cool-Top™	up to 356 °F (180 °C)

All motors are designed for continuous duty in 104 °F (40 °C) ambient air conditions. For higher ambient temperature conditions, consult Grundfos.

\* We recommend xUBE shaft seals for temperatures above 200 °F. Pumps with KUHE hybrid shaft seals can only operate up to 200 °F (90 °C). Pumps with xUUE shaft seals can be operated down to -40 °F (-40 °C). ("x" is the seal type).

### 7.3 Minimum inlet pressures

All CR, CRI, CRN	NPSHR + 2 feet
CRN-SF	29 psi (2 bar)

## 7.4 Maximum inlet pressures

Pump type	Stages		Max. [psi (bar)]
	60 Hz	50 Hz	
CR, CRI, CRN 1s	2-27	2-36	145 (10)
CR, CRI, CRN 1	2-25	2-36	145 (10)
	27		217 (15)
CR, CRI, CRN 3	2-17	2-29	145 (10)
	19-25	31-36	217 (15)
CR, CRI, CRN 5	2-9	3-16	145 (10)
	10-24	18-36	217 (15)
CR, CRI, CRN 10	1-5	1-6	116 (8)
	6-17	7-22	145 (10)
CR, CRI, CRN 15	1-2	1-3	116 (8)
	3-12	4-17	145 (10)
CR, CRI, CRN 20	1	1-3	116 (8)
	2-10	4-17	145 (10)
CR, CRN 32	1-1 - 2	1-1 - 4	58 (4)
	3-2 - 6	5-2 - 10	145 (10)
	7-2 - 11-2	11-14	217 (15)
CR, CRN 45	1-1 - 1	1-1 - 2	58 (4)
	2-2 - 3	3-2 - 5	145 (10)
	4-2 - 8-1	6-2 - 13-2	217 (15)
CR, CRN 64	1-1	1-1 - 2-2	58 (4)
	1 - 2-1	2-1 - 4-2	145 (10)
	2 - 5-2	4-1 - 8-1	217 (15)
CR, CRN 90		1-1 - 1	58 (4)
	1-1 - 1	2-2 - 3-2	145 (10)
	2-2 - 4-1	3-6	217 (15)
CR, CRN 120	1-1 - 1	1 - 2-1	145 (10)
	2-2 - 3	2 - 5-1	217 (15)
	4-1 - 5-1	6-1 - 7	290 (20)
CR, CRN 150	1-1	1-1 - 1	145 (10)
	1-2	2-1 - 4-1	217 (15)
	3-2 - 4-2	5-2 - 6	290 (20)
CRT 2	2-6	2-11	145 (10)
	7-18	13-26	217 (15)
CRT 4	1-7	1-12	145 (10)
	8-16	14-22	217 (15)
CRT 8	1-16	1-20	145 (10)
CRT 16	2-10	2-16	145 (10)
CRN-SF	all	all	72 (5)*
			362 (25)**

\* While pump is off or during start-up.

\*\* During operation.

## 7.5 Maximum operating pressures

250 °F (194 °F for CRN-SF)

Pump type/ connection	Stages		Max. [psi (bar)]
	60 Hz	50 Hz	
CR, CRI, CRN 1s			
Oval flange	1-17	1-23	232 (16)
FGJ, PJE	1-27	1-36	362 (25)
CR, CRI, CRN 1			
Oval flange	1-17	1-23	232 (16)
FGJ, PJE	1-27	1-36	362 (25)
CR, CRI, CRN 3			
Oval flange	1-17	1-23	232 (16)
FGJ, PJE	1-27	1-36	362 (25)
CR, CRI, CRN 5			
Oval flange	1-16	1-22	232 (16)
FGJ, PJE	1-24	1-36	362 (25)
CR, CRI 10			
Oval flange CR	1-6		145 (10)
Oval flange, CRI	1-10	1-16	232 (16)
FGJ, GJ, PJE	1-10	1-16	232 (16)
FGJ, GJ, PJE	12-17	17-22	362 (25)
CRN 10			
All	1-17	1-22	362 (25)
CR, CRI 15			
Oval flange	1-5	1-7	145 (10)
FGJ, GJ, PJE	1-8	1-10	232 (16)
FGJ, GJ, PJE	9-12	12-17	362 (25)
CRN 15			
All	1-12	1-17	362 (25)
CR, CRI 20			
Oval flange	1-5	1-7	145 (10)
FGJ, GJ, PJE	1-7	1-10	232 (16)
FGJ, GJ, PJE	8-10	12-17	362 (25)
CRN 20			
All	1-10	1-17	362 (25)
CR, CRN 32			
	1-1 - 5	1-1 - 7	232 (16)
	6-2 - 11-2	8-2 - 14	435 (30)
CR, CRN 45			
	1-1 - 4-2	1-1 - 5	232 (16)
	4-2 - 8-1	6-2 - 13-2	435 (30)
CR, CRN 64			
	1-1 - 3	1-1 - 5	232 (16)
	4-2 - 5-2	6-2 - 8-1	435 (30)
CR, CRN 90			
	1-1 - 3	1-1 - 4	232 (16)
	4-2 - 4-1	5-2 - 6	435 (30)

Pump type/ connection	Stages		Max. [psi (bar)]
	60 Hz	50 Hz	
CR, CRN 120			
	1-1 - 3		232 (16)
	4-2 - 5-2	1-1 - 5-2	435 (30)
CR, CRN 150			
	1-1 - 3		232 (16)
	4-1 - 4-2	1-1 - 4-2	435 (30)
CRT 2	2-18	2-26	305 (21)
CRT 4	1-16	1-22	305 (21)
CRT 8	1-8	1-12	232 (16)
	10-16	14-20	362 (25)
CRT 16	1-8	1-8	232 (16)
	10-12	10-16	362 (25)

Consult Grundfos in case of other operating conditions.

## 8. Installation



### Warning

**Do not turn on the power supply until the pump is properly installed.**

### 8.1 Pump location

Locate the pump in a dry, well-ventilated, frost-free area which is not subject to extreme variation in temperature.

Make sure the pump is mounted at least 6 inches (150 mm) clear of any obstruction or hot surfaces.

The motor requires an adequate air supply to prevent overheating and adequate vertical space to remove the motor for repair.


In open systems requiring suction lift, locate the pump as close to the liquid source as possible to reduce friction loss in pipes.

### 8.2 Foundation

Use concrete or similar foundation material to provide a secure, stable mounting base for the pump.

See table below for bolt hole center line dimensions for the various pump types.

Secure the pump to the foundation using all four bolts and shim pump base to assure the pump is vertical and all four pads on the base are properly supported (uneven surfaces can result in pump base breakage when mounting bolts are tightened).



**Fig. 4** Pump position


The pump can be installed vertically or horizontally. See fig. 4. Ensure that an adequate supply of cool air reaches the motor cooling fan. The motor must never fall below the horizontal plane. Arrows on the pump base show the direction of flow of liquid through the pump.

To minimize possible noise from the pump, it is advisable to fit expansion joints on either side of the pump and anti-vibration mountings between the foundation and the pump.

**Note** *Make sure the vent plug is located in the uppermost position.*

Fit isolating valves on either side of the pump to avoid draining the system if the pump needs to be cleaned, repaired or replaced.

### Base and bolt hole center line dimensions



Pump type	L1		L2		B1		B2		Ø	
	[inches]	[mm]	[inches]	[mm]	[inches]	[mm]	[inches]	[mm]	[inches]	[mm]
CR 1s, 1, 3, 5	3 15/16	100	5 11/16	145	7 1/16	180	8 11/16	220	1/2	13
CRI, CRN 1s 1, 3, 5 CRT 2, 4	3 15/16	100	5 7/8	150	7 1/16	180	8 11/16	220	1/2	13
CR 10, 15, 20	5 1/8	130	6 15/16	176	8 7/16	215	10 1/16	256	9/16	13.5
CRN 10, 15, 20 CRT 8, 16	5 1/8	130	7 7/8	200	8 7/16	215	9 3/4	248	1/2	13
CR 32	6 11/16	170	8 3/4	223	9 7/16	240	11 3/4	298	9/16	14
CRN 32	6 11/16	170	8 7/8	226	9 7/16	240	11 3/4	298	9/16	14
CR 45, 64	7 1/2	190	9 3/4	248	10 1/2	266	13 1/16	331	9/16	14
CRN 45, 64	7 1/2	190	9 7/8	251	10 1/2	266	13 1/16	331	9/16	14
CR, CRN 90	7 13/16	199	10 1/4	261	11	280	13 11/16	348	9/16	14
CR, CRN 120, 150	10 13/16	275	13 9/16	344	14 15/16	380	18 9/16	472	11/16	18

### 8.3 Pump mounting



#### Warning

**CR, CRI, CRN pumps are shipped with covered suction and discharge ports. Remove the covers before the pipes are connected to the pump.**

#### 8.3.1 Recommended installation torques

Pump type	Recommended foundation torque [ft-lbs]	Recommended flange torque [ft-lbs]
CR, CRI, CRN 1s/1/3/5 and CRT 2/4	30	37-44
CR, CRI, CRN 10/15/20 and CRT 8/16	37	44-52
CR, CRN 32/45/64/90/120/150	52	52-59

### 8.4 Suction pipe

The suction pipe should be adequately sized and run as straight and short as possible to keep friction losses to a minimum (minimum of four pipe diameters straight run prior to the suction flange). Avoid using unnecessary fittings, valves or accessory items. Use butterfly valves in the suction line only when it is necessary to isolate a pump because of a flooded suction condition. This would occur if the water source is above the pump. See fig. 5 and fig. 6. Flush piping prior to pump installation to remove loose debris.




Fig. 5 Flooded suction




Fig. 6 Suction lift\*

\* The suction pipe should have a fitting on it for priming. CRN-SF pumps cannot be used for suction lift.

### 8.4.1 Suction pipe sizes

The following recommended suction pipe sizes are the smallest sizes which should be used with any specific CR pump type.

Verify the suction pipe size in each installation to ensure that good pipe practices are being observed and excess friction losses are not encountered.

High temperatures may require larger diameter pipes to reduce friction and improve NPHSA.

Pump type		Min. suction pipe size
CR, CRI, CRN 1s, 1, 3; CRT 2	1"	Nominal diameter acc. to ANSI schedule 40
CR, CRI, CRN 5; CRT 4	1 - 1/4"	Nominal diameter acc. to ANSI schedule 40
CR, CRI, CRN 10, 15, 20; CRT 8, 16	2"	Nominal diameter acc. to ANSI schedule 40
CR, CRN 32	2 - 1/2"	Nominal diameter acc. to ANSI schedule 40
CR, CRN 45	3"	Nominal diameter acc. to ANSI schedule 40
CR, CRN64, 90	4"	Nominal diameter acc. to ANSI schedule 40
CR, CRN 120, 150	5"	Nominal diameter acc. to ANSI schedule 40

### 8.5 Discharge pipe

We suggest to install a check valve and a isolating valve in the discharge pipe.

Pipe, valves and fittings should be at least the same diameter as the discharge pipe or sized in accordance with good piping practices to reduce excessive flow velocities and friction losses in pipes.

#### Caution

**The pressure rating of pipes, valves and fittings must be equal to or greater than the maximum system pressure.**

Before installing the pump, pressure check the discharge piping to at least the maximum pressure the pump is capable of generating or as required by codes or local regulations.

Whenever possible, avoid high pressure-loss fittings, such as elbows or branch tees directly on either side of the pump. The piping should be adequately supported to reduce thermal and mechanical stresses on the pump.

According to good installation practices, clean the system thoroughly and flush it of all foreign materials and sediment prior to pump installation. Furthermore, never install the pump at the lowest point of the system due to the natural accumulation of dirt and sediment. If there is excessive sediment or suspended particles, we recommend that a strainer or filter is used. Grundfos recommends that pressure gauges are installed on suction and discharge flanges or in pipes to monitor pump and system performance.



#### Warning


**To avoid problems with water hammer, do not use quick-closing valves in CRN-SF applications.**

## 8.6 Bypass


Install a bypass in the discharge pipe if there is any risk that the pump may operate against a closed valve in the discharge line. Flow through the pump is required to ensure that adequate cooling and lubrication of the pump is maintained.

See [7.3 Minimum inlet pressures](#) for minimum flow rates.


Elbows should be at least 12" from the bypass opening to prevent erosion.



**Fig. 7** Recommended bypass arrangement




**Fig. 8** Optional bypass arrangement



**Fig. 9** Optional bypass arrangement for CR, CRN 32, 45, 64 and CR 90, 120 and 150 only

## 8.7 Flange forces and torques

If not all loads reach the maximum permissible value stated in the tables after [fig. 10](#), one of these values may exceed the normal limit. Contact Grundfos for further information.



Y-direction: Direction of chamber stack

Z-direction: 90 ° from inlet/outlet

X-direction: Inlet/outlet

**Fig. 10** Flange forces and torques

Flange	CR, CRI, CRN	Force [F]		
		Y-direction [lb]	Z-direction [lb]	X-direction [lb]
1 1/4"	1s to 5	171	263	175
2"	10, 15 and 20	303	371	337
2 1/2"	32	382	466	422
3"	45	461	562	506
4"	64 and 90	607	753	674
5", 6"	120 and 150	607	753	674

Flange	CR, CRI, CRN	Torque [M]		
		Y-direction [ft-lb]	Z-direction [ft-lb]	X-direction [ft-lb]
1 1/4"	1s to 5	605	715	900
2"	10, 15 and 20	738	848	1,033
2 1/2"	32	793	904	1,106
3"	45	848	959	1,180
4"	64 and 90	922	1,069	1,291
5", 6"	120 and 150	922	1,069	1,291



## 8.8 Minimum continuous duty flow rates [gpm]

Pump type	min. °F to 176 °F (min. °C to 80 °C)	at 210 °F (at 99 °C)	at 248 °F (at 120 °C)	at 356 °F (at 180 °C)
CR, CRI, CRN 1s	0.5	0.7	1.2	1.2*
CR, CRI, CRN 1	0.9	1.3	2.3	2.3*
CR, CRI, CRN 3	1.6	2.4	4.0	4.0*
CR, CRI, CRN 5	3.0	4.5	7.5	7.5*
CR, CRI, CRN 10	5.5	8.3	14	14*
CR, CRI, CRN 15	9.5	14	24	24*
CR, CRI, CRN 20	11	17	28	28*
CR, CRN 32	14	21	35	35*
CR, CRN 45	22	33	55	55*
CR, CRN 64	34	51	85	85*
CR, CRN 90	44	66	110	110*
CR, CRN 120	60	90	N/A	N/A
CR, CRN 150	75	115	N/A	N/A
CRT 2	1.3	2.0	3.3	N/A
CRT 4	3.0	4.5	7.5	N/A
CRT 8	4.0	6.0	10	N/A
CRT 16	8.0	12	20	N/A

\* Grundfos Cool-Top® is only available in the following pump types:

Pump type	CR 1s	CR 1	CR 3	CR 5	CR 10	CR 15	CR 20	CR 32	CR 45	CR 64	CR 90
Standard (CR)								•	•	•	•
I version (CRI)	•	•	•	•	•	•	•				
N version (CRN)	•	•	•	•	•	•	•	•	•	•	•

## 8.9 Check valves

A check valve may be required on the discharge side of the pump to prevent the pump inlet pressure from being exceeded.

When a pump with no check valve is stopped because there is no demand on the system (all valves are closed), the high system pressure on the discharge side of the pump will "find" its way back to the inlet of the pump.

This is especially critical for CRN-SF applications because of the very high discharge pressures involved. As a result, most CRN-SF installations require a check valve on the discharge piping.

## 8.10 Temperature rise

It may sometimes be necessary to stop the flow through a pump during operation.

When the flow is stopped, the power to the pump is transferred to the pumped liquid as heat, causing a temperature rise in the liquid.

The result is risk of overheating and consequent damage to the pump. The risk depends on the temperature of the pumped liquid and for how long the pump is operating without flow. See the following temperature rise table.

Pump type	Time for temperature rise of 18 °F (10 °C)	
	Seconds	Minutes
CR 1s, 1, 3	210	3.5
CR 5	240	4.0
CR 10	210	3.5
CR 15	150	2.5
CR 20	120	2.0
CR 32, 45, 64, 90, 120, 150	60	1.0

### Conditions/reservations

The listed times are subject to the following conditions/reservations:

- No exchange of heat with the surroundings.
- The pumped liquid is water with a specific heat capacity of 1.0 Btu/lb. °F (4.18 kJ/kg °C).
- Pump parts (chambers, impellers and shaft) have the same heat capacity as water.
- The water in the base and the pump head is not included.

These reservations should give sufficient safety margin against excessive temperature rise.

The maximum temperature must not exceed the pump maximum temperature rating.

## 8.11 Electrical connection

### Warning

**The safe operation of this pump requires that it is grounded in accordance with the National Electrical Code and local codes and regulations. Connect the ground conductor to the grounding screw in the terminal box and then to the ACCEPTABLE grounding point. All electrical work must be performed by a qualified electrician in accordance with the latest edition of the National Electrical Code and local codes and regulations.**



## 8.12 Motors

Grundfos CR pumps are supplied with heavy-duty, 2-pole (3600 rpm), ODP (open drip-proof) or TEFC (totally enclosed fan cooled), NEMA C frame motors selected to our rigid specifications.

Motors with other enclosure types and for other voltages and frequencies are available on a special-order basis.

CRN-SF pumps are supplied with an IEC (metric) type motor with a reverse thrust bearing.

If you replace the pump, but keep a motor previously used on another CR pump, be sure to read [12. Maintaining the motor](#) for proper adjustment of the coupling height.

## 8.13 Position of terminal box

The motor terminal box can be turned to any of four positions in steps of 90 °.

To rotate the terminal box, remove the four bolts securing the motor to the pump but do not remove the coupling. Turn the motor to the desired position; replace and securely tighten the four bolts. See fig. 11.




Fig. 11 Motor terminal box positions (top view)

## 8.14 Field wiring

Lead sizes should be based on the current carrying properties of conductors required by the latest edition of the National Electrical Code or local regulations. Direct-on-line (DOL) starting is approved due to the extremely short run-up time of the motor and the low moment of inertia of the pump and motor. If DOL starting is not acceptable and reduced starting current is required, use an auto transformer, resistance starter or soft starter. We suggest to use a fused disconnect for each pump in case standby pumps are installed.

TM04 3923 0409

## 8.15 Motor protection

### 8.15.1 Single-phase motors

All CR pumps with single phase motors, except 10 hp, are equipped with multi-voltage, squirrel cage induction motors which include built-in thermal protection.

### 8.15.2 Three-phase motors

CR pumps with three-phase motors must be used with the proper size and type of motor-protective circuit breaker to ensure the motor is protected against damage from low voltage, phase failure, current unbalance and overloads.

Use a properly sized circuit breaker with manual reset and ambient-temperature compensated extra-quick trip in all three phases. The overload protection should be set and adjusted to the full-load current rating of the motor. Under no circumstances should the overload protection be set to a higher value than the full-load current shown on the motor nameplate. This will void the warranty.

Set overload protection for auto transformers and resistance starters in accordance with the recommendations of the manufacturer.

Three-phase MLE motors (CRE-pumps) require only fuses as circuit breaker. They do not require a motor-protective circuit breaker. Check for phase unbalance (worksheet is provided. See section 18. [Worksheet for three-phase motors](#)).

**Caution** Standard allowable phase unbalance is 5 %.

### 8.15.3 CRN-SF

The CRN-SF is typically operated in series with a feed pump. Because the maximum allowable inlet pressure of the CRN-SF increases from 73 psi (when pump is off and during start-up) to 365 psi (during operation), use a control device to start the CRN-SF pump one second before the feed pump starts. Similarly, the CRN-SF must stop one second after the feed pump stops. See CRN-SF start-up timeline below.




Fig. 12 CRN-SF start-up

## 9. Commissioning

### 9.1 Priming

To prime the pump in a closed system or an open system where the water source is above the pump, close the pump isolating valve(s) and open the priming plug on the pump head.

See fig. 13, fig. 14, and fig. 15.




Fig. 13 Position of plugs and bypass valve




Fig. 14 Position of plugs CR, CRN 32, 45, 64, 90, 120, 150




Fig. 15 Vent plug

In open systems where the water level is below the pump inlet, the suction pipe and pump must be filled with liquid and vented before starting the pump.

1. Close the discharge isolating valve and remove the priming plug.
2. Pour water through the priming hole until the suction pipe and pump are completely filled with liquid. If the suction pipe does not slope downwards away from the pump, the air must be purged while priming the pump.
3. Replace the priming plug and tighten securely.

## 9.2 Startup

1. Gradually open the isolating valve in the suction line until a steady stream of airless water runs out of the priming hole.
2. Close the plug and tighten securely.
3. Completely open the isolating valves.

For pumps with Cool-Top®, see section [16. Startup of pump with air-cooled top \(Cool-Top®\)](#).

Follow these steps:

1. Switch off the power supply.
2. Check to make sure the pump has been filled and vented.
3. Remove the coupling guard and rotate the pump shaft by hand to make sure it turns freely.
4. Verify that the electrical connections are in accordance with the wiring diagram on the motor.
5. Switch on the power and observe the direction of rotation. When viewed from above, the pump should rotate counter-clockwise (clockwise for CRN-SF).
6. To reverse the direction of rotation, first switch off the power supply.
7. On three-phase motors, interchange any two phases of the power supply.  
On single-phase motors, see wiring diagram on the nameplate. Change wiring as required.
8. Switch on the power again and check for proper direction of rotation. Once direction of rotation has been verified, switch off the power again. Do not attempt to reinstall the coupling guards while the motor is on. Replace the coupling guard if the direction of rotation is correct. When the guards are in place, the power can be switched on again.

**For CR, CRI, CRN 1s to 5 it is advisable to open the bypass valve during start-up. See fig. 13.**

**Note**

**The bypass valve connects the suction and discharge sides of the pump, thus making the filling procedure easier. Close the bypass valve when operation is stable.**

**Motors should not be run unloaded or uncoupled from the pump at any time; damage to the motor bearings will occur.**

**Caution**

**Do not start the pump before priming or venting the pump. See fig. 15. Never let the pump run dry.**

## 10. Operation

### 10.1 Operating parameters

CR multi-stage centrifugal pumps installed in accordance with these instructions and sized for correct performance will operate efficiently and provide years of service. The pumps are water-lubricated and do not require any external lubrication or inspection. The motors may require periodic lubrication as described in section [12. Maintaining the motor](#).

Under no circumstances should the pump be operated for any prolonged periods of time without flow through the pump. This can result in motor and pump damage due to overheating. A properly sized relief valve should be installed to allow sufficient liquid to circulate through the pump to provide adequate cooling and lubrication of the pump bearings and seals.

## 10.2 Pump cycling

Pump cycling should be checked to ensure the pump is not starting more often than the following max. starts per hour:

Grundfos ML motors:

- 200 times per hour on 1/3 to 5 hp models
- 100 times per hour on 7 1/2 to 15 hp models
- 40 times per hour on 20 to 30 hp models.

Baldor motors:

- 20 times per hour on 1/3 to 5 hp models
- 15 times per hour on 7 1/2 to 15 hp models
- 10 times per hour on 20 to 100 hp models.

Rapid cycling is a major cause of premature motor failure due to overheating of the motor. If necessary, adjust controller to reduce the frequency of starts and stops.

## 10.3 Boiler feed installations

If the pump is used as a boiler feed pump, make sure the pump is capable of supplying sufficient water throughout its entire evaporation and pressure ranges. Where modulating control valves are used, a bypass around the pump must be installed to ensure pump lubrication. See section [7.3 Minimum inlet pressures](#).

## 10.4 Frost protection

If the pump is installed in an area where frost could occur, the pump and system should be drained during freezing temperatures to avoid damage. To drain the pump, close the isolating valves, remove the priming plug and drain plug at the base of the pump. Do not refit the plugs until the pump is to be used again. Always replace the drain plug with the original or an exact replacement. Do not replace with a standard plug. Internal recirculation will occur, reducing the output pressure and flow.

## 11. Maintaining the pump

Depending on the conditions and operating time, make the following checks at regular intervals:

- Check that the pump meets the required performance and is operating smoothly and quietly.
- Check that there are no leaks, particularly at the shaft seal.
- Check that the motor is not overheating.
- Remove and clean all strainers or filters in the system.
- Check that the tripping function of the motor overload protection works.
- Check the operation of all controls.
- If the pump is not operated for unusually long periods, maintain the pump in accordance with these instructions. In addition, if the pump is not drained, the pump shaft should be manually rotated or run for short periods of time at monthly intervals.
- In severe-duty applications, pump life may be extended by performing one of the following actions:
  - Drain the pump after each use.
  - Flush the pump with water or other liquid that is compatible with the pump materials and process liquid.
  - Disassemble the pump and thoroughly rinse or wash components in contact with the pumped liquid with water or other liquid that is compatible with the pump materials and process liquid.

If the pump fails to operate or there is a loss of performance, see to section [17. Diagnosing specific problems](#).

## 12. Maintaining the motor



### Warning

**Before starting work on the motor, make sure that all power supplies to the motor have been switched off and that they cannot be accidentally switched on. Electric shock can cause serious or fatal injury. Only qualified personnel should attempt installation, operation, and maintenance of this equipment.**

### 12.1 Motor inspection

Inspect the motor approximately every 500 hours of operation or every three months, whichever occurs first. Keep the motor clean and the ventilation openings clear.

Go through the following steps during each inspection:

1. Check that the motor is clean. Check that the interior and exterior of the motor are free of dirt, oil, grease, water, etc. Oily residue, paper, pulp, textile lint, etc. can accumulate and block motor ventilation. If the motor is not properly ventilated, overheating can occur and cause early motor failure.
2. Use an ohmmeter periodically to ensure that the winding insulation is OK. Record the ohmmeter readings, and immediately investigate any significant drop in insulation resistance.
3. Check all electrical connections to be sure that they are tightened securely.

### 12.3 Recommended lubricant

Severity of duty	Ambient temperature (max.)	Environment	Approved types of grease
Standard	104 °F (40 °C)	Clean, little corrosion	Grundfos ML motors are greased for life, or the grease type will be stated on the nameplate. Baldor motors are greased with Polyrex EM (Exxon Mobile).
Severe	122 °F (50 °C)	Moderate dirt, corrosion	
Extreme	> 122 °F (50 °C) or class H insulation	Severe dirt, abrasive dust, corrosion	

### 12.4 Lubricating chart (for motors with grease zerks)

New motors that have been stored for a year or more should be regreased according to the following table:

NEMA (IEC) frame size	Service intervals [hours]			Weight of grease [oz (grams)]	Volume of grease [in <sup>3</sup> (teaspoons)]
	Standard duty	Severe duty	Extreme duty		
Up to and incl. 210 (132)	5500	2750	550	0.30 (8.4)	0.6 (2)
Over 210 up to and incl. 280 (180)	3600	1800	360	0.61 (17.4)	1.2 (3.9)
Over 280 up to and incl. 360 (225)	2200	1100	220	0.81 (23.1)	1.5 (5.2)
Over 360 (225)	2200	1100	220	2.12 (60.0)	4.1 (13.4)

### 12.2 Motor lubrication

Electric motors are pre-lubricated from factory and do not require additional lubrication at start-up. Motors without external grease zerks have sealed bearings that cannot be re-lubricated. Motors with grease zerks should only be lubricated with approved types of grease. Do not over-grease the bearings. Over-greasing will cause increased bearing heat and can result in bearing or motor failure. Do not mix oil-based grease and silicon grease in motor bearings.

Bearing grease will lose its lubricating ability over time.

The lubricating ability of a grease depends primarily on the type of grease, the size of the bearings, the speed at which the bearings operate and the severity of the operating conditions.

Good results can be obtained if the following recommendations are used in your maintenance program. It should also be noted that multistage pumps, pumps running to the left of the performance curve, and certain pump ranges may have higher thrust loads. Pumps with high thrust loads should be greased according to the next service interval level.



### Warning

**The grease outlet plug *MUST* be removed before adding new grease.**

## 12.5 Lubricating procedure

**Keep grease free from dirt to avoid damage to motor bearings. If the environment is extremely dirty, contact Grundfos, the motor manufacturer, or an authorized service center for additional information.**

### Caution

**Do not mix dissimilar types of grease.**

1. Clean all grease zerks. If the motor does not have grease zerks, the bearing is sealed and cannot be greased externally.
2. If the motor is equipped with a grease outlet plug, remove it. This will allow the old grease to be displaced by the new grease. If the motor is stopped, add the recommended amount of grease. If the motor is to be lubricated while running, add a slightly greater quantity of grease.
3. Add grease SLOWLY taking approximately one minute until new grease appears at the shaft hole in the flange or grease outlet plug. Never add more than 1 1/2 times the amount of grease shown in the lubricating chart.

**If new grease does not appear at the shaft hole or grease outlet, the outlet passage may be blocked. Contact Grundfos service center or certified motor shop.**

### Note

4. Let motors equipped with a grease outlet plug run for 20 minutes before replacing the plug.

## 13. Replacing the motor

**Motors used on CR pumps are specifically selected to our rigid specifications. Replacement motors must be of the same frame size, should be equipped with the same or better bearings and have the same service factor. Failure to follow these recommendations may result in premature motor failure.**

### Caution

If the motor is damaged due to bearing failure, burning or electrical failure, observe the following instructions as to how to remove the motor and how to mount the replacement motor.



### Warning

**Before starting work on the motor, make sure that the mains switch has been switched off. It must be ensured that the power supply cannot be accidentally switched on.**

## 13.1 Disassembly

Proceed as follows:

1. Disconnect the power supply leads from the motor. Remove the coupling guards.

### Note

**For CR 1s, 1, 3, 5, 10, 15, and 20: Do not loosen the three hexagon socket head cap screws securing the shaft seal.**

2. Use the proper metric hexagon key to loosen the four cap screws in the coupling. Remove coupling halves completely. On CR 1s-CR 20, the shaft pin can be left in the pump shaft. CR, CRN 32, 45, 64, 90, 120, and 150 do not have a shaft pin.
3. Use the correct size spanner to loosen and remove the four mounting bolts joining motor and pump.
4. Lift the motor straight up until the shaft has cleared the motor stool.

## 13.2 Assembly

Proceed as follows:

1. Remove key from motor shaft, if present, and discard.
2. Thoroughly clean the surfaces of the motor and pump mounting flanges. The motor and shaft must be clean of all oil or grease and other contaminants where the coupling attaches. Place the motor on top of the pump.
3. Turn the terminal box to the desired position by rotating the motor.
4. Insert the four mounting bolts, then tighten diagonally and evenly:
  - for 3/8" bolts (1/2 - 2 hp), torque = 17 ft-lb
  - for 1/2" bolts (3 - 40 hp), torque = 30 ft-lb
  - for 5/8" bolts (50 - 100 hp), torque = 59 ft-lb
  - follow instructions for particular pump model in sections [13.2.2 CR 1s, 1, 3, and 5](#) to [13.2.5 CR, CRN 32, 45, 64, 90, 120, and 150](#).

### 13.2.1 Torque specifications

**Torque specifications for CR, CRI, CRN 1s, 1, 3, 5, 10, 15, and 20 CRT 2, 4, 8, and 16**

Coupling screw size	Minimum torque
M6	10 ft-lb
M8	23 ft-lb
M10	46 ft-lb




### 13.2.2 CR 1s, 1, 3, and 5

1. Insert shaft pin into shaft hole.
2. Mount the coupling halves onto shaft and shaft pin.
3. Fit the coupling screws and leave loose. Check that the gaps on either side of the coupling are even and that the motor shaft keyway is centered in the coupling half as shown in fig. 16.
4. Tighten the screws to the correct torque. See section 13.2.1 *Torque specifications*.

### 13.2.3 CR 10, 15 and 20

1. Insert shaft pin into shaft hole.
2. Insert plastic shaft seal spacer beneath shaft seal collar.
3. Mount the coupling halves onto shaft and shaft pin.
4. Fit the coupling screws and leave loose. Check that the gaps on either side of the coupling are even and that the motor shaft keyway is centered in the coupling half as shown in fig. 16.
5. Tighten the screws to the correct torque. See section [13.2.1 Torque specifications](#).
6. Remove plastic shaft seal spacer and hang it on inside of coupling guard.




**Fig. 16** Coupling adjustment all CR, CRI, CRN, CRT

TM04 3919 3613

### 13.2.4 CRT 2, 4, 8 and 16

1. Mount coupling halves. Make sure the shaft pin is located in the pump shaft.
2. Put the cap screws loosely back into the coupling halves.
3. Using a large screwdriver, raise the pump shaft by placing the tip of the screwdriver under the coupling and carefully raising the coupling to its highest point. See fig. 17.




**Fig. 17** Coupling adjustment CRT 2, 4, 8, and 16

TM02 1051 2713

### Note

***The shaft can only be raised approximately 0.20 inches (5 mm).***

4. Now lower the shaft halfway back the distance you just raised it and tighten the coupling screws (finger tight) while keeping the coupling gap equal on both sides. When the screws are tight enough to keep the coupling in place, then cross-tighten the screws.
  - Note the clearance below the coupling.
  - Raise the coupling as far as it will go.
  - Lower it halfway back down (1/2 the distance you just raised it).
  - Tighten screws (see torque specifications).




**Fig. 18** Coupling adjustment clearance CRT 2, 4, 8, and 16

TM02 1051 0501


### 13.2.5 CR, CRN 32, 45, 64, 90, 120, and 150

1. Make sure pump shaft is all the way down. Tighten the set screws on the mechanical shaft seal.
2. Place the plastic adjusting fork under the cartridge seal collar. See fig. 19.



**Fig. 19** Coupling adjustment CR, CRN 32, 45, 64, 90, 120, and 150

3. Fit the coupling on the shaft so that the top of the pump shaft is flush with the bottom of the coupling chamber. See fig. 20.




**Fig. 20** Coupling adjustment, CR, CRN 32, 45, 64, 90, 120, and 150

#### Caution

**To avoid damaging the coupling halves, ensure that the motor shaft keyway is centered in the coupling half as shown in fig. 16.**

4. Lubricate the coupling screws with an anti-seize, lubricating compound. Tighten the coupling screws (finger tight) while keeping the coupling gap equal on both sides and the motor shaft keyway centered in the coupling half as shown in fig. 16. When the screws are tight enough to keep the coupling in place, then cross-tighten the screws.

5. Tighten coupling screws to 62 ft-lbs (75 and 100 hp motors to 74 ft-lbs). Remove the adjusting fork from under the cartridge seal collar and replace it to the storage location. See fig. 21.



**Fig. 21** Adjusting fork storage CR, CRN 32, 45, 64, 90, 120, and 150

6. Check to see that the gaps between the coupling halves are equal. Loosen and readjust, if necessary.
7. Make sure the pump shaft can be rotated by hand. If the shaft cannot be rotated or it jams, disassemble and check for misalignment.
8. Prime the pump.
9. Follow the wiring diagram on the motor label for the correct motor wiring combination which matches your supply voltage. Once this has been confirmed, reconnect the power supply leads to the motor.
10. Check the direction of rotation by bump-starting the motor. Direction of rotation must be left to right (counter-clockwise) when looking directly at the coupling.
11. Switch off the power, then mount the coupling guards. When the coupling guards have been mounted, the power can be switched on again.



## 14. Parts list

Grundfos offers an extensive parts list for each CR pump model. A parts list typically covers the following items:

- a diagram of pump parts which we recommend to have on hand for future maintenance
- a list of prepacked service kits covering the pump components most likely to be exposed to wear over time
- complete chamber stacks needed to replace the rotating assembly of each model.

These parts lists are available separately from the Grundfos literature warehouse or as a set with extensive service instructions in the Grundfos CR Service Manuals.



Fig. 22 Prepacked chamber stack kits



Fig. 23 Prepacked flange kits

### 14.1 Spare parts

Grundfos offers an extensive list of spare parts for CR pumps. For a current list of these parts, see Grundfos All Product Spare Parts/Service Kits Price List, part number L-SK-SL-002.

## 15. Preliminary electrical tests

### Warning

*When working with electrical circuits, use caution to avoid electrical shock. It is recommended that rubber gloves and boots be worn, and metal terminal boxes and motors are grounded before any work is done. For your protection, always disconnect the pump from its power source before handling.*



### 15.1 Supply voltage

#### 15.1.1 How to measure the supply voltage

Use a voltmeter (set to the proper scale) to measure the voltage at the pump terminal box or starter. On single-phase units, measure between power leads L1 and L2 (or L1 and N for 115 volt units). On three-phase units, measure between:

- Power leads L1 and L2
- Power leads L2 and L3
- Power leads L3 and L1.




Fig. 24 Measuring supply voltage


#### 15.1.2 Meaning of supply voltage measurement

When the motor is under load, the voltage should be within + 10 %/- 10 % of the nameplate voltage. Larger voltage variation may cause winding damage. Large variations in the voltage indicate a poor electrical supply and the pump should not be operated until these variations have been corrected. If the voltage constantly remains high or low, the motor should be changed to the correct supply voltage.

15.2 Current

15.2.1 How to measure the current

Use an ammeter (set on the proper scale) to measure the current on each power lead at the terminal box or starter. See the motor nameplate for amp draw information. Current should be measured when the pump is operating at constant discharge pressure.



TM04 3908 2609

Fig. 25 Measuring current

15.2.2 Meaning of current measurement


If the amp draw exceeds the listed service factor amps (SFA) or if the current unbalance is greater than 5 % between each leg on three-phase units, check for the following faults:

Fault	Remedy
Burned contacts in the motor-protective circuit breaker.	Replace contacts.
Loose terminals in motor-protective circuit breaker or terminal box or possibly defective lead.	Tighten terminals or replace lead.
Too high or too low supply voltage.	Reestablish correct supply voltage.
Motor windings are short-circuited or grounded. (Check winding and insulation resistances).	Remove cause of short circuit or grounding.
Pump is damaged causing motor overload.	Replace defective pump parts.

15.3 Insulation resistance

15.3.1 How to measure the insulation resistance

Turn off power and disconnect the supply power leads in the pump terminal box. Using an ohmmeter or megohmmeter, set the scale selector to R x 100K and zero-adjust the meter. Measure and record the resistance between each of the terminals and ground.



TM04 3907 2609

Fig. 26 Measuring insulation resistance

15.3.2 Meaning of insulation resistance measurement

Motors of all hp, voltage, phase and cycle duties have the same value of insulation resistance. Resistance values for new motors must exceed 1,000,000 ohms. If they do not, the motor should be repaired or replaced.





## 16. Startup of pump with air-cooled top (Cool-Top®)

**Caution**

Do not start the pump until it has been filled with liquid and vented.


**Warning**

Pay attention to the direction of the vent hole and ensure that the escaping liquid does not cause injury to persons or damage to the motor or other components. In hot-liquid installations, pay special attention to the risk of injury caused by scalding hot liquid. We recommend you to connect a drain pipe to the 1/2" air vent in order to lead the hot water/steam to a safe place.

Step	Action
<p>1</p>  <p>Open Closed</p> <p>TM02 4151 5001</p>	<p>The air-cooled top should only be started up with cold liquid. Close the isolating valve on the discharge side and open the isolating valve on the suction side of the pump.</p>
<p>2</p>  <p>TM02 4153 1503</p>	<p>Remove the priming plug from the air-cooled chamber (pos. 2) and slowly fill the chamber with liquid.</p> <p>When the chamber is completely filled with liquid, replace the priming plug and tighten securely.</p>
<p>3</p>  <p>Open Open</p> <p>TM02 5907 1503</p>	<p>Open the isolating valve on the discharge side of the pump. The valve may have to be partially closed when the pump is started if there is no counter pressure (i.e. boiler not up to pressure).</p>
<p>4</p>  <p>TM01 1406 3702 - TM01 1405 4497</p>	<p>Start the pump and check the direction of rotation.</p> <p>See the correct direction of rotation of the pump on the motor fan cover.</p> <p>If the direction of rotation is wrong, interchange any two of the incoming power supply leads.</p> <p>After 3 to 5 minutes, the air vent has been filled with liquid.</p> <p><b>Note</b></p> <p><i>During start-up of a cold pump with hot liquid, it is normal that a few drops of liquid are leaking from the sleeve.</i></p>

## 17. Diagnosing specific problems



### Warning

*Before removing the terminal box cover and before removing/dismantling the pump, make sure that the power supply has been switched off and that it cannot be accidentally switched on.*

Problem	Possible cause	Remedy
1. The pump does not run.	a) No power to motor.	Check voltage to motor terminal box. If no voltage to motor, check starter panel for tripped circuits and reset circuits.
	b) Fuses blown or circuit breaker tripped.	Turn off power and remove fuses. Check for continuity with ohmmeter. Replace blown fuses or reset circuit breaker. If new fuses blow or circuit breaker trips, the electrical installation, motor and wires must be checked.
	c) Motor starter overload protection burned or tripped out.	Check for voltage on line and load side of starter. Replace or reset burned motor protection. Inspect starter for other damage. If protection trips again, check the supply voltage and starter holding coil.
	d) Starter does not energize.	Energize control circuit and check for voltage to the holding coil. If no voltage, check control circuit fuses. If voltage, check holding coil for short circuits. Replace bad coil.
	e) Defective control devices.	Check that all safety and pressure switches function correctly. Inspect contacts in control devices. Replace worn or defective parts or control devices.
	f) Motor is defective.	Turn off power and disconnect wiring. Measure the lead-to-lead resistances with ohmmeter (RX-1). Measure lead-to-ground values with ohmmeter (RX-100K). Record measured values. If an open or grounded winding is found, remove motor and repair or replace it.
	g) Defective capacitor (single-phase motors).	Turn off power and discharge capacitor. Check with ohmmeter (RX-100K). When the meter is connected to the capacitor, the needle should jump towards 0 ohms and slowly drift back to infinity (h). Replace capacitor if defective.
	h) Pump is blocked or seized.	Turn off power and manually rotate pump shaft. If shaft does not rotate easily, check coupling setting and adjust as necessary. If shaft rotation is still tight, remove pump and inspect. Disassemble and repair the pump.

Problem	Possible cause	Remedy
2. The pump runs but at reduced performance or does not deliver water.	a) Wrong direction of rotation.	Check wiring for proper connections. Correct wiring.
	b) Pump is not primed or is air-bound.	Turn pump off, close isolation valve(s) and remove priming plug. Check liquid level. Refill the pump, replace plug and start the pump. Long suction lines must be filled before starting the pump.
	c) Strainers, check or foot valves are clogged.	Remove strainer, screen or check valve and inspect. Clean and replace. Reprime pump.
	d) Suction lift too large.	Install compound pressure gauge at the suction side of the pump. Start pump and compare reading to performance data. Reduce suction lift by lowering pump, increase suction line size or removing high friction loss devices.
	e) Suction and/or discharge pipes leaking. (Pump spins backwards when turned off)	Air in suction pipe. Suction pipe, valves and fittings must be airtight. Repair any leaks and retighten all loose fittings.
	f) Pump worn.	Install pressure gauge, start pump, gradually close the discharge valve and read pressure at shutoff. Convert measured pressure (in psi) to head (in feet): (Measured psi x 2.31 ft/psi = ____ ft). Refer to the specific pump curve for shutoff head for that pump model. If head is close to curve, pump is probably OK. If not, remove pump and inspect.
	g) Pump impeller or guide vane is clogged.	Disassemble and inspect pump passageways. Remove any foreign materials found.
	h) Incorrect drain plug installed.	If the proper drain plug is replaced with a standard plug, water will recirculate internally. Replace with proper plug.
	i) Improper coupling setting.	Check/reset the coupling. See page 18.
3. Pump cycles too much	a) Pressure switch is not properly adjusted or is defective.	Check that pressure switch is set and functions correctly. Check voltage across closed contacts. Readjust switch or replace if defective.
	b) Level control is not properly adjusted or is defective.	Check that level control is set and functions correctly. Readjust setting (refer to level control manufacturer's data). Replace if defective.
	c) Insufficient air charging or leaking tank or piping.	Pump air into tank or diaphragm chamber. Check diaphragm for leaks. Check tank and piping for leaks with soap and water solution. Check air-to-water volume. Repair as necessary.
	d) Tank is too small.	Check tank size and air volume in tank. Tank volume should be approximately 10 gallons for each gpm of pump performance. The normal air volume is 2/3 of the total tank volume at the pump cut-in pressure. Replace tank with one of correct size.
	e) Pump is oversized.	Install pressure gauges on or near pump suction and discharge ports. Start and run pump under normal conditions, record gauge readings. Convert psi to feet (Measured psi x 2.31 ft/psi = ____ ft) Refer to the specific pump curve for that model, ensure that total head is sufficient to limit pump delivery within its design flow range. Throttle pump discharge flow if necessary.

Problem	Possible cause	Remedy
4. Fuses blow or circuit breakers or overload relays trip	a) Tank is too small.	Check voltage at starter panel and motor. If voltage varies more than - 10 %/+ 10 %, contact power company. Check wire sizing.
	b) Motor overload protection set too low.	Cycle pump and measure amperage. Increase size of overload protection or adjust trip setting to maximum motor nameplate (full load) current.
	c) Three-phased current is imbalanced.	Check current draw on each lead to the motor. Must be within - 5 %/+ 5 %. If not, check motor and wiring. Rotating all leads may eliminate this problem.
	d) Motor short-circuited or grounded.	Turn off power and disconnect wiring. Measure the lead-to-lead resistance with an ohmmeter (RX-1). Measure lead-to-ground values with an ohmmeter (RX-100K) or a megaohmmeter. Record values. If an open or grounded winding is found, remove the motor, repair and/or replace.
	e) Wiring or connections are faulty.	Check proper wiring and loose terminals. Tighten loose terminals. Replace damaged wires.
	f) Pump is blocked or seized.	Turn off power and manually rotate pump shaft. If shaft does not rotate easily, check coupling setting and adjust as necessary. If shaft rotation is still tight, remove pump and inspect. Disassemble and repair the pump.
	g) Defective capacitor (single-phase motors).	Turn off power and discharge capacitor. Check with ohmmeter (RX-100K). When the meter is connected to the capacitor, the needle should jump towards 0 ohms and slowly drift back to infinity ( $\infty$ ). Replace capacitor if defective.
	h) Motor overload protection devices at higher ambient temperature than motor.	Use a thermometer to check the ambient temperature near overload protection devices and motor. Record these values. If ambient temperature at motor is lower than at overload protection devices, especially where temperature at overload protection devices is above 104 °F (40 °C), replace standard protection devices with ambient-compensated protection devices.

## 18. Worksheet for three-phase motors

Below is a worksheet for calculating current unbalance on a three-phase hookup. Use the calculations below as a guide.

Note

*Current unbalance should not exceed 5 % at service factor load or 10 % at rated input load. If the unbalance cannot be corrected by rolling the leads, the source of the unbalance must be located and corrected. If, on the three possible hookups, the leg farthest from the average stays on the same power lead, most of the unbalance is coming from the power source. However, if the reading farthest from the averages moves with the same motor lead, the primary source of unbalance is on the "motor side" of the starter. In this instance, consider if the cause can be a damaged cable, an untight cable splice, a poor connection, or a faulty motor winding.*

Explanation and examples		
Here is an example of current readings at maximum pump loads on each leg of a three-wire hookup. You must make calculations for all three hookups. To begin, add up all three readings for hookup numbers 1, 2, and 3.	<b>Hookup 1</b> T1 = 51 amps T2 = 46 amps T3 = 53 amps <hr/> TOTAL = 150	
Divide the total by three to obtain the average.	<b>Hookup 1</b> 50 amps 3 $\overline{)150 \text{ amps}}$	
Calculate the greatest current difference from the average.	<b>Hookup 1</b> 50 amps — 46 amps <hr/> 4 amps	
Divide this difference by the average to obtain the percentage of the unbalance. In this case, the current unbalance for <b>Hookup 1</b> is 8 %.	<b>Hookup 1</b> .08 or 8 % 50 $\overline{)4.00 \text{ amps}}$	
Blank worksheet		
<b>Hookup 1</b> L <sub>1</sub> to T <sub>1</sub> = ___ amps L <sub>2</sub> to T <sub>2</sub> = ___ amps L <sub>3</sub> to T <sub>3</sub> = ___ amps <hr/> TOTAL = ___ amps	<b>Hookup 2</b> L <sub>1</sub> to T <sub>3</sub> = ___ amps L <sub>2</sub> to T <sub>1</sub> = ___ amps L <sub>3</sub> to T <sub>2</sub> = ___ amps <hr/> TOTAL = ___ amps	<b>Hookup 3</b> L <sub>1</sub> to T <sub>2</sub> = ___ amps L <sub>2</sub> to T <sub>3</sub> = ___ amps L <sub>3</sub> to T <sub>1</sub> = ___ amps <hr/> TOTAL = ___ amps
<b>Hookup 1</b> ___ amps 3 $\overline{) \text{ ___ amps}}$	<b>Hookup 2</b> ___ amps 3 $\overline{) \text{ ___ amps}}$	<b>Hookup 3</b> ___ amps 3 $\overline{) \text{ ___ amps}}$
<b>Hookup 1</b> ___ amps ___ amps <hr/> ___ amps	<b>Hookup 2</b> ___ amps ___ amps <hr/> ___ amps	<b>Hookup 3</b> ___ amps ___ amps <hr/> ___ amps
<b>Hookup 1</b> ___ or ___ % ___ $\overline{) \text{ ___ amps}}$	<b>Hookup 2</b> ___ or ___ % ___ $\overline{) \text{ ___ amps}}$	<b>Hookup 3</b> ___ or ___ % ___ $\overline{) \text{ ___ amps}}$

## 19. Disposal

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

Subject to alterations.

**Grundfos Kansas City**

17100 West 118th Terrace  
Olathe, Kansas 66061  
Phone: +1-913-227-3400  
Fax: +1-913-227-3500

[www.grundfos.us](http://www.grundfos.us)

**Grundfos Canada**

2941 Brighton Road  
Oakville, Ontario L6H 6C9 Canada  
Phone: +1-905 829 9533  
Fax: +1-905 829 9512

[www.grundfos.ca](http://www.grundfos.ca)

**Grundfos México**

Boulevard TLC No. 15  
Parque Industrial Stiva Aeropuerto  
C.P. 66600 Apodaca, N.L. Mexico  
Phone: +011-52-81-8144 4000  
Fax: +011-52-81-8144 4010

[www.grundfos.mx](http://www.grundfos.mx)



L-CR-TL-001

<b>98419736</b> 0114
----------------------

ECM: 1122180
--------------

*LEFT BLANK*



MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL  
AMARUQ WTP – NUNAVUT  
VEOLIA PROJECT: 5000 218 009

---

***HACH***

***MODEL SOLITAX SC, TURBIDITY SENSOR***

---

**WATER TECHNOLOGIES**

*LEFT BLANK*



**DOC023.54.03232**

**SOLITAX sc**

**User Manual**

12/2009, Edition 4A

**This page is intentionally left blank**

# Table of Contents

---

<b>Section 1 Specifications</b>	5
<b>Section 2 General Information</b>	7
2.1 Safety Information	7
2.1.1 Use of Hazard Information	7
2.1.2 Precautionary Labels	7
2.2 Sensor Overview	8
2.3 Measuring Principle	8
2.4 Handling	8
<b>Section 3 Installation</b>	9
3.1 Unpacking the Instrument	9
3.1.1 Function Check	9
3.2 Sensor Installation	10
3.3 Pipe Installation	11
3.4 Connecting sensor cable	13
<b>Section 4 Operations</b>	15
4.1 Use of an sc controller	15
4.2 Sensor Setup	15
4.3 Sensor Data Logging	15
4.4 Sensor Diagnostics Menu for pH and ORP	15
4.5 Sensor Setup Menu	15
4.6 Calibration	16
4.6.1 Setting the Outmode	17
4.6.2 Calibration for Turbidity	17
4.6.2.1 Calculating the Factor	17
4.6.3 Calibration for Suspended Solids	18
4.6.3.1 For Single Point (Factor) Calibration	18
4.6.3.2 Multi-point Calibration	18
<b>Section 5 Maintenance</b>	19
5.1 Maintenance Schedule	19
5.2 Cleaning the Sensor Measuring Windows	19
5.3 Replacing the Wiper	20
<b>Section 6 Troubleshooting</b>	21
6.1 Error Codes	21
6.2 Warnings	21
<b>Section 7 Replacement Parts and Accessories</b>	23
7.1 Immersion Sensors	23
7.2 Insertion Sensors	23
7.3 Replacement Parts	23
<b>Section 8 Contact Information</b>	25
<b>Section 9 Limited warranty</b>	27
<b>Appendix A Modbus Register Information</b>	29






# Section 1 Specifications

Specifications are subject to change without notice.

<b>Measuring Technique</b>	Infrared Duo scattered light technique for color-independent turbidity measurement Turbidity in accordance with DIN EN 27027 / TS equivalent DIN 38414
<b>Measuring Range</b>	t-line turbidity: 0.001–4000 FNU/NTU ts-line, inline turbidity: 0.001–4000 FNU/NTU; TSS content: 0.001 mg/L–50 g/L hs-line, highline turbidity: 0.001–4000 FNU/NTU; TSS content: 0.001 mg/L–500 g/L TSS
<b>Reproducibility</b>	Turbidity < 1 %, Total Suspended Solids (TSS) < 3 %
<b>Measuring Accuracy</b>	Turbidity up to 1000 FNU/NTU: without calibration < 5 % of the measured value $\pm$ 0.01 FNU/NTU with calibration < 1 % of the measured value $\pm$ 0.01 FNU/NTU
<b>Technique variation coefficient</b>	1 % in accordance with DIN 38402
<b>Response Time</b>	1 s $\leq$ T90 $\leq$ 300 s (adjustable)
<b>Calibration</b>	Zero point permanently set from the factory, gradient once for the TS content
<b>Cable Length</b>	10 m (33 ft), max. 100 m (328 ft) with extension cable
<b>Ambient Temperature</b>	0 to +40 °C (32 to 104 °F)
<b>Pressure Range</b>	Stainless steel: $\leq$ 6 bar or $\leq$ 60 m (87 psi) PVC: $\leq$ 1 bar or $\leq$ 10 m (14,5 psi)
<b>Flow Velocity</b>	Max. 3 m/s (the presence of air bubbles affects the measurement)
<b>Materials</b>	Optics carrier and sleeve: stainless steel 1.4571 or PVC black
	Wiper shaft: stainless steel 1.4104
	Wiper arm: stainless steel 1.4581
	Wiper rubber: silicone rubber (standard) Optional: Viton <sup>1</sup> (LZX578)
	Windows and light guide: quartz glass
	O-rings (optics carrier, wiper, windows): NBR (acrylonitrile butadiene rubber)
	Housing seals: NBR 70
	Sensor connecting cable (hard-wired): 1 cable pair AWG 22 / 12 V DC twisted, 1 cable pair AWG 24 / data twisted, common cable screen, Semoflex (PUR)
	Sensor connection plug (hard-wired): type M12 enclosure rating IP 67
	Threaded cable fitting: stainless steel 1.4305
<b>Inspection interval</b>	On request 1/year service contract with guarantee extension to 5 years
<b>Dimensions</b>	Tank probe: D x L 60 mm x 200 mm (2 x 8 in.) Probe for pipe installation: D x L 60 mm x 315 mm (2 x 12.4 in.) (Pipe installation fitting: DN 65 / PN 16 DIN 2633; < 5 bar (73 psi); for pipes from DN 80) Distance sensor - wall (floor): TS > 10 cm (4 in.), turbidity > 50 cm (20 in.)
<b>Weight</b>	Tank probe: approx. 1.8 kg (63 oz) (t-line: approx. 0.6 kg (21 oz)) Probe for pipe installation: approx. 2.4 kg (85 oz) Pipe installation fitting: approx. 2.7 kg (95 oz) (without probe) Pipe installation safety fitting: approx. 18 kg (40 lb) (without probe)
<b>User Maintenance</b>	1 h / month, typical
<b>Certifications</b>	CE

<sup>1</sup> Viton® is a registered trademark of E.I. DuPont de Nemours + Co.

Figure 1      Sensor Dimensions



- |   |
|---|
| 1. SOLITAX sc models t-line, ts-line, and hs-line for immersion in open tanks |
| 2. SOLITAX sc models inline and highline sensors for insertion in pipes       |

2.1

Safety Information

Please read this entire manual before unpacking, setting up, or operating this equipment. Pay attention to all danger and caution statements. Failure to do so could result in serious injury to the operator or damage to the equipment.

Make sure that the protection provided by this equipment is not impaired, do not use or install this equipment in any manner other than that specified in this manual.

2.1.1

Use of Hazard Information



**DANGER**  
*Indicates a potentially or imminently hazardous situation which, if not avoided, will result in death or serious injury.*



**CAUTION**  
*Indicates a potentially hazardous situation that may result in minor or moderate injury.*

**Important Note:** *Information that requires special emphasis.*  
**Note:** *Information that supplements points in the main text.*

2.1.2

Precautionary Labels

Read all labels and tags attached to the instrument. Personal injury or damage to the instrument could occur if not observed

	This symbol, if noted on the instrument, references the instruction manual for operation and/or safety information.
	This symbol indicates that a risk of electrical shock and/or electrocution exists.
	Electrical equipment marked with this symbol may not be disposed of in European public disposal systems after 12 August of 2005. In conformity with European local and national regulations (EU Directive 2002/96/EC), European electrical equipment users must now return old or end-of life equipment to the Producer for disposal at no charge to the user. <b>Note:</b> <i>For return for recycling, please contact the equipment producer or supplier for instructions on how to return end-of-life equipment, producer-supplied electrical accessories, and all auxiliary items for proper disposal.</i>

## 2.2 Sensor Overview

**Note:** All sensors are also available without wipers for special applications.

**t-line: 0.001–4000 FNU/NTU**

High-resolution turbidity probe made of plastic for the outlets of sewage treatment plants and bodies of water.

**ts-line: 0.001–4000 FNU/NTU; 0.001 mg/L–50.0 g/L**

High-precision turbidity and solids probe made of stainless steel or plastic for color-independent measurement of fine turbidities and sludges.

**hs-line: 0.001–4000 FNU/NTU; 0.001 mg/L–500.0 g/L**

High-precision turbidity and solids probe made of stainless steel or plastic for color-independent measurement of highly concentrated sludges.

**inline: 0.001–4000 FNU/NTU; 0.001 mg/L–50.0 g/L**

High-precision pipe installation probe for turbidity and solids made of stainless steel for color-independent measurement of fine turbidities and sludges.

**highline: 0.001–4000 FNU/NTU; 0.001 mg/L–500.0 g/L**

High-precision pipe installation probe for turbidity and suspended solids made of stainless steel for color-independent measurement of highly concentrated sludges.

---

**Figure 2**      **Solitax sc Sensors**



## 2.3 Measuring Principle

The measuring principle is based on a combined infrared absorption scattered light technique that measures the lowest turbidity values in accordance with DIN EN 27027 just as precisely and continuously as high sludge content. Using this method, the light scattered sideways by the turbidity particles is measured over an angle of 90°.

## 2.4 Handling


The sensor contains high-quality optical and electronic assemblies. Make sure the sensor is not subjected to any hard mechanical knocks. There are no customer-serviceable items inside the sensor.



**DANGER**  
*Only qualified personnel should conduct the tasks described in this section of the manual.*

3.1    Unpacking the Instrument

Figure 3      Items Supplied with Sensor



1. SOLITAX sc Sensor	3. Factory Test Certificate
2. User Manual	4. Wiper Set (for 5 changes) LZX050

3.1.1    Function Check

After unpacking, both components should be checked for any transport damage and a short function check performed prior to installation.

To perform a function check, connect the sensor to the display unit and power the unit. Shortly after the unit is plugged in, the display is activated and the instrument switches to the measurement display. Measured values taken in air is meaningless.

If no messages appear in the lower part of the display, the function check is then complete.

### 3.2 Sensor Installation

Figure 4 on page 10 illustrates the installation overview for Solitax sc Models t-line, ts-line, and hs-line for immersion in open tanks.


The maximum distance from the mounting surface to the sensor without the use of an extension tube is 1.5 m (4.9 ft). When that distance exceeds 1.5 m (4.9 ft), one of the following extension tubes is required and can be ordered separately:

- 1.0 m (3.28 ft) extension pipe LZY413
- 1.8 m (5.90 ft) extension pipe LZY414

To ensure a suitable measuring position, install the probe to the following conditions:

- The probe optical window must have a ground clearance of at least 30 cm (11.8 in.).
- Install the probe with the optical window facing (downstream) in the direction of the flow to minimize the risk of fouling.
- Avoid installation sites where air bubbles are inconsistent. If this not possible, try moving the probe slightly or adjusting its alignment to minimize the bubble effect.
- Protect the probe against the oncoming flow of large objects, such as branches or ice and against flow surges.
- Avoid installing the probe with the optical window facing into direct light or facing a highly-reflective surface.


**Figure 4**      **Sensor Installation Overview**



### 3.3 Pipe Installation

- Install the sensor in an up-flow pipe section for best results. Do not mount the sensor in a down-flow pipe section.
- Mounting in a horizontal pipe section is acceptable if the sensor is fully immersed at all times. Usually, mounting 90 degrees from the top of the pipe guarantees full immersion. Do not mount on the top or bottom of a horizontal pipe section.
- Install the sensor in a pipe that is equal to or greater than 4 inches in diameter.
- Install the sensor at least 1.5 m (5 ft.) or three times the pipe diameter (whichever is greater) downstream of pumps, valves, or pipe elbows.
- Install the sensor on the discharge side of a pump, if possible, with a dilution or flush valve installed on the suction side of the pump.
- If the sensor is to be used to measure sludge with significant amounts of debris, install it after a sludge grinding pump or after a pump with a grinding/comminuting unit in front of it.
- Install the sensor within 7.8 m (25 ft.) of the controller with the standard probe cable. Optional cable extensions can be added for a maximum combined distance of 100 meters (330 ft.).
- If the flange cannot be welded to the pipe due to incompatibility of materials between the stud and the pipe, it is recommended that a stainless steel pipe section be fabricated. Weld the flange onto the stainless steel pipe section and attach the stainless steel section as a segment of the process pipe.

Figure 5 Proper Positioning for Insertion into Pipe





### 3.4 Connecting sensor cable



**CAUTION**

*Always lay cables and hoses so they do not pose a trip hazard and are not bent.*


1. Unscrew the protective cap on the controller socket and retain it.
2. Pay attention to the guide in the plug and push the plug into the socket.
3. Tighten the nuts.

Connector cables are available in various lengths (refer to [Section 7 Replacement Parts and Accessories on page 23](#)). Maximum overall cable length: 50 m (165 ft).

**Figure 6** Connection of the sensor plug to the controller



**Figure 7** Sensor connector pin assignment



Number	Description	Cable colour (Standard-Cable)
1	+12 VDC	brown
2	Ground	black
3	Data (+)	blue
4	Data (-)	white
5	Screen	Screen (grey)
6	Notch	—



## Section 4 Operations

### 4.1 Use of an sc controller

Before using the sensor in combination with an sc controller, refer to the controller user manual for navigation information.

### 4.2 Sensor Setup

When a sensor is initially installed, the serial number of the sensor will be displayed as the sensor name. To change the sensor name refer to the following instructions:

1. Select Main Menu.
2. From the Main Menu, select SENSOR SETUP and confirm.
3. Highlight the appropriate sensor if more than one sensor is attached and confirm.
4. Select CONFIGURE and confirm.
5. Select EDIT NAME and edit the name. Confirm or cancel to return to the Sensor Setup menu.

### 4.3 Sensor Data Logging

A data memory and event memory per sensor are available via the sc controller. While measured data are saved in the data memory at stipulated intervals, the event memory collects numerous events such as configuration changes, alarms and warning conditions. Both the data memory and the event memory can be read out in CSV format. For information on how you can download the data, please see the controller manual.

### 4.4 Sensor Diagnostics Menu for pH and ORP

**SELECT SENSOR (if more than one sensor is attached)**

STATUS	
ERROR LIST	See <a href="#">section 6.1 on page 21</a> .
WARNING LIST	See <a href="#">section 6.2 on page 21</a> ..

### 4.5 Sensor Setup Menu

**SELECT SENSOR (if more than one sensor is attached)**

WIPE	
	Initiates a wiping action on the sensor window.
CALIBRATE	
SET OUTMODE	Select the behavior of the outputs during calibration for zero point setting (Hold, Active, Transfer, Selection). Hold maintains the last reading prior to going into the menu. Active transmits the current level readings, corrected with previous calibration data until new data is entered. Set Transfer transmits the value designated during the system setup
SENSOR MEASURE	Displays the current, uncorrected measured value.
CONFIGURE	Select the calibration type and follow the calibration steps for 2 point, 3 point, 4 point, and 5 point calibration.
FACTOR/2 POINTS/ 3 POINTS/4 POINTS/ 5 POINTS	Display depends on the selection in configuration.
SET CAL DEFAULT	Return the instrument to the default calibration settings.

## 4.5 Sensor Setup Menu (continued)

CONFIGURE	
EDIT NAME	Enter up to a 10-digit name in any combination of symbols and alpha or numeric characters.
SET PARAMETER	This setting configures the Solitax to measure turbidity or suspended solids. The Solitax cannot simultaneously measure both. Choose "TRB" for turbidity measurements, or "TS" for suspended solids measurement. This selection determines which units may be selected in the "Meas Units" menu.
MEAS UNITS	Choose from the displayed units. TRB (FNU, EBC, TE/F, NTU); TS (mg/L, g/L, ppm, %) Default: FNU If TRB was selected in set parameter, select "NTU" (commonly used in the U.S.), FNU, EBC, or TE/F. If TS was selected, choose mg/L, g/L, ppm, or %. Press enter to choose the selection. If the units selected result in a reading that exceeds 4 digits, the display will only show dashes. For example, if mg/L were selected, and the measurement was 10,500 mg/L, the display will show dashes until the reading drops to 9999 or lower.
CLEAN INTERVAL	Select the cleaning interval (1, 5, 15 or 30 minutes; 1, 4, or 12 hours; 1, 3, 7 days) Default: 12 hours This is the interval between wiper cleaning of the sensor window. It is recommended to start with a setting of 30 minutes. This time may be adjusted according to the application. If readings continue to be accurate, try a longer interval. If not, shorten the interval.
RESPONSE TIME	This is a damping function. While the Solitax takes readings continually, it will average them together over the period of the response time. Once the response time has elapsed, the displayed reading, 4-20 outputs, and alarm status are updated. (0 to 300 seconds) Default: 3 seconds
LOGGER INTERVAL	This is the datalog interval, with options from 1–15 minutes. Values logged are the average of the all readings during the previous logging interval. The controller will hold approximately 360 days of readings for one sensor at 15 minute intervals, or 24 days at 1 minute intervals (and proportional in between). Default: 10 minutes
SET DEFAULTS	Resets all user-editable options to the factory-defaults.
TEST/MAIN	
PROBE INFO	Displays the sensor type, entered name of the sensor (Default: sensor serial number), the sensor serial number, the software version number, and the sensor driver version number.
PROFILE	Select Profile Counter to display the number of wipes made (from 20000 backwards). Select Reset Config to manually reset the profile counter.
COUNTER	Shows the number of hours or cycles left for operating hours, test/maint, gasket, and the motor.
TEST/MAIN	WIPE—Initiates the wiping action of the wiper.
	SIGNALS—displays the signal outputs for the device.
	OUTPUT MODE—Select the behavior of the instrument outputs (Hold, Active, Transfer, Selection)
	DEFAULT SETUP—Resets all user-editable options to the factory defaults.

## 4.6 Calibration

There are two calibration techniques; depending on whether turbidity or suspended solid is required (refer to [section 4.6.2](#) or [section 4.6.3 on page 18](#)). Before calibration, determine the behavior of the 4–20 outputs and alarm relays while the user is in the CALIBRATE menu (refer to [section 4.6.1](#)).

### 4.6.1 Setting the Outmode

1. From the Main Menu, select SENSOR SETUP and press confirm.
2. Select the appropriate sensor if more than one is attached and confirm.
3. Select CALIBRATE and press confirm.
4. Select SET OUTMODE. Select the available Out Mode (Active, Hold, Transfer) and confirm.

### 4.6.2 Calibration for Turbidity

Turbidity calibration requires the use of a Turbidity Standard Solution. The manufacturer recommends the 800 NTU Turbidity Standard Solution (part of the calibration kit No. 57330-00). A zero-point calibration using deionized water is also recommended.

1. From the Main Menu, select SENSOR SETUP and press confirm.
2. Select the appropriate sensor if more than one is attached and confirm.
3. Select CALIBRATE and press confirm.
4. Select SENSOR MEASURE and confirm.
5. Place the sensor in the calibration cylinder with deionized water, mounting it with the supplied clamp. The tip of the probe should be approximately 1-inch below the surface of the water. Record the reading from the sensor measure display.
6. Select OFFSET. Multiply the reading obtained in step 5 and enter the value.
7. Select SENSOR MEASURE.
8. Rinse the outside of the StablCal® 800 NTU standard with water to remove any dust or debris adhering to the surface of the bottle. Gently invert both StablCal standard bottles a minimum of 50 times. Remove the lid and seal from each bottle. Slowly (to avoid creating bubbles) pour the contents of the bottles into the calibration cylinder. Immediately place the tip of the probe into the positioning bracket in the calibration cylinder. The tip of the probe should be approximately 1-inch below the surface standard. Allow the reading to become stable on the SENSOR MEASURE screen. Record the value (measured value). Calculate the factor. Refer to [section 4.6.2.1](#).
9. Select FACTOR to display the corrected measurement.

#### 4.6.2.1 Calculating the Factor

$$\text{New Factor} = \frac{800 \text{ NTU Standard}}{\text{measured value}}$$

For example, if a sample measures 750 NTU using the sensor and the standard is 800 NTU, the new factor would be calculated as follows:

$$\text{New Factor} = \frac{800 \text{ NTU}}{750 \text{ NTU}} = 1.07$$

### 4.6.3 Calibration for Suspended Solids

Suspended solids calibration requires calibration to the actual sample. This optimizes the compensation for the particle size and shape typical at a measuring site. It is best performed by mounting the sensor as usual for normal measurement, and then grab samples collected and evaluated by laboratory methods. While a single point calibration is usually sufficient to provide accuracy, the SOLITAX does offer the ability to calibrate with up to 5 calibration points.

1. From the Main Menu, select SENSOR SETUP and press confirm.
2. Select the appropriate sensor if more than one is attached and confirm.
3. Select CALIBRATE and press confirm.
4. Select CONFIGURE and confirm.
5. Select the number of points desired for calibration (the unit will linearly interpolate values between calibration points). Select Factor for a single point calibration.
6. Mount the sensor as is during normal operation. Alternatively, place the sensor in the calibration cylinder (or a container with dark, non-reflective walls) 2 inches of clearance from the probe face with the probe face submerged by 1 inch or more.
7. Select SENSOR MEASURE and record the reading.
8. Immediately take a grab sample. Determine the total suspended solids using a gravimetric method such as Method 2540 D in *Standards Methods for the Examination of Water and Wastewater*.
9. Calculate the new factor. Refer to [section 4.6.3.1](#) for single point (Factor) calibration. Refer [section 4.6.3.2 on page 18](#) for multiple point calibrations.
10. Select FACTOR and press confirm. The corrected measurement should be displayed.

#### 4.6.3.1 For Single Point (Factor) Calibration

Calculate the new factor:

$$\text{New Factor} = \frac{\text{Determined gravimetric value}}{\text{measured value}}$$

For example, if a sample measures 2.3 g/L using the SS sensor and the gravimetric value was 2.0 g/L, the new factor would be calculated as follows:

$$\text{New Factor} = \frac{2.0 \text{ g/L}}{2.3 \text{ g/L}} = 0.87$$

#### 4.6.3.2 Multi-point Calibration

1. Repeat steps 6–8 in [section 4.6.3 on page 18](#) at different times to obtain different measurements.
2. From the CONFIGURE menu, select the appropriate calibration point menu.
3. Enter the pairs of values for each reading, the target value being the laboratory determined value, and the actual value being the reading that the SOLITAX produced in step 5. The pairs should be entered in order from lowest values to highest.



### **DANGER**

**Only qualified personnel should conduct the tasks described in this section of the manual.**

Proper maintenance of the measuring windows in the sensor is critical for accurate measurements. The measuring windows should be checked monthly for soiling and the wiper checked for wear.

**Important Note:** *The seals must be replaced every 2 years by the Service Department. If the seals are not changed regularly, water may enter the probe head and seriously damage the instrument.*

### 5.1 Maintenance Schedule

Maintenance Task	Duration
Visual inspection	monthly
Check calibration	monthly (depending on the ambient conditions)
Inspection	six months (counter)
Seal change	every 2 years (counter)
Change wiper and reset counter	as per counter (20000 cycles)

### 5.2 Cleaning the Sensor Measuring Windows



### **CAUTION**

**Always wear**

- **Safety glasses,**
- **Gloves and**
- **Overall**

**handling hydrochloric acid and observe safety regulations.**


The measuring windows are made of quartz glass. If necessary, they can be cleaned with a cleaning agent and a cloth.

### 5.3 Replacing the Wiper

The life of the wiper is dependent on the number of cleaning actions performed and the type of deposits to be removed. The life of the wiper varies. The wipers supplied with the instrument should last for approximately one year.

- 1. From the Main Menu, select SENSOR SETUP and press confirm.
- 2. Select the appropriate sensor if more than one is attached and confirm.
- 3. Select TEST/MAINT and press confirm.
- 4. Select PROFILE and confirm. Change the wiper, see [section 5.3 on page 20](#).
- 5. Select RESET CONFIG and confirm.
- 6. Select MAN. RESET ARE YOU SURE? and confirm.

Figure 8 Wiper Replacement



1. Wiper arm	3. Wiper
2. M4 hex socket head bolt	4. Wiper axle



## Section 6 Troubleshooting

---

### 6.1 Error Codes

In the case of an error, the indication of the measured value flashes on the display and all the contacts and current outputs allocated to this sensor are placed on hold. The following conditions will result in flashing measured values:

- Data transmission between controller and sensor interrupted

On the Main menu open the SENSOR DIAG menu using **ENTER** and determine the cause of the fault.

**Table 1 Error Messages**

Error Displayed	Cause	Solution
POS. UNKNOWN	Wiper position unknown	Open the TEST/MAINT menu and trigger the "WIPE" function, if the problem persists contact the manufacturer's customer service
LED FAULTY	Faulty LED	Contact customer service
MOIST	Moisture value > 10	Remove the sensor immediately and store in a dry place, contact customer service
CAL. DATA	Factory calibration data lost	Contact customer service

### 6.2 Warnings

A warning results in a flashing warning icon on the right of the display, all menus, contacts and outputs remain unaffected and continue to work normally. On the Main menu open the SENSOR DIAG menu using **ENTER** and determine the cause of the warning.

A warning may be used to trigger a relay and users can set warning levels to define the severity of the warning.

**Table 2 Warnings**

Warning Displayed	Cause	Solution
WARNING	Cause	Action
REPLACE WIPER	Counter elapsed	Replace wiper, reset counter
TEST/MAINT	Counter elapsed	Contact customer service
GASKET	Counter elapsed	Contact customer service



## Section 7 Replacement Parts and Accessories

### 7.1 Immersion Sensors<sup>1</sup>

Description	Catalog Number
Turbidity, t-line sc, PVC with wiper (0.001 to 4000 NTU)	LXV423.99.10000
Turbidity, t-line sc, PVC without wiper (0.001 to 4000 NTU)	LXV423.99.12000
Turbidity and Suspended Solids, ts-line sc, PVC with wiper (0.001 to 4000 NTU, 0.001 mg/L to 50 g/L)	LXV423.99.10100
Turbidity and Suspended Solids, ts-line sc, PVC without wiper (0.001 to 4000 NTU, 0.001 mg/L to 50 g/L)	LXV423.99.12100
Turbidity and Suspended Solids, ts-line sc, stainless steel with wiper (0.001 to 4000 NTU, 0.001 mg/L to 50 g/L)	LXV423.99.00100
Turbidity and Suspended Solids, ts-line sc, stainless steel without wiper (0.001 to 4000 NTU, 0.001 mg/L to 50 g/L)	LXV423.99.02100
Turbidity and Suspended Solids, hs-line sc, PVC with wiper (0.001 to 4000 NTU, 0.001 mg/L to 500 g/L)	LXV423.99.10200
Turbidity and Suspended Solids, hs-line sc, PVC without wiper (0.001 to 4000 NTU, 0.001 mg/L to 500 g/L)	LXV423.99.12200
Turbidity and Suspended Solids, hs-line sc, stainless steel with wiper (0.001 to 4000 NTU, 0.001 mg/L to 500 g/L)	LXV423.99.00200
Turbidity and Suspended Solids, hs-line sc, stainless steel without wiper (0.001 to 4000 NTU, 0.001 mg/L to 500 g/L)	LXV423.99.02200

<sup>1</sup> All sensors come with the sensor, replacement wipers, and manual.

### 7.2 Insertion Sensors<sup>1</sup>

Description	Catalog Number
Turbidity and Suspended Solids, inline sc, stainless steel with wiper (0.001 to 4000 NTU, 0.001 mg/L to 50 g/L)	LXV424.99.00100
Turbidity and Suspended Solids, inline sc, stainless steel without wiper (0.001 to 4000 NTU, 0.001 mg/L to 50 g/L)	LXV424.99.02100
Turbidity and Suspended Solids, highline sc, stainless steel with wiper (0.001 to 4000 NTU, 0.001 mg/L to 500 g/L)	LXV424.99.00200
Turbidity and Suspended Solids, highline sc, stainless steel without wiper (0.001 to 4000 NTU, 0.001 mg/L to 500 g/L)	LXV424.99.02200

<sup>1</sup> All sensors come with the sensor, replacement wipers, and manual.

### 7.3 Replacement Parts

Description	Catalog Number
Set of wipers (for 5 changes) made of silicone for normal applications	LZX050
Set of wipers (for 5 changes) made of Viton for e. g. media containing oil	LZX578
SOLITAX sc User Manual, english	DOC023.54.03232
Extension cable, 5 m (16.4 ft)	LZX848
Extension cable, 10 m (33 ft)	LZX849
Extension cable, 15 m (50 ft)	LZX850
Extension cable, 20 m (65 ft)	LZX851
Extension cable, 30 m (100 ft)	LZX852
Extension cable, 50 m (165 ft)	LZX853

### 7.3 Replacement Parts (continued)

Description	Catalog Number
Extension pipe, 1,0 m (3.28 ft)	LZY413
Extension pipe, 1,8 m (5.90 ft)	LZY414
Installation kit, fixed-point (for t-line, ts-line, and hs-line immersion sensors)	LZX414.00.10000
Consisting of:	
Base	ATS010
Mounting plate	HPL061
Holding clamp (2x)	LZX200
Assembly pipe 2 m	BRO075
HS small parts set	LZX416
Installation kit with straight adapter	LZX414.00.20000
Kit, screws and seals for sensor adapters	LZX417
Miscellaneous hardware for probe installation kit	LZX416
Second fastening point, includes: bracket, sensor pipe stand, sensor pipe stand bracket, screws, and grommet)	LZX456
Sensor fixed-point mounting kit: Sensor pipe bracket	ATS010
Sensor pipe stand bracket	LZX200
L-bracket	ATS011
Adapter, Sensor 90° elbow	AHA034
Ball valve for insertion probes without adapting flange	LZX337
Welded flange made of C-steel for the pipe installation fitting	LZX703
Welded flange made of stainless steel for pipe installation safety fitting	LZX660

## Section 8 Contact Information

---

### **HACH Company World Headquarters**

P.O. Box 389  
Loveland, Colorado  
80539-0389 U.S.A.  
Tel (800) 227-HACH  
(800) -227-4224  
(U.S.A. only)  
Fax (970) 669-2932  
orders@hach.com  
www.hach.com

### **Repair Service in the United States:**

HACH Company  
Ames Service  
100 Dayton Avenue  
Ames, Iowa 50010  
Tel (800) 227-4224  
(U.S.A. only)  
Fax (515) 232-3835

### **Repair Service in Canada:**

Hach Sales & Service  
Canada Ltd.  
1313 Border Street, Unit 34  
Winnipeg, Manitoba  
R3H 0X4  
Tel (800) 665-7635  
(Canada only)  
Tel (204) 632-5598  
Fax (204) 694-5134  
canada@hach.com

### **Repair Service in Latin America, the Caribbean, the Far East, Indian Subcontinent, Africa, Europe, or the Middle East:**

Hach Company World  
Headquarters,  
P.O. Box 389  
Loveland, Colorado,  
80539-0389 U.S.A.  
Tel +001 (970) 669-3050  
Fax +001 (970) 669-2932  
intl@hach.com

### **HACH LANGE GMBH**

Willstätterstraße 11  
D-40549 Düsseldorf  
Tel. +49 (0)2 11 52 88-320  
Fax +49 (0)2 11 52 88-210  
info@hach-lange.de  
www.hach-lange.de

### **HACH LANGE LTD**

Pacific Way  
Salford  
GB-Manchester, M50 1DL  
Tel. +44 (0)161 872 14 87  
Fax +44 (0)161 848 73 24  
info@hach-lange.co.uk  
www.hach-lange.co.uk

### **HACH LANGE LTD**

Unit 1, Chestnut Road  
Western Industrial Estate  
IRL-Dublin 12  
Tel. +353(0)1 46 02 5 22  
Fax +353(0)1 4 50 93 37  
info@hach-lange.ie  
www.hach-lange.ie

### **HACH LANGE GMBH**

Hütteldorferstr. 299/Top 6  
A-1140 Wien  
Tel. +43 (0)1 9 12 16 92  
Fax +43 (0)1 9 12 16 92-99  
info@hach-lange.at  
www.hach-lange.at

### **HACH LANGE**

Rorschacherstrasse 30 a  
CH-9424 Rheineck  
Tel. +41 (0)71 886 91 11  
Fax +41 (0)71 886 91 66  
info@hach-lange.ch  
www.hach-lange.ch

### **HACH LANGE FRANCE S.A.S.**

8, mail Barthélémy Thimonnier  
Lognes  
F-77437 Marne-La-Vallée  
cedex 2  
Tél. +33 (0)8 20 20 14 14  
Fax +33 (0)1 69 67 34 99  
info@hach-lange.fr  
www.hach-lange.fr

### **HACH LANGE SA**

Motstraat 54  
B-2800 Mechelen  
Tél. +32 (0)15 42 35 00  
Fax +32 (0)15 41 61 20  
info@hach-lange.be  
www.hach-lange.be

### **DR. LANGE NEDERLAND B.V.**

Laan van Westroijen 2a  
NL-4003 AZ Tiel  
Tel. +31(0)344 63 11 30  
Fax +31(0)344 63 11 50  
info@hach-lange.nl  
www.hach-lange.nl

### **HACH LANGE APS**

Åkandevvej 21  
DK-2700 Brønshøj  
Tel. +45 36 77 29 11  
Fax +45 36 77 49 11  
info@hach-lange.dk  
www.hach-lange.dk

### **HACH LANGE AB**

Vinthundsvägen 159A  
SE-128 62 Sköndal  
Tel. +46 (0)8 7 98 05 00  
Fax +46 (0)8 7 98 05 30  
info@hach-lange.se  
www.hach-lange.se

### **HACH LANGE S.R.L.**

Via Riccione, 14  
I-20156 Milano  
Tel. +39 02 39 23 14-1  
Fax +39 02 39 23 14-39  
info@hach-lange.it  
www.hach-lange.it

### **HACH LANGE S.L.U.**

Edif. Arteaga Centrum  
C/Larrauri, 1C- 2ª Pl.  
E-48160 Derio/Vizcaya  
Tel. +34 94 657 33 88  
Fax +34 94 657 33 97  
info@hach-lange.es  
www.hach-lange.es

### **HACH LANGE LDA**

Av. do Forte nº8  
Fracção M  
P-2790-072 Camaxide  
Tel. +351 214 253 420  
Fax +351 214 253 429  
info@hach-lange.pt  
www.hach-lange.pt

### **HACH LANGE SP.ZO.O.**

ul. Opolska 143 a  
PL-52-013 Wrocław  
Tel. +48 (0)71 342 10-83  
Fax +48 (0)71 342 10-79  
info@hach-lange.pl  
www.hach-lange.pl

### **HACH LANGE S.R.O.**

Lešanská 2a/1176  
CZ-141 00 Praha 4  
Tel. +420 272 12 45 45  
Fax +420 272 12 45 46  
info@hach-lange.cz  
www.hach-lange.cz

### **HACH LANGE S.R.O.**

Roľnícka 21  
SK-831 07 Bratislava –  
Vajnory  
Tel. +421 (0)2 4820 9091  
Fax +421 (0)2 4820 9093  
info@hach-lange.sk  
www.hach-lange.sk

### **HACH LANGE KFT.**

Vöröskereszt utca. 8-10.  
H-1222 Budapest XXII. ker.  
Tel. +36 (06)1 225 7783  
Fax +36 (06)1 225 7784  
info@hach-lange.hu  
www.hach-lange.hu

### **HACH LANGE S.R.L.**

Str. Căminului nr. 3  
Sector 2  
RO-021741 București  
Tel. +40 (0) 21 205 30 03  
Fax +40 (0) 21 205 30 17  
info@hach-lange.ro  
www.hach-lange.ro

### **HACH LANGE**

8, Kr. Sarafov str.  
BG-1164 Sofia  
Tel. +359 (0)2 963 44 54  
Fax +359 (0)2 866 15 26  
info@hach-lange.bg  
www.hach-lange.bg

### **HACH LANGE SU ANALİZ SİSTEMLERİ LTD.ŞTİ.**

Hilal Mah. 75. Sokak  
Arman Plaza No: 9/A  
TR-06550 Çankaya/ANKARA  
Tel. +90 (0)312 440 98 98  
Fax +90 (0)312 442 11 01  
bilgi@hach-lange.com.tr  
www.hach-lange.com.tr

## Contact Information

---

### **HACH LANGE D.O.O.**

Fajfarjeva 15  
SI-1230 Domžale  
Tel. +386 (0)59 051 000  
Fax +386 (0)59 051 010  
info@hach-lange.si  
www.hach-lange.si

### **HACH LANGE E.Π.E.**

Αυλίδος 27  
GR-115 27 Αθήνα  
Τηλ. +30 210 7777038  
Fax +30 210 7777976  
info@hach-lange.gr  
www.hach-lange.gr

### **HACH LANGE E.P.E.**

27, Avlidos str  
GR-115 27 Athens  
Tel. +30 210 7777038  
Fax +30 210 7777976  
info@hach-lange.gr  
www.hach-lange.gr

### **HACH LANGE D.O.O.**

Ivana Severa bb  
42 000 Varaždin  
Tel. +385 (0) 42 305 086  
Fax +385 (0) 42 305 087  
info@hach-lange.hr  
www.hach-lange.hr

### **HACH LANGE MAROC SARLAU**

Villa 14 – Rue 2 Casa  
Plaisance  
Quartier Racine Extension  
MA-Casablanca 20000  
Tél. +212 (0)522 97 95 75  
Fax +212 (0)522 36 89 34  
info-maroc@hach-lange.com  
www.hach-lange.ma

## Section 9      Limited warranty

---

Hach Company warrants its products to the original purchaser against any defects that are due to faulty material or workmanship for a period of one year from date of shipment unless otherwise noted in the product manual.

In the event that a defect is discovered during the warranty period, Hach Company agrees that, at its option, it will repair or replace the defective product or refund the purchase price excluding original shipping and handling charges. Any product repaired or replaced under this warranty will be warranted only for the remainder of the original product warranty period.

This warranty does not apply to consumable products such as chemical reagents; or consumable components of a product, such as, but not limited to, lamps and tubing.

Contact Hach Company or your distributor to initiate warranty support. Products may not be returned without authorization from Hach Company.

### **Limitations**

This warranty does not cover:

- Damage caused by acts of God, natural disaster, labor unrest, acts of war (declared or undeclared), terrorism, civil strife or acts of any governmental jurisdiction
- Damage caused by misuse, neglect, accident or improper application or installation
- Damage caused by any repair or attempted repair not authorized by Hach Company
- Any product not used in accordance with the instructions furnished by Hach Company
- Freight charges to return merchandise to Hach Company
- Freight charges on expedited or express shipment of warranted parts or product
- Travel fees associated with on-site warranty repair

This warranty contains the sole express warranty made by Hach Company in connection with its products. All implied warranties, including without limitation, the warranties of merchantability and fitness for a particular purpose, are expressly disclaimed.

Some states within the United States do not allow the disclaimer of implied warranties and if this is true in your state the above limitation may not apply to you. This warranty gives you specific rights, and you may also have other rights that vary from state to state.

This warranty constitutes the final, complete, and exclusive statement of warranty terms and no person is authorized to make any other warranties or representations on behalf of Hach Company.

### **Limitation of Remedies**

The remedies of repair, replacement or refund of purchase price as stated above are the exclusive remedies for the breach of this warranty. On the basis of strict liability or under any other legal theory, in no event shall Hach Company be liable for any incidental or consequential damages of any kind for breach of warranty or negligence.





# Appendix A Modbus Register Information


**Table 3 Sensor Modbus Registers**

Group Name	Tag Name	Register	Data Type#	Length	R/W	Description
Measurements	TurbidityFNU	40001	Float	2	R	Turbidity FNU
Measurements	TurbidityEBC	40003	Float	2	R	Turbidity EBC
Measurements	SolidsMGL	40005	Float	2	R	Solids mg/L
Measurements	SolidsGL	40007	Float	2	R	Solids g/L
Measurements	SolidsPR	40009	Float	2	R	Solids %
—	Reserved	40011	Unsigned Integer	1	R	Reserved
Base	Parameter	40012	Unsigned Integer	1	R/W	Parameter
Base	UnitTRB	40013	Unsigned Integer	1	R/W	Unit Turbidity
Base	UnitTS	40014	Unsigned Integer	1	R/W	Units Solids
Calibration	OffsetTRB	40015	Float	2	R/W	Turbidity Offset
Calibration	FactorTRB	40017	Float	2	R/W	Turbidity Factor
Calibration	FactorTS	40019	Float	2	R/W	Solids Factor
Data	Wiperstate	40021	Unsigned Integer	1	R/W	Wiper register
Setup	ResponseInterval	40022	Unsigned Integer	1	R/W	Response time
Setup	CleaningInterval	40023	Unsigned Integer	1	R/W	Wiper interval
Setup	LogInterval	40024	Unsigned Integer	1	R/W	Logger interval
Setup	Outputmodekal	40025	Unsigned Integer	1	R/W	Output when calibrate
Setup	Outputmodesrv	40026	Unsigned Integer	1	R/W	Output when service
Setup	Location	40027	String	8	R/W	Edited name
Setup	ProfilCounter	40035	Unsigned Integer	1	R/W	Profi counter
Data	SerienNummer	40036	String	6	R	Serial number
Calibration	DateUserCal	40042	Date	2	R	Date of manufacturing calibration
Calibration	DateUserCalTURB	40044	Date	2	R	Date of calibration turbidity
Calibration	DateUserCalSOLID	40046	Date	2	R	Date of calibration solid
Data	VersionAppl	40048	Float	2	R	Version application
Data	VersionBoot	40050	Float	2	R	Version Bootlader
Data	VersionStruct	40052	Unsigned Integer	1	R	Version structure probedriver
Data	VersionContent	40053	Unsigned Integer	1	R	Version register probedriver
Data	VersionFirmware	40054	Unsigned Integer	1	R	Version firmware probedriver
Data	FormatMinFNU	40055	Float	2	R	Minimum turbidity FNU
Data	FormatMaxFNU	40057	Float	2	R	Maximum turbidity FNU
Data	FormatMinEBC	40059	Float	2	R	Minimum turbidity EBC
Data	FormatMaxEBC	40061	Float	2	R	Maximum turbidity EBC
Data	FormatMinGL	40063	Float	2	R	Minimum solids g/L
Data	FormatMaxGL	40065	Float	2	R	Maximum solids g/L
Data	FormatMinMGL	40067	Float	2	R	Minimum solids mg/L
Data	FormatMaxMGL	40069	Float	2	R	Maximum mg/L
Data	FormatMinPR	40071	Float	2	R	Minimum solids %
Data	FormatMaxPR	40073	Float	2	R	Maximum solids %
Data	SignalsLED	40075	Unsigned Integer	1	R	Signal LED
Data	SignalsMoist	40076	Unsigned Integer	1	R	Signal moist



**LZX337**  
**LZX660**  
**LZX661**  
**LZY630.00.10000**  
**LZY630.00.11000**  
**LZY630.00.12000**

DOC273.99.90204/6A



**BG** Преди инсталацията/монтажа на продукта, прочетете внимателно всички инструкции за инсталация и ги спазвайте по време на инсталацията. Инсталацията трябва да се извършва от квалифициран специалист в съответствие с местните разпоредби за безопасност. Погледнете се избраното място на инсталацията за гарантира безопасна инсталация и експлоатация. Продуктът е предназначен единствено за придържане/прикрепване на измервателните сензори/продукти на HACH/HACH LANGE. Всяко друго приложение може да носи риск за потребителя. Работите по поддръжката и ремонта трябва да се извършват изключително от оторизирания отдел за обслужване на клиенти. Могат да се използват само оригинални резервни части и препоръчани от производителя принадлежности. Всякакви изменения по продукта водят до анулиране на всички отговорности от страна на производителя. Неспазването на инструкциите за употреба или използването на продукта за цели, различни от тези, за които е предназначен, може да доведе до сериозно нараняване на потребителя и/или повреда на оборудването. Работата по заваряване, трябва да бъде извършвана само от квалифицирани заварчици съгласно DIN/EN 287 или от сертифицирани фирми по EN 3834-2.

**CS** Při instalaci/montáži produktu si pečlivě přečtěte všechny pokyny k instalaci a v průběhu instalace tyto pokyny dodržujte. Instalaci musí provádět kvalifikovaný odborník v souladu s místními bezpečnostními předpisy. Pečlivě vyberte umístění pro instalaci, které zajistí bezpečnou instalaci a provoz. Produkt je určen pouze k upevnění/přichycení měřičích snímačů/produktů HACH/HACH LANGE. Jakékoli jiné použití může znamenat riziko pro uživatele. Údržbu a opravy smí provádět výhradně autorizované oddělení zákaznických služeb. Je dovoleno používat pouze originální náhradní díly a příslušenství doporučené výrobcem. Jakékoli změny provedené na produktu způsobí neplatnost veškerých záruk. Nedodržení těchto pokynů nebo používání produktu pro jiný účel než pro který je určen může způsobit uživateli vážné zranění anebo poškodit zařízení. Potřebné svařecké práce musí být provedeny kvalifikovaným svařčem výhradně podle DIN/EN 287 nebo dodavatelem v souladu s EN 3834-2.

**DA** Før du installerer/monterer produktet, skal du læse alle installationsinstruktionerne grundigt og følge dem under installationen. Installationen skal udføres af en kvalificeret ekspert i overensstemmelse med alle lokale sikkerhedsbestemmelser. Vælg sikker og betjeningsvenligt placering til installationen. Produktet er kun beregnet til at holde/fastgøre HACH/HACH LANGE-målesensorer/-produkter. Enhver anden form for brug kan medføre skadesrisiko for brugeren. Vedligeholdelse og reparation bør kun udføres af en autoriseret kundeserviceafdeling. Der må kun anvendes originale reservedele og tilbehør, der er anbefalet af producenten. Alle ændringer af produktet ophæver garantien. Hvis du ikke følger disse instruktioner eller bruger produktet til et andet formål, end det er beregnet til, kan der forekomme alvorlige personskader og/eller skader på udstyret. Svejsearbejde må kun udføres af DIN/EN 287 kvalificerede svejsere, eller EN 3834-2 certificerede firmaer.

**DE** Die Montageanleitung ist vor der Installation/Montage des Produktes sorgfältig und vollständig zu lesen und zu befolgen. Die Installation muss von einer Fachkraft (qualifiziertes Personal) unter Einhaltung aller lokal gültigen Sicherheitsvorschriften erfolgen. Der Montageort ist so zu wählen, dass eine sichere Installation und der sichere Betrieb gewährleistet ist. Die Verwendung des Produktes ist ausschließlich zum Halten/Befestigen von HACH/HACH LANGE Messsonden/Produkten vorgesehen. Jede andere Benutzung ist mit Risiken für den Benutzer verbunden. Wartungs- und Reparaturarbeiten sollten nur vom autorisierten Kundendienst durchgeführt werden. Es dürfen nur vom Hersteller empfohlene Originalersatz- und Zubehörteile verwendet werden. Änderungen am Produkt haben den Verlust jeglicher Haftungsansprüche zur Folge. Nichtbeachtung dieser Anweisungen oder eine andere Verwendung des Produktes kann schwerwiegende Verletzungen der Anwender oder Beschädigung am Gerät zur Folge haben. Die notwendigen Schweißarbeiten dürfen ausschließlich von entsprechend DIN/EN 287 qualifizierten Schweißern durchgeführt werden, oder von Fachfirmen entsprechend EN 3834-2.

**EL** Πριν από την εγκατάσταση/τοποθέτηση του προϊόντος, διαβάστε προσεκτικά και ακολούθηστε όλες τις οδηγίες εγκατάστασης κατά την εγκατάσταση. Η εγκατάσταση πρέπει να πραγματοποιηθεί από κατάλληλα εκπαιδευμένο τεχνικό και σύμφωνα με όλους τους τοπικούς κανονισμούς ασφαλείας. Επιλέξτε μια θέση τοποθέτησης που θα διασφαλίσει την ασφαλή εγκατάσταση και λειτουργία. Το προϊόν προορίζεται αποκλειστικά για τη στήριξη/σύνδεση των αισθητήρων μέτρησης/προϊόντων HACH/HACH LANGE. Οποιαδήποτε άλλη χρήση ενδέχεται να ενέχει κινδύνους για τον χρήστη. Οι εργασίες συντήρησης και επισκευής θα πρέπει να εκτελούνται αποκλειστικά από το εξουσιοδοτημένο τμήμα εξυπηρέτησης πελατών. Επιτρέπεται η χρήση μόνον των γνήσιων ανταλλακτικών και των αξεσουάρ που συνιστά ο κατασκευαστής. Οποιοδήποτε αλλαγές στο προϊόν ακυρώνουν την ευθύνη της εταιρείας. Σε περίπτωση που δεν τηρηθούν αυτές τις οδηγίες ή χρησιμοποιηθούν το προϊόν για διαφορετικό σκοπό από αυτόν που προορίζεται, ενδέχεται να προκληθεί σοβαρός τραυματισμός στον χειριστή και/ή βλάβη στον εξοπλισμό. Οι απαιτούμενες εργασίες συγκόλλησης θα πρέπει να διεξάγονται από εξειδικευμένο προσωπικό σύμφωνα με DIN / EN287 ή από κατασκευαστικές εταιρείες σύμφωνα με DIN 3834-2.

**EN** Before installing/mounting the product, read all the installation instructions carefully and follow the instructions during installation. Installation must be carried out by a qualified expert in accordance with all local safety regulations. Take care to choose an installation location that will ensure safe installation and operation. The product is intended solely for holding/attaching HACH/HACH LANGE measuring sensors/products. Any other use may involve risks for the user. Maintenance and repair work should be carried out exclusively by the authorized customer service department. Only original replacement and accessory parts recommended by the manufacturer may be used. Any changes made to the product will nullify all liability. Failure to follow these instructions or use of the product for a purpose other than that for which it was intended may result in serious injury to the user and/or damage to the equipment. The required welding work must be performed exclusively in accordance with DIN / EN 287 qualified welders, or from contractors in accordance with EN 3834-2.

**ES** Antes de instalar o fijar el producto, lea con atención todas las instrucciones de instalación y sigalas durante el montaje. La instalación debe llevarla a cabo un experto cualificado, de acuerdo con las normas de seguridad locales. Elija una ubicación para la instalación que garantice que ésta y el funcionamiento del producto sean seguros. El producto sólo está diseñado para sujetar o fijar sensores o productos de medición de HACH/HACH LANGE. Cualquier otro uso puede conllevar riesgos para el usuario. El trabajo de mantenimiento y reparación sólo debe llevarse a cabo por el departamento de atención al cliente autorizado. Sólo deben utilizarse las piezas de repuesto recomendadas por el fabricante. Cualquier cambio que se realice en el producto anulará toda responsabilidad. Si no se siguen estas instrucciones o si se utiliza el producto para un uso distinto del uso para el que fue diseñado, el usuario puede sufrir heridas graves y/o se puede dañar el equipo. Los trabajos de soldadura requeridos deben ser realizados exclusivamente por soldadores cualificados según DIN / EN 287, o por contratistas de acuerdo a EN 3834-2.

**FI** Ennen kuin asennat/kiinnität tuotteen, lue kaikki asennusohjeet huolellisesti ja noudata niitä. Tuotteen saa asentaa vain valtuutettu henkilö, ja asennuksessa on noudatettava kaikkia paikallisia turvallisuusmääräyksiä. Asenna tuote sellaiseen paikkaan, johon asentaminen on turvallista ja jossa tuote toimii oikein. Tuote on tarkoitettu ainoastaan HACH/HACH LANGE -mittausanturien/-tuotteiden ripustamiseen/kiinnittämiseen. Muulainen käyttö voi aiheuttaa vaaratilanteita käyttäjälle. Huolto- ja korjaustyöt saa tehdä vain valtuutettu asiakashuoltoasasto. Tuotteessa saa käyttää vain valmistajan suosittelemia alkuperäisiä vara-

ja lisäosia. Tuotteeseen tehdyt muutokset mitätöivät kaikki vastuut. Jos näitä ohjeita ei noudateta tai jos tuotetta käytetään johonkin muuhun kuin sen varsinaiseen käyttötarkoitukseen, käyttäjälle voi aiheutua vakavia vammoja ja/tai laite voi vaurioitua. Vain DIN / EN 287 mukaan hyväksytyt hitsaajat tai EN 3834-2 mukaiset urakoitsijat saavat tehdä vaaditut hitsaukset.

**FR** Avant l'installation/le montage du produit, lisez attentivement toutes les instructions d'installation et suivez-les au cours de l'installation. L'installation doit être réalisée par un expert qualifié conformément à toutes les réglementations de sécurité locales. Veillez à choisir un emplacement permettant d'assurer une installation et un fonctionnement en toute sécurité. Ce produit est uniquement destiné à maintenir/fixer des capteurs/équipements de mesure HACH LANGE. Toute autre utilisation entraînerait un risque pour l'utilisateur. Seul le service clientèle agréé est autorisé à effectuer les travaux de maintenance et de réparation. Seuls les pièces de rechange et les accessoires d'origine recommandés par le fabricant doivent être utilisés. La modification du produit annule toute responsabilité. Le non-respect de ces instructions ou l'utilisation de ce produit à des fins autres que celles auxquelles il est destiné risqueraient de gravement blesser l'utilisateur et/ou d'endommager le matériel. Le travail de soudure requis doit être réalisé exclusivement par des soudeurs qualifiés en conformité avec DIN / EN 287, ou par prestataires conformément à EN 3834-2.

**HR** Prije instalacije/postavljanja uređaja, pažljivo pročitajte sve upute za montažu i pratite ih tijekom postupka instalacije. Instalaciju mora provesti kvalificirani stručnjak u skladu s lokalnim sigurnosnim propisima. Brižljivo odaberite mjesto instalacije na kojem će se postavljanje uređaja i njegovo korištenje odvijati u sigurnim uvjetima. Uređaj je namijenjen isključivo za držanje/pričvršćivanje HACH/HACH LANGE mjernih senzora/uređaja. Upotreba uređaja u druge svrhe može predstavljati rizik za korisnika. Održavanje i popravke smije provoditi isključivo ovlašteni servisni odjel. Mogu se upotrebljavati samo originalni rezervni i dodatni dijelovi koje je preporučio proizvođač. Bilo kakve izmjene izvršene na uređaju poništiti će njegovu pouzdanost. Nepoštivanje ovih uputa ili upotreba uređaja za svrhe za koje nije namijenjen mogu dovesti do ozbiljnih ozljeda osoba koje se njime koriste i/ili štete na opremi. Potreban posao za zavarivanje mora biti izveden prema DIN / EN 287 od strane kvalificiranih varoica ili izvođača radova prema EN 3834-2.

**HU** A termék üzembe helyezésére/rögzítésre előtt tekintse át a vonatkozó utasításokat, és tartsa is be azokat. Az üzembe helyezést kizárólag szakember végezheti, a hatályos biztonsági előírásoknak megfelelően. A telepítéshez biztonságos üzemet szavatoló helyet válasszon. A termék kizárólag HACH/HACH LANGE mérőberendezések és készületek rögzítésére szolgál. Az ettől eltérő bármilyen használat kockázattal jár. A karbantartást és egyéb javításokat kizárólag az arra feljogosított ügyfélszolgálati részleg végezheti el. Csak a gyártó által ajánlott cserealkatrészek használhatóak. A terméken végzett bármilyen módosítás a felelősség kizárását vonja maga után. Az utasítások be nem tartása, a termék megadott felhasználási területétől eltérő célra való alkalmazása a kezelő súlyos sérülését és/vagy a berendezés károsodását okozhatja. A szükséges hegesztési munkákat csak DIN/EN 287 bizonyítvánnyal rendelkező hegesztő szakember, vagy EN 3834-2 minősítéssel rendelkező szakőég végezheti.

**IT** Prima di installare/montare il prodotto, leggere le istruzioni sull'installazione e attenersi scrupolosamente ad esse durante l'installazione. L'installazione deve essere eseguita da personale qualificato in base alle norme di sicurezza locali. Scegliere con cura il punto di installazione per un'installazione corretta e un funzionamento sicuro. Il prodotto è adatto esclusivamente per il sostegno/collegamento di prodotti/sensori di misura HACH/HACH LANGE. Qualsiasi altro utilizzo può provocare lesioni all'utente. La manutenzione e gli interventi di riparazione devono essere eseguiti esclusivamente dal reparto assistenza clienti. Il produttore consiglia di sostituire gli accessori solo con ricambi originali. Qualsiasi modifica apportata al prodotto prevede l'esclusione da qualsiasi responsabilità. La mancata osservanza della procedura di installazione o l'utilizzo inappropriato del prodotto possono provocare serie lesioni all'utente e/o danni all'apparecchiatura. Il lavoro di saldatura richiesto deve essere effettuato esclusivamente in accordo alla direttiva DIN / EN 287 da saldatori qualificati o da costruttori in accordo a EN 3834-2.

**JA** 製品を取り付ける前にすべての設置手順をよく読み、手順に従って設置してください。設置は地域の安全基準に従い、資格のある担当者が行ってください。設置場所は、安全に取り付けで操作できる場所を選んでください。本製品は、HACH/HACH LANGE 測定センサー/製品の保持および接続専用です。その他の用途には、ユーザーの責任において使用してください。メンテナンスおよび修理は、認定されたカスタマー サービス部門のみが実施できます。交換部品および付属品には、メーカー推奨の純正品ののみを使用してください。製品を改変した場合、保証は無効になります。手順に従わなかった場合、または製品を用途外に使用した場合は、整備を負ったり、装置が破壊されることがあります。フルディングはDIN/EN287に基づいて認定された作業業者あるいはEN3834-2に基づく受託業者が実施する。

**KO** 본 제품을 설치하거나 장착하기 전에 모든 설치 지침을 충분히 검토하고 설치 시 반드시 해당 지침을 따르십시오. 설치는 숙련된 기술자가 지역의 모든 관련 안전 규정을 준수하여 수행해야 합니다. 설치 및 작동 시 안전한 장소를 신중하게 고려하십시오. 본 제품은 HACH/HACH LANGE 측정 센서 또는 측정 제품을 지지하거나 연결하는 용도로만 사용됩니다. 그 외 다른 용도로 사용 시 작업자가 위험할 수 있습니다. 유지 관리 및 보수 작업은 공인된 고객 서비스 부서에서 전적으로 담당해야 합니다. 제조사가 승인한 교체용 부품 및 주변 장치만 사용 가능합니다. 제품 변경으로 인한 책임은 지지 않습니다. 이러한 지침에 어긋나거나 원래 제품의 용도나, 본 목적으로 사용할 경우 작업자에게 심각한 부상이 일어나거나 장비가 손상될 수 있습니다. 용접 작업이 필요한 경우에는 반드시 DIN/EN 287 자격을 가진 용접공이나 EN3834-2에 상응한 사람에 의해서 반드시 수행되어야 합니다.

**NL** Lees vóór montage van het product alle montage-instructies grondig door en volg de instructies tijdens de montage op. Montage dient te worden uitgevoerd door een gekwalificeerde persoon en in overeenstemming met alle plaatselijke veiligheidsvoorschriften. Kies een montagelocatie die een veilige montage en werking garandeert. Het product is uitsluitend bedoeld voor opname/bevestiging van meetsensoren/-producten van HACH/HACH LANGE. Elk ander gebruik kan gevaren voor de gebruiker met zich meebrengen. Onderhoud en reparatie mogen uitsluitend worden uitgevoerd door de geautoriseerde afdeling klantenservice. Er mogen alleen originele, door de fabrikant aanbevolen reservedelen en accessoires worden gebruikt. Bij elke aanpassing van het product vervalt de aansprakelijkheid. Als u deze instructies niet opvolgt of als u het product voor een ander doel gebruikt dan waarvoor het is bedoeld, kan dit leiden tot ernstig letsel van de gebruiker en/of beschadiging van de apparatuur. Het benodigde laswerk mag uitsluitend uitgevoerd worden door DIN/EN287 gekwalificeerde lassers, of door EN3834-2 gecertificeerde installateurs.

**PL** Przed zainstalowaniem/zamontowaniem produktu, uważnie przeczytać wszystkie instrukcje i postępować zgodnie z ich zaleceniami podczas instalacji. Instalacja powinna zostać wykonana przez specjalistę o odpowiednich kwalifikacjach, zgodnie ze wszystkimi obowiązującymi lokalnie przepisami bezpieczeństwa. Wybrać takie miejsce instalacji, które zapewni bezpieczeństwo podczas instalacji i użytkowania. Produkt jest przeznaczony wyłącznie do zamocowania/zawieszenia czujników/mierników firmy HACH/HACH LANGE. Jakiegokolwiek inne zastosowanie niesie ze sobą ryzyko dla użytkownika. Konserwację i naprawy powinny być przeprowadzane wyłącznie przez upoważnioną personel działu serwisowego klienta. Wolno używać tylko oryginalnych części zamiennych i części wyposażenia zalecanych przez producenta. Jakiegokolwiek modyfikacje w budowie i działaniu produktu uznają wygaśnięcie

gwarancji i wykluczają wszelką odpowiedzialność producenta. Nieprzestrzeganie tych instrukcji lub używanie produktu do celów innych niż wynika z opisu jego przeznaczenia, może być przyczyną poważnych wypadków z udziałem użytkownika i/lub uszkodzenia sprzętu. Wymagane prace spawalnicze muszą być wykonane zgodnie z normą DIN / EN 287 przez wykwalifikowany personel lub przez firmy pośredniczące zgodnie z EN3834-2.

**PT** Antes de instalar/montar o produto, leia atentamente as instruções de instalação e siga-as durante a instalação. A instalação deve ser efectuada por um profissional qualificado em conformidade com todas as regulamentações locais de segurança. Escolha cuidadosamente o local de instalação de modo a assegurar uma operação e instalação com segurança. Este produto foi concebido apenas para segurar/fixar sensores/produtos para medições da HACH/HACH LANGE. Qualquer outro tipo de utilização pode implicar riscos para o utilizador. O trabalho de manutenção e reparação deve ser efectuado única e exclusivamente pelo departamento de assistência ao cliente devidamente autorizado. Apenas podem ser utilizados acessórios e peças de substituição originais recomendados pelo fabricante. Qualquer alteração feita ao produto anula qualquer responsabilidade da nossa parte. O não cumprimento das instruções ou a utilização do produto para outros fins que não aqueles para que o produto foi concebido pode resultar em ferimentos graves e/ou danos no equipamento. O trabalho de soldadura exigido deverá ser executado exclusivamente por soldadores qualificados de acordo com a norma DIN / EN 287, ou por empreiteiros em conformidade com a norma EN 3834-2.

**RO** Înainte de instalarea/montarea produsului, citiți cu atenție toate instrucțiunile de instalare și urmați instrucțiunile în timpul instalării. Instalarea trebuie realizată de un expert calificat în conformitate cu toate reglementările locale pentru siguranță. Aveți grijă să alegeți o locație de instalare care să asigure instalarea și funcționarea în siguranță. Produsul este destinat exclusiv pentru menținerea/atașarea senzorilor/produselor de măsurare HACH/HACH LANGE. Utilizarea în alte scopuri poate implica riscuri pentru utilizator. Întreținerea și lucrările de reparație trebuie realizate exclusiv de departamentul de service autorizat pentru clienți. Pot fi utilizate numai piesele de schimb și accesoriile originale recomandate de producător. Orice modificare adusă produsului va duce la anularea oricărei răspunderi. Nerespectarea acestor instrucțiuni sau utilizarea produsului în alte scopuri decât în cele destinate pot duce la accidente grave pentru utilizator și/sau defectarea echipamentului. Lucrările de sudură necesare trebuie să fie efectuate exclusiv de sudori calificați în conformitate cu DIN / EN 287 , sau de contractori în conformitate cu EN 3834-2.

**RU** Перед установкой/монтажом изделия необходимо внимательно прочитать инструкции по установке и строго следовать им во время выполнения работ. Установка должна быть выполнена квалифицированным специалистом с соблюдением действующих правил по технике безопасности. Выбирая место для установки, необходимо учитывать требования по безопасности при монтаже и эксплуатации изделий. Данное изделие предназначено только для крепления измерительных датчиков/приборов компании HACH/HACH LANGE. Любое другое применение может представлять опасность для пользователя. Работы по ремонту и техобслуживанию должны выполняться исключительно специалистами уполномоченной сервисной организации. С изделием могут использоваться только запчасти и принадлежности, рекомендуемые изготовителем. Любые изменения, внесенные в конструкцию изделия, приведут к отмене гарантии поставщика. Несоблюдение требований инструкций или использование изделия не по назначению могут стать причиной серьезных травм для людей и/или повреждения оборудования. Необходимые сварочные работы должны проводиться только сварщиками, квалифицированными в соответствии с DIN / EN 287, или подрядчиками в соответствии с DIN 3834-2.

**SK** Pred inštaláciou/upevnením produktu si pozorne prečítajte všetky pokyny k inštalácii a počas inštalácie ich dodržujte. Inštaláciu musí vykonať kvalifikovaný expert v súlade so všetkými miestnymi bezpečnostnými nariadeniami. Uistite sa, že si vyberiete miesto inštalácie, ktoré zaručí bezpečnú inštaláciu a prevádzku. Produkt je určený výlučne pre uchytenie/upevnenie meracích snímačov/produktov HACH/HACH LANGE. Akékoľvek iné použitie môže zahŕňať riziká pre používateľa. Údržbu a opravy by malo vykonávať výlučne autorizované oddelenie služieb pre zákazníkov. Môžu sa použiť len originálne náhradné diely a príslušenstvo, ktoré odporúča výrobca. Akékoľvek zmeny vykonané na produkte spôsobia neplatnosť všetkej zodpovednosti. Nedodržanie týchto pokynov alebo používanie produktu na iný než určený účel môže spôsobiť vážne zranenie používateľa alebo poškodenie zariadenia. Požadované zváračské práce musia byť vykonané výhradne v súlade s DIN/EN 287 kvalifikovanými zváračmi, alebo dodávateľmi v súlade s EN 3834-2.




**SL** Pred namestitvijo/postavitvijo izdelka natančno preberite vsa navodila za namestitev in jih med nameščanjem upoštevajte. Namestitev mora izvesti usposobljen strokovnjak v skladu z vsemi lokalnimi varnostnimi predpisi. Za namestitev izberite mesto, ki zagotavlja varno namestitev in uporabo. Izdelek je namenjen izključno za namestitev/prireditve merilnih senzorjev/izdelkov HACH/HACH LANGE. Vsakršna drugačna uporaba lahko predstavlja nevarnost za uporabnika. Vzdrževanje in popravilo lahko izvaja izključno osebje pooblaščenega servisnega oddelka. Uporabljajte lahko samo originalne nadomestne dele in dodatno opremo, ki jih priporoča proizvajalec. Spremembe izdelka razveljavijo vsakršno odgovornost. Če teh navodil ne upoštevate ali izdelek uporabljate v neprimeren namen, lahko pride do hudih poškodb uporabnika in/ali poškodovanja opreme. Zahtevana dela varenja lahko izvajajo izključno usposobljeni varilci v skladu z DIN/EN 287 ali izvajalci v skladu z EN 3834-2.

**SR** Pre instalacije/montaže uređaja pažljivo pročitajte sva uputstva za montažu i pratite ih tokom postupka montaže. Instalaciju mora provesti kvalifikovani stručnjak u skladu sa lokalnim propisima o bezbednosti. Bržljivo odaberite mesto instalacije na kom će se montaža uređaja i korišćenje odvijati u bezbednim uslovima. Uređaj je namenjen isključivo za držanje/pričvršćivanje HACH/HACH LANGE mernih senzora/uređaja. Upotreba uređaja u druge svrhe može da predstavlja rizik po korisnika. Održavanje i opravke sme da provodi isključivo ovlašćeni serviser. Kod zamene i opravaka smeju da se koriste samo originalni rezervni i dodatni delovi koje je preporučio proizvođač. Bilo kakve izmene izvršene na uređaju poništice njegovu pouzdanost. Nepridržavanje uputstava ili upotreba uređaja u svrhe za koje nije namenjen mogu dovesti do ozbiljnih povreda ljudi koji ga koriste i/ili štete na opremi. Neophodni radovi zavarivanja treba da budu izvršeni od strane zavarivača u skladu sa DIN / EN 287 ili od ugovorenog izvođača radova u skladu sa EN 3834-2.








**SV** Läs alla installationsanvisningar noggrant innan du installerar/monterar produkten och följ anvisningarna under installationen. Installationen måste utföras av en kvalificerad expert i enlighet med alla lokala säkerhetsföreskrifter. Se till att välja en installationsplats som garanterar säker installation och drift. Produkten är endast ämnad för att hålla/fästa mätensorer/-produkter från HACH/HACH LANGE. Annan användning kan medföra risker för användaren. Underhålls- och reparationsarbeten ska uteslutande utföras av den auktoriserade kundserviceavdelningen. Endast originalreservdelar och -tillbehör som rekommenderas av tillverkaren ska användas. Om någon ändring görs på produkten upphävs tillverkarens ansvar. Det kan det medföra allvarliga skador för användaren eller skador på utrustningen om du inte följer anvisningarna eller om du använder produkten i installationer den inte är avsedd för. Svetsarbeten skall uteslutande utföras av svetsare kvalificerade enligt DIN/EN 287, eller av entreprenör enligt EN3834-2.





**TR** Ürünün montajını yapmadan önce, tüm montaj talimatlarını dikkatlice okuyun ve kurulum sırasında talimatları mutlaka takip edin. Montaj, kalifiye bir uzman tarafından tüm yerel güvenlik düzenlemelerine uygun şekilde yapılmalıdır. Ürünü, montaj ve kullanımin güvenli olacağı bir yere monte edin. Ürün sadece HACH/HACH LANGE ölçüm sensörlerini/ ürünlerini, tutmak/takmak için tasarlanmıştır. Başka amaçlarla kullanılması, kullanıcı için tehlikeler doğurabilir. Bakım ve onarım sadece yetkili müşteri hizmetleri departmanı tarafından gerçekleştirilmelidir. Sadece üretici tarafından önerilen orijinal yedek parça ve aksesuarlar kullanılmalıdır. Ürüne yapılan her türlü değişiklik, tüm sorumluluğu ortadan kaldırır. Bu talimatlara uyulmaması veya ürünün üretim amacından başka bir amaçla kullanılması sonucunda kullanıcı ciddi şekilde yaralanabilir ve/veya ürün zarar görebilir. Gerekli kaynak işi yalnızca kalifiye kaynakçılar tarafından DIN / EN 287'ye göre yapılmalıdır, veya müteahhitler tarafından EN 3834-2'ye göre yapılmalıdır.





**ZH** 在安装/固定产品之前，请仔细阅读所有安装说明，并在安装过程中遵守这些说明。必须由合格的专家完成安装，并遵守当地的所有安全法规。仔细选择安装地点，确保安全地安装和操作。本产品只能用于固定/连接 HACH/HACH LANGE 测量传感器/产品。用于其它用途可能会给用户带来危险。维护和修理工作应由经授权的客户服务中心完成。只能使用正宗替换件和制造商推荐的附件。对本产品进行任何更改均可能导致所有担保失效。不遵守这些说明，或者将本产品用于其它用途，可能会对用户造成严重伤害和/或设备损坏。所需的焊接工作必须根据 DIN/EN 287，由合格的焊接工人单独执行，或者根据 EN 3834-2 由承包人执行。




































 <b>LZX337</b> SOLITAX inline sc SOLITAX highline sc	<b>A1</b>		<b>A2</b>	<b>LZY441</b>	<b>A3</b>	<b>M16x45mm A4 ISO4017</b>	<b>A4</b>	<b>LZY462</b>	<b>A5</b>	<b>DOC273. 99. 03911</b>	<b>A6</b>	<b>LZV678</b>
	1x		1x		4x		1x		1x		1x	





 <b>LZX660</b> SS 316Ti/ 1.4571 DN65/PN16 DIN 2633	<b>B1</b>	<b>DN65</b>	<b>B2</b>	<b>DOC273. 99. 03911</b>	<b>B3</b>	<b>DN65</b>						
	1x		1x		1x							


 <b>LZX661</b> C-steel / 1.0037 DN65/PN16 DIN 2633	<b>B1</b>	<b>DN65</b>	<b>B2</b>	<b>DOC273. 99. 03911</b>	<b>B3</b>	<b>DN65</b>						
	1x		1x		1x							

 <b>LZY630.00.12000</b> TSS inline sc	<b>A1</b>		<b>A2</b>	<b>LZY441</b>	<b>A3</b>	<b>M16x45mm A4 ISO4017</b>	<b>A4</b>	<b>LZY462</b>	<b>A5</b>	<b>DOC273. 99. 03911</b>	<b>A6</b>	<b>LZV678</b>
	1x		1x		4x		1x		1x		1x	





 <b>LZY630.00.10000</b> TSS inline sc												
 <b>LZY630.00.12000</b>	<b>A1</b>		<b>A2</b>	<b>LZY441</b>	<b>A3</b>	<b>M16x45mm A4 ISO4017</b>	<b>A4</b>	<b>LZY462</b>	<b>A5</b>	<b>DOC273. 99. 03911</b>	<b>A6</b>	<b>LZV678</b>
	1x		1x		4x		1x		1x		1x	
 <b>LZX660</b> SS 316Ti/ 1.4571 DN65/PN16 DIN 2633	<b>B1</b>	<b>DN65</b>	<b>B2</b>	<b>DOC273. 99. 03911</b>	<b>B3</b>	<b>DN65</b>						
	1x		1x		1x							


 <b>LZY630.00.11000</b> TSS inline sc												
 <b>LZY630.00.12000</b>	<b>A1</b>		<b>A2</b>	<b>LZY441</b>	<b>A3</b>	<b>M16x45mm A4 ISO4017</b>	<b>A4</b>	<b>LZY462</b>	<b>A5</b>	<b>DOC273. 99. 03911</b>	<b>A6</b>	<b>LZV678</b>
	1x		1x		4x		1x		1x		1x	
 <b>LZX661</b> C-steel / 1.0037 DN65/PN16 DIN 2633	<b>B1</b>	<b>DN65</b>	<b>B2</b>	<b>DOC273. 99. 03911</b>	<b>B3</b>	<b>DN65</b>						
	1x		1x		1x							












10

A1



A1



11



24 mm





A3





4x




A3















1

A2



2





[illegible]

[illegible]





**HACH Company  
World Headquarters**  
P.O. Box 389  
Loveland, Colorado  
80539-0389 U.S.A.  
Tel (800) 227-HACH  
(800) -227-4224  
(U.S.A. only)  
Fax (970) 669-2932  
orders@hach.com  
www.hach.com

**Repair Service in the  
United States:**  
HACH Company  
Ames Service  
100 Dayton Avenue  
Ames, Iowa 50010  
Tel (800) 227-4224  
(U.S.A. only)  
Fax (515) 232-3835

**Repair Service in Canada:**  
Hach Sales & Service  
Canada Ltd.  
1313 Border Street, Unit 34  
Winnipeg, Manitoba  
R3H 0X4  
Tel (800) 665-7635  
(Canada only)  
Tel (204) 632-5598  
Fax (204) 694-5134  
canada@hach.com

**Repair Service in  
Latin America, the  
Caribbean, the Far East,  
Indian Subcontinent, Africa,  
Europe, or the Middle East:**  
Hach Company World  
Headquarters,  
P.O. Box 389  
Loveland, Colorado,  
80539-0389 U.S.A.  
Tel +001 (970) 669-3050  
Fax +001 (970) 669-2932  
intl@hach.com

**HACH LANGE GMBH**  
Willstätterstraße 11  
D-40549 Düsseldorf  
Tel. +49 (0)2 11 52 88-320  
Fax +49 (0)2 11 52 88-210  
info@hach-lange.de  
www.hach-lange.de

**HACH LANGE LTD**  
Pacific Way  
Salford  
GB-Manchester, M50 1DL  
Tel. +44 (0)161 872 14 87  
Fax +44 (0)161 848 73 24  
info@hach-lange.co.uk  
www.hach-lange.co.uk

**HACH LANGE LTD**  
Unit 1, Chestnut Road  
Western Industrial Estate  
IRL-Dublin 12  
Tel. +353(0)1 46 02 5 22  
Fax +353(0)1 4 50 93 37  
info@hach-lange.ie  
www.hach-lange.ie

**HACH LANGE GMBH**  
Hütteldorferstr. 299/Top 6  
A-1140 Wien  
Tel. +43 (0)1 9 12 16 92  
Fax +43 (0)1 9 12 16 92-99  
info@hach-lange.at  
www.hach-lange.at

**HACH LANGE GMBH**  
Rorschacherstrasse 30 a  
CH-9424 Rheineck  
Tel. +41 (0)848 55 66 99  
Fax +41 (0)71 886 91 66  
info@hach-lange.ch  
www.hach-lange.ch

**HACH LANGE FRANCE S.A.S.**  
8, mail Barthélemy Thimonnier  
Lognes  
F-77437 Marne-La-Vallée  
cedex 2  
Tél. +33 (0)8 20 20 14 14  
Fax +33 (0)1 69 67 34 99  
info@hach-lange.fr  
www.hach-lange.fr

**HACH LANGE NV/SA**  
Motstraat 54  
B-2800 Mechelen  
Tél. +32 (0)15 42 35 00  
Fax +32 (0)15 41 61 20  
info@hach-lange.be  
www.hach-lange.be

**DR. LANGE NEDERLAND B.V.**  
Laan van Westroijen 2a  
NL-4003 AZ Tiel  
Tel. +31(0)344 63 11 30  
Fax +31(0)344 63 11 50  
info@hach-lange.nl  
www.hach-lange.nl

**HACH LANGE APS**  
Åkandevej 21  
DK-2700 Brønshøj  
Tel. +45 36 77 29 11  
Fax +45 36 77 49 11  
info@hach-lange.dk  
www.hach-lange.dk

**HACH LANGE AB**  
Vinhundsvägen 159A  
SE-128 62 Sköndal  
Tel. +46 (0)8 7 98 05 00  
Fax +46 (0)8 7 98 05 30  
info@hach-lange.se  
www.hach-lange.se

**HACH LANGE S.R.L.**  
Via Rossini, 1/A  
I-20020 Lainate (MI)  
Tel. +39 02 93 575 400  
Fax +39 02 93 575 401  
info@hach-lange.it  
www.hach-lange.it

**HACH LANGE S.L.U.**  
Edificio Seminario  
C/Larrauri, 1C- 2ª Pl.  
E-48160 Derio/Vizcaya  
Tel. +34 94 657 33 88  
Fax +34 94 657 33 97  
info@hach-lange.es  
www.hach-lange.es

**HACH LANGE LDA**  
Av. do Forte nº8  
Fracção M  
P-2790-072 Carnaxide  
Tel. +351 214 253 420  
Fax +351 214 253 429  
info@hach-lange.pt  
www.hach-lange.pt

**HACH LANGE SP.ZO.O.**  
ul. Krakowska 119  
PL-50-428 Wrocław  
Tel. +48 801 022 442  
Zamówienia: +48 717 177 707  
Doradztwo: +48 717 177 777  
Fax +48 717 177 778  
info@hach-lange.pl  
www.hach-lange.pl

**HACH LANGE S.R.O.**  
Zastrčená 1278/8  
CZ-141 00 Praha 4 - Chodov  
Tel. +420 272 12 45 45  
Fax +420 272 12 45 46  
info@hach-lange.cz  
www.hach-lange.cz

**HACH LANGE S.R.O.**  
Roľnícka 21  
SK-831 07 Bratislava –  
Vajnory  
Tel. +421 (0)2 4820 9091  
Fax +421 (0)2 4820 9093  
info@hach-lange.sk  
www.hach-lange.sk

**HACH LANGE KFT.**  
Vöröskereszt utca. 8-10.  
H-1222 Budapest XXII. ker.  
Tel. +36 (06)1 225 7783  
Fax +36 (06)1 225 7784  
info@hach-lange.hu  
www.hach-lange.hu

**HACH LANGE S.R.L.**  
Str. Căminului nr. 3  
et. 1, ap. 1, Sector 2  
RO-021741 București  
Tel. +40 (0) 21 205 30 03  
Fax +40 (0) 21 205 30 17  
info@hach-lange.ro  
www.hach-lange.ro

**HACH LANGE**  
8, Kr. Sarafov str.  
BG-1164 Sofia  
Tel. +359 (0)2 963 44 54  
Fax +359 (0)2 866 15 26  
info@hach-lange.bg  
www.hach-lange.bg

**HACH LANGE SU  
ANALİZ SİSTEMLERİ  
LTD.ŞTİ.**  
İlkbahar mah. Galip Erdem  
Cad. 616 Sok. No:9  
TR-Oran-Çankaya/ANKARA  
Tel. +90312 490 83 00  
Fax +90312 491 99 03  
bilgi@hach-lange.com.tr  
www.hach-lange.com.tr

**HACH LANGE D.O.O.**  
Fajfarjeva 15  
SI-1230 Domžale  
Tel. +386 (0)59 051 000  
Fax +386 (0)59 051 010  
info@hach-lange.si  
www.hach-lange.si

**HACH LANGE E.Π.Ε.**  
Αυλίδος 27  
GR-115 27 Αθήνα  
Τηλ. +30 210 7777038  
Fax +30 210 7777976  
info@hach-lange.gr  
www.hach-lange.gr

**HACH LANGE D.O.O.**  
Ivana Severa bb  
HR-42 000 Varaždin  
Tel. +385 (0) 42 305 086  
Fax +385 (0) 42 305 087  
info@hach-lange.hr  
www.hach-lange.hr

**HACH LANGE MAROC SARLAU**  
Villa 14 – Rue 2 Casa Plaisance  
Quartier Racine Extension  
MA-Casablanca 20000  
Tél. +212 (0)522 97 95 75  
Fax +212 (0)522 36 89 34  
info-maroc@hach-lange.com  
www.hach-lange.ma

**HACH LANGE OOO**  
Finlyandsky prospekt, 4A  
B. Zentrum "Petrovsky fort", R.803  
RU-194044, Sankt-Petersburg  
Tel. +7 (812) 458 56 00  
Fax. +7 (812) 458 56 00  
info.russia@hach-lange.com  
www.hach-lange.com



MANUFACTURER INSTALLATION OPERATION AND MAINTENANCE MANUAL  
AMARUQ WTP – NUNAVUT  
VEOLIA PROJECT: 5000 218 009

---

***HACH***

***MODEL SC200, UNIVERSAL CONTROLLER***

---

**WATER TECHNOLOGIES**

*LEFT BLANK*




DOC023.53.80040

# sc200 Controller

07/2016, Edition 8

**User Manual**



## Table of Contents

<b>Specifications</b>	3
<b>General information</b>	3
Safety information	4
Use of hazard information	4
Precautionary labels	4
Certification	4
Product overview	5
Sensors and sensor modules	6
Relays outputs and signals	6
Device scans	6
Controller enclosure	6
Controller mounting options	6
<b>Installation</b>	7
Mounting components and dimensions	7
Controller mounting	8
High-voltage barrier	11
Electrostatic discharge (ESD) considerations	11
Wiring overview	12
Wiring for power	12
Alarms and relays	15
Wiring relays	15
Analog output connections	17
Discrete input wiring connections	18
Connect a digital sc sensor	20
Connect the optional digital communication output	21
Install a Secure Digital (SD) memory card	21
<b>User interface and navigation</b>	22
User interface	22
Display	22
Additional display formats	23
Graphical display	23
<b>System startup</b>	24
Set the language, date and time for the first time	24
Controller configuration information	24
<b>Advanced operation</b>	25
Security setup	25
Enable or disable the passcode	25
Edit the passcode	25
Protect features	26
Configure a 4-20 mA input module	26
Configure a 4-20 mA output module	27
Configure the controller analog outputs	27
Logarithmic output mode	29
Bilinear output mode	29
Configure relays	30

## Table of Contents

Display setup .....	39
Update the date and time .....	40
Set the datalog mode and interval .....	40
Set up a calculation .....	40
Set up the discrete inputs .....	41
Update the display language .....	42
Using the secure digital memory (SD) card .....	42
Updating software .....	42
Saving data and event logs with SD cards .....	43
Access data and event log files on the SD card .....	43
Firmware updates with SD cards .....	44
Backup settings to an SD card .....	44
Restore settings to the controller .....	44
Transfer settings to another device .....	45
Using the service port .....	45
Using DataCom .....	45
<b>Maintenance</b> .....	46
Cleaning the controller .....	46
Fuse replacement .....	46
Battery replacement .....	46
<b>Troubleshooting</b> .....	46
Test and Maintenance menu .....	48
Warning and error conditions .....	49
<b>Device scan information</b> .....	50
<b>Replacement parts and accessories</b> .....	50

## Specifications

Specifications are subject to change without notice.

Specification	Details
Component description	Microprocessor-controlled and menu-driven controller that operates the sensor and displays measured values.
Operating temperature	-20 to 60 °C (-4 to 140 °F); 95% relative humidity, non-condensing with sensor load <7 W; -20 to 50 °C (-4 to 104 °F) with sensor load <28 W
Storage temperature	-20 to 70 °C (-4 to 158 °F); 95% relative humidity, non-condensing
Enclosure <sup>1</sup>	NEMA 4X/IP66 metal enclosure with a corrosion-resistant finish
Power requirements	<p><b>AC powered controller:</b> 100-240 VAC ±10%, 50/60 Hz; Power 50 VA with 7 W sensor/network module load, 100 VA with 28 W sensor/network module load (optional Modbus, RS232/RS485, Profibus DPV1 or HART network connection).</p> <p><b>24 VDC powered controller:</b> 24 VDC—15%, + 20%; Power 15 W with 7 W sensor/network module load, 40 W with 28 W sensor/network module load (optional Modbus, RS232/RS485, Profibus DPV1 or HART network connection).</p>
Altitude requirements	Standard 2000 m (6562 ft) ASL (Above Sea Level)
Pollution degree/Installation category	Pollution Degree 2; Installation Category II
Outputs	Two analog (0-20 mA or 4-20 mA) outputs. Each analog output can be assigned to represent a measured parameter such as pH, temperature, flow or calculated values. Optional module supplies three additional analog outputs (5 total).
Relays	Four SPDT, user-configured contacts, rated 250 VAC, 5 Amp resistive maximum for the AC powered controller and 24 VDC, 5A resistive maximum for the DC powered controller. Relays are designed for connection to AC Mains circuits (i.e., whenever the controller is operated with 115 - 240 VAC power) or DC circuits (i.e., whenever the controller is operated with 24 VDC power).
Dimensions	½ DIN—144 x 144 x 180.9 mm (5.7 x 5.7 x 7.12 in.)
Weight	1.7 kg (3.75 lb)
Compliance information <sup>2</sup>	<p>CE approved (with all sensor types). Listed for use in general locations to UL and CSA safety standards by ETL (with all sensor types).</p> <p>Certain AC mains powered models are listed for use in general safety locations to UL and CSA safety standards by Underwriters Laboratories (with all sensor types).</p>
Digital communication	Optional Modbus, RS232/RS485, Profibus DPV1 or HART network connection for data transmission
Data logging	Secure Digital Card (32 GB maximum) or special RS232 cable connector for data logging and performing software updates. The controller will keep approximately 20,000 data points per sensor.
Warranty	2 years

## General information

In no event will the manufacturer be liable for direct, indirect, special, incidental or consequential damages resulting from any defect or omission in this manual. The manufacturer reserves the right to

<sup>1</sup> Units that have the Underwriters Laboratories (UL) certification are intended for indoor use only and do not have a NEMA 4X/IP66 rating.

<sup>2</sup> DC powered units are not listed by UL.



make changes in this manual and the products it describes at any time, without notice or obligation. Revised editions are found on the manufacturer's website.

## Safety information

### NOTICE

The manufacturer is not responsible for any damages due to misapplication or misuse of this product including, without limitation, direct, incidental and consequential damages, and disclaims such damages to the full extent permitted under applicable law. The user is solely responsible to identify critical application risks and install appropriate mechanisms to protect processes during a possible equipment malfunction.

Please read this entire manual before unpacking, setting up or operating this equipment. Pay attention to all danger and caution statements. Failure to do so could result in serious injury to the operator or damage to the equipment.

Make sure that the protection provided by this equipment is not impaired. Do not use or install this equipment in any manner other than that specified in this manual.

### Use of hazard information

#### ⚠ DANGER

Indicates a potentially or imminently hazardous situation which, if not avoided, will result in death or serious injury.

#### ⚠ WARNING

Indicates a potentially or imminently hazardous situation which, if not avoided, could result in death or serious injury.

#### ⚠ CAUTION





Indicates a potentially hazardous situation that may result in minor or moderate injury.

### NOTICE

Indicates a situation which, if not avoided, may cause damage to the instrument. Information that requires special emphasis.

## Precautionary labels

Read all labels and tags attached to the instrument. Personal injury or damage to the instrument could occur if not observed. A symbol on the instrument is referenced in the manual with a precautionary statement.

	This symbol, if noted on the instrument, references the instruction manual for operation and/or safety information.
	This symbol indicates that a risk of electrical shock and/or electrocution exists.
	This symbol indicates the presence of devices sensitive to Electro-static Discharge (ESD) and indicates that care must be taken to prevent damage with the equipment.
	Electrical equipment marked with this symbol may not be disposed of in European domestic or public disposal systems. Return old or end-of-life equipment to the manufacturer for disposal at no charge to the user.

## Certification

Canadian Radio Interference-Causing Equipment Regulation, IECS-003, Class A:

Supporting test records reside with the manufacturer.

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de classe A répond à toutes les exigences de la réglementation canadienne sur les équipements provoquant des interférences.

#### **FCC Part 15, Class "A" Limits**

Supporting test records reside with the manufacturer. The device complies with Part 15 of the FCC Rules. Operation is subject to the following conditions:

1. The equipment may not cause harmful interference.
2. The equipment must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at their expense. The following techniques can be used to reduce interference problems:


1. Disconnect the equipment from its power source to verify that it is or is not the source of the interference.
2. If the equipment is connected to the same outlet as the device experiencing interference, connect the equipment to a different outlet.
3. Move the equipment away from the device receiving the interference.
4. Reposition the receiving antenna for the device receiving the interference.
5. Try combinations of the above.

#### **Product overview**

The controller displays sensor measurements and other data, can transmit analog and digital signals, and can interact with and control other devices through outputs and relays. Outputs, relays, sensors and sensor modules are configured and calibrated through the user interface on the front of the controller.

[Figure 1](#) shows the product components. Components may vary according to controller configuration. Contact the manufacturer if parts are damaged or missing.

**Figure 1 System components**



1 Controller	4 Network module (optional)
2 Strain relief assembly (optional depending on controller version)	5 High-voltage barrier
3 Digital connection fitting (optional depending on controller version)	6 Sensor modules (optional)

**Sensors and sensor modules**

The controller accepts up to a maximum of two sensor modules or two digital sensors (depending on the controller configuration), along with one communication module. A single digital sensor and a single sensor module can be installed in combination. A variety of sensors can be wired to the sensor modules. Sensor wiring information is given in the specific sensor manuals and in the user instructions for specific modules.

**Relays outputs and signals**

The controller has four configurable relay switches and two analog outputs. An optional analog output module can increase the number of analog outputs to five.

**Device scans**

With two exceptions, the controller automatically scans for connected devices without user input when it is powered on. The first exception is when the controller is powered on for the first time before initial use. The second exception is after the controller configuration settings have been set to their default values and the controller is powered on. In both cases, the controller first displays the language, date and time edit screens. After the language, date and time entries are accepted, the controller performs a device scan. Refer to [Connect a digital sc sensor](#) on page 20 for instructions about how to scan for devices when the controller is already powered on.

**Controller enclosure**

The controller enclosure is NEMA 4X/IP66-rated and has a corrosion-resistant finish designed to withstand corrosive environmental constituents such as salt spray and hydrogen sulfide. Protection against environmental damage is strongly recommended for outdoor use.  
**Note:** Units that have the Underwriters Laboratories (UL) certification are intended for indoor use only and do not have a NEMA 4X/IP66 rating.

**Controller mounting options**

The controller can be mounted to a panel, to a wall or to a vertical or horizontal pipe. A neoprene sealing gasket is included and can be used to reduce vibration. The gasket can be used as a template for panel mounting before the inner gasket component is separated.

## Installation

### Mounting components and dimensions

#### ⚠ CAUTION


Personal injury hazard. Only qualified personnel should conduct the tasks described in this section of the manual.

The controller can be installed on a surface, panel or pipe (horizontal or vertical). For mounting options and instructions, refer to [Figure 2](#), [Figure 3](#) on page 8, [Figure 4](#) on page 9, [Figure 5](#) on page 10 and [Figure 6](#) on page 11.

For horizontal pipe mounts, the mounting feet ([Figure 2](#)) must be attached to the mounting bracket in a vertical position.

For both horizontal and vertical pipe mounts, attach the mounting bracket to the controller as shown in [Figure 5](#) on page 10.

**Figure 2 Mounting components**




1 Mounting foot (2x)	6 Flat washer, 1/4-inch ID (4x)
2 Sealing gasket for panel mount, Neoprene	7 Lock washer, 1/4-inch ID (4x)
3 Bracket for wall and pipe mounting	8 M5 x 0.8 Keps hexnut (4x)
4 Vibration isolation gasket for pipe mount	9 Pan head screws, M5 x 0.8 x 100mm (4x) (Used for variable diameter pipe mount installations)
5 Vibration isolation washer for pipe mount (4x)	10 Pan head screws, M5 x 0.8 x 15 mm (4x)


**Note:** A bracket for panel mounting is available as an optional accessory.

## Controller mounting

Figure 3 Surface mounting dimensions



**Figure 4 Panel mounting dimensions**



**Note:** If using the bracket (optional) for panel mounting, push the controller through the hole in the panel and then slide the bracket over the controller on the back side of the panel. Use the four 15 mm pan head screws (supplied) to attach the bracket to the controller and secure the controller to the panel.

**Figure 5** Pipe mounting (vertical pipe)





Figure 6 Top and bottom views



### High-voltage barrier

High-voltage wiring for the controller is located behind the high-voltage barrier in the controller enclosure. The barrier must remain in place except when installing modules or when a qualified installation technician is wiring for power, alarms, outputs or relays. Do not remove the barrier while power is applied to the controller.

### Electrostatic discharge (ESD) considerations

#### NOTICE



Potential Instrument Damage. Delicate internal electronic components can be damaged by static electricity, resulting in degraded performance or eventual failure.

Refer to the steps in this procedure to prevent ESD damage to the instrument:

- Touch an earth-grounded metal surface such as the chassis of an instrument, a metal conduit or pipe to discharge static electricity from the body.




- Avoid excessive movement. Transport static-sensitive components in anti-static containers or packages.
- Wear a wrist strap connected by a wire to earth ground.
- Work in a static-safe area with anti-static floor pads and work bench pads.

## Wiring overview

Figure 7 shows an overview of the wiring connections inside the controller with the high voltage barrier removed. The left side of the figure shows the back side of the controller cover.


**Note:** Remove connector caps from the connectors before module installation.

**Figure 7 Wiring connections overview**




1 Service cable connection	5 AC and DC power connector <sup>3</sup>	9 Discrete input wiring connector <sup>3</sup>
2 4-20 mA output <sup>3</sup>	6 Ground terminals	10 Digital sensor connector <sup>3</sup>
3 Sensor module connector	7 Relay connections <sup>3</sup>	
4 Communication module connector (e.g., Modbus, Profibus, HART, optional 4-20 mA module, etc.)	8 Digital sensor connector <sup>3</sup>	


## Wiring for power

<b>⚠ WARNING</b>	
	<p>Potential Electrocution Hazard. Always disconnect power to the instrument when making electrical connections.</p>

<sup>3</sup> Terminals can be removed for improved access.

<b>⚠ WARNING</b>	
	Potential Electrocutation Hazard. If this equipment is used outdoors or in potentially wet locations, a <b>Ground Fault Interrupt</b> device must be used for connecting the equipment to its mains power source.

<b>⚠ DANGER</b>	
	Electrocutation Hazard. Do not connect AC power to a 24 VDC powered model.

<b>⚠ WARNING</b>	
	Potential Electrocutation Hazard. A protective earth (PE) ground connection is required for both 100-240 VAC and 24 VDC wiring applications. Failure to connect a good PE ground connection can result in shock hazards and poor performance due to electromagnetic interferences. ALWAYS connect a good PE ground to the controller terminal.

<b>NOTICE</b>	
Install the device in a location and position that gives easy access to the disconnect device and its operation.	

The controller can be purchased as either a 100-240 VAC powered model or a 24 VDC powered model. Follow the appropriate wiring instructions for the purchased model.

The controller can be wired for line power by hard-wiring in conduit or wiring to a power cord. Regardless of the wire used, the connections are made at the same terminals. A local disconnect designed to meet local electrical code is required and must be identified for all types of installation. In hard-wired applications, the power and safety ground service drops for the instrument must be 18 to 12 AWG.

**Notes:**

- The voltage barrier must be removed before making any electrical connections. After making all connections, replace the voltage barrier before closing the controller cover.
- A sealing type strain relief and a power cord less than 3 meters (10 feet) in length with three 18-gauge conductors (including a safety ground wire) can be used to maintain the NEMA 4X/IP66 environmental rating.
- Controllers can be ordered with AC power cords pre-installed. Additional power cords may also be ordered.
- The DC power source that supplies power to the 24 VDC powered controller must maintain voltage regulation within the specified 24 VDC-15% +20% voltage limits. The DC power source must also provide adequate protection against surges and line transients.

**Wiring procedure**


Refer to the illustrated steps that follow and [Table 1](#) or [Table 2](#) to wire the controller for power. Insert each wire into the appropriate terminal until the insulation is seated against the connector with no bare wire exposed. Tug gently after insertion to make sure that there is a secure connection. Seal any unused openings in the controller box with conduit opening sealing plugs.


**Table 1 AC power wiring information (AC powered models only)**

Terminal	Description	Color—North America	Color—EU
1	Hot (L1)	Black	Brown
2	Neutral (N)	White	Blue
—	Protective Earth (PE) Ground lug	Green	Green with yellow stripe

**Table 2 DC power wiring information (DC powered models only)**

Terminal	Description	Color—North America	Color—EU
1	+24 VDC	Red	Red
2	24 VDC return	Black	Black
—	Protective Earth (PE) Ground lug	Green	Green with yellow stripe





## Alarms and relays

The controller is equipped with four unpowered, single pole relays rated 100-250 VAC, 50/60 Hz, 5 amp resistive maximum. Contacts are rated 250 VAC, 5 amp resistive maximum for the AC powered controller and 24 VDC, 5A resistive maximum for the DC powered controller. The relays are not rated for inductive loads.

## Wiring relays

⚠ WARNING	
	Potential Electrocution Hazard. Always disconnect power to the instrument when making electrical connections.
⚠ WARNING	
	Potential fire hazard. The relay contacts are rated 5A and are not fused. External loads connected to the relays must have current limiting devices provided to limit current to < 5 A.
⚠ WARNING	
	Potential fire hazard. Do not daisy-chain the common relay connections or jumper wire from the mains power connection inside the instrument.
⚠ WARNING	
	Potential electrocution hazard. In order to maintain the NEMA/IP environmental ratings of the enclosure, use only conduit fittings and cable glands rated for at least NEMA 4X/IP66 to route cables in to the instrument.

## AC line (100—250 V) powered controllers

The wiring compartment is not designed for voltage connections in excess of 250 VAC.

#### 24 VDC powered controllers

##### ⚠ WARNING



Potential electrocution hazard. AC mains powered controllers (115 V–230 V) are designed for relay connections to AC mains circuits (i.e., voltages greater than 16 V-RMS, 22.6 V-PEAK or 35 VDC).

##### ⚠ WARNING




Potential electrocution hazard. 24 V powered controllers are designed for relay connections to low voltage circuits (i.e., voltages less than 16 V-RMS, 22.6 V-PEAK or 35 VDC).


The 24 VDC controller relays are designed for the connection to low voltage circuits (i.e., voltages less than 30 V-RMS, 42.2 V-PEAK or 60 VDC). The wiring compartment is not designed for voltage connections above these levels.

The relay connector accepts 18–12 AWG wire (as determined by load application). Wire gauge less than 18 AWG is not recommended.

The Normally Open (NO) and Common (COM) relay contacts will be connected when an alarm or other condition is active. The Normally Closed (NC) and Common relay contacts will be connected when an alarm or other condition is inactive (unless the Fail Safe is set to Yes) or when power is removed from the controller.

Most relay connections use either the NO and COM terminals or the NC and COM terminals. The numbered installation steps show connection to the NO and COM terminals.





### Analog output connections

#### ⚠ WARNING



Potential Electrocution Hazard. Always disconnect power to the instrument when making electrical connections.

#### ⚠ WARNING



Potential electrocution hazard. In order to maintain the NEMA/IP environmental ratings of the enclosure, use only conduit fittings and cable glands rated for at least NEMA 4X/IP66 to route cables in to the instrument.

Two isolated analog outputs (1 and 2) are provided (Figure 8). Such outputs are commonly used for analog signaling or to control other external devices.

Make wiring connections to the controller as shown in Figure 8 and Table 3.

**Note:** Figure 8 shows the back of the controller cover and not the inside of the main controller compartment.


**Table 3 Output connections**

Recorder wires	Circuit board position
Output 2–	4
Output 2+	3
Output 1–	2
Output 1+	1



1. Open the controller cover.
2. Feed the wires through the strain relief.
3. Adjust the wire as necessary and tighten the strain relief.

4. Make connections with twisted-pair shielded wire and connect the shield at the controlled component end or at the control loop end.
  - Do not connect the shield at both ends of the cable.
  - Use of non-shielded cable may result in radio frequency emission or susceptibility levels higher than allowed.
  - Maximum loop resistance is 500 ohm.
5. Close the controller cover and tighten the cover screws.
6. Configure outputs in the controller.

**Figure 8 Analog output connections**



### Discrete input wiring connections

⚠ WARNING	
	Potential Electrocution Hazard. Always disconnect power to the instrument when making electrical connections.
⚠ WARNING	
	Potential electrocution hazard. In order to maintain the NEMA/IP environmental ratings of the enclosure, use only conduit fittings and cable glands rated for at least NEMA 4X/IP66 to route cables in to the instrument.

Three discrete inputs are provided for switch closure inputs or logic level voltage inputs. Make wiring connections and configure jumper settings to the controller as shown in [Figure 9](#), [Table 4](#) and [Figure 10](#).

**Note:** [Figure 9](#) shows the back of the controller cover and not the inside of the main controller compartment.

Figure 9 Discrete input wiring connections





Table 4 Input connections

Discrete inputs	Connector position - Switch input	Connector position - Voltage input
Input 1+	3	2
Input 1-	2	3
Input 2+	6	5
Input 2-	5	6
Input 3+	8	7
Input 3-	7	8



Figure 10 Jumper settings



1 Input 1 configuration jumpers	4 Jumpers positioned to the left for switch inputs
2 Input 2 configuration jumpers	5 Jumpers positioned to the right for voltage inputs
3 Input 3 configuration jumpers	

1. Open the controller cover.
2. Feed the wires through the cable gland.
3. Adjust the wire as necessary and tighten the cable gland.
4. The jumpers are positioned immediately behind the connector. Remove the connector for improved access to the jumpers and configure the jumper settings according to the type of input as shown in Figure 10.
5. Close the controller cover and tighten the cover screws.
6. Configure inputs in the controller.

**Note:** In **switch input** mode the controller supplies 12 volts to the switch and is not isolated from the controller. In **voltage input** mode the inputs are isolated from the controller (user input voltage from 0 to 30 volts).

### Connect a digital sc sensor

**Note:** To connect an analog sensor, refer to the instructions supplied in the module or sensor manual.

A digital sc sensor can be connected to the controller using the keyed quick-connect fitting (Figure 11). A digital sensor can be connected with the controller powered on or off.


When a sensor is connected with the controller powered on, the controller does not automatically perform a device scan. To make the controller perform a device scan, navigate to the Test/Maintenance menu and select Scan Devices. If a new device is found, the controller performs the installation process without further user action.

When a sensor is connected with the controller powered off, the controller will perform a device scan when it is powered on again. If a new device is found, the controller performs the installation process without further user action.

Retain the connector cap to seal the connector opening in case the sensor must be removed.

Figure 11 Digital sensor quick connect

1.



### Connect the optional digital communication output

The manufacturer supports Modbus RS485, Modbus RS232, Profibus DPV1 and HART communication protocols. The optional digital output module is installed in the location indicated by item 4 in Figure 7 on page 12. Refer to the instructions supplied with the network module for more details.


For information about Modbus registers, go to <http://www.de.hach.com> or <http://www.hach.com> and search *Modbus registers* or go to any sc200 product page.

### Install a Secure Digital (SD) memory card

For instructions on how to install an SD card in the controller, refer to Figure 12. Information on how to use the SD memory card can be found in [Using the secure digital memory \(SD\) card](#) on page 42.

To remove an SD card, push down on the edge of the card and release, then pull the card up and out of the slot. After the card is removed, close the slot cover and tighten the cover screws.

Figure 12 SD card installation




User interface and navigation

User interface

The keypad has four menu keys and four directional keys as shown in Figure 13.

Figure 13 Keypad and front panel overview



1 Instrument display	5 <b>BACK</b> key. Moves back one level in the menu structure.
2 Cover for secure digital memory card slot	6 <b>MENU</b> key. Moves to the Settings Menu from other screens and submenus.
3 <b>HOME</b> key. Moves to the Main Measurement screen from other screens and submenus.	7 Directional keys. Used to navigate through the menus, change settings, and increment or decrement digits.
4 <b>ENTER</b> key. Accepts input values, updates, or displayed menu options.	


Inputs and outputs are set up and configured through the front panel using the keypad and display screen. This user interface is used to set up and configure inputs and outputs, create log information and calculated values, and calibrate sensors. The SD interface can be used to save logs and update software.

Display

Figure 14 shows an example of the main measurement screen with a DO sensor connected to the controller.

The front panel display screen shows sensor measurement data, calibration and configuration settings, errors, warnings and other information.

Figure 14 Example of Main Measurement screen



1 Home screen icon	7 Warning status bar
2 Sensor name	8 Date
3 SD Memory card icon	9 Analog output values
4 Relay status indicator	10 Time
5 Measurement value	11 Progress bar
6 Measurement unit	12 Measurement parameter

Table 5 Icon descriptions

Icon	Description
Home screen	The icon may vary depending on the screen or menu being displayed. For example, if an SD card is installed, an SD card icon appears here when the user is in the SD Card Setup menu.
SD memory card	This icon appears only if an SD card is in the reader slot. When a user is in the SD Card Setup menu, this icon appears in the upper left corner.
Warning	A warning icon consists of an exclamation point within a triangle. Warning icons appear on the right of the main display below the measurement value. Push the <b>ENTER</b> key then select the device to view any problems associated with that device. The warning icon will no longer be displayed once all problems have been corrected or acknowledged.
Error	An error icon consists of an exclamation point within a circle. When an error occurs, the error icon and the measurement screen flash alternately in the main display. To view errors, push the <b>MENU</b> key and select <b>Diagnostics</b> . Then select the device to view any problems associated with that device.

### Additional display formats

- From the Main Measurement screen push the **UP** and **DOWN** arrow keys to switch between measurement parameters
- From the Main Measurement screen push the **RIGHT** arrow key to switch to a split display of up to 4 measurement parameters. Push the **RIGHT** arrow key to include additional measurements. Push the **LEFT** arrow key as needed to return to the Main Measurement screen
- From the Main Measurement screen push the **LEFT** arrow key to switch to the graphical display (see [Graphical display](#) on page 23 to define the parameters). Push the **UP** and **DOWN** arrow keys to switch measurement graphs

### Graphical display

The graph shows concentration and temperature measurements for each channel in use. The graph supplies easy monitoring of trends and shows changes in the process.

1. From the graphical display screen use the up and down arrow keys to select a graph and push the **HOME** key.
2. Select an option:

Option	Description
<b>MEASUREMENT VALUE</b>	Set the measurement value for the selected channel. Select between Auto Scale and Manually Scale. For manual scaling enter the minimum and maximum measurement values
<b>DATE &amp; TIME RANGE</b>	Select the date and time range from the available options

## System startup

When initially powered up, the Language, Date Format and Date/Time screens appear in order. After these options are set, the controller performs a device scan and displays the message **Scanning for devices. Please wait...** If a new device is found, the controller performs an installation process before displaying a main measurement screen.

If the scan finds previously installed devices without configuration changes, the main measurement screen of the device in the number one position appears immediately after the scan is complete.

If a device has been removed from the controller or is not found during the next power-cycled or menu-driven scan, the controller displays a **Device missing** message and prompts to delete the missing device.

If no sensor is connected to an installed analog module, the controller will indicate an error. If devices are connected but not found by the controller, refer to [Troubleshooting](#) on page 46.

## Set the language, date and time for the first time

The controller displays the language, date and time edit screens when the controller is powered on for the first time, and when it is powered on after the configuration settings have been set to their default values.

After the language, date and time options are set for the first time, update the options as necessary through the sc200 setup menu.

1. In the Language screen, highlight a language in the options list and push the **ENTER** key. English is the default language for the controller.  
The selected language is saved. The Date Format screen appears.
2. In the Date Format screen, highlight a format and push the **ENTER** key.  
The date and time format is saved. Next, the Date /Time screen appears.
3. In the Date/Time screen, push the **RIGHT** or **LEFT** arrow keys to highlight a field, then push the **UP** and **DOWN** arrow keys to update the value in the field. Update the other fields as necessary.
4. Push the **ENTER** key.  
The changes are saved and the controller performs a start-up scan for devices. If connected devices are found, the controller displays the main measurement screen for the device in the number one position. If the controller fails to find connected devices, refer to [Troubleshooting](#) on page 46.

## Controller configuration information

General information about configuration options is listed in the table.

1. To navigate to the menu options, from the Settings Menu, select sc200 Setup.

Option	Description
<b>Security setup</b>	Sets the passcode preferences (refer to <a href="#">Security setup</a> on page 25)
<b>Output setup</b>	Configures the controller analog outputs (refer to <a href="#">Configure the controller analog outputs</a> on page 27)

Option	Description
<b>Relay setup</b>	Configures the controller relays (refer to <a href="#">Configure relays</a> on page 30)
<b>Display setup</b>	Configures the controller display (refer to <a href="#">Display setup</a> on page 39)
<b>Set Date/Time</b>	Sets the controller time and date (refer to <a href="#">Update the date and time</a> on page 40)
<b>Datalog setup</b>	Configures data logging options. Available only if Calculation has been setup. At least one sensor must be attached to enter a calculation (refer to <a href="#">Set the datalog mode and interval</a> on page 40)
<b>Manage Data</b>	Select the device from the list of installed components to view the data or event log
<b>Error Hold Mode</b>	<p><b>Hold Outputs</b>—Holds outputs at last known value when controller loses communication with the sensor.</p> <p><b>Transfer Outputs</b>—Switches to transfer mode when controller loses communication with the sensor. Outputs transfer to a pre-defined value.</p>
<b>Calculation</b>	Configures the controller math function (refer to <a href="#">Set up a calculation</a> on page 40)
<b>sc200 Information</b>	<p><b>S/W VER:</b>—Displays the current version of controller software</p> <p><b>Bootloader VER:</b>—Displays the current Bootloader version. The Bootloader is a file that loads the main operating system for the controller</p> <p><b>S/N:</b>—Displays the controller serial number</p> <p><b>Version:</b>—Displays the current version of controller hardware</p>
<b>Discrete Input Setup</b>	Configures three discrete input channels (refer to <a href="#">Set up the discrete inputs</a> on page 41)
<b>Language</b>	Assigns the language used in the controller (refer to <a href="#">Update the display language</a> on page 42)

2. Select an option and push **ENTER** to activate the menu item.

## Advanced operation

### Security setup

#### Enable or disable the passcode

By default the passcode option is disabled and all configuration settings and calibrations can be changed. When the passcode function is enabled, access to Sensor calibration and Test/Maint menus requires a passcode.

To enable the passcode:

1. From the Settings Menu, select sc200 Setup and push the **ENTER** key.
2. Select Security Setup and push the **ENTER** key.
3. Select Set Passcode and push the **ENTER** key.
4. Select Disabled or Enabled and push the **ENTER** key.  
The passcode is enabled.
5. Push the **BACK** key to return to the sc200 Setup Menu, or push the **MENU** key to return to the Settings Menu.

#### Edit the passcode

The passcode is factory set to SC200. The Edit Passcode menu option appears in the Security Setup menu only after the passcode feature is enabled and a valid passcode has been entered.

A passcode consists of up to six upper or lower-case alpha, numeric and special characters. Passcodes are case-sensitive.

To edit the passcode:

1. Make sure the passcode is enabled. Refer to [Enable or disable the passcode](#) on page 25 for information on how to enable the passcode.
2. From the Settings menu, select Security Setup and push **ENTER**.
3. Use the arrow keys to enter the current valid passcode and push **ENTER**.  
The Edit Passcode option appears in the Security Setup menu.
4. Select Edit Pass Code and push **ENTER**.  
The Edit Pass Code screen appears.
5. Use the arrow keys to edit the passcode and push **ENTER**.  
The new passcode is saved and the Security Setup menu appears.  
*Note: All menus stay accessible until the **HOME** key is pushed or the controller is restarted.*
6. Push the **HOME** key or perform a controller restart.  
The new passcode settings are saved, and the new passcode is required to enter the Security Setup, Datalog Setup and Test/Maint menus.

### Protect features

This option is only displayed if an analyzer or sensor that supports this feature is connected to the controller. Security categories are displayed that are defined by the connected analyzer or sensor. The user can then enable or disable password protection against individual menu options within these categories.

### Configure a 4-20 mA input module

An analog module must be installed in the controller.

1. Determine what output the connected device is using (0-20 mA or 4-20 mA). This information will be used to set the scale.
2. Determine what the 20 mA value is equal to (e.g., 100 psi).
3. Determine what the low end (0 or 4 mA) value is equal to (e.g., 10 psi). This information will be used to set the display range.
4. From the Settings Menu, select Sensor Setup.
5. Select Configure.
6. Update the options.
  - a. Highlight an option and push **ENTER**.
  - b. Make a selection or update the entries.
  - c. Push **ENTER** to save the changes.

Option	Description
Edit name	Edits the module name
Edit units	Edits the measurement units
Edit parameter	Edits the parameter name
Display range	Sets the values used for the selected scale (0-20 mA or 4-20 mA)
For the 0-20 mA scale:	
• Set the 20 mA value	
• Set the 0 mA value	
For the 4-20 mA scale:	
• Set the 20 mA value	
• Set the 4 mA value	

Option	Description
<b>Signal average</b>	Sets how often signals are averaged. Higher values produce a smoother signal but increase the time it takes for a signal to respond to a change in the process value.
<b>Set resolution— X.XXX, XX.XX, XXX.X, XXXX</b>	Sets the number of decimal places used in the display.
<b>Select scale— 4-20 mA or 0-20 mA</b>	Sets scale used for the 4-20 mA input
<b>Data log interval—5 sec, 30 sec, 1 min, 2 min, 5 min, 10 min, 15 min, 30 min, 60 min</b>	Sets how often data is logged to the internal controller memory.
<b>Reset defaults—Push ENTER to reset configuration settings or push the BACK key to cancel.</b>	Resets configuration settings to the default values.

For additional information, refer to the *sc200 4-20 Analog Input Module User Manual*.

## Configure a 4-20 mA output module

The Network Setup option appears in the Settings Menu only if an analog output module or other network module such as Modbus or Profibus is installed in the controller.

Outputs for analog output modules are set at 4-20 mA. Outputs can be assigned to represent a measured parameter such as pH, temperature, flow or calculated values.

1. From the Settings menu, select Network Setup.
2. Select Edit Name and enter a name for the module. Push **ENTER** to save the name.
3. Select an output (A, B, C, D) and push **ENTER**.
  - a. Highlight an option and push **ENTER**.
  - b. Make a selection from the list or update the entries.
  - c. Push **ENTER** to save the changes.

Option	Description
<b>Select Source</b>	Selects the output to configure—None, sensor 1 name, sensor 2 name, calculation (if set up). For sensor output, Select Parameter sets the measurement options. When the measurement is autorange, Set Range sets the range.
<b>Set Low Value</b>	Sets the 4 mA value (default: 0.000). (Range and units depend on sensor)
<b>Set High Value</b>	Sets the 20 mA value (default: 1.000). (Range and units depend on sensor)
<b>Set Transfer</b>	Sets the transfer value. Range 3.0 to 25.0 mA (default 4.000).
<b>Set Filter</b>	Sets a time-average filter value of 0 (default) to 120 seconds.

For additional information, refer to the *sc200 4-20 Output Module User Manual*.

## Configure the controller analog outputs

The controller analog outputs can be assigned to represent the measured parameter or secondary measurements such as temperature and calculations. To configure the options, highlight a menu option, push **ENTER** and select an option or update the entries. Push **ENTER** after an option is selected or the entries are updated.

1. From the Settings menu, select sc200 Setup.
2. Select Output Setup.
3. Select Output 1 or Output 2.



4. Choose Select Source and select a source from the list. Typically the source is one of the sensors attached to the system. If an analog input card is installed, the analog input may be used as a source.
5. From the Output Setup menu, choose Select Parameter and choose an option from the list. Parameters will vary depending on the type of sensors installed.
6. From the Output Setup menu, select Set Function and choose a function. Further setup options will vary depending on which function is chosen.

Option	Description
<b>Linear</b>	Signal is linearly dependent on the process value
<b>PID</b>	Signal works as a PID (Proportional, Integral, Derivative) controller
<b>Logarithmic</b>	Signal is represented logarithmically within the process variable range
<b>Bilinear</b>	Signal is represented as two linear segments within the process variable range

7. From the Output Setup menu, select Activation. Use the information in the table below the chosen function to configure the options.
8. If Transfer is or will be selected as the Error Hold Mode, or if the Transfer will be used during calibration or other functions within the sensor menu, select Set Transfer from the Output Setup menu and enter the transfer value.
9. From the Output Setup menu, select Set Filter and enter the filter value.
10. From the Output Setup menu, select Scale and choose the scale (0-20 mA or 4-20 mA).

- **Linear**

Option	Description
<b>Set low value</b>	Sets the low endpoint of the process variable range
<b>Set high value</b>	Sets the high endpoint of the process variable range

- **PID**

Option	Description
<b>Set mode (Auto or Manual)</b>	Auto—the signal is automatically controlled by the algorithm within the analyzer using proportional, integral, and derivative inputs. Manual—the signal is controlled by the user through manual adjustment of the % change value. This option is shown as Manual Output after the manual set mode is selected.
<b>Phase (Direct or Reverse)</b>	The direction in which the signal responds to process change. Direct—signal increases as the process increases. Reverse—signal increases as process decreases.
<b>Set setpoint</b>	Creates a desired control point of process
<b>Prop band</b>	A function of the difference between the measured signal and the desired setpoint.
<b>Integral</b>	The period of time from the injection point of a reagent to contact with the measuring device.
<b>Derivative</b>	Used to compensate for the 2 <sup>nd</sup> order effects of the process. The majority of applications can be controlled without the use of the derivative setting.
<b>Transit time</b>	Stops all PID control for a selected period of time as the sample travels from the control pump to the measurement sensor.

• **Logarithmic**

Option	Description
Set 50% value	Sets the value corresponding to 50% of the process variable range.
Set high value	Sets the upper value of the process variable range.


• **Bilinear**

Option	Description
Set low value	Sets the low endpoint value of the process variable range.
Set high value	Sets the high endpoint value of the process variable range.
Set knee point value	Sets the value at which the process variable range divides into another linear segment.
Set knee point current	Sets the value of the current at the knee point value.

**Logarithmic output mode**

Figure 15 shows in graph form the operation of the logarithmic output mode.


**Figure 15** Logarithmic output



**Bilinear output mode**

Figure 16 shows in graph form the operation of the bilinear output mode.

**Figure 16 Bilinear output**



1 Output current axis	5 Low value
2 Source value axis	6 Minimum output current (0-4 mA)
3 High value	7 Knee point current
4 Knee point value	8 Maximum output current (20 mA)

## Configure relays

The Normally Open (NO) and Common (COM) relay contacts will be connected when an alarm or other condition is active. The Normally Closed (NC) and Common relay contacts will be connected when an alarm or other condition is inactive (unless the Fail Safe is set to Yes), or when power is removed from the controller. To select a menu option, highlight the option and push **ENTER**.

1. From the sc200 Setup menu, select Relay Setup.
2. Select a relay from the list.
3. From the Relay Setup menu, choose Select Source and push **ENTER**. Normally, a source is one of the sensors attached to the system, but the controller can also function as a source. If an analog input module is installed, the source may be the analog input.
4. From the Relay Setup menu, select Set Parameter and choose from the list of parameters. The list of parameter options will vary with the type of attached sensor.
5. From the Relay Setup menu, select Set Function and choose from the list. Further setup will depend on the function chosen.

Option	Description
<b>Scheduler Function (available if the controller is selected as the relay source)</b>	Relay switches at certain times independently of any process value
<b>Alarm Function</b>	Relay activates when upper or lower alarm value is exceeded
<b>Feeder Control Function</b>	Relay indicates if a process value exceeds or falls below a setpoint
<b>Event Control Function</b>	Relay toggles if a process value reaches an upper or lower limit
<b>Pulse Width Modulation (PWM) Control Function</b>	Relay uses a Pulse Width Modulation control depending on a process value


Option	Description
<b>Frequency control</b>	Relay switches with a frequency depending on a process value
<b>Warning</b>	Relay indicates warning and error conditions in probes

6. From the Relay Setup menu, select Set Transfer and choose Active or Inactive.
7. From the Relay Setup menu, select Fail Safe and choose Yes or No.
8. From the Relay Setup menu, select Activation.  
The activation options for the selected function appear. Use the information in the table below each function to update the options.
9. Test the relay function to make sure it is properly energizing the connected device. To do relay testing, go to the Setting menu, then select **Test/Maint>Test Relay**.

• **Scheduler Function (refer to Figure 17)**

Option	Description
<b>Hold outputs</b>	Holds outputs in the present ON or OFF state
<b>Run days</b>	Sets the weekday(s) that the relay operates. Options: Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday
<b>Start time</b>	Sets the start time.
<b>Interval</b>	Sets the time between activation cycles (Default value: 5 min).
<b>Duration</b>	Sets the period of time the relay is energized (Default value: 30 sec).
<b>Off delay</b>	Sets the time for additional hold/output time after the relay has been turned off.

**Figure 17 Scheduler function**




1 Duration	3 Interval
2 OFF delay	4 Time (x-axis)

• **Alarm Function (refer to Figure 18)**

Option	Description
<b>Low alarm</b>	Sets the value where the relay will turn on in response to decreasing measured value. For example, if the low alarm is set for 1.0 and the measured value drops to 0.9, the relay activates.
<b>High alarm</b>	Sets the value where the relay will turn on in response to increasing measured value. For example, if the high alarm is set for 1.0 and the measured value increases to 1.1, the relay activates.

Option	Description
<b>Low deadband</b>	Sets the range where the relay remains on after the measured value increases above the low alarm value. For example, if the low alarm is set for 1.0 and the low deadband is set for 0.5, the relay remains on between 1.0 and 1.5. Default is 5% of the range.
<b>High deadband</b>	Sets the range where the relay remains on after the measured value decreases below the high alarm value. For example, if the high alarm is set for 4.0 and the high deadband is set for 0.5, the relay remains on between 3.5 and 4.0. Default is 5% of the range.
<b>Off delay</b>	Sets a time (0-300 seconds) to delay the relay from normally turning off (Default: 0 seconds).
<b>On delay</b>	Sets a delay time for the relay to turn on (Default: 0 seconds).

Figure 18 Alarm function




1 High alarm	5 ON delay
2 High deadband	6 OFF delay
3 Low deadband	7 Time (x-axis)
4 Low alarm	8 Source (y-axis)

• Feeder Control Function (refer to [Figure 19](#) and [Figure 20](#))

Option	Description
<b>Phase</b>	Defines the relay status if the process value exceeds the setpoint. High (default)—turns the relay on when the process value exceeds the setpoint. Low—turns the relay on when the process value falls below the setpoint.
<b>Set setpoint</b>	Sets the process value at which the relay toggles. The default value is different for each sensor.
<b>Deadband</b>	Sets the area for an amount of change necessary after the relay setpoint is reached in order to satisfy a condition.


Option	Description
<b>Overfeed timer</b>	Sets a time period for de-activating an active relay if the process setpoint cannot be reached. Once an overfeed alarm is present, it must be manually reset.
<b>Off delay</b>	Sets a delay time for the relay to turn off (default: 0 seconds).
<b>On delay</b>	Sets a delay time for the relay to turn on (default: 0 seconds).

Figure 19 Feeder control function



1 Deadband (Phase = Low)	6 Time (x-axis)
2 Deadband (Phase = High)	7 ON delay (phase set high)
3 Setpoint	8 OFF delay (phase set low)
4 OFF delay (phase set high)	9 Source (y-axis)
5 ON delay (phase set low)	

Figure 20 Feeder control function (Phase low, Overfeed timer)




1 Deadband	5 ON delay
2 Setpoint	6 OFF delay
3 Overfeed timer	7 Source (y-axis)
4 Time (x-axis)	

• Event Control Function (refer to [Figure 21](#), [Figure 22](#) and [Figure 23](#))

Option	Description
<b>Set setpoint</b>	Sets the value where the relay will turn on.
<b>Deadband</b>	Sets a hysteresis so the relay will not swing unregulated when the process value converges to the setpoint.
<b>OnMax timer</b>	Sets the maximum time the relay can stay on independent from the measured value (default: + 0 min).
<b>OffMax timer</b>	Sets the maximum time the relay can stay off independent from the measured value (default: + 0 min).
<b>OnMin timer</b>	Sets the minimum time the relay can stay on independent from the measured value (default: + 0 min).
<b>OffMin timer</b>	Sets the minimum time the relay can stay off independent from the measured value (default: + 0 min).


**Figure 21 Event control function (no delay)**



1 Source (y-axis)	5 Low alarm
2 High alarm	6 Time (x-axis)
3 Deadband	7 OnMax-time
4 Setpoint	8 OffMax-time




Figure 22 Event control function (OnMin timer, OffMin timer)



1 High alarm	5 Time (x-axis)
2 Deadband	6 OffMin timer
3 Setpoint	7 OnMin timer
4 Low alarm	8 Source (y-axis)

Figure 23 Event control function (ON/OFF delay)




1 High alarm	4 OFF delay
2 Low alarm	5 Time (x-axis)
3 ON delay	6 Source (y-axis)

• **Pulse Width Modulation Control Function (refer to [Figure 24](#))**

Option	Description
<b>Set mode</b>	Auto—the relay output works as a PID controller. Manual—the signal is controlled by the user through manual adjustment of the % change value. This option is shown as Manual Output after the manual set mode is selected.
<b>Phase</b>	Reverses the leading sign of the control deviation for the PID controller (default: Reverse). The phase selects whether the relay will operate at the first part of a cycle (direct phase) or the second part (reverse phase).
<b>Set setpoint</b>	Creates a setpoint value.
<b>Dead zone</b>	The range above and below the setpoint. In this set range, the PID controller does not take action to change the Pulse Width Modulation On/Off Ratio output signal until the limits of the dead zone are reached.
<b>Period</b>	Sets the cycle duration of the PWM output signal (default: 5 seconds).
<b>Min width</b>	Sets the minimum PWM ratio (default: 1.0 second).
<b>Max width</b>	Sets the maximum PWM ratio (default: 4.0 seconds).
<b>Prop band</b>	Sets the proportional part of the PID controller. The proportional part of the controller supplies an output signal which is linearly dependent to the control deviation. The proportional part reacts on any changes at the input but starts to oscillate easily if the value is set high. The proportional part cannot completely compensate for disturbances.
<b>Integral</b>	Sets the integral part of the PID controller (default: 000 minutes). The integration part of the controller supplies an output signal. The output signal increases linearly if the control deviation is constant. The integration part responds slower than the proportional part and can completely compensate disturbances. The higher the integration part, the slower it responds. If the integration part is set too low, it starts to oscillate.


**Figure 24 Pulse Width Modulation function (linear mode)**



- **Frequency Control Function (refer to [Figure 25](#))**

Option	Description
<b>Set mode</b>	Auto—The relay works as a PID controller. Manual—the signal is controlled by the user through manual adjustment of the % change value. This option is shown as Manual Output after the manual set mode is selected.
<b>Phase</b>	Reverses the leading sign of the control deviation for the PID controller (default: Reverse). The phase selects whether the relay will operate at the first part of a cycle (direct phase) or the second part (reverse phase).
<b>Set setpoint</b>	Sets the process value which is controlled by the PID controller.
<b>Dead zone</b>	In this set range, the PID controller does not take action to change the output frequency until within the limits of the dead zone.
<b>Pulse width</b>	Sets the cycle duration (0-600 seconds) of the PWM output signal. (default: 0.5 seconds) The cycle duration is equal to the duty cycle of the output signal.
<b>Minimum pulses</b>	Sets the minimum number of pulses per minute at which the relay can operate. Range: 0.001–4.000 (default: 1.000)
<b>Maximum pulses</b>	Sets the maximum number of pulses per minute at which the relay can operate. Range: 0.001–60.000 (default: 04.000). This value cannot be set lower than Minimum Pulses value.
<b>Prop band</b>	Sets the proportional part of the PID controller. The proportional part of the controller supplies an output signal which is linearly dependent to the control deviation. The proportional part reacts on any changes at the input but starts to oscillate easily if the value is set high. The proportional part cannot fully compensate for disturbances.
<b>Integral</b>	Sets the derivative part of the PID controller (default: 000 minutes). The integration part of the controller generates an output signal. The output signal increases linearly if the control deviation is constant. The integration part responds slower than the proportional part and can fully compensate disturbances. The higher the integration part, the slower it responds. If the integration part is set too low, it starts to oscillate.

Figure 25 Frequency control function



1 High limit	5 Cycle duration
2 Deadband	6 Time (x-axis)
3 Setpoint	7 Selected source (y-axis)
4 Low limit	

#### • Warning Function

Option	Description
<b>Warning</b>	Sets the level for warning activation. Refer to the sensor manual for the numbers for individual warning messages.

## Display setup

Configures the controller display.

1. From the Settings menu, select **sc200 Setup** and push **ENTER**.
2. Select **Display Setup** and push **ENTER**.

Option	Description
<b>Adjust Order</b>	View and modify the measurement display order. <ul style="list-style-type: none"> <li>• <b>See Current Order</b>—View the current display order</li> <li>• <b>Add Measurements</b>—Add selected measurements to the display</li> <li>• <b>Remove Measurements</b>—Remove selected measurements from the display</li> <li>• <b>Reorder List</b>—Select one or more measurements and change their order in the display</li> <li>• <b>See Default Order</b>—View the default display order</li> <li>• <b>Set to Default</b>—Set the display order to the default configuration</li> </ul> <p><i>Note: Some of the above will not be available if no adjustment is possible for that option (e.g. <b>Reorder List</b> and <b>Remove Measurements</b> will not be available if only one measurement is selected for display).</i></p>
<b>Display Contrast</b>	Adjust the contrast to a value between the minimum of +1 and the maximum of +9
<b>Edit Name</b>	Assigns a name to the controller

## Update the date and time

1. From the Settings menu, select sc200 Setup and push **ENTER**.
2. Select Set Date/Time and push **ENTER**.
3. Select Date Format from the Set Date/Time screen and push **ENTER**.
4. Select a format and push **ENTER**.
5. Select Date/Time from the Set Date/Time screen and push **ENTER**.
6. Update the entries.
  - a. Use the right and left arrow keys to highlight a field.
  - b. Use the up and down arrow keys to change the values in the field and push **ENTER**.
  - c. At the end of the date field, push the right arrow to wrap down to the time fields.
  - d. Use the up and down and arrow keys to update the time fields.
7. Push **ENTER** to save the changes.  
The controller returns to the Set Date/Time menu.

## Set the datalog mode and interval

Datalog Setup is available if a calculation has been set up.

1. From the Settings menu, select sc200 Setup and push **ENTER**.
2. Select Datalog Setup and push **ENTER**.
3. Select Set Mode and push **ENTER**.
4. Select an option (Snap Shot, Average, Maximum, Minimum) and push **ENTER**.
5. From the Datalog Setup menu, select Set Interval and push **ENTER**.
6. Select an interval from the list and push **ENTER**.

## Set up a calculation

1. From the Settings menu, select sc200 Setup and push **ENTER**.
2. Select Calculation and push **ENTER**. Select a menu option and choose from the displayed list or update the entry. Refer to the table below for more information about each option.

Option	Description
<b>Set variable X</b>	Selects the sensor for the x variable
<b>Set parameter X</b>	Selects the sensor measurement for the x variable
<b>Set variable Y</b>	Selects the sensor for the y variable
<b>Set parameter Y</b>	Selects the sensor measurement for the y variable
<b>Set formula</b>	Select the math function to implement: <ul style="list-style-type: none"><li>• <b>None</b>—Disables the math function</li><li>• <b>X-Y</b>—Subtraction function</li><li>• <b>X+Y</b>—Addition function</li><li>• <b>X/Y</b>—Division function</li><li>• <b>[X/Y]%</b>—Percentage function</li><li>• <b>[X+Y]/2</b>—Average function</li><li>• <b>[X*Y]</b>—Multiplication function</li><li>• <b>[X-Y]/X</b>—Difference function</li></ul>
<b>Display format</b>	Selects the number of digits and decimal points

Option	Description
<b>Set units</b>	Selects the units for the calculated reading
<b>Set parameter</b>	Selects the parameter for the calculated reading

3. Push **ENTER** to save the selection or setting and return to the Calculation menu.

## Set up the discrete inputs

Use these inputs to switch closure inputs or logic level voltage inputs.

1. Press the **MENU** key.
2. Select sc200 Setup and push **ENTER**.
3. Select Discrete Input Setup and push **ENTER**.
4. Select the desired channel (Input 1, Input 2 or Input 3) and push **ENTER**.
5. Select a control logic option and push **ENTER**.

Option	Description
<b>Disable</b>	This channel is disabled and not used.
<b>On/High</b>	This channel is active when either the switch input is On (or closed), or the logic level voltage input is at a High level.
<b>Off/Low</b>	This channel is active when either the switch input is Off (or opened), or the logic level voltage input is at a Low level.

6. Select a warning option and push **ENTER**.

Option	Description
<b>Off</b>	An active discrete input does not trigger a device warning.
<b>On</b>	An active discrete input triggers a device warning.

7. Select an output mode option and push **ENTER**.

Option	Description
<b>Active</b>	Output level continues to represent operating conditions.
<b>Hold</b>	Output level is held static.
<b>Transfer</b>	Output level moves to a pre-configured value.

8. Select the sensors that will have their outputs (analog and relay) affected when one of the discrete inputs becomes active. Push **ENTER**.
9. Use the arrows to select the On Delay value (the duration time delay between the discrete input activation and the configured response of the controller). Push **ENTER**.
10. Use the arrows to select the Off Delay value (the duration time delay between the discrete input de-activation and the configured response of the controller). Push **ENTER**.
11. Repeat steps 4–10 for each desired channel.
12. If a discrete input needs to be changed after initially set up:
  - a. Repeat steps 1–4 and an Input Settings menu appears with the following options:
    - Control Logic
    - Set Warning
    - Output Mode
    - On Delay
    - Off Delay
  - b. Select the desired option and push **ENTER**.

- c. Make the desired changes and push **ENTER** to save the changes and return to the Inputs Setting menu.

## Update the display language

The display language can be changed through the Setup menu.

1. From the Settings Menu, select sc200 Setup and push **ENTER**.
2. Select Language and push **ENTER**.  
The list of language options appears. English is the default language for the controller.
3. Highlight the language to be used for the controller and push **ENTER**.  
The selected language is saved and is used for the controller display. The display returns to the sc200 Setup menu.

## Using the secure digital memory (SD) card

An SD card must be installed in the controller.

- The SD card can be used to update software and firmware and to download event and data logs. If the SD card is installed while the controller is in the Settings Menu, push the **HOME** key and then the **MENU** key to verify the option is visible. The SD icon will also be visible in the upper status bar of the main measurement screen when a card is installed.
- Data log files on the SD card are available in XML and binary formats.
- DataCom is used to convert files from binary to CSV format. Refer to the DataCom manual for more information on how to use the application. For a copy of the DataCom manual, software updates or other downloadable resources, go to <http://www.de.hach.com> or <http://www.hach.com>. Search *DataCom* or go to any sc200 product page.

## Updating software

### Notes:

- The controller does not automatically transfer information to or from an SD card.
  - When the SD card is put in multiple controllers, each controller has a separate set of folders in the SD card memory. To make sure software updates are in the correct folder for the controller in use, it is best to use a separate dedicated SD card for each controller.
1. From the Settings Menu, select SD Card Setup and push the **ENTER** key.
  2. Select Upgrade Software and push the **ENTER** key.  
*Note: If the Upgrade Software option does not appear, do the steps in [Firmware updates with SD cards](#) on page 44.*
  3. Select a device from the list and push the **ENTER** key. The list of options includes the controller and all connected devices that have software placed in the appropriate folder on the SD card.
  4. If more than one version of the upgrade software is available, select the version with the highest number and push the **ENTER** key.
  5. Push the **ENTER** key to begin the software transfer.  
The display will show "Transferring files. Please wait..." The percentage of completion appears in the bottom left corner of the display. The upgrade cannot be halted once it has begun.
    - When the transfer is successful, the display will show "Transfer complete" along with a prompt to push **ENTER** to restart the controller or to push the **BACK** key and exit to the SD Card Setup menu. Controller updates take effect when the controller is restarted. A restart is not necessary for sensor updates.
    - If the transfer is unsuccessful, the display will show "Transfer failed" and an error message. Press the **ENTER** key to acknowledge the warning and exit out of the menu. Error messages are different for each sensor. Refer to the applicable sensor manual.

## Saving data and event logs with SD cards

### Notes:

- Data and event logs can be downloaded to an SD card and viewed with any device capable of reading an SD card.
- Data logs store the measurement data at selected intervals in a packed binary format (.flg file).
- Event logs store a variety of events that occur on the devices such as configuration changes, alarms and warning conditions. Event logs are set up during the sensor or module configuration process. Event logs are stored in a CSV format.

1. From the Settings Menu, select SD Card Setup and push the **ENTER** key.
2. Select Save Logs and push the **ENTER** key.
3. If more than one device appears on the screen, all devices are selected by default. To deselect an item, highlight the selection and push the left arrow key. Select the devices from which logs will be saved and push the **ENTER** key.
4. Select the time period from which logs are to be saved.

Option	Description
<b>Last Day</b>	All logs from the last full 24 hours, starting from 12:00 a.m., and any additional time remaining on the current day
<b>Last Week</b>	All logs from the last full week (7 days) starting from 12:00 a.m., and any additional time remaining on the current day
<b>Last Month</b>	All logs from the last full month (30 days) starting from 12:00 a.m., and any additional time remaining on the current day
<b>All</b>	Save all logs in memory
<b>New</b>	All logs that are new since the last time logs were saved to the SD card

5. Push the **ENTER** key to confirm the choice, and push the **ENTER** key again to begin the file transfers.
6. Allow time for the files to transfer. The display will show Transferring files. Please wait... and the percentage of files transferred.  
If the transfer is successful, the display will show "Transfer complete." If the transfer is not successful, the display will show "Transfer failed."
7. Do one of the following:
  - a. Push the **ENTER** key to exit back to the SD Card Setup menu.
  - b. Push the **HOME** key to return to the measurement screen.
  - c. Push the **BACK** keys to return to the Settings Menu.

## Access data and event log files on the SD card

A PC with an SD Card reader device or USB adapter is necessary to view the event and data logs kept on the SD Card. Excel 2003 or higher (for XML files) or the Data Com application (for binary flg files) is necessary to open the event and data logs.

Data logs have the following structure: Device Name, Device Serial Number, Device Identification, Data Log, Time Stamp.

Event logs have the following structure: Device Name, Device Serial Number, Device Identification, Event Log, Time Stamp.

To view data or event log files stored on the SD card:

1. Attach the card reader device to the PC (if necessary) and install the SD card that contains the files in the reader device.
2. In the SD card directory, open the HACH folder.
3. Select the Logs folder.
4. Select a device folder.



The event and data log files in the folder are shown.

5. To view XML data log files:
  - a. Make sure the HachDatalog.xml style sheet exists in the device folder.
  - b. Open the Excel application.
  - c. Go to File, Open.
  - d. Select the data log file.
  - e. In the Import XML dialog box, select **Open the file with the following style sheet applied** and select **HachDatalog.xml**.
  - f. Click OK to view the data.
6. To view binary data log (.flg) files:
  - a. Make sure the device driver (.flg.drv) file exists in the device folder.
  - b. Open Data Com.
  - c. In the File Viewer section, click Open.
  - d. Select the data log file.  
The data log file is shown in the box and a comma separated values (csv) file with the same file name is created. This csv file can be opened in Excel.

### Firmware updates with SD cards

The latest firmware updates can be placed on an SD card. The SD card can then be used to update the controller or device firmware.

A PC and a USB card reader or other device capable of reading an SD card are necessary.

1. Find the zip file at <http://www.hach-lange.com> or <http://www.hach.com> and copy it to the PC.
2. Extract file(s) from the zip folder and save them to the SD card.
3. Remove the SD card and update the controller and device firmware. Refer to [Updating software](#) on page 42.

### Backup settings to an SD card

Saves the configuration of a device to the SD card.

1. Push the **MENU** key.
2. Select SD Card Setup and push **ENTER**.
3. Select Manage Configuration and push **ENTER**.
4. Select Backup Settings and push **ENTER**.
5. Select the devices to be backed up. All devices are selected by default. To deselect an item, highlight the selection and push the left arrow key. Push **ENTER** to begin the file transfers. If backup files already exist on the SD card, a confirmation window appears. Select the devices again and push **ENTER**. Wait for the "Transfer complete" message.
6. Push **ENTER** again to return to the Manage Configuration menu.

### Restore settings to the controller

This menu selection only appears if a (serial number-specific) backup file for the controller or one of the sensors connected to it exists on the SD Card. This menu selection loads the configuration of a specific device from the SD card to the same device (serial number-controlled function).

1. Push the **MENU** key.
2. Select SD Card Setup and push **ENTER**.
3. Select Manage Configuration and push **ENTER**.
4. Select Restore Settings and push **ENTER**.
5. Select the device that will be restored. All devices are selected by default. To deselect an item, highlight the selection and push the left arrow key. Push **ENTER** to begin the file transfers.

6. When the transfer is complete, push **ENTER**.
7. To have the settings take effect immediately, restart the controller. Push the **BACK** key to exit the Manage Configuration menu.

### Transfer settings to another device

All device settings including calibration, sensor name, selected temperature and measurement units and data logging settings are transferred.

1. Push the **MENU** key.
2. Select SD Card Setup and push **ENTER**.
3. Select Manage Configuration and push **ENTER**.
4. Select Transfer Settings and push **ENTER**. Two options appear:
  - Retrieve Settings
  - Copy Settings
5. To retrieve settings from the controller (or a device connected to it) and put the settings on the SD card:
  - a. Select Retrieve Settings and push **ENTER**.
  - b. Select the devices that contain the information to be transferred. All devices are selected by default. To deselect an item, highlight the selection and push the left arrow key. Push **ENTER** to begin the file transfers. Wait for the "Transfer complete" message.
  - c. If files already exist on the SD card, a confirmation window appears. Select the devices again and push **ENTER**. Wait for the "Transfer complete" message.
  - d. Push **ENTER** to return to the Manage Configuration menu.
6. To copy settings from the SD card to a controller (or a device connected to it):
  - a. Select Transfer Settings and push **ENTER**.
  - b. Select Copy Settings and push **ENTER**.
  - c. Select the devices on the SD card. All devices are selected by default. To deselect an item, highlight the selection and push the left arrow key. Push **ENTER** to begin the file transfers.
7. When the transfer is complete, push **ENTER** to restart the connected devices.
8. Push **ENTER** to restart the controller or push **BACK** to return to the Manage Configuration menu.

### Using the service port

The service port is used to download data files from the controller and install new versions of controller and sensor firmware. To download data and update software, use the service port in combination with DataCom and a service cable (LZX887).

### Using DataCom

When using the service port, it is necessary to use DataCom. DataCom is a PC Application Utility that downloads data log and event log files from the controller and installed sensors. Files are downloaded from the controller through the controller service port or they can be placed on a Secure Digital Memory (SD) card installed in the controller. In addition, DataCom is used to upload software for the controller and sensors. The DataCom application must be installed on a PC to read the files.

Refer to the DataCom manual for more information on how to use the application. The DataCom manual, software updates and other downloadable resources are available at <http://www.de.hach.com> or <http://www.hach.com> on any sc200 product page.

## Maintenance

⚠ DANGER	
	Multiple hazards. Only qualified personnel must conduct the tasks described in this section of the document.

### Cleaning the controller

⚠ DANGER	
	Always remove power from the controller before performing maintenance activities.

**Note:** Never use flammable or corrosive solvents to clean any part of the controller. Use of these solvents may degrade the environmental protection of the unit and may void the warranty.

1. Make sure the controller cover is securely closed.
2. Wipe the controller exterior with a cloth dampened with water, or with a mixture of water and mild detergent.

### Fuse replacement

Fuses are not user-serviceable items. The need for fuse replacement in controllers indicates severe technical failure and is therefore considered to be a service activity. If a blown fuse is suspected, contact Technical Support.

### Battery replacement

The lithium ion backup battery is not user replaceable. Contact technical support for replacement.

## Troubleshooting

Problem	Resolution
No current output	Verify current output configuration.
	Test current output signal using the Test/Maintenance submenu. Input a current value and verify the output signal at the controller connections.
	Contact Technical Support.
Incorrect current output	Verify current output configuration.
	Test current output signal using the Test/Maintenance submenu. Input a current value and verify the output signal at the controller connections. If the output is incorrect, perform an output calibration.

Problem	Resolution
No relay activation	Make sure relay connections are secure.
	If using an external power source, make sure the relay wiring is correct.
	Make sure the relay configuration is correct.
	Test the relay activation through the Test/Maintenance menu. The relay should energize and de-energize as selected.
	Make sure the controller is not in calibration mode and that the relay is not being held.
	Reset the Overfeed Timer to make sure the timer has not expired.
Secure Digital Memory (SD) card not recognized by the controller	Make sure the SD card is properly oriented. The copper traces should face toward the controller display.
	Make sure the SD card is fully seated in the slot and the spring lock is engaged.
	Make sure the SD card is properly formatted with a Fat 32 format. The MMC format is not supported. Follow the instructions of the card manufacturer to format the SD card on a PC.
	Make sure the card is not larger than 32 GB.
	Make sure an SD card is being used. Other types of cards (such as xSD, micro SD, mini SD) will not work properly.
Information not saving, or not saving properly to the SD card.	Make sure the SD card is properly formatted with the FAT 32 format. The MMC format is not supported. Follow the instructions of the card manufacturer to format the SD card on a PC.
	If the SD card has previously been in use, format the card with the Fat 32 format, install the card in the controller, and try downloading files.
	Try a different SD card.
SD card full	Read the SD card with a PC or other card reader device. Save important files and then delete some or all of the files on the SD card.
Controller cannot find software updates on the SD card.	Make sure an appropriate folder is created by installing the SD card in the controller. An update folder will automatically be created.
	Install the SD card on a PC and make sure the software files are located in the appropriate update folder.
	If the same SD card is used with multiple controllers, each controller will have a separate folder on the system. Make sure the software updates are in the folder dedicated to the controller in use.
Display is lit but shows no characters or characters are faint or blurry.	Adjust the display contrast
	Make sure protective film has been removed from display.
	Clean the outside of the controller, including the display screen.

Problem	Resolution
Controller will not power up, or powers up intermittently	Make sure the AC power connections are properly terminated in the controller.
	Make sure the power strip, line power, wall plug are all properly plugged in.
	Contact Technical Support
Network or sensor module not recognized	Make sure the module is properly installed.
	Make sure the module selector switch is set to the proper number.
	Remove sensor module and install the module into the second analog slot. Apply power to the controller and allow the controller to perform a device scan.
	Contact Technical Support.
Sensor not recognized <i>Note: Example of possible display message: ****</i>	If the sensor is an analog sensor and a corresponding module is installed in the controller, refer to the instructions supplied with the Network or Sensor Module.
	Make sure the digital connector wiring harness is seated on the inside of the door assembly and that the wiring harness is not damaged.
	If the digital sensor is connected to the controller with a digital termination box, user supplied junction box, digital extension cables, or a user-supplied extension cable, connect the sensor directly to the controller and perform a device scan. If the controller recognizes the sensor, check that all the wiring in the junction boxes or extension cables is correct.
	Make sure that only two sensors are installed in the controller. Although two analog module ports are available, if a digital sensor and two analog modules are installed, only two of the three devices will be seen by the controller.
	Contact Technical Support
Device Missing error message appears	Perform a Device Scan from the Test/Maintenance menu.
	Power cycle the controller

## Test and Maintenance menu

- From the Settings Menu, select Test/Maint and push **ENTER**.

Option	Description
<b>Scan devices</b>	Performs a scan for active and missing devices.
<b>Output cal</b>	Lets the user calibrate the 4–20 mA outputs with a 250 ohm resistor in series to the mA output terminals. The settings for each output are adjusted until the correct value (4 mA or 20 mA) is supplied.
• <b>Output 1</b>	Calibrate 4 mA output (Min: 0 Max: 25000)
• <b>Output 2</b>	Calibrate 20 mA output (Min: 35000 Max: 65533)
<b>Hold outputs</b>	Sets the value the controller sends to an external system for a defined period of time. After the time period, the instrument goes back to reporting real time values. Set activation—Launch or release Set Outmode—Hold Outputs (default) or Transfer Outputs Set Channels—All (default) or select from hardware list

Option	Description
<b>Test output</b>	Lets the user select a mA value that is sent by the controller for verification.
• <b>Output 1</b>	Min: 0 mA (default +04.00)
• <b>Output 2</b>	Max: 25.00 mA
<b>Status</b>	View status of all modules, sensors and relays.
<b>Test relay—A, B, C, D</b>	Energize or De-energize the selected relay
<b>Overfeed reset</b>	Resets the Overfeed Timer.
<b>Reset default config</b>	Resets the controller configuration settings to the default values (language, date and time, relay function and data output function).
<b>Restart sc200</b>	Performs a controller restart
<b>Simulation (only displays if sensors or modules are connected)</b>	<p>After the sim value is entered, the controller outputs this value as if it was the value sent from the sensor. The simulation stops after the user exits the screen.</p> <p>Source-</p> <ul style="list-style-type: none"> <li>• &lt;Module 1&gt;</li> <li>• &lt;Module 2&gt;</li> </ul> <p>(Footer displays current source selection)</p> <p>Parameter—Source measurement type (footer displays current source selection)</p> <p>Sim value—Use arrow keys to change value (footer displays current source selection)</p>
<b>Modbus stats</b>	<p>Displays Error and Good count stats for selected port.</p> <ul style="list-style-type: none"> <li>• Sensor port 1, 2, 3 or 4</li> <li>• Network port</li> <li>• Service port</li> <li>• Clear stats</li> </ul>
<b>System data</b>	Displays the current system current, temperature and voltage data.

## Warning and error conditions

Follow the steps below to acknowledge controller warnings.

1. From the Settings menu, select Diagnostics and push **ENTER**.
2. Select the device (controller, sensor, network card) with the warning or error and push **ENTER**.
3. Select the warning, error or event list and push **ENTER**.
4. Select Yes and push **ENTER** to acknowledge the warning.  
*Note: Errors cannot be acknowledged.*
5. For more information on a specific warning, error or event, refer to the device manual.

## Device scan information

Display message	Action
Installing device...please wait	The controller has found a new device. No action is necessary. The controller automatically performs an installation process for the new device and displays the main measurement screen of the device installed in the number one position.
Device missing <device id>	<p>A previously installed device has been removed from the controller or is not detected.</p> <ul style="list-style-type: none"> <li>• Push the <b>Enter</b> key to continue.</li> <li>• Push the left arrow key to select or de-select a missing device.</li> <li>• Push the <b>Enter</b> key to delete the missing device.</li> </ul> <p>The controller will display the main measurement screen for the device in the number one position.</p> <p><i><b>Note:</b> This message also displays when a device is missing and a new device has been installed. After the missing device is deleted, the controller automatically installs the new device and displays Installing device...please wait. The controller then displays the main measurement screen for the device installed in the number one position.</i></p>

## Replacement parts and accessories

**Note:** Product and Article numbers may vary for some selling regions. Contact the appropriate distributor or refer to the company website for contact information.

Description	Item number
4 GB Secure Digital Memory (SD) card	9218100
Connector kit for digital sensor	9201000
Controller installation kit	8806200
DataCom cable	LZX887
Mounting bracket inserts	9177900
Plug, conduit opening (set of 3)	5868700
Power cord kit, with strain relief, 125 VAC, U.S.-style plug	9202900
Power cord kit, with strain relief, 230 VAC, European-style plug	9203000
Screw driver	6134300
SD card reader	9218200
SD card cover kit for sc200 controller	9200900
Screws for controller installation kit	9177800
Cord grip kit (1)	9178000
Sealing washer for cord grip assembly	1033814
UV protection screen	8809200
Weather and sun shield w/ UV protection screen	9220600
<b>Sensor and communication modules</b>	
Conductivity module	9013000

Description	Item number
Flow module	9012700
4-20 mA input module	9012800
pH and DO module	9012900
4-20 mA output module	9334600
HART network module kit	9328100
Modbus network module	9013200
Profibus network module	9173900
Profibus M12 connector kit	9178500
Profibus M12 socket (hard wire to quick connector adapter)	9178200
Profibus M12 T-splitter	9178400







**HACH COMPANY World Headquarters**

P.O. Box 389, Loveland, CO 80539-0389 U.S.A.  
Tel. (970) 669-3050  
(800) 227-4224 (U.S.A. only)  
Fax (970) 669-2932  
orders@hach.com  
www.hach.com

**HACH LANGE GMBH**

Willstätterstraße 11  
D-40549 Düsseldorf, Germany  
Tel. +49 (0) 2 11 52 88-320  
Fax +49 (0) 2 11 52 88-210  
info-de@hach.com  
www.de.hach.com

**HACH LANGE Sàrl**

6, route de Compois  
1222 Vézenaz  
SWITZERLAND  
Tel. +41 22 594 6400  
Fax +41 22 594 6499

---


© Hach Company/Hach Lange GmbH, 2011-2014, 2016.  
All rights reserved. Printed in U.S.A.



DOC023.97.80194

# HART<sup>®</sup> Module

11/2013, Edition 4



User Manual

English .....	3
---------------	---

## Specifications

Specifications are subject to change without notice.

Specification	Details
Minimum current	3 mA
Maximum current	23 mA
Linearity	± 0.05% of span
HART receive impedance	$R_x \geq 200 \text{ K}\Omega$ ; $C_x = 4 \text{ pF}$
Internal module loop power	15 VDC
Lift-off voltage	13.3 VDC
External loop power over temperature	30 VDC maximum
Loop resistance (HART communications)	Internal module loop power: 250–350 $\Omega$ ; 18–24 VDC power supply: 250–500 $\Omega$ ; 24–30 VDC power supply: 250–976 $\Omega$
Loop resistance (non-HART communications)	Internal module loop power: 0–350 $\Omega$ ; 12–24 VDC power supply: 0–250 $\Omega$ ; 24–30 VDC power supply: 250–976 $\Omega$
HART burst mode	Not supported
HART protocol revision	7.2
Certification	Class I, Division 2 Groups A, B, C, D and Class I, Zone 2 Group IIC, T4 Hazardous and Ordinary Locations

## General information





In no event will the manufacturer be liable for direct, indirect, special, incidental or consequential damages resulting from any defect or omission in this manual. The manufacturer reserves the right to make changes in this manual and the products it describes at any time, without notice or obligation. Revised editions are found on the manufacturer's website.

## Safety information

NOTICE
The manufacturer is not responsible for any damages due to misapplication or misuse of this product including, without limitation, direct, incidental and consequential damages, and disclaims such damages to the full extent permitted under applicable law. The user is solely responsible to identify critical application risks and install appropriate mechanisms to protect processes during a possible equipment malfunction.
Please read this entire manual before unpacking, setting up or operating this equipment. Pay attention to all danger and caution statements. Failure to do so could result in serious injury to the operator or damage to the equipment.
Make sure that the protection provided by this equipment is not impaired. Do not use or install this equipment in any manner other than that specified in this manual.
Use of hazard information
▲ DANGER
Indicates a potentially or imminently hazardous situation which, if not avoided, will result in death or serious injury.
▲ WARNING
Indicates a potentially or imminently hazardous situation which, if not avoided, could result in death or serious injury.
▲ CAUTION
Indicates a potentially hazardous situation that may result in minor or moderate injury.
NOTICE
Indicates a situation which, if not avoided, may cause damage to the instrument. Information that requires special emphasis.

Precautionary labels

Read all labels and tags attached to the instrument. Personal injury or damage to the instrument could occur if not observed. A symbol on the instrument is referenced in the manual with a precautionary statement.


	This symbol, if noted on the instrument, references the instruction manual for operation and/or safety information.
	This symbol indicates that a risk of electrical shock and/or electrocution exists.
	This symbol indicates the presence of devices sensitive to Electrostatic Discharge (ESD) and indicates that care must be taken to prevent damage with the equipment.
	Electrical equipment marked with this symbol may not be disposed of in European public disposal systems after 12 August of 2005. In conformity with European local and national regulations (EU Directive 2002/96/EC), European electrical equipment users must now return old or end-of-life equipment to the Producer for disposal at no charge to the user.

Product overview

The HART module enables HART digital communication and gives two HART connections to the controller. HART communication is an industrial standard bidirectional digital communication over 4-20 mA analog current loops. The module connects to the network card connector inside the controller.

Three isolated analog outputs (output A – output C) are provided. Such outputs are commonly used for analog signaling or to control other external devices. Each output can be active through the use of internal module power or external/loop power (requires an external VDC power supply). When configured for HART communication, an external power supply is recommended. For maximum loop resistance versus voltage information, refer to [Figure 1](#).

Figure 1 Loop load limitations



### Circuit diagrams for HART communication

For HART communication, refer to Figure 2, Figure 3, Table 1, Figure 4, Figure 5 and Table 2.

Figure 2 HART voltage circuit - externally/loop powered




Figure 3 HART current circuit - externally/loop powered




Table 1 Recommended resistance values for externally/loop powered HART circuits

Power supply voltage	Loop resistance
18–24 VDC	250–500 $\Omega$
24–30 VDC	250–976 $\Omega$

Figure 4 HART voltage circuit - active module powered




Figure 5 HART current circuit - active module powered




Table 2 Resistance values for active module powered HART circuits

Loop resistance
250–350 Ω

Circuit diagrams for non-HART communication

Figure 6, Table 3, Figure 7 and Table 4 are not recommended for HART communication.

Figure 6 4-20 mA circuit - active module powered





Table 3 Resistance values for active module powered 4-20 mA circuit

Power supply voltage	Loop resistance
15 VDC	0–350 Ω

Figure 7 4-20 mA circuit - externally/loop powered





**Table 4 Recommended resistance values for externally/loop powered 4-20 mA circuit**

Power supply voltage	Loop resistance
12-24 VDC	0-250 Ω
24-30 VDC	250-976 Ω

## Wiring tables

Table 5 is recommended for HART communication.

**Table 5 Wiring information for externally/loop powered outputs**

Output	Connection	Connector pin number
Output C	(-) IN	1
Output C	(+) IN	2
—	—	3
Output B	(-) IN	4
Output B	(+) IN	5
—	—	6
Output A	(-) IN	7
Output A	(+) IN	8
—	—	9

Table 6 is not recommended for HART communication.

**Table 6 Wiring information for module powered active outputs**

Output	Connection	Connector pin number
Output C	(+) OUT	1
—	—	2
Output C	(-) OUT	3

**Table 6 Wiring information for module powered active outputs (continued)**

Output	Connection	Connector pin number
Output B <sup>1</sup>	(+) OUT	4
—	—	5
Output B <sup>1</sup>	(-) OUT	6
Output A <sup>1</sup>	(+) OUT	7
—	—	8
Output A <sup>1</sup>	(-) OUT	9

<sup>1</sup> This connection method is not recommended for HART communication.

## Installation

### ▲ DANGER

Explosion Hazard. For the module installation in classified hazardous locations, refer to the controller user manual for safety instructions.

### ▲ DANGER



Electrocution Hazard. Always remove power from the instrument before making any electrical connections.

### ▲ WARNING







Potential Electrocution Hazard. Only qualified personnel should conduct the tasks described in this section of the manual.





### NOTICE



Potential Instrument Damage. Delicate internal electronic components can be damaged by static electricity, resulting in degraded performance or eventual failure.

To install the module and connect the outputs, refer to [Wiring tables](#) on page 7 and the illustrated steps that follow.





## Operation

### Configure a HART module

The Network Setup option appears in the Settings Menu only if a HART module or other network module such as Modbus, Profibus or 4-20 mA is installed in the controller.

The range on the HART module is set at 4-20 mA. Each of the outputs can be assigned to represent a measured parameter from a sensor that is connected to the controller such as pH, temperature, flow or calculated values.

1. From the Settings menu, select Network Setup.
2. Select Edit Name and enter a name for the module. Push **ENTER** to save the name.

3. Select an output (A, B, C) and push **ENTER**.

**Note:** Only outputs A and B can be configured for HART communications.

- a. Highlight an option and push **ENTER**.
- b. Make a selection from the list or update the entries.
- c. Push **ENTER** to save the changes.

Option	Description
<b>Select Source</b>	Selects the sensor to be represented on the selected output —None, sensor 1 name, sensor 2 name, calculation (if set up). For sensor output, Select Parameter sets the measurement options. When the measurement is autorange, Set Range sets the range.
<b>Set Low Value</b>	Sets the measured value from the sensor to be represented by a 4 mA signal (default: 0.000). (Range and units depend on sensor)
<b>Set High Value</b>	Sets the measured value from the sensor to be represented by a 20 mA signal (default: 1.000). (Range and units depend on sensor)

Option	Description
<b>Set Transfer</b>	Sets the transfer value. Range 3.0 to 23.0 mA (default 4.000). If a device malfunction is detected, the output goes to the user-selected transfer value. <b>Note:</b> In addition, the transfer value can be set during a sensor calibration or maintenance (Diag/Test>Hold Outputs).
<b>Set Filter</b>	Sets a time-average filter value of 0 (default) to 120 seconds.
<b>Set HART Address</b>	Sets the HART address for the selected output channel. Range 0 to 63.

### Diagnostics and tests menu

1. From the Settings menu, select **Network Setup>Diag/Test**.
2. Select an option and push **ENTER** to perform the function or view the data.

Option	Description
<b>Output Cal</b>	Calibrates the low (4 mA) and high (20 mA) values for each of the three 4-20 mA outputs (A, B, C). Adjust the DAC counts until a connected multimeter reads the applicable output value. The default DAC counts are: <ul style="list-style-type: none"><li>• Output A—2807 for 4 mA, 14046 for 20 mA</li><li>• Output B—2797 for 4 mA, 14109 for 20 mA</li><li>• Output C—2641 for 4 mA, 13294 for 20 mA</li></ul>
<b>Hold output</b>	Sets the hold output options to Hold, Transfer or Release for each of the three 4-20 mA outputs (A, B, C).
<b>Test output</b>	Drives selected output to a simulated value.
<b>Status</b>	Displays the output value.
<b>Error hold mode</b>	Selects the behavior of the output in an error condition.

Option	Description
<b>Module Information</b>	Displays information about the installed module. <ul style="list-style-type: none"> <li>• Software version</li> <li>• Bootloader version</li> <li>• Serial Number</li> </ul>
<b>Default Setup</b>	Sets the configuration to factory defaults.

Troubleshooting

For general problems with HART module communications, try the corrective actions listed below. If the problem continues or other problems occur, contact technical support.

- Make sure the connections between the module and the HART host are correct.
- Make sure the loop supply is live.
- Make sure the HART host is set to the correct device address.
- Check the module network setup for the selected channel. Make sure that the installed device is mapped to the selected channel. Make sure the SET LOW VALUE and the SET HIGH VALUE are within the range of the selected source.
- If the HART output from the HART host cannot be trimmed or fixed, make sure the sensor does not have an error that makes the controller hold or transfer the output at a fixed value.

**HACH COMPANY World Headquarters**  
P.O. Box 389, Loveland, CO 80539-0389 U.S.A.  
Tel. (970) 669-3050  
(800) 227-4224 (U.S.A. only)  
Fax (970) 669-2932  
orders@hach.com  
www.hach.com

**HACH LANGE GMBH**  
Willstätterstraße 11  
D-40549 Düsseldorf, Germany  
Tel. +49 (0) 2 11 52 88-320  
Fax +49 (0) 2 11 52 88-210  
info@hach-lange.de  
www.hach-lange.de

**HACH LANGE Sàrl**  
6, route de Compois  
1222 Vésenaz  
SWITZERLAND  
Tel. +41 22 594 6400  
Fax +41 22 594 6499






DOC023.97.80192

## Active 4-20 mA Output Module

05/2013, Edition 2



User Manual

English .....	3
---------------	---



## General Information

In no event will the manufacturer be liable for direct, indirect, special, incidental or consequential damages resulting from any defect or omission in this manual. The manufacturer reserves the right to make changes in this manual and the products it describes at any time, without notice or obligation. Revised editions are found on the manufacturer's website.

## Safety information

Please read this entire manual before unpacking, setting up or operating this equipment. Pay attention to all danger and caution statements. Failure to do so could result in serious injury to the operator or damage to the equipment.





Make sure that the protection provided by this equipment is not impaired, do not use or install this equipment in any manner other than that specified in this manual.

## Use of hazard information

<b>▲ DANGER</b>	Indicates a potentially or imminently hazardous situation which, if not avoided, will result in death or serious injury.
<b>▲ WARNING</b>	Indicates a potentially or imminently hazardous situation which, if not avoided, could result in death or serious injury.
<b>▲ CAUTION</b>	Indicates a potentially hazardous situation that may result in minor or moderate injury.
<b>NOTICE</b>	Indicates a situation which, if not avoided, may cause damage to the instrument. Information that requires special emphasis.

## Precautionary labels




Read all labels and tags attached to the instrument. Personal injury or damage to the instrument could occur if not observed. A symbol on the instrument is referenced in the manual with a precautionary statement.

	This symbol, if noted on the instrument, references the instruction manual for operation and/or safety information.
	This symbol, when noted on a product enclosure or barrier, indicates that a risk of electrical shock and/or electrocution exists.
	Delicate internal electronic components can be damaged by static electricity, resulting in degraded performance or eventual failure.
	Electrical equipment marked with this symbol may not be disposed of in European public disposal systems after 12 August of 2005. In conformity with European local and national regulations (EU Directive 2002/98/EC), European electrical equipment users must now return old or end-of-life equipment to the Producer for disposal at no charge to the user. <i>Note: For return for recycling, please contact the equipment producer or supplier for instructions on how to return end-of-life equipment, producer-supplied electrical accessories, and all auxiliary items for proper disposal.</i>

## Overview of the 4-20 mA output module

The 4-20 mA output module gives three additional 4-20 mA output connections to a controller. The module connects to the network card connector inside the controller.

## Installation

<b>⚠ WARNING</b>	
	Potential Electrocution Hazard. Always disconnect power to the instrument when making electrical connections.
<b>⚠ WARNING</b>	
	Potential Electrocution Hazard. Only qualified personnel should conduct the tasks described in this section of the manual.
<b>NOTICE</b>	
	Potential Instrument Damage. Delicate internal electronic components can be damaged by static electricity, resulting in degraded performance or eventual failure.

Three isolated analog outputs (output 1–output 3) are provided. Such outputs are commonly used for analog signaling or to control other external devices. Each output is loop powered and requires a customer supplied 12 to 24 VDC power supply or the use of internal module power. To install the module and connect the outputs, refer to the [Illustrated steps](#) and either [Table 1](#) or [Table 2](#).

**Table 1 Wiring information for module powered**

Output	Connection	Connector pin number
Output C	(+) IN	1
—	—	2
Output C	(-) IN	3
Output B	(+) IN	4
—	—	5
Output B	(-) IN	6
Output A	(+) IN	7
—	—	8
Output A	(-) IN	9

**Table 2 Wiring information for external customer powered**


Output	Connection	Connector pin number
Output C	(-) IN	1
Output C	(+) IN	2
—	—	3
Output B	(-) IN	4
Output B	(+) IN	5
—	—	6
Output A	(-) IN	7
Output A	(+) IN	8

**Table 2 Wiring information for external customer powered (continued)**

Output	Connection	Connector pin number
—	—	9

1. Disconnect controller power.
2. Open the controller cover.
3. Feed the twisted-pair shielded wire through the strain relief.
4. Adjust the wire as necessary and tighten the strain relief.
5. Connect the shield at the power supply side. The power supply positive polarity connects to the (+) terminal, and the negative polarity connects to the (-) terminal ([Figure 1](#) or [Figure 2](#)).
  - Do not connect the shield at both ends of the cable.
  - Use only shielded cable to minimize radio frequency emissions and susceptibility.
  - External loop resistance may be required ([Table 3](#) or [Table 4](#)).
6. Close the controller cover and tighten the cover screws.
7. Connect controller power.
8. Configure outputs in the controller.


**Figure 1 Wiring diagram for external customer powered**



**Table 3 Resistance values for external customer powered**

Power supply voltage	Loop minimal resistance	Loop maximal resistance
12–18 VDC	0 Ω	250 Ω typical
18–24 VDC	250 Ω	500 Ω typical

**Figure 2 Wiring diagram for module powered**



**Table 4 Resistance values for module powered**

Power supply voltage	Loop minimal resistance	Loop maximal resistance
15 VDC	0 Ω	350 Ω typical