

בסבר ל≪נהלסבים האליך?ההליל Department of Community and Government Services Nunalingni Kavamatkunnilu Pivikhaqautikkut Ministère des Services Communautaires et gouvernementaux

# RESOLUTE BAY SEWAGE MACERATOR FACILITY OPERATIONS AND MAINTENANCE PROCEDURES

Updated 2020-08-04





# RESOLUTE BAY SEWAGE MACERATOR FACILITY OPERATIONS AND MAINTENANCE PROCEDURES

# **TABLE OF CONTENTS**

- A: MACERATOR FACILITY DAILY, WEEKLY, MONTHLY
- B: EMERGENCY LIGHTING ANNUAL
- C: EXIT SIGNAGE MONTHLY
- D: COMPRESSOR DAILY, MONTHLY AND SEMI-ANNUAL:
- E: HEAT TRACE DAILY
- F: PORTABLE FIRE EXTINGUISHER MONTHLY
- G: DOORS MONTHLY AND ANNUAL
- H: ROOFING INSPECTION ANNUAL
- J: ELECTRIC FORCED AIR UNIT HEATER DAILY AND MONTHLY
- K: 1977 AS-BUILT DRAWINGS D212 AND D301\*
- \* Refer to Reference Drawings D212 and D301 for general O&M Reference.
  All conditions to be confirmed onsite.

# RESOLUTE BAY SEWAGE MACERATOR FACILITY OPERATIONS AND MAINTENANCE PROCEDURES

# A: MACERATOR BUILDING – DAILY, WEEKLY, MONTHLY

Before entering the building, operate the ventilation system for a minimum of 5 minutes. If ventilation system is not operating, obtain a portable fan to ventilate building.

### **Daily**

- 1. Check operation of interior and exterior lighting.
- 2. Check heating system operation.
- 3. Check for excessive noise, heat and/or vibration of motorized components
- 4. Check that all pumps, valves and other equipment are performing correctly, and service is required.
- 5. Lock out power for macerator unit and configure bypass.
- 6. Remove gas-tight macerator cover.
- 7. Drain Macerator basket and remove debris to maintain at least 90% of flow through capacity
- 8. Flush basin
- 9. Clean all combs, coarse screens or other preliminary treatment devices.
- 10. Replace gas-tight macerator cover.
- 11. Restore power to macerator unit.

### Weekly

- 1. Operate backup power supply and check fuel tank (if backup power supply available)
- 2. Exercise backup pump if pumps are not being cycled as duty pump.

### **Monthly**

- 1. Maintain records of problems, repairs/modifications/replacement, and fuel and electrical consumption.
- 2. Clean and disinfect floor of building, and equipment.
- 3. Lubricate all components as recommended.

### <u>Annual</u>

- Inspect cutting edge and shear bars and replace if necessary
- 2. Open, check, overhaul and sharpen cutters
- 3. Lubricate all components as recommended.
- 4. Service motor as recommended.

# RESOLUTE BAY SEWAGE MACERATOR FACILITY OPERATIONS AND MAINTENANCE PROCEDURES

#### **B:** EMERGENCY LIGHTING - ANNUAL

- 1. Simulate power failure to prove operation.
- 2. Check that pilot lights are functioning and not obviously damaged or obstructed.
- 3. Top up electrolytes if applicable.
- 4. Check that terminal connections are clean, free of corrosion and lubricated as required.
- 5. Check that terminal clamps are clean and tight.
- 6. Ensure that battery is clean and dry.
- 7. Ensure that security devices or locks are operational, and guards are in place.
- 8. Wipe down and remove dust accumulation on lamp.
- 9. Ensure supports are securely fastened and not damaged.
- 10. Test to ensure that the unit will provide emergency lighting for the following durations:
  - a. two (2) hours for high buildings (as defined by the National Building Code 3.2.6; and
  - b. one (1) hour for buildings where persons are detained or under special care; and
  - c. one-half (1/2) hour for all other buildings
  - d. At this time the unit must be able to produce 50% of its designed illumination or 10 lux at floor or tread level.
- 11. At the end of the test required by #10 check that the charging system functions.
- 12. When maintenance is complete, return to service.
- 13. Check expiry date of batteries and general condition.

#### C: EXIT SIGNAGE - MONTHLY

1. Check that exit signs are illuminated, clean and legible.

# D: COMPRESSOR - DAILY, MONTHLY AND SEMI-ANNUAL:

### Daily

- 1. check compressor visually.
- 2. Drain receiver.
- 3. Check gauges on reservoir.

# **Monthly**

- 1. Check oil in compressor.
- 2. Clean air filter intake and trap.
- 3. Check operation of pressure reducing valves and high and low limit compressor switches.
- 4. Check and adjust belts.
- 5. Check safety guards and mounts.

# Semi-Annual

- 1. Check heat trace and controls for proper settings/operation. (Water lines)
- 2. Verify safety and check valve operation.

# RESOLUTE BAY SEWAGE MACERATOR FACILITY OPERATIONS AND MAINTENANCE PROCEDURES

- 3. Change belts if showing wear.
- 4. Check and record amp draw on motor.
- 5. Connect power supply to eve heat cables as required to prevent or remove ice build up. Verify proper operation. Disconnect when not required.
- 6. Drain crankcase and refill with clean oil
- 7. Clean air intake filter and trap.

# Air filter and dryer:

- 1. Check operation of automatic dryer.
- 2. Clean entire unit and filter on airline.
- 3. Change drying media as required.

# Piping:

- 1. Check pipe work for leaks.
- 2. Check quick couplers and utility outlets for leaks, repair as required.

### E: HEAT TRACE - DAILY

Check heat trace and controls for proper settings/operation.

### F: PORTABLE FIRE EXTINGUISHER - MONTHLY

- 1. Check that extinguishers are in designated place with no obstruction to access or visibility.
- 2. Check for damage, corrosion, defects, leakage or clogged nozzle.
- 3. Check that operating instructions are facing out and legible and that seals and tamper indicators are not broken or missing.
- 4. Check that pressure gauge reading or indicator is in the operable range. Check fullness by weighing or "hefting".
- 5. If inspection (2,3,4) reveals any deficiencies the unit is to be removed from service and replaced or the deficiency corrected.
- 6. Record the inspection date and initial the tag or label attached to the extinguisher.

# **Dry Chemical Extinguishers:**

- 1. Note: Residential extinguishers are to be replaced with a ULC listed A.B.C disposable unit when 5 or 12 yr service is due.
- 2. Note: Surplus units are to have head/cap and powder removed before being put in the dump. The powder must be buried if put in the dump.
- 3. These systems are to be serviced by qualified persons only.
- 4. Any extinguishers of a type not mentioned here is to be serviced as required by N.F.P.A. 10.
- 5. Unless required by the hazard class or some special requirement, all other types of
- 6. extinguisher can be replaced with a U.L.C. listed A.B.C stored pressure unit as 6 or 12 service is due.

# RESOLUTE BAY SEWAGE MACERATOR FACILITY OPERATIONS AND MAINTENANCE PROCEDURES

#### G: DOORS – MONTHLY AND ANNUAL

# **Monthly**

- 1. Check action and motion of doors, adjust and lubricate as required.
- 2. Check all hardware for tightness and smooth operation. Adjust and lubricate as required.
- 3. Replace damaged, ineffective, or missing weather stripping and gaskets.

# <u>Annual</u>

- 4. Check metal doors, frames and screens, correct any deficiencies including:
  - a. looseness
  - b. rust or corrosion
  - c. warping, poor fit or binding
  - d. missing caulking.
- 5. Check electric operators and controls (if applicable).
- 6. Inspect all fire doors for any damage that may affect their fire rating. Repair as required.
- 7. Check/clear/clean door tracks as necessary.
- 8. Ensure fusible link is free of dirt and paint where applicable.

#### H: ROOFING INSPECTION - ANNUAL

- 1. Inspect asphalt-shingle roofing for lifting; weathering; cracking; curling; buckling; blistering; loss of granules.
- 2. Inspect built-up roofing for cracking; alligatoring; low spots, and water ponding; failure of or lack of gravel stops; cracks in membrane; exposed bituminous coatings; exposed, disintegrated, curled or buckled felts.
- 3. Inspect asphalt-roll roofing for weathering, cracking, alligatoring, buckling, blistering, sufficient laps, tearing, other damage to the coating.
- 4. Inspect metal roofing for holes, looseness, punctures, broken seams; adequate side end laps adequate expansion joints; rust corrosion or physical damage. Check all exposed fasteners, caulking, and condition of gaskets at screws.
- 5. Inspect "M.B.M." torch on roofing, to ensure membrane laps are fully adhered. Check granule loss.
- 6. Inspect metal base flashings for rust, vertical joints, flanges, adequate nailing, proper fastening,
- 7. proper sealing, cant strip. Inspect chimney, wall, ridge, vent, valley, and edge flashings for open
- 8. joints, looseness, proper fastening.
- 9. Inspect other base flashings for sagging; separation adequate coverage or embedment; vertical
- 10. joints; proper fastening; buckling; cracking; surface coat; cant strip.
- 11. Inspect cap flashings for open joints, cracking, buckling; surface coat; proper fastenings; rust and corrosion.
- 12. Inspect parapet walls and copings for cracks, spalling, caulking, other damage; open joints.

# RESOLUTE BAY SEWAGE MACERATOR FACILITY OPERATIONS AND MAINTENANCE PROCEDURES

- 13. Inspect roof drains, remove debris, clean screen replace as necessary; examine membrane around drain for damage.
- 14. Inspect gutters eavestrough: clean screens, clean gutters, check caulking, ensure down-spouts are securely fastened.
- 15. Inspect catwalks, pipe walks. Clean debris from underneath, check for membrane damage a supports. Check fastenings.
- 16. Inspect all protrusions to ensure that seals are intact.
- 17. Inspect all vent hoods, turbine vents, for proper operation. Check seal at base.

### I: ELECTRICAL – ANNUAL

- 1. De-energize lock and tag out.
- 2. Replace or repair and tighten connections. A/R.
- 3. Ensure breaker size is proper for equipment it protects.
- 4. Exercise breaker to ensure freedom from binding.
- 5. Wipe down breaker faces; ensure they are clean and dry.
- 6. Ensure fuse size and type is proper for equipment it protects.
- 7. Ensure fuse holders in good condition.
- 8. Check out and ensure labelling on the index card is correct.
- 9. Ensure labelling is legible.
- 10. Note spare circuit capacity remaining.
- 11. Remove accumulation of dirt dust and debris.
- 12. Install knockout seals if required.
- 13. Remove locks, tags and return to service

### J: ELECTRIC FORCED AIR UNIT HEATER – DAILY AND MONTHLY

### Daily

- 1. Visually check Unit
- 2. Check operation of controls
- 3. Check for any unusual noise

### Monthly

1. Check fan bearing/belts



