

Bray [®] **SERIES 70**

2ND GENERATION ELECTRIC ACTUATOR

OPERATION AND MAINTENANCE MANUAL




TABLE OF CONTENTS:

	PAGE
SAFETY INSTRUCTIONS: DEFINITION OF TERMS.....	2
INTRODUCTION	3
PRINCIPLE OF OPERATION.....	3
ELECTRICAL OPERATION	3
MECHANICAL OPERATION.....	3
MANUAL OVERRIDE OPERATION	4
PRE-INSTALLATION STORAGE.....	4
INSTALLATION.....	4
MOUNTING TO A VALVE	4
FIELD WIRING	4
MULTIPLE ACTUATOR WIRING.....	5
SERIES 70 ON/OFF ACTUATOR WITH INTERPOSING RELAY BOARD.....	5
TRAVEL LIMIT SWITCH AND MECHANICAL TRAVEL STOP ADJUSTMENT	6
CLOSE ADJUSTMENT	6
OPEN ADJUSTMENTS	7
BASIC DISASSEMBLY AND ASSEMBLY INSTRUCTIONS.....	7
FIELD OR FACTORY INSTALLABLE OPTIONS	
TORQUE SWITCHES OPERATION.....	8
HEATER.....	9
SERVO PRO MODULE.....	9
EXTERNAL FEEDBACK POTENTIOMETER	11
AUXILIARY SWITCHES.....	11
BATTERY BACKUP UNIT	12
AUXILIARY SWITCH CONFIGURATION CHART.....	13
TYPICAL WIRING DIAGRAMS FORM C (SPDT) SWITCHES ON/OFF SERVICE	14
TYPICAL WIRING DIAGRAMS MODULATING SERVICE	15
ADJUSTMENTS, CALIBRATION & STATUS LED OF SERVO PRO	16
QUICK CONNECT RECEPTACLES	17
SPINNER	18
LOCAL CONTROL STATION.....	18
APPENDIX A	
BASIC TOOLS	19
APPENDIX B	
ACTUATOR TROUBLESHOOTING CHART.....	20
SERVO TROUBLESHOOTING CHART.....	21
APPENDIX C	
EXPLODED VIEW AND PARTS LIST OF SIZE 003 AND 005.....	22
EXPLODED VIEW AND PARTS LIST OF SIZE 008, 012 AND 020	23
EXPLODED VIEW AND PARTS LIST OF SIZE 030, 050 AND 065	24
EXPLODED VIEW AND PARTS LIST OF SIZE 130 AND 180 (ELECTRIC).....	25
EXPLODED VIEW AND PARTS LIST OF SIZE 130 AND 180 (GEAR BOX).....	26

SAFETY INSTRUCTIONS - DEFINITION OF TERMS

READ AND FOLLOW THESE INSTRUCTIONS SAVE THESE INSTRUCTIONS



WARNING

indicates a potentially hazardous situation which, if not avoided, **could** result in death or serious injury.



CAUTION

indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



NOTICE

used without the safety alert symbol indicates a potential situation which, if not avoided, may result in an undesirable result or state, including property damage.

1.1 HAZARD-FREE USE

This device left the factory in proper condition to be safely installed and operated in a hazard-free manner. The notes and warnings in this document must be observed by the user if this safe condition is to be maintained and hazard-free operation of the device assured.

Take all necessary precautions to prevent damage to the actuator due to rough handling, impact, or improper storage. Do not use abrasive compounds to clean the actuator, or scrape metal surfaces with any objects.

The control systems in which the actuator is installed must have proper safeguards to prevent injury to personnel, or damage to equipment, should failure of system components occur.

1.2 QUALIFIED PERSONNEL

A qualified person in terms of this document is one who is familiar with the installation, commissioning and operation of the device and who has appropriate qualifications, such as:

- Is trained in the operation and maintenance of electric equipment and systems in accordance with established safety practices
- Is trained or authorized to energize, de-energize, ground, tag and lock electrical circuits and equipment in accordance with established safety practices

- Is trained in the proper use and care of personal protective equipment (PPE) in accordance with established safety practices
- Is trained in first aid
- In cases where the device is installed in a potentially explosive (hazardous) location – is trained in the operation, commissioning, operation and maintenance of equipment in hazardous locations



WARNING

The actuator must only be installed, commissioned, operated and repaired by qualified personnel.

The device generates large mechanical force during normal operation.

All installation, commissioning, operation and maintenance must be performed under strict observation of all applicable codes, standards and safety regulations.

Reference is specifically made here to observe all applicable safety regulations for actuators installed in potentially explosive (hazardous) locations.

BRAY Series 70 Electric Actuator Operation and Maintenance Manual

PART NUMBERING SYSTEM REFERENCE CHART

SERIES	SIZE CODE	SPEED	PRODUCT	STYLE	VOLTAGE	TRIM
70	AAA	X	113	Y	Z	536

PART NUMBER	TORQUE (In.Lbs)	SPEED, 1/4 TURN (Seconds)	SUPPLY (Z Voltage)
70-003X-113yz-536	300	30/15	0/1/2/3/4
70-005X-113yz-536	500	30/15	0/1/2/3/4
70-008X-113yz-536	800	30/15/6	0/1/2/3/4/5/6/7/8
70-012X-113yz-536	1200	30/15/6	0/1/2/3/4/5/6/7/8
70-020X-113yz-536	2000	30/15	0/1/2/3/4/5/6/7/8
70-030X-113yz-536	3000	30/18	0/2/3/4/5/6/7/8
70-050X-113yz-536	5000	30/18	0/2/3/4/5/6/7/8
70-065X-113yz-536	6500	30	0/2/4/5/6/7/8
70-13W6-113yz-536	13000	110	0/2/4/5/6/7/8
70-18W6-113yz-536	18000	110	0/2/4/5/6/7/8

Use this chart as a guide to interpret the S70 electric actuator part number.

W - DESIGNATES THE OUTPUT BORE DIAMETER

0	2.5 Inches
1	1.97 Inches

X - DESIGNATES THE SPEED

X:	1	2	3	4	5
Sec:	30	18	10	6	8

Y - DESIGNATES STYLE

A	Basic Unit - Dec clutchable
D	With Interposing Relay Board*

*Only available for 120VAC or 220VAC On/Off units

Z - DESIGNATES THE VOLTAGE

Z:	0	1	2	3	4	5	6	7	8
Voltage:	120VAC	12VDC	24VDC	24VAC	220VAC	380V 3-PH	400V 3-PH	440V 3-PH	480V 3-PH

INTRODUCTION

The **Bray Series 70** is a quarter turn electric actuator with manual override for use on any quarter turn valve requiring up to 18000 in.lb of torque. Operating speeds vary between 6 to 110 seconds.

PRINCIPLE OF OPERATION

The Series 70 actuator is basically divided into two internal sections; the power center below the switchplate, and the control center above the switchplate. Below the switchplate the capacitor and gearmotor with its spur geartrain drive a final non-backdriveable worm gear output. The override mechanism for manual operation is also housed here. Above the switchplate is where user required, readily accessible components are placed. The camshaft assembly, limit switches, terminal strips, torque switches, heater, and servo are all placed here for easy access. External to the unit are found adjustable mechanical travel stops, a large easy to read indicator, the unique manual override handwheel and dual conduit entry ports. The external coating is a high quality polyester powder coat which has exceptional UV as well as chemical resistance.

ELECTRICAL OPERATION

The motors used in the **Bray Series 70** are either permanent induction split capacitor design (single phase AC power), SCI (Three Phase AC Power) or PM (DC Power). Travel limit switches are mechanical form (SPDT) with contacts rated at 10 amp (0.8 PF), 1/2 HP 125/250 VAC. In cases where the torque capacity of the unit is exceeded to the point where the motor stalls and overheats, a thermal protector switch built into the motor windings will automatically disconnect the motor power. Once the motor cools sufficiently the thermal protector switch will reset. Optional torque switches are available in all


units to prevent the possibility of stalling the motor, thus reducing the necessity for an inoperable thermal cooldown period. Torque switches installed by Bray are factory adjusted to the output torque rating of the unit using electronic torque testing equipment.

NOTICE

Field adjustment of the torque switches is not recommended.

General Electrical Schematic

NOTE: this is only a reference. For the actual wiring diagram refer to the diagram placed inside the actuator cover.



MECHANICAL OPERATION

Mechanically, the ratio of the gearmotor determines the speed of the unit. The gearmotor utilizes high efficiency spur gears with various ratios for the different speeds. Initial gear reduction through the spur gears is then transferred to the worm shaft. The final gear reduction and output is through a non-backdriveable worm gear set. Positioning is determined by an indicator-cam shaft linked to the output shaft. In the dec clutchable condition the manual override drives the worm shaft when engaged.

BRAY Series 70 Electric Actuator Operation and Maintenance Manual

MANUAL OVERRIDE OPERATION (DECLUTCHABLE)

The manual override operates similar to a watch adjusting knob. To engage the manual override, simply pull the handwheel to its outermost position. A yellow stripe is revealed for visual indication that the unit cannot run electrically. The two handwheel positions, engaged and disengaged, are held in place with the use of spring plungers. The handwheel remains in position until physically moved. Rotating the handwheel in the clockwise direction will rotate the output shaft in the same clockwise (closed) direction and vice-versa.



CAUTION

A label on the handwheel hub warns users not to exceed a specific rim pull force, for each size of actuator. If the rim pull force is exceeded, the roll pin securing the handwheel onto the manual override shaft is designed to shear, thus preventing more serious internal gearing damage.

PRE-INSTALLATION STORAGE

Units are shipped with two metal screw-in plugs in order to prevent foreign matter from entering the unit.

NOTICE

To prevent condensation from forming inside these units, maintain a near constant external temperature and supply power to the optional heater internal to the unit.

INSTALLATION

MOUNTING TO A VALVE

All Bray Series 70 electric actuators are suitable for direct mounting on Bray butterfly valves. With proper mounting hardware, the S70 actuator can be installed onto other quarter-turn valves or devices.

NOTICE

The standard mounting position for the actuator is to orient the unit with its handwheel in a vertical plane and parallel to the pipeline. If the actuator is to be mounted on a vertical pipe, it is recommended that the unit be positioned with the conduit entries on the bottom to prevent condensation from entering the actuator by way of the conduit. In all cases, the conduit should be positioned to prevent drainage into the actuator.

The actuator should be mounted to the valve as follows:

1. Manually operate the actuator until the output shaft of the actuator is in line with the valve stem. If possible, select an intermediate position (i.e. valve disc/stem and actuator both half open).
2. Place the proper adapter, if required, onto the valve stem. It is recommended that a small amount of grease be applied to the adapter to ease assembly.
3. Mount the actuator onto the valve stem. It may be necessary to swing or manually override the actuator to align the bolt patterns.
4. Install the furnished mounting studs by threading them all the way into the actuator base.
5. Fasten in place with the furnished hex nuts and lock washers.

FIELD WIRING



WARNING

Turn off all power and lock out service panel before installing or modifying any electrical wiring.

Each actuator is provided with two (2) conduit entries (one for power and one for control).

1. The motor full load current is noted on the nameplate of the actuator. The terminal strip will accept wire sizes ranging from 14 to 22AWG (14 to 24AWG for the servo).

NOTICE

18AWG minimum wire is recommended for all field wiring.

Note that the optional heaters use approximately 0.5 amps at 110 volts.

2. **All actuators have their applicable wiring diagram attached to the inside of the cover.** Field wiring should be terminated at the actuator terminal strip in accordance with **this** wiring diagram.

NOTICE

The conduit connections must be properly sealed to maintain the weatherproof integrity of the actuator enclosure.

MULTIPLE ACTUATOR (PARALLEL) WIRING



CAUTION


Do not connect more than one S70 actuator which do not have I.R.B. installed to a single SPDT switch. A voltage is present on the opposite winding to the powered one. If this winding is connected to another as shown in the INCORRECT diagram it will interfere with the motor performance. Use a multiple pole switch as shown in the CORRECT diagram.*




CAUTION

Do not reverse motor instantaneously when it is still running. Reversing direction to actuator motor when it is running can cause damage to motor, switches and gearing. Directional control switching can be done by PLC in 20ms or by a small relay in 46ms. Therefore time delay of 1s has to be incorporated into the control scheme to avoid damage.

ACTUATOR DIAGRAM WITHOUT I.R.B.



INCORRECT



CORRECT

TRAVEL LIMIT SWITCH AND MECHANICAL TRAVEL STOP ADJUSTMENT



CAUTION

The electrical travel switches **must** be set to activate (depress) prior to reaching the mechanical travel stops. The cams are color coded (green for open, red for closed).

NOTE: Manual travel stops are designed to prevent manual overtravel from turning the handwheel, not to stop the electric motor. The travel stops have an adjustment range of approximately 10-degrees.


S70 ON/OFF ACTUATOR WITH INTERPOSING RELAY BOARD (I.R.B.)

The back feeding of one actuator by another one wired in parallel is eliminated by using the I.R.B.


If actuator is running Open & customer switches "instantaneously" to run Closed, the Open relay will take time to 'drop-out' & the Close relay will take time to 'pull-in' this time lapse is ~ 40ms. The time delay provided by the I.R.B. will protect the switches and gears from the controller's instantaneous command signal reversal.

Current draws and field wirings are not affected by adding I.R.B.

S70 120VAC I.R.B., auxiliary switch option, and heater option are UL certified units.




BRAY Series 70 Electric Actuator Operation and Maintenance Manual



CLOSE TRAVEL SWITCH ADJUSTMENT

1. Loosen the mechanical stop for the closed position and back it off so that it does not interfere with actuator travel (closed stop located on right when viewed from travel stop side of actuator).
2. Remove the indicator rotor by pulling up it straight up away from the indicator shaft. This will expose the machined groove on the end of the cam shaft, which is the reference to the valve disc position.
3. **NOTE:** For Sizes 130 and 180, ignore steps 2 and 6. The valve position indicator plate on the lower gearbox is the reference to the valve position.
4. Manually operate the actuator handwheel clockwise until the valve reaches the desired fully closed position.
5. Rotate the **red** adjusting knob by hand or with a flat head screwdriver until the cam lobe just activates (depresses) the switch from a clockwise direction.

NOTICE: All continuous duty actuators have a cam locking screw. Cam locking screw must be slackened before cam adjustments and re-tightened after cam adjustments.



NOTE: It is possible that the rotation of one cam will move the other cam. If this occurs, hold the other knobs or cams during adjustment.

6. With the travel switch in the closed position, rotate the **handwheel** clockwise $\frac{1}{2}$ turn for size 6, 1 turn for size 12, $\frac{1}{2}$ turn for size 30, and $1 \frac{1}{2}$ turn for size 130 and 180. Adjust the closed travel stop bolt until it bottoms against the output gear and lock it in position with the locknut.
7. After all travel switch adjustments have been completed, replace the indicator rotor and secure the actuator cover.

OPEN TRAVEL SWITCH ADJUSTMENT

1. Loosen the mechanical stop for the open position and back it off, so that it does not interfere with actuator travel. The open stop is located on the left, when viewed from travel stop side of actuator.
2. Remove the indicator rotor by pulling it straight up away from the indicator shaft. This will expose the machined groove on the end of the cam shaft, which is the reference to the valve disc position.
- NOTE:** For Sizes 130 and 180, ignore steps 2 and 6. The valve position indicator plate on the lower gearbox is the reference to the valve position.
3. Manually operate the actuator handwheel counterclockwise until the valve reaches the desired open position.
4. Rotate the green adjusting knob until the cam lobe just activates (depresses) the switch from a counterclockwise direction.


NOTICE: All continuous duty actuators have a cam locking screw. Cam locking screw must be slackened before cam adjustments and re-tightened after cam adjustments.

NOTE: It is possible that the rotation of one cam will move the other cam. If this occurs, hold the other knobs or cams during adjustment.

5. With the travel switch in the open position, rotate the **handwheel** counterclockwise $\frac{1}{2}$ turn for size 6, 1 turn for size 12, $\frac{1}{2}$ turn for size 30, and $1 \frac{1}{2}$ turn for size 130 and 180. Adjust the open travel stop bolt until it bottoms against the output gear and lock in position with the locknut.
6. After all travel stop adjustments have been completed, replace indicator rotor and secure the actuator cover.

DISASSEMBLY AND ASSEMBLY

TOOLS REQUIRED:



See Appendix A for a complete list of basic tools.


PROCEDURE:



WARNING

Turn off all power and lock out service panel before installing or modifying any electrical wiring.

1. Disconnect motor wires from the main terminal strip (motor neutral, open, and close).




2. Remove the switchplate by unscrewing the seven phillips head mounting screws. The switchplate should lift out as an assembly with the camshaft attached.
3. The switchplate can be independently disassembled.
4. To remove the Gearmotor, first disconnect the motor leads which run to the capacitor, and unscrew the mounting screws for size 003-005 (two lower, one upper) for size 008-180 (four lower, one upper). The motor can now be removed vertically out of the unit. Note: do not misplace the alignment pin.
5. To remove the worm shaft spur gear, remove the spring pin using a $\frac{3}{32}$ " punch, then slide the gear off the end of the worm shaft for size 003-020. Remove bowed E-clip retainer for size 030-180.
6. To remove the output drive worm gear, back off both mechanical travel stops. Remove the retaining ring and thrust washer, then lift the output drive worm gear out of its base.
7. The handwheel is held by a spring pin.



CAUTION

8. Further disassembly of the unit requires special tools and procedures, and thus will not be covered in this manual.



BRAY Series 70 Electric Actuator Operation and Maintenance Manual

FIELD OR FACTORY INSTALLABLE OPTIONS


TORQUE SWITCHES

Torque switches are a factory installed and calibrated option available for all Series 70 units. Installation is simple, but due to the requirement for special calibration equipment, it is not recommended for field installation. In fact, modifying the factory torque setting voids the actuator warranty.

The unique mechanism is extremely accurate and has excellent repeatability. The worm is pinned to the worm shaft, which is held in position with a stack of disc springs at both ends. The torque transmitted through the worm to the output worm gear acts directly against the disc springs, which compress proportionately. The worm and worm shaft shift longitudinally as a result.


A specially designed drive lever and pin is incorporated into the worm, providing the profile for the torque switching

mechanism. A drive lever & pin rides in the worm gear torque sensor groove, and in turn drives a cam. The cam then actuates its electrical switch, which interrupts the power to the motor winding when the torque exceeds the setting. The motor can still be powered to run in the opposite direction, or if the torque diminishes, the switch will release automatically.



Switching Mechanism

TORQUE SWITCH MECHANISM



HEATER

To prevent condensation from forming inside the actuator, Bray offers an optional heater. The heater is a PTC (Positive Temperature Coefficient) style which has a unique temperature - resistance characteristic. The heater self-regulates by increasing its electrical resistance relative to its temperature. The heater does not require external thermostats or switches to control its heat output. It is constructed of a polycrystalline ceramic, sandwiched between two conductors, and wrapped inside a thermally conductive electrical insulator.

Connect the heater wires to the terminal strip as indicated on the wiring diagram.

NOTE: The heater must have a constant power supply to be effective.



WARNING

The heater surface can reach temperatures in excess of 200 degrees Celsius

HEATER KIT CONSISTS OF:

1. Heater with flying leads
2. Heater Mounting Bracket
3. #10 pan head screw, phillips drive


TOOLS REQUIRED:

- For terminal wiring: Screwdriver, $\frac{3}{16}$ " tip flat blade
- For heater mounting screw: Screwdriver, No.1 phillips

INSTALLATION PROCEDURE:

The heater is mounted through a hole provided in the switchplate.

Before servicing unit, switch all power off at the service panel and lock the service disconnecting means to prevent power from being switched on accidentally. When the service



disconnecting means cannot be locked, securely fasten a prominent warning device, such as a tag, to the service panel.

Disconnect all power to the unit.

1. Place the heater snugly into its mounting bracket until approx. 1/2 to 1" is left above the bracket as shown in diagram.
2. Slip the heater into its mounting hole.
3. Align the fastening hole in the bracket with the threaded screw hole in the plate. Fasten the heater to the switchplate.
4. Connect the heater wires to the terminal strip as indicated on the wiring diagram.

SERVO-PRO MODULE


Servo kits can be field installed on any continuous duty actuator (30 or 60 sec. operation speed) to provide proportional positioning in response to a control signal. Intermittent duty actuators are not adaptable for servo control.

SERVO KIT CONSISTS OF:

1. One servo module
2. Four #6 cross drive pan head screw (two for servo, two for pot)
3. One potentiometer assembly
4. Two #6 type A internal lockwashers (for pot)
5. One wiring diagram sticker for attaching to inside of actuator's cover
6. One wiring diagram sticker for servo units with torque switches

TOOLS REQUIRED:

- For actuator terminals wiring Screwdriver, $\frac{3}{16}$ " flatblade
- For servo terminals Screwdriver, No.1 phillips
- For servo and pot mounting screws Screwdriver, No.2 phillips



BRAY Series 70 Electric Actuator Operation and Maintenance Manual

INSTALLATION PROCEDURE:

Disconnect all power to the unit.

Remove the on/off duty, 9 point terminal strip and its marker

1. Disconnect all wiring to the terminal strip.
2. All wiring in the actuator is color coded to facilitate wiring, and does not need to be tagged or marked.
3. Field wiring should be marked if it is not already color coded.


Mount the servo module

4. Secure the servo card module onto switchplate with the 2X #6 screws.

Install the potentiometer assembly

5. The potentiometer installs next to the camshaft where there are two threaded holes provided.
6. The potentiometer assembly must be mounted in the correct orientation, with the actuator in its fully open (counter clockwise) position, the indicator shaft should be in-line with raised green rib on pot gear.
7. Push the assembly towards the cam to mesh the pot gears. Then tighten the mounting screws.

Note: Sizes 130 and 180, the raised green rib on pot gear should be aligned with arrow on lower gear box's position indicator plate.



Wire the pot to the servo

8. Connect the pot wires into the terminal strip on the servo module.
9. Wire according to the wiring diagram provided.

Wire the servo to the actuator

10. Wire according to the wiring diagram provided.
11. See the servo calibration instructions.

SERVO CALIBRATION

The calibration procedure defines the limits of operation of the Series 70 Actuator between the fully open valve position and the fully closed valve position. The cams on the Series

70 Actuator define the fully open and closed positions of the valve and may be set at any degree of opening. The only requirement is that the open cam limit setting must set at a higher degree of opening than the closed cam limit setting. In other words, the "Open" position must be more open than the "Closed" position.

Calibration is performed as follows:

1. Adjust the Open and Closed limit switch cams on the Series 70 Actuator to the desired position.
2. Engage the handwheel and move the Series 70 Actuator to its mid position.


NOTE:

An analog signal source is not required for calibration. Press and hold the "Calibrate" Set pushbutton for a minimum of 2 seconds. When the servo begins to drive the actuator closed, release the button. The servo will now seek both travel limits and record these values to its nonvolatile memory. Following a successful calibration, the status LED will begin to flash a steady single green flash. If the calibration is unsuccessful the status LED will flash two green flashes. If this occurs, make sure the cams and the potentiometer are set correctly.

This completes the "Self Calibration" procedure.

After completing the calibration procedure, it is good practice to apply the fully closed and fully open Command Signals, and verify that the S70 Actuator moves to the proper positions.

* Refer to Servo Pro Manual for more details



EXTERNAL SIGNAL FEEDBACK POTENTIOMETER


Potentiometers for external feedback can be field installed on all continuous duty actuators. Actuators which are not continuous duty do not have a pot gear fitted on their indicator shafts & must be fitted with a new shaft which has a pot drive gear for feedback pot (see Options: Auxiliary Switches).

FEEDBACK POTENTIOMETER KIT CONSISTS OF:

1. One potentiometer assembly
2. Two #6 cross drive pan head screws
3. Two #6 internal lockwashers
4. One 4 point terminal strip
5. One terminal strip marker for feedback pot
6. One small wiring diagram sticker for the additional potentiometer

TOOLS REQUIRED:

- For terminal wiring Screwdriver, $\frac{3}{16}$ " tip flat blade
- For pot mounting screws Screwdriver, No.2 phillips



INSTALLATION PROCEDURE:

1. The potentiometer installs next to the camshaft where there are two threaded holes provided for it.
2. The potentiometer assembly must be mounted in the correct orientation, with the actuator in its fully open (counter clockwise) position, the indicator shaft should be in-line with raised green rib on pot gear.
3. Push the assembly towards the cam to mesh the pot gears. Then tighten the mounting screws.
4. Fit the 4 point terminal strip and marker in the kit. Before laying down the marker, cut it to obtain a marker as illustrated: opposite
5. Wire the pot to the terminal strip using the small stick-on wiring diagram provided.
6. Adhere the wiring diagram sticker to the inside of the cover.

SET THE POTENTIOMETER:

1. Manually operate the actuator handwheel until the unit is in the fully closed position.
2. Rotate the black potentiometer drive gear adjustment knob, to engage the potentiometer gear at the closed position.
3. Manually operate the actuator to the fully open position.

AUXILIARY SWITCHES


Auxiliary switches are available / refer to chart on next page.

NOTES:

1. All auxiliary switches have voltage-free contacts.
2. Size 6, 12, and 30 have double lobe cams. Sizes 130 and 180 has single lobe cams.
3. Main switches are one OPEN and one CLOSE switch.
4. Auxiliary switches are one OPEN and one CLOSE switch, which are fixed to activate 3° before the main switches.
5. Adjustable auxiliary switches are adjustable to any position.

INSTALLATION PROCEDURE:

1. Cut terminal strip marker to length needed with letters facing up.
2. Mount terminal strip and marker to switchplate using two #4-40 screws.



BRAY Series 70 Electric Actuator

Operation and Maintenance Manual

MODULATING CONFIGURATION FOR FAIL OPEN OR CLOSE BATTERY BACKUP UNIT (BBU)

OPERATION

If the external power fails, the actuator will switch to battery power, send a signal to the Servo Pro and drive the actuator to its fail-open or fail-close position.

The BBU has a 4.5 minute fail safe feature during which time if the actuator does not reach its end of travel, the BBU will shutdown until external power is reapplied. Once external power is reapplied, there is a 10 second time delay before the actuator goes to the position dictated by the control signal. Every time external power is reestablished, the 4.5 minute timer is reset.

AFFECTS ON S70 DESIGN

The BBU in no way modifies the basic operation of the Servo Pro. Under normal operations it simply passes power to operate the actuator and charge the batteries. In the event of power failure the BBU switches to the battery and supplies power to the Servo and fails open or close depending on the BBU configuration. In order to prevent battery discharge the unit shuts itself off after 4.5 minutes. Battery condition is checked hourly. The charging circuit is also temperature regulated to prevent over heating or over charging the batteries.

FAIL OPEN OR CLOSE CONFIGURATION Fail Open or Fail Close is determined by the wiring of the M and N terminal block to the Servo Pro mounted inside the S70 Actuator.

FAIL CLOSE Wire terminal M on the terminal block to the Close terminal block on the Servo Pro's Control Box Input. Refer to Figure 1 for wiring details.

FAIL OPEN Wire terminal M on the terminal block to the Open terminal block on the Servo Pro's Control Box Input. Refer to Figure 2 for wiring details.

ON/OFF CONFIGURATION FOR FAIL OPEN OR CLOSE BATTERY BACKUP UNIT (BBU)

OPERATION

If the external power fails, the actuator will switch to battery power, send a signal to the Servo Pro and drive the actuator to its fail-open or fail-close position. The BBU has a 4.5 minute fail safe feature during which time if the actuator does not reach its end of travel, the BBU will shutdown until external power is reapplied. Once external power is reapplied, there is a 10 second time delay before the actuator goes to the position dictated by the control signal. Every time external power is reestablished, the 4.5 minute timer is reset.




Figure 1




Figure 2

AFFECTS ON S70 DESIGN

The BBU in no way modifies the basic operation of the Servo Pro. Under normal operations it simply passes power to operate the actuator and charge the batteries. In the event of power failure the BBU switches to the battery and supplies power to the Servo and fails open or close depending on the BBU configuration. In order to prevent battery discharge the unit shuts itself off after 4.5 minutes. Battery condition is checked hourly. The charging circuit is also temperature regulated to prevent over heating or over charging the batteries.





Figure 3

FAIL OPEN OR CLOSE CONFIGURATION


Fail Open or Fail Close is determined by the jumper pin position on the BBU board labeled J1. Refer to Figure 3 for proper orientation.

CONFIGURATION	SIZE 6	SIZE 12 & 30	SIZE 180
1. ON/OFF (Intermittent Duty Motor) with Main Switches (Standard OPEN and CLOSE switches)	2 Switch 2 Cams Standard Assembly P/N	2 Switch 2 Cams Standard Assembly P/N	N/A
2. ON/OFF (Continuous Duty Motor) with Main Switches (Standard OPEN and CLOSE Switches)	2 Switch 2 Cams & Pot Gear Standard Assembly P/N	2 Switch 2 Cams & Pot Gear Standard Assembly P/N	N/A
3. ON/OFF (Intermittent Duty Motor) with Main and 1 set of Auxiliary Switches	4 Switch 2 Cams Kit P/N/ 70-0006-22980-536	4 Switch 2 Cams Kit P/N/ 70-0012-22960-536	N/A
4. ON/OFF (Continuous Duty Motor) with Main and 1 set of Auxiliary Switches	4 Switch 2 Cams & Pot Gear Kit P/N 70-006-22983-536	4 Switch 2 Cams & Pot Gear Kit P/N 70-0012-22960-536	4 Switch 2 Cams & Pot Gear Standard Assembly P/N
5. ON/OFF with Main, 1 set of Auxiliary, and 1 Adjustable Auxiliary Switches	5 Switch 3 Cams Kit P/N 70-0006-22983-536	6 Switch 3 Cams Kit P/N 70-0012-22964-536	N/A
6. ON/OFF with Main, 1 set of Auxiliary, and 1 set of Adjustable Auxiliary Switches	6 Switch 3 Cams Kit P/N 70-006-22984-536	6 Switch 3 Cams Kit P/N 70-0012-22964-536	N/A
7. ON/OFF with Main, 1 set of Auxiliary, and 2 adjustable Auxiliary Switches	N/A	6 Switch 4 Cams Kit P/N 70-0012-22961-536	6 Switch 4 Cams & Pot Gear
8. ON/OFF with Main, 1 set of Auxiliary, and 2 sets of adjustable Auxiliary Switches	N/A	8 Switch 4 Cams Kit P/N 70-0012-22962-536	N/A
9. Servo with Main, 1 set of Auxiliary, and 1 adjustable Auxiliary Switches	N/A	5 Switch 3 Cams & 1 Pot Gear Kit P/N 70-0012-22966-536	N/A
10. Servo with Main, 1 set of Auxiliary, and 2 Adjustable Auxiliary Switches	N/A	N/A	6 Switch 4 Cams & Pot Gear
11. ON/OFF with Main and 1 Adjustable Auxiliary Switch	3 Switches 3 Cams Kit P/N 70-0006-22988-536	3 Switch 3 Cams Kit P/N 70-0012-22968-536	3 Switch 3 Cams
12. Servo with Main and 1 Adjustable Auxiliary Switch	N/A	3 Switch 3 Cams & 1 Pot Gear Kit P/N 70-0012-22971-536	3 Switch 3 Cams 1 Pot Gear

BRAY Series 70 Electric Actuator Operation and Maintenance Manual



Wiring diagram for basic unit with C-Form (SPDT) travel switches.
(Drawn for actuator in its fully closed condition.)



Wiring diagram for unit with one set of "Voltage Free" C-Form (SPDT) open/close travel switches.
(Drawn for actuator in its fully closed condition.)

Actuator 'C'-Form Switches, SPDT


Size-6
V3-Sw



COM.

N.C.
N.O.


Size-12 & 30
V3-Sw with
Lever



COM.

N.C.
N.O.

BRAY Series 70 Electric Actuator Operation and Maintenance Manual



WARNING: TURN ALL POWER OFF PRIOR TO ADJUSTING DIP SWITCHES.

SWITCH	COMMAND INPUT			
	4-20 mA DC	0-5 VDC *	0-10 VDC	2-10 VDC
1	Off	On	On	On
2	Off	Off	On	On
3	Off	Off	Off	On
	OUTPUT			
	4-20 mA DC	0-5 VDC	0-10 VDC	2-10 VDC
4	Off	On	On	N/A
5	On	Off	Off	N/A
6	Off	On	Off	N/A
FORWARD ACTING		REVERSE ACTING		
7	Off	On		
FAIL IN LAST POSITION		FAIL ENABLE **		
8	Off	On		
FAIL CLOSE		FAIL OPEN		
9	Off	On		
TORQUE SWITCH ENABLE		TORQUE SWITCH DISABLE		
10	Off	On		

*To control servo with a remote potentiometer, set the Command Input to 0-5VDC (see Command Signal Connector section; page 8 Servo Pro Manual).

**Fail position is the position that the servo will travel to when the control signal is removed. It does not apply to 0-5VDC or 0-10VDC Command Signals.

BRAY Series 70 Electric Actuator

Operation and Maintenance Manual

I. ADJUST THE OPEN AND CLOSE SPEED OF YOUR ACTUATOR (THE FASTEST CLOSING SPEED OF YOUR ACTUATOR IS PRINTED ON THE LABEL OF THE UNIT):

1. Use the Close Speed trim pot to adjust the closing speed of your actuator (pot in the fully CCW position equals fastest close speed).
2. Use the Open Speed trim pot to adjust the opening speed of your actuator (pot in the fully CCW position equals fastest open speed).

II. CALIBRATE THE SERVO:

1. Manually position your actuator somewhere in mid position; away from the travel limits.
2. Disengage your handwheel (push it back in towards the actuator), hold down the Calibration push button for two seconds and release, the servo will begin to drive the actuator in the close direction and then in the open direction in order to save these limits to memory.
3. Following a successful calibration the servo's Status LED will begin to flash the normal operation code, an unsuccessful calibration will yield a Red-

Green-Red-Green flash immediately following the attempted calibration (for more information on the Status LED flash codes see the Status LED Flash Code Table).

STATUS LED

The "Status LED" is a bi-color LED which provides detailed information regarding the operation of the S70 Servo Pro. Table 2 below illustrates the different combinations of LED flash codes and their corresponding conditions. Following the table is a more descriptive explanation of the Flash Code. Whenever the LED is flashing green, regardless of the flash code, the servo will operate, but not necessarily optimally. Whenever the LED flash codes are RED, the servo will not operate. An example is an engaged handwheel, the Status LED will flash a single red flash code and will not operate.

TABLE 2: STATUS LED FLASH CODES

GREEN STATUS LED WARNING AND INFORMATION FLASH CODES:

#	INDICATION	REASON	SOLUTION
1	Steady Green Flash	Normal Operation	Servo Functioning Ok
2	2 Green Flashes	Calibration Defaults Loaded	Adjust travel limits, push autocalibration PB
3	3 Green Flashes	Reverse Acting Mode	If you would like your servo to not operate in reverse acting mode, set DIP switch 7 accordingly
4	4 Green Flashes	2-10VDC Input Command Signal Selected	If you require a different configuration, set DIP switches 1, 2, and 3 accordingly
5	1 Red Flashes	Handwheel engaged	Push the Handwheel in towards the actuator
6	2 Red Flashes	Command Signal Failure	Set DIP switches accordingly, send servo appropriate signal
7	3 Red Flashes	Feedback Pot Fault	Position the feedback Pot correctly, see Feedback Pot calibration
8	4 Red Flashes	Limit Switch Fault	Check wiring of limit switches, ensure that both switches are not tripped simultaneously
9	5 Red Flashes	Torque Switch Fault	Ensure that DIP switch 10 is positioned correct, check wiring of torque switches, reverse direction of actuator, correct over torque condition
10	6 Red Flashes	Feedback Pot Wired In Reverse	Correctly wire the Feedback Pot

Note: A flashing green LED provides status and warning information. The servo will operate normally in this state. Some flash codes indicate a warning, where the servo has recovered automatically such as the detection of an invalid calibration. In this case, a default calibration is automatically loaded that will allow the Servo to operate, but may not be a perfect match to the actuator. The servo should be re-calibrated as soon as possible.

BRAY Series 70 Electric Actuator Operation and Maintenance Manual

RECEPTACLES (QUICK CONNECTORS)

Unless otherwise specified, power receptacles will be 5-pin mini style standard duty with a black anodized aluminum finish. They conform to ANSI B93.55M except in wire color. Euro receptacles will be used for low power instrument and signal cable since they can be supplied shielded. Wiring diagrams for plug-in receptacles for either the **Bray Series 70** or the local control station will be provided as a separate diagram. Units ordered with pin connector receptacles factory installed are wired and tested. Cordsets which fit these receptacles may be ordered in several lengths.

RECEPTACLE KIT CONSISTS OF:

1. Receptacle(s), male pin and male thread $\frac{1}{2}$ "-NPT, in the qty., style and number of pins ordered

2. Reducing bushing $\frac{3}{4}$ " to $\frac{1}{2}$ " NPT for installation in size 12 - 180 and control stations
3. Wiring diagram (SK-# below)

TOOLS REQUIRED:

- For terminal wiring Screwdriver, $\frac{3}{16}$ " tip flat blade
- For Mini or Euro receptacle Wrench, 1"

INSTALLATION PROCEDURE:

1. Screw the receptacle into the actuator conduit entry using teflon tape or similar.
2. Wire to the terminal strip according to the wiring diagram or the field wiring requirements.

WIRING SCHEMATIC FOR OPTIONAL PIN CONNECTOR RECEPTACLES

REQUIREMENTS				RECEPTACLES REQ'D		NO L.C.S. ¹ DIAGRAM	WITH L.C.S. ¹ DIAGRAM
ON - OFF UNITS (INTERMITTENT OR CONTINUOUS)							
POWER	_____			ONE MINI		SK-960517	SK-960515
POWER	_____	POSITION INDICATION ²	_____	ONE MINI	ONE EURO	SK-960717	SK-960513
POWER	_____	POSITION INDICATION ³	_____	ONE MINI	ONE EURO	SK-960516	SK-960716 ⁵
POWER	_____		FEEDBACK POTENTIOMETER	ONE MINI	ONE EURO	SK-960718	SK-960720
POWER	_____	POSITION INDICATION ³	FEEDBACK POTENTIOMETER	ONE MINI	6-PIN EURO ⁴	SK-960719	N/A

Custom configurations are possible - consult the factory.

¹ L.C.S.: Local Control Station , WHICH implies mounted to the actuator

² Travel indication is wired to the supply voltage

³ Travel indication wiring is voltage free

⁴ A 6-pin EURO connector is required for this application, consult factory for price and availability.

⁵ The Local Control Station comes standard with 120 Volt lamp bulbs, for other voltages consult factory.

Note: the Control Station lights must be wired to the same voltage as the remote end of travel indication.

Euro receptacles use 22 AWG wire rated at 250V, 4 Amp. Pin configuration interfaces with European standards.

Mini receptacles use 18 AWG wire rated at 300 V, 9 Amp. Pin configuration conforms to ANSI B93.55M.

* For requirements beyond these ratings consult the factory.

BRAY Series 70 Electric Actuator Operation and Maintenance Manual

SPINNER

A spinner is available to ease and speed the manual override of the Bray Series 70 actuator. The 300 and 500 in.lb. units mount the spinner on a lever which screws onto the back of the handwheel. The 800 through 18000 in.lb. units mount the spinner on the rim of the handwheel. Note that care should be exercised in the use of spinner equipped handwheels. Rapid operation of the handwheel to close the valve may cause water hammer. Also, rapid travel into a travel stop may cause damage.

SPINNER KIT CONSISTS OF:

For 300 and 500 in.lb.

Spinner and lever assembly
Flat head socket cap screw,
#10-32UNF x 3/8

For 800 to 18000 in.lb. units


Socket head shoulder bolt,
1/4-20UNC x .75
Spinner handle

TOOLS REQUIRED:


- For socket head shoulder bolt and flat head cap screw
- Hex key, $\frac{1}{8}$ " for 300 and 500 in.lb.
- Hex key, $\frac{3}{16}$ " for 800 to 18000 in.lb.

INSTALLATION PROCEDURE:

- For 300 and 500 in.lb. units simply position the lever onto the back of the handwheel then screw the flat head cap screw in to place from behind.



- For 800 up to 18000 in.lb. units, put the socket head shoulder bolt through the spinner handle and screw it firmly into the handwheel rim.



LOCAL CONTROL STATION (SINGLE PHASE POWERED ACTUATORS)

Bray's local control station gives the user the ability to locally override the actuator electrically. The station is open / stop / close operation in the local control mode. Red and green end of travel indication lights are also provided. Depending on how it is wired the control station can be used on the on - off

units and the servo controlled modulating units. Optional key operated locking switches are available.

Note: The control station used with On - Off S70 and that used with modulating S70 have different contact blocks internally, the correct part number must be used to ensure you order the correct unit (see price sheet).

LOCAL CONTROL STATION KIT CONSISTS OF:


1. Local control station assembly
2. Four socket head cap screws, #10-24UNC x 4.50 long, for mounting the station to the actuator
3. A gasket for sealing the station to the actuator
4. Wiring diagram

TOOLS REQUIRED:


- For tapping control station mounting holes on actuator, #10-24UNC Tap.
- For wiring Screwdriver, $\frac{3}{16}$ " flat blade.
- For mounting and cover screws Hex key, $\frac{5}{32}$ "

INSTALLATION PROCEDURE:

1. Tap #10-24UNC holes using the cored holes on the side of actuator.
2. Adhere the gasket to the control box.
3. Mount the control box to the actuator using the 4 long socket head cap screws.
4. Wire the control box to the actuator in accordance to the wiring diagram provided. The local control station contains no terminal strips, and all wiring is direct to the switches and lights via 2" x $\frac{3}{4}$ " NPT holes in bottom of housing. Ordering the control station with optional pin connector receptacles will eliminate the necessity of field wiring. The units will be completely factory wired and tested.



Note: The inclined cover of the local control station can be mounted in any of its four symmetrical positions. If field wiring is required, first mount the base to the actuator, then remove the cover to gain access for wiring.



*Local Control Station requires a dedicated set of auxiliary switches for control station use only

APPENDIX A

BASIC TOOLS

COMMON TO ALL UNITS

Terminal connections, cam adjustment
All switches, terminal strip, torque switch plate
Switchplate screws, capacitor
Servo trimmer pots

Screwdriver, 1/4" tip flat tip blade
Screwdriver, No.1 phillips
Screwdriver, No.2 phillips
Screwdriver, 1/8" flat tip for trim pots

300-500 IN•LB UNITS

Mounting nuts
Cover captivated capscrews
Travel stop adjusting bolts
Travel stop jam nuts
Motor mount socket flat head capscrew
Motor mount socket head capscrew

Wrench, 1/2"
Hex key, 1/4"
Wrench, 7/16"
Wrench, 7/16"
Hex key, 3/32"
Hex key, 9/64"

800-1200 IN•LB UNITS

Mounting nuts (small pattern)
Mounting nuts (large pattern)
Cover captivated capscrews
Travel stop adjusting bolts
Travel stop nuts
Motor mount socket head capscrew

Wrench, 1/2"
Wrench, 3/4"
Hex key, 5/16"
Wrench, 9/16"
Wrench, 9/16"
Hex key, 5/32"

3000-6500 IN•LB UNITS

Mounting nuts, travel stop jam nuts
Cover captivated capscrews
Travel stop adjusting studs
Motor mount socket head shoulder bolt
Motor mount socket head cap screws

Wrench, 3/4"
Hex key, 3/8"
Wrench, 3/4"
Hex key, 5/32"
Hex key, 3/16"

13000-18000 IN•LB UNITS

Mounting nuts, travel stop jam nuts
Cover captivated capscrews
Travel stop adjusting studs
Motor mount socket head shoulder bolt
Motor mount socket head cap screws

Wrench, 3/4"
Hex key, 3/8"
Wrench, 15/16"
Hex key, 5/32"
Hex key, 3/16"

APPENDIX B

ACTUATOR TROUBLESHOOTING CHART

PROBLEM	POSSIBLE CAUSE	SOLUTIONS
Actuator does not operate	Override is engaged	Push handwheel in all the way
	Wiring is incorrect	Check wiring and power supply
	Actuator motor has reached its thermal shutdown temperature	Allow time to cool
Actuator operates in reverse directions	Field wiring is reversed	Rewire field wiring
Actuator does not fully close valve (or open valve)	Limit switches are depressed	Readjust travel limit switches
	Mechanical travel stop is stopping actuator	Adjust mechanical travel stops
	Valve torque requirement is higher than actuator output	Manually override out of seat, try angle seating or larger actuator
	Optional torque switches are activating	Valve torque exceeds actuator torque rating - consult factory
	Voltage power supply is low	Check power source.
Engaging override handwheel does not shut off motor	Override pin is corroded or damaged	Clean and check for smooth operation of the override switch pin
	Override switch is damaged	Replace switch
Disengaging override hand-wheel does not restart motor	Not completely disengaged	Push handwheel in as far as possible (no yellow showing)
	Override pin is damaged or and does not activate switch	Replace override pin
	Incorrect wiring of override switch	Check wiring
Motor runs but worm and gear segment do not	Worm gear segment is not meshing with worm	Remove switchplate and inspect, adjust travel stops to prevent gear disengaging
	Pin/Key on Worm/Motor drive gear sheared	Replace Pin/Key on drive gear
Corrosion inside unit	Condensation forming	Test heater wiring, should have constant power
	Water leaking in	Check all seals and possible water entry through conduit

S70 SERVO PRO TROUBLESHOOTING CHART Refer to the Servo Pro Operation Manual for more information.

PROBLEM	POSSIBLE CAUSE	SOLUTIONS
Actuator moves back and forth near setpoint (hunts)	Signal is fluctuating beyond deadband setting	Increase the deadband using the Deadband trim pot.
	Signal has interference	Shield signal from interference
Actuator does not travel fully open or fully closed	Travel limit switches are not set correctly	Set travel limit switches for 90° operation
	Servo DIP switches are not set correctly	See Quick Setup Instructions on page 5
	Mechanical travel stops are not set correctly	Set mechanical travel stops for 90° operation
Actuator motor does not run and green servo power light is off	Power is disconnected	Connect power
Actuator motor does not run and green servo power light is on	Limit switches or torque switches are triggered	Ensure that there is continuity between the two wires going to each switch
	Handwheel is engaged	Push handwheel in (disengage)
	Servo is not wired correctly	Check servo wiring to all points
	Motor has thermally tripped	Allow motor to cool down
Actuator does not properly respond to command signal	Potentiometer gear is not engaged	Engage and adjust pot. gear
	Command signal DIP switch selection is not correct	Set the DIP switches correctly
	Command signal polarity is incorrect	Wire the command signal correctly
Actuator runs in one direction only	Wiring is incorrect	Correct Wiring
	Potentiometer wired backwards	Reverse white and gray wires, see wiring diagram inside cover
	Limit switch or torque switch is triggered	Ensure that there is continuity between the wires coming from the switches. If your actuator has reached its travel limit, reverse direction. If one of your torque switches has tripped, reverse the actuator direction and correct the over torque condition.
	Command signal DIP switch selection is not correct	Set the DIP switches correctly

APPENDIX C

SERIES 70 SIZE: 003 - 005

ON / OFF


- | | |
|----------------------------------|-----------------------------|
| 1 POSITION INDICATOR COVER | 31 SPRING PLUNGER |
| 2 POSITION INDICATOR SEAL | 32 MANUAL OVERRIDE SLEEVE |
| 3 COVER FASTENING SCREWS | 33 RETAINING RING |
| 4 COVER | 34 HANDWHEEL |
| 5 O-RING | 35 HANDWHEEL WARNING LABEL |
| 6 INDICATOR ROTOR | 36 BUSHING |
| 7 CAM ASSEMBLY | 37 DRIVE GEAR |
| 8 TERMINAL STRIP | 38 DRIVE GEAR PIN |
| 9 TERMINAL STRIP TAG | 39 E-RING |
| 10 SCREW, PAN HEAD | 40 OUTPUT WORM GEAR SEGMENT |
| 11 WIRE ASSEMBLY | 41 GEARMOTOR |
| 12 LIMIT SWITCH (SPDT FORM C) | 42 DOWEL PIN |
| 13 HEATER MOUNTING BRACKET | 43 SOCKET HEAD CAP SCREW |
| 14 HEATER | 44 LOCK WASHER |
| 15 SWITCH PLATE | 45 TRAVEL STOP BOLT |
| 16 FLAT HEAD SCREW | 46 LOCK NUT |
| 17 OVERRIDE SWITCH (SPDT FORM C) | 47 NYLON FLAT WASHER |
| 18 OVERRIDE SWITCH TRIGGER PIN | 48 OVERRIDE SPRING PIN |
| 19 GREEN GROUND SCREW | 49 CAPACITOR |
| 20 GROUND CUP WASHER | 50 FIBER WASHER |
| 21 CONDUIT WIRE DEFLECTOR | 51 BASE |
| 22 THRUST WASHER | 52 INSULATOR |
| 23 THRUST ROLLER BEARING | 53 CONDUIT PLUG |
| 24 DISC SPRING | 54 NAME TAG |
| 25 WORM | 55 |
| 26 SPRING PIN | 56 TORQUE SWITCH COVER |
| 27 MANUAL OVERRIDE BUSHING | 57 WORM SHAFT SPACER |
| 28 WORM SHAFT | 58 |
| 29 OVERRIDE DRIVE PIN | |
| 30 MANUAL OVERRIDE SHAFT | |

Items 13, 14 and 10C are optional.

When optional torque switches are required:

Item 23 is installed and quantity of items 22 & 24 increased.

Items 56 & 57 are installed in units when torque switches are not required.



SERIES 70 SIZE: 008 - 012 - 020

ON / OFF


- | | |
|----------------------------------|-----------------------------|
| 1 POSITION INDICATOR COVER | 30 MANUAL OVERRIDE SHAFT |
| 2 POSITION INDICATOR SEAL | 31 SPRING PLUNGER |
| 3 COVER FASTENING SCREWS | 32 MANUAL OVERRIDE SLEEVE |
| 4 COVER | 33 RETAINING RING |
| 5 O-RING | 34 HANDWHEEL |
| 6 INDICATOR ROTOR | 35 HANDWHEEL WARNING LABEL |
| 7 CAM ASSEMBLY | 36 BUSHING |
| 8 TERMINAL STRIP | 37 DRIVE GEAR |
| 9 TERMINAL STRIP TAG | 38 DRIVE GEAR PIN |
| 10 SCREW, PAN HEAD | 39 E-RING |
| 11 WIRE ASSEMBLY | 40 OUTPUT WORM GEAR SEGMENT |
| 12 LIMIT SWITCH (SPDT FORM C) | 41 GEARMOTOR |
| 13 HEATER MOUNTING BRACKET | 42 DOWEL PIN |
| 14 HEATER | 43 SOCKET HEAD CAP SCREW |
| 15 SWITCH PLATE | 44 LOCK WASHER |
| 16 FLAT HEAD SCREW | 45 TRAVEL STOP BOLT |
| 17 OVERRIDE SWITCH (SPDT FORM C) | 46 LOCK NUT |
| 18 OVERRIDE SWITCH TRIGGER PIN | 47 NYLON FLAT WASHER |
| 19 GREEN GROUND SCREW | 48 OVERRIDE SPRING PIN |
| 20 GROUND CUP WASHER | 49 CAPACITOR |
| 21 CONDUIT WIRE DEFLECTOR | 50 FIBER WASHER |
| 22 THRUST WASHER | 51 BASE |
| 23 THRUST ROLLER BEARING | 52 INSULATOR |
| 24 DISC SPRING | 53 CONDUIT PLUG |
| 25 WORM | 54 NAME TAG |
| 26 SPRING PIN | 55 SWITCH SPACER |
| 27 MANUAL OVERRIDE BUSHING | 56 TORQUE SWITCH COVER |
| 28 WORM SHAFT | 57 WORM SHAFT SPACER |
| 29 OVERRIDE DRIVE PIN | 58 |

Items 13, 14 and 10C are optional.

When optional torque switches are required:

Item 23 is installed and quantity of items 22 & 24 increased.

Items 56 & 57 are installed in units when torque switches are not required.



SERIES 70
SIZE: 030 - 050 - 065

ON / OFF


- | | |
|----------------------------------|-----------------------------|
| 1 POSITION INDICATOR COVER | 30 MANUAL OVERRIDE SHAFT |
| 2 POSITION INDICATOR SEAL | 31 SPRING PLUNGER |
| 3 COVER FASTENING SCREWS | 32 MANUAL OVERRIDE SLEEVE |
| 4 COVER | 33 RETAINING RING |
| 5 O-RING | 34 HANDWHEEL |
| 6 INDICATOR ROTOR | 35 HANDWHEEL WARNING LABEL |
| 7 CAM ASSEMBLY | 36 BUSHING |
| 8 TERMINAL STRIP | 37 DRIVE GEAR |
| 9 TERMINAL STRIP TAG | 38 DRIVE GEAR KEY |
| 10 SCREW, PAN HEAD | 39 E-RING |
| 11 WIRE ASSEMBLY | 40 OUTPUT WORM GEAR SEGMENT |
| 12 LIMIT SWITCH (SPDT FORM C) | 41 GEARMOTOR |
| 13 HEATER MOUNTING BRACKET | 42 DOWEL PIN |
| 14 HEATER | 43 SOCKET HEAD CAP SCREW |
| 15 SWITCH PLATE | 44 LOCK WASHER |
| 16 FLAT HEAD SCREW | 45 TRAVEL STOP BOLT |
| 17 OVERRIDE SWITCH (SPDT FORM C) | 46 LOCK NUT |
| 18 OVERRIDE SWITCH TRIGGER PIN | 47 NYLON FLAT WASHER |
| 19 GREEN GROUND SCREW | 48 OVERRIDE SPRING PIN |
| 20 GREEN CUPWASHER | 49 CAPACITOR |
| 21 CONDUIT WIRE DEFLECTOR | 50 FIBER WASHER |
| 22 THRUST WASHER | 51 BASE |
| 23 THRUST ROLLER BEARING | 52 INSULATOR |
| 24 DISC SPRING | 53 CONDUIT PLUG |
| 25 WORM | 54 NAME TAG |
| 26 SPRING PIN | 55 SWITCH SPACER |
| 27 MANUAL OVERRIDE BUSHING | 56 TORQUE SWITCH COVER |
| 28 WORM SHAFT | 57 |
| 29 OVERRIDE DRIVE PIN | 58 |

Items 13, 14 and 10C are optional.

When optional torque switches are required:

Item 23 is installed and quantity of items 22 & 24 increased.

Items 56 & 57 are installed in units when torque switches are not required.




**SERIES 70
SIZE: 130-180 For 3:1 Gear Box**

ON / OFF

- | | | |
|----|----|--------------------------|
| 1 | 30 | MANUAL OVERRIDE SHAFT |
| 2 | 31 | SPRING PLUNGER |
| 3 | 32 | MANUAL OVERRIDE SLEEVE |
| 4 | 33 | RETAINING RING |
| 5 | 34 | HANDWHEEL |
| 6 | 35 | HANDWHEEL WARNING LABEL |
| 7 | 36 | BUSHING |
| 8 | 37 | DRIVE GEAR |
| 9 | 38 | DRIVE GEAR KEY |
| 10 | 39 | E-RING |
| 11 | 40 | OUTPUT WORM GEAR SEGMENT |
| 12 | 41 | GEARMOTOR |
| 13 | 42 | DOWEL PIN |
| 14 | 43 | SOCKET HEAD CAP SCREW |
| 15 | 44 | LOCK WASHER |
| 16 | 45 | TRAVEL STOP BOLT |
| 17 | 46 | |
| 18 | 47 | |
| 19 | 48 | OVERRIDE SPRING PIN |
| 20 | 49 | CAPACITOR |
| 21 | 50 | FIBER WASHER |
| 22 | 51 | BASE |
| 23 | 52 | INSULATOR |
| 24 | 53 | CONDUIT PLUG |
| 25 | 54 | NAME TAG |
| 26 | 55 | SWITCH SPACER |
| 27 | 56 | |
| 28 | 57 | |
| 29 | 58 | TORQUE SWITCH ASSEMBLY |



Items 13, 14 and 10C are optional.



SERIES 70 **3:1 GEAR BOX**

ON / OFF

- 59 INDICATOR FASTENING SCREW
- 60 POSITION INDICATOR PLATE
- 61 POSITION INDICATOR GASKET
- 62 ACTUATOR/GEAR BOX GASKET
- 63 COVER
- 64 TRAVEL STOP BOLT
- 65 LOCK NUT
- 66 NYLON FLAT WASHER
- 67 O-RING
- 68 ACTUATOR/GEAR BOX FASTENING SCREW
- 69 OUTPUT GEAR BEARING
- 70 IDLER/INPUT GEAR BEARING
- 71 COVER GASKET
- 72 INPUT GEAR KEY
- 73 INPUT GEAR
- 74 IDLER GEAR
- 75 OUTPUT GEAR
- 76 BASE
- 77 LOCK WASHER
- 78 BASE FASTENING SCREW





 **Bray**® **CONTROLS**

A Division of BRAY INTERNATIONAL, Inc.

13333 Westland East Blvd. Houston, Texas 77041

281-894-5454 FAX 281/894-9499 www.bray.com

Bray® is a registered trademark of BRAY INTERNATIONAL, Inc.

© 2011 Bray International. All rights reserved. OM-70-001 06-2011