

Model CY-50-CA-"D"-"O" Dual-Chamber, Starved-Air, Oxygen-Controlled Incinerator System







Operating and Maintenance Manual

Westland Environmental Services Inc. 20204 110 Ave. NW Edmonton, Alberta Canada T5S 1X8 780 447 5052

info@westlandenvironmental.com

TABLE OF CONTENTS

1	Intr	oduction	1 -
2	Prir	nciples of waste incineration	1 -
	2.1	Combustion	1 -
	2.2	Why incinerate waste?	2 -
	2.3	Waste components	2 -
	2.4	Heating Value	
	2.5	Different Expressions for Heating Value	4 -
	2.6	Examples of waste characteristics	
	2.7	Incinerator Capacity and Load Size	
3	Sys	tem Description	7 -
	3.1	Nomenclature for Different Models	
	3.2	Overview	7 -
	3.3	Description of system components	9 -
	3.4	Primary Chamber Section	
	3.5	Secondary Chamber Section	
	3.6	Control Panel Section	15 -
4	Ope	eration and Maintenance	20 -
	4.1	Safety equipment and protocol	20 -
	4.2	Routine inspection and maintenance	
	4.3	Waste batch preparation	21 -
	4.4	Ash removal	21 -
	4.5	Pre-operational checks	22 -
	4.6	Start-up: see Figure 13	22 -
	4.7	Waste charging: see Figure 14	23 -
	4.8	Burn-Down: see Figure 15	
	4.9	Cool-down	24 -
	4.10	Maintenance and Inspection	24 -
	4.11	Trouble Shooting	25 -
	4.12	Auxiliary Fuel Consumption Rate	26 -
5	Ma	nual Mode: Operating the Incinerator without the Control System	27 -
	5.1	Butterfly Valve Adjustments for Manual Mode Operation	27 -
	5.2	Modification to Operation during Manual Mode	28 -
6		rranty	30 -
7	Apı	pendix A: Information sheets and Manuals	32 -

LIST OF TABLES

Table 1 Organization of Manual	1 -
Table 2 Classification and Properties of Common Wastes	
Table 3 High Heating Values (Approximate) of Common Waste Components	
Table 4 Proximate Composition of Various Materials	
Table 5 Components in the Primary Chamber Section	
Table 6 Components in the Secondary Chamber Section	
Table 7 Components in the Control Panel Section	
Table 8 Recommended Inspections	
Table 9 Trouble Shooting Guidelines	
Table 10 Waste Charging in Manual Mode	
Tuble 10 Waste Charging in Marian Mode	
LIST OF FIGURES	
Figure 1 Schematic Diagram of Incineration Process	
Figure 2 The Concept of Heating Value	
Figure 3 Different Bases for Expressing Heating Value (HV)	4 -
Figure 4 Schematic of the Incineration System	8 -
Figure 5 View of the Incinerator Sections	10 -
Figure 6 Components in the Primary and Secondary Chamber Sections (1)	13 -
Figure 7 Components in the Primary and Secondary Chamber Sections (2)	14 -
Figure 8 Overview of Control Panel, showing the Different Sections	16 -
Figure 9 Sub-Section A: Indicating Lights	17 -
Figure 10 Sub-Sections B and C: Controllers for Burners and Blowers	18 -
Figure 11 Sub-Section D: Temperature Controllers; E: PLC Indicating Lights and	
Control Button	19 -
Figure 12 Steps in the Operation of the Incinerator	20 -
Figure 13 Procedure for Start-Up	
Figure 14 Procedure for Waste Charging	
Figure 15 Procedure for Burn Down	
Figure 16 Consumption Rates of Propane and Diesel	
Figure 17 Butterfly Valve Adjustment for Manual Mode Operation	

1 INTRODUCTION

Thank you for selecting Westland Environmental Services Inc. (Westland) to provide you with a reliable, proven and cost-effective system to manage your waste in an environmentally sound manner. This manual has been prepared to allow you to operate and maintain the system safely and efficiently, thereby ensuring its proper operation and continued use for a long period of time.

It also contains information on the combustion process. We believe that understanding the basic principles would make you more knowledgeable, and hence a better operator. Table 1 outlines the contents of this manual, of which Sections 3 and 4 are the required minimum reading.

Table 1 Organization of Manual

Section	Title				
Number	Brief Description				
2	Principles of waste incineration				
	What incineration or combustion process is, why waste is incinerated and the				
	components of a waste, including heating value, and how waste properties affect				
	incinerator operation.				
3	System Description				
	The components, their designs and their functions are described				
4	Operation and Maintenance				
	How to operate and maintain the system, including safety equipment to be used.				
5	Manual Mode: Operating the Incinerator without the Control System				
	How to operate the system when the oxygen control system is out of order.				
6	Warranty				
	Terms of the warranty				

2 PRINCIPLES OF WASTE INCINERATION

2.1 Combustion

Combustion, burning, incineration, and thermal oxidation all denote the same process, which is the reaction of a "combustible" matter with oxygen that occurs at temperatures higher than the ignition temperature ¹ of that matter. The reaction is exothermic, meaning that it generates heat in the form of hot gases.

¹ Below the ignition temperature combustion does not take place. Consider, for example, gasoline or wood: it has to be "ignited" for combustion to take place. That is, the temperature in some portion of the matter must be brought up to the ignition temperature for combustion to start.

In the case of waste, it may also contain non-combustible matter which does not react with oxygen. In waste incineration, the non-combustible component ends up as ash and a small portion of it is also present in the hot gas in the form of particulate matter or dust.

Figure 1 shows schematically the process of waste incineration. The oxygen used comes from air, which contains 21% of oxygen by volume, and the hot gas is typically referred to as flue gas or stack gas.




Figure 1 Schematic Diagram of Incineration Process

2.2 Why incinerate waste?

The main purpose is to reduce the mass and volume for final disposal. Another important reason, since the waste may contain pathogenic, infectious or toxic materials, is to "detoxify" it by the high temperature process. In remote areas where wildlife is present, scavenging can be prevented by incineration.

In some cases, typically in large-scale operation, incineration is used to recover the energy contained in the waste in the form of electricity, steam, hot fluids or hot air. In other cases, valuable materials can be recovered from the ash, or the ash as a whole can be used for soil amendment or as a construction material.

2.3 Waste components

There are different ways of characterizing waste, depending on the purpose for doing it. Here, it is sufficient to characterize the components as follows: ²

A. Water is an important component because in incineration it has to be evaporated first, which requires a lot of energy, ³ which in turn, has the effect of lowering the temperature of the flue gas.

B. Combustible is the component that reacts with oxygen and releases heat in the process. ⁴ The higher the combustible content in the waste, the more air per kg of waste is needed for incineration.

 3 It takes ~ 2.3 MJ (2200 BTU or 90 cc of propane or 60 cc of diesel) to evaporate 1 L or 1 kg of water. This is referred to as the latent heat of evaporation.

² This is referred to as proximate analysis. Another method is elemental analysis, which produces the elemental composition (C, H, O, N, S, Cl ...) of the waste.

This component can be further classified as:

- (i) Volatile, which is released to the gas phase when the combustible matter is heated without the presence of oxygen, and
- (ii) Fixed carbon which remains in the solid waste after the volatile has been released. This is often referred to as charcoal.
- **C. Non-combustible** is the component that does not react with oxygen. ⁵ As previously mentioned, this forms ash, and some of it is entrained in the flue gas in the form of particulate matter or dust. The higher the non-combustible content in the waste, the less quantity of waste that can be incinerated without removing ash from the combustion chamber. Note also if the waste contains metals, such as lead and cadmium, these metals will be present in the ash as well as in the flue gas, in the form of particulate matter and vapour.

2.4 Heating Value

Heating value, calorific value and heat of combustion are synonyms that quantify the heat released by the combustible component in the waste upon complete combustion. An understanding of the concept can be gained from the hypothetical processes shown in Figure 2.




Figure 2 The Concept of Heating Value

A measured mass of dry waste and a sufficient amount of oxygen, at room temperature, are ignited, and the resulting hot flue gas is passed through a heat exchanger, where heat is extracted until the flue gas is brought back to room temperature. Let M be the mass (kg) of the dry waste fed, and H (MJ) the heat extracted from the heat exchanger. The heating value of the dry waste is H/M (MJ/kg).

⁴ The term "organic" is also used, which is strictly incorrect in that some "inorganic" elements or compounds are combustible, such as carbon, sulphur, ammonia and carbon monoxide.

⁵ The terms "ash" and "inorganic" are also used. Note that the latter is inaccurate as explained previously.

2.5 Different Expressions for Heating Value

Two different values are reported in the literature (a) "high" or "gross", and (b) "low" or "net". The former corresponds to the case where the moisture in the flue gas is condensed, and hence the high or gross heating value *includes* the latent heat of evaporation of the water formed in combustion (see Footnote 3). The latter excludes the latent heat evaporation. The low or net heating value thus represents the maximum available energy that can be recovered from the flue gas without condensation.

To be noted also is the basis on which the heating value is expressed, which can be (a) as fired, (b) dry basis or (c) ash free. The distinction is illustrated in Figure 3. An understanding of the different bases can be gained by noting that heating value is a property of only the combustible component in the waste. Water and the non-combustible component simply "dilute" the heating value. In terms of incinerator operation, the relevant basis is "as fired".




Figure 3 Different Bases for Expressing Heating Value (HV)

2.6 Examples of waste characteristics

Proximate compositions and heating values of commonly found wastes are given in Table 2.

Table 2 Classification and Properties of Common Wastes

				Weight %		
Type*	Description Components		Moist	Comb	Non-C	HHV (A/F)
0	Trash	Paper, cardboard, cartons wood boxes and combustible floor sweepings from commercial and industrial activities. Up to 10% by weight of plastic bags, coated paper, aminated paper, treated corrugated cardboard, oily rags and plastic or rubber scraps.		85%	5%	19.7
Ι	Rubbish	Trash + Type 3 (up to 20%)	25%	65%	10%	15
2	Refuse	Rubbish and Garbage	50%	43%	7%	10
3	Garbage	Animal and vegetable wastes, restaurants, hotels, markets, institutional, commercial and club sources	70%	25%	5%	5.8
4	Animal/ Pathological	Carcasses, organs, hospital and laboratory, abattoir, animal pound, veterinary sources	85	10	5	2.3

Notes:

Moist = moisture, Comb = Combustible, Non-C = Non-combustible, HHV = High Heating Value, A/F = As Fired

 $[\]mbox{\ensuremath{^{\star}}}$ In some cases Roman numerals are used. That is Types 0, I, II, III and IV

2.7 Incinerator Capacity and Load Size

Incinerator capacity is dependent on waste composition. For a given mass, the amount of air required for complete combustion increases with increasing heating value. Hence, for a given incinerator which delivers a given flow rate of combustion air, its capacity for waste burning in kg/h decreases with increasing heating value of the waste, or to put it in opposite way, it, increases with decreasing heating value.

Another important consideration is the size of the batch loaded to the incinerator. The higher the heating value, the smaller (lighter) the load should be. Otherwise, the insufficient amount of air will generate black smoke.

Unfortunately, waste composition is usually not known. Nevertheless there may be indications on the basis of the components present. To assist in getting a qualitative estimate of the heating value of a batch of waste, the heating values of common "generic" waste components are shown in Table 3.

Table 3 High Heating Values (Approximate) of Common Waste Components

Component	MJ/kg A/F *	Component	MJ/kg A/F *
Kerosene, Diesel	44	Leather	16
Plastics	46	Wax paraffin	44
Rubber, Latex	23	Rags (linen, cotton)	17
Wood	18	Animal fats	39
Paper	17	Citrus rinds	4
Agricultural waste	17	Linoleum	25

^{*} A/F: As Fired

Another important waste component is the volatile content in the waste. Table 4 shows the proximate components of various materials and wastes.

In general, this component is responsible for smoke generation. Therefore, as in the case with heating value, the higher the volatile content, the smaller the load that should be charged to the incinerator.

Table 4 Proximate Composition of Various Materials

	Volatile	Moisture	FC	Ash	FC/V
Material	%wt	%wt	%wt	%wt	-
Coal (bit.)	30	5	45	20	1.5
Peat	65	7	20	8	0.3
Wood	85	6	8	1	0.1
Paper	75	4	11	10	0.15
Sewage sludge	30	5	20	45	0.66
MSW	33	40	7	20	0.21
RDF	60	20	8	12	0.13
PDF	73	1	3	13	0.04
TDF	65	2	30	3	0.46
PE,PP,PS	100	0	0	0	0
Plastics + Colour	98	0	0	2	0
PVC	93	0	7	0	0.08

Notes: FC: Fixed Carbon; FC/V: Ratio of Fixed Carbon to Volatile

(bit: bituminous; MSW: municipal solid waste; RDF: refuse derived fuel; PDF: packaging DF: TDF: Tire DF; PE: polyethylene; PP: polypropylene; PS: polystyrene; PVC: polyvinyl chloride)

3 SYSTEM DESCRIPTION

3.1 Nomenclature for Different Models

This series of incinerator is designated by

$$CY-(nn)-CA-(x)-O$$

where **nn**: a number denoting the nominal capacity of the incinerator in kg/h;

x: a letter denoting the auxiliary fuel used, denoted as follows:

D for diesel; P for propane and N for natural gas

For example, **CY-100-CA-D-O** denotes a 100 kg/h unit using diesel as auxiliary fuel.

3.2 Overview 6

Regardless of the model of your incinerator, the main components are similar. Figure 4 shows a schematic diagram of the incineration system. It consists of a **Primary Chamber** and a **Secondary Chamber**, which are connected by a "flame-port". Combustion air to the

⁶ Bolded words correspond to those used in Figure 4

primary chamber is delivered by the **under-fire air blower**, and to the fame-port by the **flame-port air blower**. **Aux**iliary **burners** are provided for start-up and to maintain the minimum temperatures set in the primary and secondary chambers.

Thermocouples are used to measure the temperatures in the primary and secondary chambers, the outputs of which are used by on-off **Omron controllers** which regulate the operation of the auxiliary burners.

The oxygen concentration in the secondary chamber is measured by an **oxygen probe**, the output of which is used by a programmable logic controller (**PLC**) to regulate the flows of the under-fire and flame-port air. This control minimizes the occurrence of black smoke generation, and will ensure that black smoke is not generated provided the size of the waste load is not too large. The PLC also informs the operator when the combustion of a batch has been completed, and hence the next batch can be charged.

Waste is charged manually and intermittently via the **waste charging door (1)**, and ash is removed manually and batch-wise after previous operation via the **ash removal door (2)**. This door is also used to rake the waste in the primary chamber after several loads have been charged, which is necessary to expose the fixed carbon component in the waste to the under-fire air.




Figure 4 Schematic of the Incineration System

3.3 Description of system components

For convenience, the system has been grouped into sections, as shown in Figure 5. In each section, the components are shown in subsequent photographs. Each component is coded with a number and a prefix corresponding to the section to which it belongs. *These codes are unique and will be used in later sections on operation, maintenance and trouble shooting.* The following Tables contain all the components in the system, their codes and brief descriptions of their functions.

Information on components that are not manufactured in-house, such as blowers and burners, is given in the accompanying binder. Please consult the corresponding manuals for details of operation and maintenance.




Figure 5 View of the Incinerator Sections

3.4 Primary Chamber Section

The components are listed in Table 5, and the photographs are shown in Figure 6 and Figure 7.

Table 5 Components in the Primary Chamber Section


Code	Component	Description	Function		
PC1	Primary Chamber	In-house made. Inside Vol: 0.57 m ³	Pyrolysis and gasification		
	·	Refractory: 10.8 cm; Insulation 5.1 cm	Combustion of fixed carbon		
PC2	Charge Door	In-house made. Door opening: 67 cm in	Load waste to primary chamber		
		diameter			
PC3	Ash Door	In-house made. Door opening: approximately	Raking and ash removal		
		67 cm x 40 cm			
PC4a	Contact Switch	SquareD ZCKJ1H7	Turn off primary chamber burner when charge		
			door is opened		
PC4b		Same as PC4a for ash door			
PC5	Auxiliary Burner	Becket WIC-201; 630,000 Btu/h; 4.5 USG/h	Start-up and maintains a minimum temperature		
PC6	Under-fire Air	AMU 245	Combustion air supply to primary chamber		
	Blower				
PC7	Butterfly Valve	V51E-1075	Regulate under-fire air flow		
PC8	Actuator	Neptronics BBMF 2000A	Adjust position of butterfly valve		
PC9	Under-fire Plenum	In-house made	Distribute under-fire air in primary chamber		
PC10	Thermocouple	Wika (sheathed)	Measure temperature in primary chamber		

3.5 Secondary Chamber Section

The components are listed in Table 6, and the photographs are shown in Figure 6 to Figure 7.

Table 6 Components in the Secondary Chamber Section

Code	Component	Description	Function
SC1	Secondary Chamber	In-house made. Inside Vol: 0.84 m ³ ,	Combustion of combustible gases and soot generated in
		Refractory: 10.8 cm; Insulation 5.1 cm	primary chamber
SC2	Flame-port Plenum	In-house made.	Mixing of combustible gases and flame-port air
SC3	Flame-port Air	AMU 400	Combustion air supply to flame-port plenum
	Blower		
SC4	Butterfly Valve	V51E-1075	Regulate under-fire air flow
SC5	Actuator	Neptronics BBMF 2000A	Adjust position of butterfly valve
SC6	Thermocouple	Wika (sheathed)	Measure temperature in secondary chamber
SC7	Oxygen Probe	Marathon	Measure oxygen concentration in secondary chamber
SC8	Auxiliary Burner	Becket WIC-201; 770,000 Btu/h;	Start-up and maintain minimum set temperature
	·	5.5 USG/h	
SC9	Sight glass	In-house made	Observation of secondary chamber
SC10	Stack	In-house made	Dispersal of flue gas







Figure 6 Components in the Primary and Secondary Chamber Sections (1)






Figure 7 Components in the Primary and Secondary Chamber Sections (2)

3.6 Control Panel Section

The components are listed in Table 7. Figure 8 shows a photograph of the whole control panel, which has been divided into sub-sections marked A, B, C, D and E, each of which is shown in Figure 9 to Figure 11

Table 7 Components in the Control Panel Section

Code	Label	Function	
	Sub-S	ection A: Indicating Lights (ON_OFF). Figure 9	
CP1	Burner Blower #1 and #3	#1: Motors for burners in primary chamber: PC5	
	#3: Motor for burner in secondary chamber: SC8		
	Under-fire Blower	Under-fire air blower: PC6	
	Flame-port Blower	Fame-port air blower: SC3	
CP2	Primary Chamber	Flames in auxiliary burners indicated on the labels	
	Secondary Chamber		
	Sub-Sections B and C: M	ain Controller and Controllers for Burners and Blowers. Figure 10	
CP3	Blower Timer	Turn to connect power to blowers and burners for the specified time periods	
	Burner Timer		
CP4	Blowers Start and Stop	Turn ON and OFF all blowers or burners while time has not expired in Timers CP3	
	Burners Start and Stop	(Note: These buttons are inactive when the timers are OFF, that is, at zero time)	
CP5	Oxygen Probe Air Flow	Adjust to 40 cc/min.	
	Rotameter		
	Sub-Section D: (Omron Temperature Controllers and Indicators. Figure 11	
CP6	Primary Chamber T.C.	Temperature displays and control of minimum temperatures in primary and secondary	
	Secondary Chamber T.C.	chambers by setting adjustable set points (OMRON E5CN)	
CP7	E-STOP	Emergency stop:	
		Push to activate: disconnects main power	
		Twist right to connect main power	
	Sub-Section I	E: PLC Indicating Lights and Control Button. Figure 11	
CP8	Red Indicating Light	FLASHING: PLC is NOT ready since temperature is too low for oxygen probe	
		ON: PLC is ready	
CP9	Green Indicating Light	Indicating Light • ON: Combustion from previous batch is complete: READY to load a new batch	
		 OFF: Combustion is taking place. Do NOT load. Wait. 	
CP10	Green Button	PRESS immediately after a loading: Activates PLC control	




Figure 8 Overview of Control Panel, showing the Different Sections




Figure 9 Sub-Section A: Indicating Lights [CP1 and CP2 in Table 7]






Figure 10 Sub-Sections B and C: Controllers for Burners and Blowers [CP3, CP4 and CP5 in Table 7]





Figure 11 Sub-Section D: Temperature Controllers; E: PLC Indicating Lights and Control Button [CP6 to CP10 in Table 7]

4 OPERATION AND MAINTENANCE

The operation of the incinerator can be described by distinct sequential steps as shown in Figure 12. In addition there are additional necessary steps which involve safety, routine inspection and waste batch preparation, which will be first described.




Figure 12 Steps in the Operation of the Incinerator

4.1 Safety equipment and protocol

The following personal protective equipment should be used while operating the incinerator system:

- Long sleeved shirt and long pants;
- Long cuffed, puncture resistant gloves;
- CSA approved, Grade 1 safety footwear;
- CSA/ANSI approved safety glasses. The personal protective equipment related to specific tasks is listed below:
- Ash removal and handling: NIOSH N85 respirator

Waste charging: (i) heat protective clothing and gloves, and (2) CSA/ANSI approved full face shield.

The hazards that could be encountered arise from the following (not in any order of importance):

- Contact with waste (infectious or toxic components, or sharps);
- Exposure to heat, from contact with hot surface or radiation from the primary combustion chamber when the waste charging door or ash removal door is opened.

Therefore, the general precautionary actions include:

- Not opening waste batches
- Not touching hot surfaces, and minimum exposure to heat radiation through open doors (charging and ash doors while combustion is taking place).
- Wearing appropriate personal protective equipment for charging waste and raking the primary chamber, AND minimize the time for those tasks.

4.2 Routine inspection and maintenance

- Check fuel lines for leak and check connections
- Check spark arrestor to ensure no plugging
- During ash removal (see later section):
 - o Inspect refractory for large cracks (not expansion cracks)
 - o Check combustion air hole for plugging
 - o Inspect door gaskets for damages

4.3 Waste batch preparation

The following cautionary notes should be followed:

- NO explosives, aerosol cans or sealed containers containing combustible liquids
- Make sure that every batch can go through the waste charging door easily, regardless of its weight. If others prepare the batches, the operator should tell them about the maximum batch size.
- Do not open batches and "rearrange" the contents.

4.4 Ash removal

Typically the ash from previous operation was left to cool, and ash removal is done first prior to current operation.

- Make sure combustion chamber is sufficiently cool. ⁷
- (Do NOT spray water into the combustion chamber)
- While removing ash, avoid plugging the combustion air holes and damaging the burner tip
- Use non-combustible container

⁷ The use of a "remote" thermometer is recommended to check the temperatures in the various places in the primary chamber.

- Minimize dust generation
- Light water spraying on ash in the container is recommended to minimize dust generation
- Dispose of ash as specified in the guidelines or regulations

4.5 Pre-operational checks

- When diesel or propane is used: check fuel tank to make sure enough fuel (see Figure 16 for estimates of fuel consumption, depending on burner size and length of operation)
- Open fuel valve
- Re-check that the combustion chamber is empty and combustion air holes are clear
- Check power connection
- When diesel is used, bleed the diesel lines to the burners if necessary

4.6 Start-up: see Figure 13

Note: Temperatures in Steps 8 and 9 may be regulated: If so, SET TO THE REGULATED VALUES




Figure 13 Procedure for Start-Up

4.7 Waste charging: see Figure 14





Figure 14 Procedure for Waste Charging

Additional Notes to Figure 14:

- ** : The main danger is from exposure to heat radiation, and the waste batch catching fire before it is inside the primary chamber. Precautionary steps include: (a) Wear proper PPE, (b) Make sure waste batch can go through the charge door easily, (c) open door, charge waste and close door as quickly as possible.
- *** : The time for complete combustion varies, depending on batch size, weight and composition. More than 30 minutes would be unusual. Check burning conditions from ash door or charge door. Rake if necessary [Note Step 8 above].

4.8 Burn-Down: see Figure 15



When the LAST batch has been charged, and the indicator light 2 is ON (steady), indicating readiness for the non-existent batch:

- 1. Rake primary chamber.
- 2. Turn BLOWER TIMER to ~ 3 hours *
- 3. Turn BURNER TIMER to 0.5 to 1 hour
- 4. Wait.
- 5. When burner time period has elapsed, then shut down fuel valve.

BURN-DOWN DONE

Note: *: The actual time depends on how much and what kind of waste has been charged. The rule-of-thumb is

Burn-Down Time (hours) = 1 + Waste Charging time (hours)/3

Figure 15 Procedure for Burn Down

4.9 Cool-down

There is nothing to be done here, except ensuring that the incinerator is sufficiently cooled (approximately 6 – 8 hours) for the scheduled ash removal for the next operation.

4.10 Maintenance and Inspection

In addition to the routine inspection and maintenance previously mentioned, only the burner(s) and the blower(s) require maintenance, which is quite minimal; see manuals in the binder. The following inspection steps are recommended:

Table 8 Recommended Inspections

How Often	Component	Inspection and checking
Daily	Thermocouples PC10 and	Check readings of CP6, Figure 11 that they are
	SC6	"close" to the estimated temperatures of the
		primary and secondary chambers
	Contact switches PC4a and	Free movement, no obstruction
	PC4b	
	Gasket/seal in charge and ash door PC2 and PC3	Wear and tear; proper seating
	Actuators PC8 and SC5	Observe free movement while waste is burnt. PLC action is typically as follows:
		a. PC8 at minimum for a few minutes, while SC5 goes up (and down);
		b. PC8 starts to ramp
		c. SC5 goes to a minimum
		d. PC8 goes up and down, then to minimum
	Refractory and under-fire air	No large (not expansion) cracks; repair if
	holes in primary chamber	necessary No plugging of air holes; clean if
	PC1	necessary
Weekly	Air blowers PC6 and SC3	Inspect clean in-takes, clean if necessary
Monthly	External surfaces of PC1 and	"Spotty" discoloration may indicates damage to
	secondary chamber SC1	refractory and/or insulation
	Refractory in SC1	No large (not expansion) cracks; repair if
		necessary

4.11 Trouble Shooting

Table 9 shows a list of operational problems that may be encountered, the possible causes and corrective measures. No list can cover all potential problems. Please report problems or unusual observations, even if you have solved them yourself. Thanks.

Table 9 Trouble Shooting Guidelines

Observation	Possible Causes	Corrective Measures
Auxiliary burner PC5 or SC8	No fuel	 Fuel tank is empty: fill
not lit		Pump not primed: prime
As above, and also blowers	No power	E-stop disconnects main power: twist
PC6 and SC3		right
Waste not igniting	Auxiliary burners	See above
(temperature in primary	PC5 not	 Check set point: too low? Increase it.
chamber plummets	functioning	
Flame pattern in burner not	Burner setting	 Consult manual and correct
correct: "lazy", sooting or		
detached flame		

4.12 Auxiliary Fuel Consumption Rate

Figure 16 shows the volumetric flow rates of propane and diesel as a function of burner rating. If the TOTAL burner rating is X million Btu/h, and the operating time from start-up to the end of burn-down is t hours, the maximum fuel needed is:

$$V = Y * t USG$$

where Y is the fuel consumption rate for X million Btu/h rating, as shown in the graph.




Figure 16 Consumption Rates of Propane and Diesel

5 MANUAL MODE: OPERATING THE INCINERATOR WITHOUT THE CONTROL SYSTEM

The schematic in Figure 4 shows the oxygen control system and how the oxygen probe in the secondary chamber, the PLC, and the under-fire and flame-port air valves are linked. In the event that the incinerator's oxygen control system becomes inoperable due to either a loss of signal from the oxygen probe, SC7, or a failure of the 24 volt power supply that powers the oxygen control system, the incinerator can be temporarily modified to allow operation to continue in a "manual mode" until the appropriate repair(s) is made.

Manual mode operation does not affect the control of the primary and secondary chamber temperatures; however, the ability of the control system to indicate to the operator that a new waste batch can be loaded, as described in STEP5 on Figure 14, will be lost. Visual inspection of the waste in the primary chamber, via the feed door or ash door, will be required to determine when a new waste batch can be loaded. This will be further discussed in Section 5.2.

In manual mode, the under-fire air flow into the primary chamber through the under-fire butterfly valve is at a low rate (10% open), and the flame-port air flow into the secondary chamber is at maximum. That is, the butterfly valve **PC7** is set at 10% open and butterfly valve **SC4** is set at 100% open.


Section 5.1 below describes the mechanical modifications to the incinerator for manual mode operation. Section 5.2 describes the changes to the operational procedure needed for running the system in manual mode.

5.1 Butterfly Valve Adjustments for Manual Mode Operation

As indicated above, physical modification to the incinerator system to accommodate operation under manual mode is necessary, and requires that the under-fire butterfly valve PC7 be adjusted to 10% open, and the flame-port butterfly valve SC4 be adjusted to 100% open.

Figure 17 provides a further description of the adjustments to the butterfly valves. In general, when modifying the butterfly valves for manual mode, the actuator power supply to be disconnected and the actuator is disconnected from the butterfly valve shaft. A flat-blade screwdriver is then used to turn butterfly valve shaft to the desired position. The actuator is then reconnected to the butterfly valve shaft so that it is held in position by the un-powered actuator. Once these adjustments have been made, the butterfly valve should be tagged to show that it has been modified.

When repairs to the incinerator's oxygen control system have been satisfactorily carried out, the flame-port butterfly valve and actuator can be reconnected, that is, the valve shaft can be tuned back to the 10% open position, and the wire reconnected to resume power to the actuator.



Adjustment Steps to Under-Fire (PC7) and Flame-Port (SC4) Butterfly Valves for Manual Mode Operation:

- 1. Press the Emergency Stop button on the control panel to disconnect power from the incinerator.
- Remove actuator cover 1.
- 3. Remove actuator electronics cover 2.
- 4. Disconnect the black wire 3 and tape the exposed wire with a small piece of electrical tape.
- Loosen the U-clamp nuts 4.
- Use a flat-blade screwdriver to turn the shaft 5 to the desired setting: 10% open for PC7 and 100% open for SC4.
- 7. Tighten the U-camp nuts 4 to secure the valve shaft in place: DO NOT RE-CONNECT THE BLACK WIRE.
- 8. Replace covers.
- 9. Place a tag on the valve to indicate that it has been adjusted for manual mode operation.
- 10. Twist the Emergency Stop button on the control panel to re-connect power to the incinerator.

Adjustments for Manual Mode Done

Figure 17 Butterfly Valve Adjustment for Manual Mode Operation

5.2 Modification to Operation during Manual Mode

During manual mode operation of the incineration system, there are some changes to the loading procedure when compared to normal operation with the oxygen control system in good working order. The Procedure for Startup as outlined in Figure 13 remains the same, but **the Procedure for Waste Charging as outlined in Figure 14 must be ignored**. When the Procedure for Startup has been completed, the procedure shown in Table 10 should be followed for waste charging. The Procedure for Burn Down as outlined in Figure 15 must still be followed during manual mode operations, though the reference to "Indicator Light 2" can be ignored.

Table 10 Waste Charging in Manual Mode

STEP	PROCEDURE			
1	Confirm that the primary and secondary chambers are at their			
	respective set points (see Figure 13).			
2	Open the Charging Door, quickly load the batch and close the			
	door.**			
3	Wait approximately 10*** minutes and repeat Step 2.			
4	Repeat Steps 2 and 3 for three or four loads, and then proceed to Step			
	5.			
5	Open the Ash Door or the Charging Door, rake the waste, and then			
	close the door.			
6	Wait approximately 10 minutes for any unburned waste to be			
	consumed.			
7	Repeat Steps 2 to 6 until the last waste batch has been charged.			
8	Follow the Burn Down Procedure outlined in Figure 15.			
	WASTE CHARGING DONE			
**	This is very hazardous, see the safety notes following Figure 14.			
***	The time varies depending on the waste being incinerated.			

6 WARRANTY

WESTLAND ENVIRONMENTAL SERVICES INC.

- 1. Westland Environmental Services Inc. hereby warrants to the Purchaser, for a one (1) year period of time from the date of acceptance and upon the conditions hereinafter set forth, each new product sold by it, to be free from defects in material and workmanship (specifically excluding there from component parts and accessories manufactured, furnished, and supplied by others) under normal use, maintenance and service. Except for the above Warranty, it is agreed and understood that no other WARRANTY or CONDITION whether express, implied, or statutory is made by Westland Environmental Services Inc.
- 2. The obligation of Westland Environmental Services Inc. under this Warranty shall be limited to the repair or replacement (**not in excess of its factory labour rate**) of its units; which, upon examination by Westland Environmental Services Inc., shall disclose to their satisfaction to have been defective in material and/or workmanship under normal use, maintenance, and service.
- 3. The foregoing shall be the Purchaser's sole and exclusive remedy whether in contract, tort, or otherwise; and Westland Environmental Services Inc. shall not be liable for injuries to persons, for damage to property or for loss of any kind which results (whether directly or indirectly) from such defects in material or workmanship, or for any other reason; and, it is agreed and understood that the Purchaser shall keep Westland Environmental Services Inc. indemnified against any such claim. In no event shall Westland Environmental Services Inc. be liable for incidental or consequential damages, or commercial losses, or for any loss or damage except as set forth in paragraph 2 herein.
- 4. This Warranty does not apply to, and no warranty or condition is made by Westland Environmental Services Inc. regarding any purchased components, parts, and accessories; manufactured, supplied and/or furnished by others, or any non-standard features or items specified by the Purchaser; nor does this Warranty expand, enlarge upon, or alter in any way, the warranties provided by the makers and suppliers of such component parts and accessories.
- 5. The liability of Westland Environmental Services Inc. under this Warranty shall cease and determine if:
 - (a) The Purchaser shall not have paid in full all invoices as submitted by Westland Environmental Services Inc., or affiliated companies on or before their due dates:
 - (b) Representatives of Westland Environmental Services Inc., are denied full and free right of access to the units:
 - (c) The Purchaser permits persons other than the agents of Westland Environmental Services Inc. or those approved or authorized by Westland Environmental Services Inc. to effect any replacement of parts, maintenance, adjustments, or repairs to the units:
 - (d) The Purchaser has not properly maintained the units in accordance with instructions, pamphlets or directions given or issued by Westland Environmental Services Inc. at the time of the sale and/or from time to time thereafter:
 - (e) The Purchaser uses any spare parts or replacements not manufactured by or on behalf of Westland Environmental Services Inc. and supplied by it, or by someone authorized by it, or fails to follow the instructions for the use of the same:
 - (f) The Purchaser misuses, or uses this unit for any purpose other than that for which it was intended or manufactured:
 - (g) The defective parts are not returned to Westland Environmental Services Inc. within 15 days of repair.
- 6. No condition is made or is to be implied, nor is any Warranty given or to be implied as to the life or wear of the units supplied; or that they will be suitable for use under any specific conditions; notwithstanding that such conditions may be known or made known to the seller.
- 7. Defects in material and/or workmanship must be brought to the attention of Westland Environmental Services Inc. by written notification within ten (10) days of discovery, and repairs must be commenced within forty-five (45) days thereafter.
- 8. It is agreed and understood that the Purchaser is responsible for and must pay for the transporting of the defective goods or of the replacement parts to the place of repair. Premium freight charges (such as air express or air fare charges for transportation of personnel, tools and for replacement parts) and other expenses, apart from servicemen's regular straight time travel, mileage, and regular straight time labour required to repair or replace defective parts and the cost of the parts, will be paid for by the customer at Westland Environmental Services Inc. regular billing rates on usual credit terms.


- The liability of Westland Environmental Services Inc. under this Warranty is limited to the purchase price of 9. the unit and in no case shall a claim be advanced for more than such amount.
- All repairs and replacements are made and furnished subject to the same terms, conditions, warranties, 10. disclaimer or warranty and limitations of liability and remedy as applied to each new unit sold. This warranty and the Purchaser's rights under it, is not transferable, or is it assignable.
- 11.

DATE IN SERVICE:	
MODEL NUMBER:	CY - 50 - CA- "D"-"O"
SERIAL NUMBER:	2K8 - 780
PURCHASED BY:	Environment Canada, Eureka Weather Station
SELLING BRANCH:	Edmonton, Alberta

7	APPENDIX A: INFORMATION SHEETS AND MANUALS

ModelsSF & SM Oil Burners

WIC 201 Burner



Maranae

Potential for Fire, Smoke and Asphyxiation Hazards



Incorrect installation, adjustment, or misuse of this burner could result in death, severe personal injury, or substantial property damage.

To the Homeowner or Equipment Owner:

- Please read and carefully follow all instructions provided in this manual regarding your responsibilities in caring for your heating equipment.
- Contact a professional, qualified service agency for installation, start-up or service work.
- Save this manual for future reference.

To the Professional, Qualified Installer or Service Agency:

- Please read and carefully follow all instructions provided in this manual before installing, starting, or servicing this burner or heating system.
- The Installation must be made in accordance with all state and local codes having jurisdiction.

6104BSF/SM R03 Page 1

Table of Contents

Owner's Information	3
Hazard Definitions	
Information To Be Used Only By Qualified Serv	vice Technicians
General Information	4
Table 1 Burner Specification	4 A
Notice Special Requirements	
Table 2 Air Tube Combination (ATC) Codes	5
Inspect/Prepare Installation Site	
Chimney or Vent	
Combustion Air Supply	
Clearances to burner and appliance	
Combustion chamber - Burner Retrofitting	
Prepare the Burner	
Burner Fuel Unit	6
Attach Air Tube	
Install Burner Nozzie	6
Check/Adjust Electrodes	
Servicing nozzle line assembly	7
Check/Adjust 'Z' Dimension - F Heads	
Mount Burner on Appliance	8
Mounting Options	
Mounting Dimensions	
Connect Fuel Lines	
Wire Burner	10
Burner Packaged with Appliance	10
Burner Installed at Job Site	
Start-up Burner/Set Combustion	10
Set Combustion with Test Instruments	12
Perform Regular Maintenance	13
Parts Diagram	14
Beckett Limited Warranty Information	

Owner's Information

To the Owner:

Thank you for purchasing a Beckett burner for use with your heating appliance. Please pay attention to the Safety Warnings contained within this instruction manual. Keep this manual for your records and provide it to your qualified service agency for use in professionally setting up and maintaining your oil burner.

Your Beckett burner will provide years of efficient operation if it is professionally installed and maintained by a qualified service technician. If at any time the burner does not appear to be operating properly, immediately contact your qualified service agency for consultation.

We recommend annual inspection/service of your oil heating system by a qualified service agency.

Daily - Check the room in which your burner/appliance is installed. Make sure:

- · Air ventilation openings are clean and unobstruct-
- Nothing is blocking burner inlet air openings
- No combustible materials are stored near the heating appliance
- There are no signs of oil or water leaking around the burner or appliance

Weekly

· Check your oil tank level. Always keep your oil tank full, especially during the summer, in order to prevent condensation of moisture on the inside surface of the tank.

WARNING Owner's Responsibility



Incorrect installation, adjustment, and use of this burner could result in severe personal injury, death, or substantial property damage from fire,

carbon monoxide poisoning, soot or explosion.

Contact a professional, qualified service agency for the installation, adjustment and service of your oil heating system. This work requires technical training, trade experience, licensing or certification in some states and the proper use of special combustion test instruments.

Please carefully read and comply with the following instructions:

- Never store or use gasoline or other flammable liquids or vapors near this burner or appliance.
- Never attempt to burn garbage or refuse in this appliance.
- Never attempt to light the burner/appliance by throwing burning material into the appliance.
- Never attempt to burn any fuel not specified and approved for use in this burner.
- Never restrict the air inlet openings to the burner or the combustion air ventilation openings in the room.

NOTICE

This manual contains information that applies to both SM and SF burners. These burners may appear to be basically identical, but there are differences in design and performance. Please review the comparison chart below:

Feature	SM	SF
Firing Rate Range	1.25 to 3.00 gph	1.25 to 5.50 gph
Motor	1/5 HP	1/4 HP
Fuel pump capacity	3 gph (standard)	7 gph (standard)
UL Air Tube Combinations	See Table 2	See Table 2
Blocking oil solenoid valve	Optional	Required above 3 gph
Primary control lockout timing	15 to 45 seconds (optional)	15 seconds maximum

Hazard Definitions

DANGER Indicate ardous

Indicates an imminently hazardous situation, which, if not

avoided, will result in death, serious injury, or property damage.



Indicates a potentially hazardous situation, which,

if not avoided, could result in death, severe personal injury, and/or substantial property damage.

∆CAUTION

Indicates a potentially hazardous situation, which, if

not avoided, may result in personal injury or property damage.

Within the boundaries of the hazard warning, there will be information presented describing consequences if the warning is not heeded and instructions on how to avoid the hazard.

NOTICE

Intended to bring special attention to information, but not related to personal injury or property damage.

General Information

Table 1 – Burner Specifications

	-
Model SM Ca- pacity (Note1)	Firing rate range:01.25 – 3.00 GPH Input:
Model SF Ca- pacity (Note1)	Firing rate range:1.25 - 5.50 GPH Input:175,000 – 770,000 Btu/hr
Certifications/ Approvals	Model SM - UL listed to comply with ANSI/ UL296 & certified to CSA B140.0. Model SF - UL listed to comply with ANSI/UL 296 & certified to CSA B140.0.
Fuels	U. S: No.1 or No.2 heating oil only (ASTM D396) Canada: No. 1 stove oil or No. 2 furnace oil only
Electrical	Power supply:
Fuel pump	Outlet pressure:Note 2
Air tube	ATC code:See Table 2
Dimensions (Standard)	Height 12.5 inches Width 15 inches Depth 8.50 inches Air tube diameter 4.00 inches
Air tube	ATC code:See Table 2

- Note 1: Approval agency listed rating for Model SM is 1.25 to 3.00 gph and Model SF is 1.25 to 5.50 gph. However, the firing rate range is limited by the specific air tube combination being used. Refer to Table 2.
- **Note 2.** UL Recognized to 4.0 GPH with a CleanCut pump for use in pressure washers.
- **Note 3.** See appliance manufacturer's burner specifications for recommended pump discharge pressure.

Notice Special Requirements

- For recommended installation practice in Canada, refer to the latest version of CSA Standard B139 & B140.
- Concealed damage If you discover damage to the burner or controls during unpacking, notify the carrier at once and file the appropriate claim.
- When contacting Beckett for service information
 — Please record the burner serial number (and have available when calling or writing). You will find the serial number on the silver label located on the left rear of the burner. Refer to Figure 1.

AWARNING

Professional Service Required



Incorrect installation, adjustment, and use of this burner could result in severe personal injury, death, or substantial property damage from

fire, carbon monoxide poisoning, soot or explosion.

Please read and understand the manual supplied with this equipment. This equipment must be installed, adjusted and put into operation only by a qualified individual or service agency that is:

- Licensed or certified to install and provide technical service to oil heating systems.
- Experienced with all applicable codes, standards and ordinances.
- Responsible for the correct installation and commission of this equipment.
- Skilled in the adjustment of oil burners using combustion test instruments.

The installation must strictly comply with all applicable codes, authorities having jurisdiction and the latest revision of the National Fire Protection Association Standard for the installation of Oil-burning Equipment, NFPA 31 (or CSA B139 and B140 in Canada).

Regulation by these authorities take precedence over the general instructions provided in this installation manual.

Table 2 – Air Tube Combination (ATC) codes

Firing Rate (gph)	Head	Static plate size	ATC Codes for usable air tube lengths ('A' in inches; See Figure 3.)			
(min- max)		(inch- es)	6-5/8	16		
			For SF Burr	ner Only		
1.25-2.25	F12	2-3/4	SF65VW	SF90VW	SF130VW	SF160VW
1.75-2.75	F22	2-3/4	SF65VP	SF90VP	SF130VP	SF160VP
1.75-3.25	F220	None	SF65FD	SF90FD	SF130FD	SF160FD
2.5-5.5	F310	None	SF65FU	SF90FU	SF130FU	SF160FU
		-	For SM Buri	ner Only		
1.25-2.00	F12	2-3/4	SM65VW	SM90VW	SM130VW	SM160VW
2.00-3.00	F220	None	SM65FF	SM90FF	SM130FF	SM160FF
2.00-3.00	F22	None	SM65VM	SM90VM	SM130VM	SM160VM

Inspect/Prepare Installation Site

· Chimney or vent

- Inspect the chimney or vent, making sure it is properly sized and in good condition for use.
- For those installations not requiring a chimney, such as through-the-wall vented appliances, follow the instructions given by the appliance and power venter (if used) manufacturers.

Combustion air supply



Adequate Combustion and Ventilation Air Supply Required

Failure to provide adequate air supply could seriously affect the burner performance and result in damage to the equipment, asphyxiation, explosion or fire hazards.

- The burner cannot properly burn the fuel if it is not supplied with a reliable combustion air source.
- Follow the guidelines in the latest editions of the NFPA 31 and CSA-B139 regarding providing adequate air for combustion and ventilation.

See NFPA 31 Standard for complete details.

Appliance located in confined space

The confined space should have two (2) permanent openings: one near the top of the enclosure and one near the bottom of the enclosure. Each opening shall have a free area of not less than (1) one square inch per 1,000 BTU's per hour of the total input rating of all appliances within the enclosure. The openings shall have free access to the building interior, which should have adequate infiltration from the outside.

6104BSF/SM R03 Page 5

Exhaust fans and other air-using devices

Size air openings large enough to allow for all airusing devices in addition to the minimum area required for combustion air. If there is any possibility of the equipment room developing negative pressure (because of exhaust fans or clothes dryers, for example), either pipe combustion air directly to the burner or provide a sealed enclosure for the burner and supply it with its own combustion air supply.

Clearances to burner and appliance

- Provide space around burner and appliance for easy service and maintenance.
- Check minimum clearances against those shown by the appliance manufacturer and by applicable building codes.

Combustion chamber — Burner retrofitting

Verify that the appliance combustion chamber provides at least the minimum dimensions given in Table 3.

Table 3. Chamber Dimensions

Chamber Dimensions (inches)						
Firing	Round	Rectangular Width Length		Height	Floor to	
Rate (GPH)	I.D.				nozzle	
1.25	11	10	11	12	5-6	
1.50	12	11	12	13	6-7	
2.00	14	12	15	13	6-7	
2.50	16	13	17	14	7-8	
3.00	18	14	18	15	7-8	
3.50	19	15	19	15	7-8	
4.00	20	16	21	16	8-9	
5.00	23	18	23	18	9-10	
5.50	24	19	24	19	10-11	



Protect Steel Combustion Chamber From Burnout

Failure to comply could result in damage to the heating equipment and result in fire or asphyxiation hazards.

- When retrofitting appliances that have unlined stainless steel combustion chambers, protect the chamber by lining the inside surfaces with a ceramic fiber blanket, such as a wet-pac or other suitable refractory material.
- Some steel chambers may not require liners because the appliance was designed and tested for use with flame retention burners. Refer to the manufacturer's instructions.

Prepare the Burner

· Burner fuel unit

Verify that the burner fuel unit is compatible with the oil supply system. For more details, refer to "Connect fuel lines" later in this manual.


Attach air tube (if not already installed)

If using a flange and gasket, slide them onto the air tube. Then attach the air tube to the burner chassis using the four sheet metal screws provided. Refer to Figure 3 for details.

Install burner nozzle (if not already installed)

- 1. Remove the plastic plug protecting the nozzle adapter threads
- 2. Place a ¾" open-end wrench on the nozzle adapter. Insert the nozzle into the adapter and finger tighten. Finish tightening with a ¾" open-end wrench. Use care to avoid bending the electrodes.

Figure 1. Burner Label Location



6104BSF/SM R03

WARNING Correct Nozzle and Flow Rate Required



Incorrect nozzles and flow rates could result in impaired combustion, under-firing, over-firing, sooting, puff-back of hot gases, smoke and potential fire or asphyxiation hazards.

Use only nozzles having the brand, flow rate (gph), spray angle and pattern specified by the appliance manufacturer.

Follow the appliance manufacturer's specifications for the required pump outlet pressure for the nozzle, since this affects the flow rate.

- · Nozzle manufacturers calibrate nozzle flow rates at 100 psia.
- When pump pressures are higher than 100 psig, the actual nozzle flow rate will be greater than the gph stamped on the nozzle body. (Example: A 1.00 gph nozzle at 140 psig = 1.18 gph)

Securely tighten the nozzle (torque to 90 inch pounds). For typical nozzle flow rates at various pressures refer to Table 5.

Table 5. Nozzle Flow Rate by Size

Nozzle flow rate U. S. gallons per hour of No. 2 fuel oil when pump pressure (psig) is:						
Nozzle size (rated at 100 psig)	125 psi	140 psi	150 psi	175 psi	200 psi	
1.25	1.39	1.48	1.53	1.65	1.77	
1.35	1.51	1.60	1.65	1.79	1.91	
1.50	1.68	1.77	1.84	1.98	2.12	
1.65	1.84	1.95	2.02	2.18	2.33	
1.75	1.96	2.07	2.14	2.32	2.48	
2.00	2.24	2.37	2.45	2.65	2.83	
2.25	2.52	2.66	2.76	2.98	3.18	
2.50	2.80	2.96	3.06	3.31	3.54	
2.75	3.07	3.25	3.37	3.64	3.90	
3.00	3.35	3.55	3.67	3.97	4.24	
3.25	3.63	3.85	3.98	4.30	4.60	
3.50	3.91	4.14	4.29	4.63	4.95	
3.75	4.19	4.44	4.59	4.96	5.30	
4.00	4.47	4.73	4.90	5.29	-	
4.50	5.04	5.32	5.51	-	-	
5.00	5.59	-	-	-	-	
5.50	-	-	-	-	-	

Table 6. Nozzle Spray Angles


	Recommended	nozzle spray angles
Ì	"F" head	70°, 80° or 90° nozzle

Note: Always follow the appliance manufacturer's nozzle specification, when available.

- 3. If the nozzle is already installed, remove the nozzle line assembly to verify that the nozzle size and spray pattern are correct for the application (per appliance manufacturer's information). Verify that the electrode tip settings comply with Figure 2.
- 4. If the nozzle is not installed, obtain a nozzle having the capacity and spray angle specified in the appliance manufacturer's information. For conversions or upgrades, when information is not available for the application:
 - Refer to Table 6 to select the mid-range nozzle spray angle for the head type being used.
 - Fire the burner and make sure the combustion is acceptable and the flame is not impinging on chamber surfaces.
 - If a shorter flame is needed, select a wider spray angle. If a longer flame is needed, select a narrower spray angle.
 - Either hollow or solid spray patterns may be used. If combustion results are not satisfactory with the selected spray pattern, try the other pattern.

Check/adjust electrodes

Figure 2. – Electrode Tip Adjustment



Check the electrode tip settings. Adjust if necessary to comply with the dimensions shown in Figure 2. To adjust, loosen the electrode clamp screw and slide/rotate electrodes as necessary. Securely tighten the clamp screw when finished.

Servicing nozzle line assembly

- 1. Turn off power to burner before proceeding.
- 2. Disconnect oil connector tube from nozzle line.
- 3. Loosen the two screws securing igniter retaining clips and rotate both clips to release igniter baseplate. Then tilt igniter back on its hinge.
- Remove splined nut.
- 5. "F" head air tube. Remove nozzle line assembly from burner, being careful not to damage the electrodes or insulators while handling. To ease removal of long assemblies (over 9 inches), rotate assembly 180° from installed position after pulling partially out of tube.
- 6. To replace the nozzle assembly, reverse the above steps.

Mount Burner on Appliance



Do Not use Adjustable Mounting Flange on Mobile Units

The shock and vibration could cause loss of burner alignment and insertion problems resulting in flame impingement, heavy smoke, fire and equipment damage.

 Only use specified factory-welded flange and air tube combinations.


Mounting options

Bolt the burner to the appliance using the factorymounted flange or an adjustable flange.

Mounting dimensions

- When using the Beckett universal adjustable flange, mount the air tube at a 2° downward pitch unless otherwise specified by the appliance manufacturer.
- Verify that the air tube installed on the burner provides the correct insertion depth. See Figure 3.
- 3. The end of the air tube should normally be ¼" back from the inside wall of the combustion chamber. Never allow the leading edge of the head assembly to extend into the chamber, unless otherwise specified by the heating appliance manufacturer. Carefully measure the insertion depth when using an adjustable flange. Verify the insertion depth when using a welded flange.

Figure 3. – Mounting Burner in Appliance



Connect fuel lines

Carefully follow the fuel unit manufacturer's literature and the latest edition of NFPA 31 for oil supply system specifications.



Do Not Install By-pass Plug with 1-Pipe System

Failure to comply could cause Immediate pump seal failure, pressurized oil leakage and the potential for a fire and injury hazard.

- The burner is shipped without the by-pass plug installed. EXCEPTION: Unless specified by the equipment manufacturer and noted on the label at top of pump cover.
- Install the by-pass plug in two-pipe oil supply systems ONLY.



Oil Supply Pressure Control Required

Damage to the filter or pump seals could cause oil leakage and a fire hazard.


- The oil supply inlet pressure to the burner cannot exceed 3 psig.
- Insure that a pressure limiting device is installed in accordance with the latest edition of NFPA 31.
- Do not install valves in the return line. (NFPA 31, Chapter 8)
- Gravity Feed Systems: Always install an anitsiphon valve in the oil supply line or a solenoid valve (RWB Part # 2182602U or 2233U) in the pump/nozzle discharge tubing to provide backup oil flow cut-off protection.

Fuel supply level with or above burner -

The burner may be equipped with a single-stage fuel unit for these installations. Connect the fuel supply to the burner with a single supply line if you want a one-pipe system (making sure the bypass plug is NOT installed in the fuel unit.) Manual bleeding of the fuel unit is required on initial start-up. If connecting a two-pipe fuel supply, install the fuel unit bypass plug.

Fuel supply below the level of the burner -

When the fuel supply is more than eight feet below the level of the burner, a two-pipe fuel supply system is required. Depending on the fuel line diameter and horizontal and vertical length, the installation may also require a two-stage pump. Consult the fuel unit manufacturer's literature for lift and vacuum capability.



• Check/Adjust 'Z' Dimension - 'F' heads

/ WARNING

Adjust the 'Z' dimension to the required specification.

ncorrect Adjustments could cause combustion problems, carbon deposition from flame impingement, heavy smoke generation and fire hazard.

- Make all adjustments exactly as outlined in the following information.
- The important 'Z' dimension is the distance from the face
 of the nozzle to the flat face of the head (or heat shield, if
 applicable). This distance for F heads is 1-1/6" (1-3/6" if the
 air tube has a heat shield). The "Z" dimension is factory
 set for burners shipped with the air tube installed. Even
 if factory set, verify that the "Z" dimension has not been
 changed.
- 2. Use the following procedure to adjust the "Z" dimension, if it is not correct:
 - Turn off power to the burner.
 - · Disconnect the oil connector tube from the nozzle line
 - See above figure. Loosen the splined nut from the nozzle line. Loosen the hex head screw securing the escutcheon plate to the burner housing.
 - Place the end of a ruler at the face of the nozzle and, using a straight edge across the head, measure the distance to the face of the head. A Beckett T501 or T650 gauge may also be used.

Figure 4. 'F' Head

- Slide the nozzle line forward or back until the Z dimension for F heads is 1-1/8" (1-1/8" plus shroud length, if using a straight edge).
- Tighten the hex head screw to secure the escutcheon plate to the burner chassis. Then tighten the splined nut and attach the oil connector tube.
- 3. Recheck the "Z" dimension periodically when servicing to ensure the escutcheon plate has not been moved. You will need to reset the "Z" dimension if you replace the air tube or nozzle line assembly. The Beckett Z gauge (part number Z-2000) is available to permit checking the F head "Z" dimension without removing the burner from the appliance.

Burner Dimensions - Models SM & SF

Dimension (inches)	F Head
A = Usable air length (inches)	(Measure accurately)
L (Total tube length)	A+1/2
R (electrode length), ± 1/4	A+2-1/4
S (adapter to static plate), ± 1/16	(Note 1)
Q (nozzle line length),	A+ 15/16
Z (F head w/o head shroud) (F head-with head shroud)	1-1/8 1-1/8 + shroud length. (Note 2)

Note 1: 1-3/8 for dimension A less than 4"; 1-5/8 for dimension A from 4" through 4-1/2", 2-13/32 for dimension A greater than 4-1/2". Note 2: When using a straight edge.

Fuel line installation -

CAUTION Do Not Use Teflon Tape

Damage to the pump could cause impaired burner operation, oil leakage and appliance soot-up.

- Never use Teflon tape on fuel oil fittings.
- Tape fragments can lodge in fuel line components and fuel unit, damaging the equipment and preventing proper operation.
- Use of Teflon tape will void the Suntec warranty.
- Use oil-resistant pipe sealant compounds.

Continuous lengths of heavy wall copper tubing are recommended. Always use flare fittings. Never use compression fittings.

Always install fittings in accessible locations. Proper routing of fuel lines is required to prevent air cavitation and vibration.

Fuel line valve and filter -

- Install two high quality fusible-handle design shutoff valves in accessible locations on the oil supply line to comply with the NFPA 31 Standard and authorities having jurisdiction. Locate one close to the tank and the other close to the burner, upstream of the filter.
- Install a generous capacity filter inside the building between the fuel tank shutoff valve and the burner, locating both the filter and the valve close to the burner for ease of servicing. Filter should be rated for 50 microns or less.

Wire Burner



WARNING Electrical Shock Hazard



Electrical shock can cause severe personal injury or death.

- Disconnect electrical power before installing or servicing the burner.
- Provide ground wiring to the burner, metal control enclosures and accessories. (This may also be required to aid proper control system operation.)
- Perform all wiring in compliance with the National Electrical Code ANSI/NFPA 70 (Canada CSA C22.1)

Burner packaged with appliance

Refer to appliance manufacturer's wiring diagram for electrical connections.

Burner installed at jobsite

Refer to Figure 5, for typical burner wiring, showing cad cell primary controls. Burner wiring may vary, depending on primary control actually used.

The R7184 primary control with valve-on delay (prepurge) and burner motor-off delay (postpurge), requires a constant 120 volts AC power source supplied to the BLACK wire on the control. The RED wire goes to the appliance limit circuit. Please note that other control manufacturers may use different wire colors for power and limit connections.

Start Up Burner/Set Combustion



WARNING Explosion and Fire Hazard



Failure to follow these instructions could lead to equipment malfunction and result in heavy smoke emission, soot-up, hot gas puffback, fire and asphyxiation hazards.

- Do not attempt to start the burner when excess oil has accumulated in the appliance, the appliance is full of vapor, or when the combustion chamber is very hot.
- · Do not attempt to re-establish flame with the burner running if the flame becomes extinguished during start-up, venting, or adjustment.
- Vapor-Filled Appliance: Allow the unit to cool off and all vapors to dissipate before attempting another start.
- Oil-Flooded Appliance: Shut off the electrical power and the oil supply to the burner and then clear all accumulated oil before continuing.
- If the condition still appears unsafe, contact the Fire Department. Carefully follow their directions.
- Keep a fire extinguisher nearby and ready for use.
- 1. Open the shutoff valves in the oil supply line to the burner.
- 2. If the air control is not preset, close air band and partially open air shutter. This is an initial air setting for the pump bleeding procedure only. Additional adjustments must be made with instruments to prevent smoke and carbon monoxide generation.
- 3. Set the thermostat substantially above room temperature.





Figure 5. - Typical Burner Wiring

- STANDBY. The burner is idle, waiting for a call for heat. When a call for heat is initiated, there is a 3-10 second delay while the control performs a safe start check.
- 2. VALVE-ON DELAY. The ignition and motor are turned on for a 15 second valve-on delay.
- TRIAL FOR IGNITION (TFI). The fuel valve is opened. A flame should be established within the 15 second lockout time.
- 4. LOCKOUT. If flame is not sensed by the end of the TFI, the control shuts down on safety lockout and must be manually reset. If the control locks out three times in a row, the control enters restricted lockout.
- 5. IGNITION CARRYOVER. Once flame is established, the ignition remains on for 10 seconds to ensure flame stability before turning off. If the control is wired for intermittent duty ignition, the ignition unit stays on the entire time the motor is running.
- 6. RUN. The burner runs until the call for heat is satified. The burner is then sent to burner motor off delay, if applicable, or it is shut down and sent to standby.

- 7. RECYCLE. If the flame is lost while the burner is firing, the control shuts down the burner, enters a 60 second recycle delay, and then repeats the above ignition sequence. If flame is lost three times in a row, the control locks out to prevent cycling with repetitious flame loss due to poor combustion.
- 8. BURNER MOTOR-OFF DELAY. The fuel valve is closed and the burner motor is kept on for the selected motor-off delay time before the control returns the burner to standby.



Control System Features

Feature	Interrupted ignition	Limited reset, Limited recycle	Diagnostic LED, cad cell indicator	Valve-on delay	Burner motor off delay	Alarm Con- tacts
R7184A	YES	YES	YES			_
R7184B	YES	YES	YES	YES	<u> </u>	_
R7184P	YEŞ	YES	YES	YES	YES	Optional

6104BSF/SM R03 Page 11

- Close the line voltage switch to start the burner.
 If the burner does not start immediately you may have to reset the safety switch of the burner primary control.
- 5. Bleed air from fuel unit as soon as burner motor starts rotating.
 - To bleed the fuel unit, attach a clear plastic hose over the vent fitting. Loosen the fitting and catch the oil in an empty container. Tighten the fitting when all air has been purged from the oil supply system.
 - If the burner locks out on safety during bleeding, reset the safety switch and complete the bleeding procedure. Note — Electronic safety switches can be reset immediately; others may require a three- to five-minute wait.
 - If burner stops after flame is established, additional bleeding is probably required. Repeat the bleeding procedure until the pump is primed and a flame is established when the vent fitting is closed.
 - For R7184 primary controls, see Technician's Quick Reference Guide, part number 61351 for special pump priming sequence.
 - Prepare for combustion tests by drilling a ¼" sampling hole in the flue pipe between the appliance and the barometric draft regulator.
- Initial air adjustment Test the flue gas for smoke.
 Adjust the air shutter (and air band, if necessary) to obtain a clean flame. Now the additional combustion tests with instruments can be made

Set combustion with instruments

- 1. Allow the burner to run for approximately 5 to 10 minutes.
- 2. Set the stack or over-fire draft to the level specified by the appliance manufacturer.
 - Natural Draft Applications; typically over-fire draft is -0.01" or -0.02" w.c.
 - **Direct Venting**; typically may not require draft adjustment.
 - High Efficiency/Positive Pressure Appliances; also vary from traditional appliances (see manufacturer's recommendations).
- 3. Follow these four steps to properly adjust the burner:
 - Step 1: Adjust the air shutter/band until a trace of smoke is achieved.
 - Step 2: At the trace of smoke level, measure the CO₂ (or O₂). This is the vital reference point for further adjustments. Example: 13.5% CO₂ (2.6% O₂)
 - Step 3: Increase the air to reduce the CO₂ by 1.5 to 2 percentage points. (O₂ will be increased by approximately 2.0 to 2.7 percentage points.) Example: Reduce CO₂ from 13.5% to 11.5% (2.6% to 5.3% O₂).
 - Step 4: Recheck smoke level. It should be Zero.
 - This procedure provides a margin of reserve air to accommodate variable conditions.
 - If the draft level has changed, recheck the smoke and CO2 levels and readjust the burner, if necessary
- 4. Once combustion is set, tighten all fasteners on air band, air shutter and escutcheon plate.
- Start and stop the burner several times to ensure satisfactory operation. Test the primary control and all other appliance safety controls to verify that they function according to the manufacturer's specifications.

Perform Regular Maintenance

/ WARNING

Annual Professional Service Required



Tampering with or making incorrect adjustments could lead to equipment malfunction and result in asphyxiation, explosion or fire.

- Do not tamper with the burner or controls or make any adjustments unless you are a trained and qualified service technician.
- To ensure continued reliable operation, a qualified service technician must service this burner annually.
- More frequent service intervals may be required in dusty or adverse environments.
- Operation and adjustment of the burner requires technical training and skillful use of combustion test instruments and other test equipment.
- ☐ Replace the oil supply line filter. The line filter cartridge must be replaced to avoid contamination of the fuel unit and nozzle.
- ☐ Inspect the oil supply system. All fittings should be leak-tight. The supply lines should be free of water, sludge and other restrictions.
- ☐ Remove and clean the pump strainer if applica-
- ☐ Replace the nozzle with the exact brand, pattern, gph flow rate and spray angle..
- ☐ Clean and inspect the electrodes for damage, replacing any that are cracked or chipped.
- ☐ Check electrode tip settings. Replace electrodes if tips are rounded.
- Inspect the igniter spring contacts.
- Clean the cad cell lens surface, if necessary.
- ☐ Inspect all gaskets. Replace any that are damaged or would fail to seal adequately.
- ☐ Inspect the combustion head and air tube. Remove any carbon or foreign matter. Replace all damaged units with exact parts.
- Clean the blower wheel, air inlet, air guide, burner housing and static plate of any lint or foreign material.

- ☐ If motor is not permanently lubricated, oil motor with a few drops of SAE 20 nondetergent oil at each oil hole. DO NOT over oil motor. Excessive oiling can cause motor failure.
- ☐ Check motor current. The amp draw should not exceed the nameplate rating.
- ☐ Check all wiring for secure connections or insulation breaks.
- ☐ Check the pump pressure and cutoff function.
- Check primary control safety lockout timing.
- ☐ Check ignition system for proper operation.
- ☐ Inspect the vent system and chimney for soot accumulation or other restriction.
- ☐ Clean the appliance thoroughly according to the manufacturer's recommendations.
- ☐ Check the burner performance. Refer to the section "Set combustion with test instruments".
- ☐ It is good practice to make a record of the service performed and the combustion test results.

Replacing the blower wheel:

 When replacing the blower wheel, insure that the wheel is centered between the two sides of the burner housing as shown below.





Figure 6. Blower Wheel Assembly

Burner Parts Diagram



Page 14 6104BSF/SM R03

For best performance specify genuine *Beckett* replacement parts

#	Part No.	Description	
1		Burner Housing Assembly with Inlet Bell	
2	3215	Air shutter, 10 Slot	
3	3819	Bulk Air Band, 10 Slot	
4	3493	Nozzle-line Escutcheon Plate	
5	Specify ** 3399	Unit Flange or Square Plate	
Not Shown	3416	Air Tube Gasket	
6	2139	Hole Plug - Wiring Box	
7	2900U 2364U	Drive Motor, 1/5 HP (SM Models) Drive Motor, 1/4 HP (SF Models)	
8	2383U	Blower Wheel (6-1/4 X 3-7/16)	
9	2433	Flexible Coupling (Fits 5/16" pump shaft)	
10	2591U 21188U	Fuel Units SF only Single-Stage 'A' Two-Stage 'B'	
10	2184404U 2460	Fuel Units SM only CleanCut Single-Stage 'A'	
12	2256	Pump outlet fitting	
	482	Pump holding screws (not shown)	
13	5394	Connector tube assembly, pump to nozzle line	

#	Part No.	Description
14	51824U	Igniter and Base Plate
14	2289U	Ignition Transformer (10,000 V/23mA)
15	7455U	R7184A - Interrupted Ignition
	7456U	R7184B - Pre-purge
	7457U	R7184P - Pre and Post-purge
	7458U	R7184P w/ Alarm Contacts
16	5770	Electrical Box
17	7006U	Cad Cell Detector
18	Specify **	Air Tube Combination
	5780	Electrode Kit - F Head up to 9"
19	5782	Electrode Kit - F Head over 9"
20	5432	Universal Flange w/ Gasket
21	3616 3666	Gasket Only Splined Nut
		········
22	2182602U	Blocking Oil Solenoid Valve
23	5685	Base Pedestal Kit

^{**} Contact your Beckett Representative for part number and pricing.

6104BSF/SM R03 Page 15

Limited

WARRANTY

For Residential, Commercial and Specialty Burners

The R. W. BECKETT CORPORATION ("Beckett") warrants to persons who purchase its Beckett burners from Beckett for resale or for incorporation into a product for resale ("Customers") that its equipment is free from defects in material and workmanship under normal use and service for 60 months from the date of manufacture for Residential Burners and 18 months from the date of manufacture for Commercial and Specialty Burners. Residential burner models include: AF, AFG, AFII, NX, SF, SR and SMG. Commercial burner models include: CF375, CF500, CF800, CF1400, CF2300A, CF2500, CF3500A, CG10, CG15, CG25 and CG50. Specialty burner models include: ADC, ADCP, ARV, SDC and SM. The provisions of this warranty are extended to individual major burner components as follows:

- a) 60 months from date of manufacture for all Beckett-branded major components, except for 12 Vdc components.
- b) 18 months from date of manufacture for all non-Beckett-branded major components and Beckett branded 12 Vdc components.

Note: Normal service items found to be defective upon receipt by the customer are covered by this warranty.

THIS WARRANTY DOES NOT EXTEND TO EQUIPMENT SUBJECTED TO MISUSE, NEGLECT, OR ACCIDENT: NOR DOES THIS WARRANTY APPLY UNLESS THE PRODUCT COVERED BY IT IS PROPERLY INSTALLED BY A QUALIFIED, COMPETENT TECHNICIAN, WHO IS LICENSED WHERE STATE AND LOCAL CODES REQUIRE, AND WHO IS EXPERIENCED IN MAKING SUCH INSTALLATIONS, IN ACCORDANCE WITH THE LATEST EDITION OF NFPA NO. 31 OF THE NATIONAL FIRE PROTECTION ASSOCIATION, THE LATEST EDITION OF THE NATIONAL FUEL GAS CODE (NFPA NO. 54) AND IN ACCORDANCE WITH ALL APPLICABLE LOCAL, STATE AND NATIONAL CODES HAVING JURISDICTIONAL AUTHORITY.

Equipment, which is defective in material or workmanship and within the warranty period, may be returned for <u>credit</u> as follows:

Beckett Burners, Beckett-branded major components and non-Beckett-branded major components that came as original equipment on a Beckett burner or were sold as a replacement part by Beckett should be returned, freight prepaid, to Beckett's home office. Credit will be issued to the customer unless the returned equipment is determined by Beckett to be out of warranty or damaged by user, in which case the equipment will be scrapped.

Note: Beckett is not responsible for any labor cost for removal and replacement of equipment.

THIS WARRANTY IS LIMITED TO THE PRECISE TERMS SET FORTH ABOVE, AND PROVIDES EXCLUSIVE REMEDIES EXPRESSLY IN LIEU OF ALL OTHER REMEDIES, AND IN PARTICULAR THERE SHALL BE EXCLUDED THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT WILL BECKETT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE OF ANY NATURE. Beckett neither assumes nor authorizes any person to assume for Beckett any other liability or obligation in connection with the sale of this equipment, Beckett's liability and Customer's exclusive remedy being limited to credit as set forth above.

R.W. BECKETT CORPORATION

P.O. Box 1289 Elvria, Ohio 44036

Form No. 61545 R72905

The Oilheat Manufacturers' Association supports the use of low sulfur fuels as defined by ASTM D396, Grades No. 1 Low Sulfur and No. 2 Low Sulfur, as the preferred heating fuel for the following reasons:

- Low sulfur fuels reduce deposits on heat exchanger surfaces, extending the service interval between cleanings.
- The reduced deposits increase the efficiency of the appliance.
- · Low sulfur fuels reduce particulate emissions.
- · Low sulfur fuels reduce oxides of nitrogen emissions.

R.W. BECKETT CORPORATION

U.S.A.: P.O. Box 1289 · Elyria, Ohio 44036

www.beckettcorp.com

Canada: R.W. Beckett Canada, Ltd. · Unit #3, 430 Laird Road · Guelph, Ontario N1G 3X7

Form Number 6104BSF/SM R03
Printed in U.S.A. © 2006 R.W. Beckett Corporation 12/06



Digital Temperature Controller

E5CN

Compact and Intelligent Temperature Controller

- Auto-tuning and self-tuning available.
 Can auto-tune even during execution of self-tuning
- Heating or heating/cooling control is available
- Event input allows multiple SP selection and run/stop function
- Water-resistant construction: NEMA4 (equivalent to IP66)
- Various temperature inputs: thermocouple, platinum resistance thermometer, non-contact temperature sensor, and analog inputs
- Conforms to UL, CSA, IEC, and CE





Ordering Information

■ E5CN STANDARD MODELS

Description				Part number	
Size	Power supply voltage	No. of alarm points	Output	Thermocouple model	Platinum resistance thermometer model
1/16 DIN	100 to 240 VAC		Relay	E5CN-RMTC-500 AC100-240	E5CN-RMP-500 AC100-240
48(W) x 48(H) x 78(D) mm			Voltage output (for driving SSR)	E5CN-QMTC-500 AC100-240	E5CN-QMP-500 AC100-240
		2	Relay	E5CN-R2MTC-500 AC100-240	E5CN-R2MP-500 AC100-240
			Voltage output (for driving SSR)	E5CN-Q2MTC-500 AC100-240	E5CN-Q2MP-500 AC100-240
	24 VAC/VDC		Relay	E5CN-RMTC-500 AC/DC24	E5CN-RMP-500 AC/DC24
			Voltage output (for driving SSR)	E5CN-QMTC-500 AC/DC24	E5CN-QMP-500 AC/DC24
		2	Relay	E5CN-R2MTC-500 AC/DC24	E5CN-R2MP-500 AC/DC24
			Voltage output (for driving SSR)	E5CN-Q2MTC-500 AC/DC24	E5CN-Q2MP-500 AC/DC24

Note: 1. The suffix "500" is added to the part number of each Controller provided with a E53-COV10 Terminal Cover.

2. The heating and cooling function is available for models with two alarm points.

■ E5CN OPTION BOARDS

The E5CN provides communications or event input functionality when mounted with one of the following Option Boards.

Item	Function	Part number
Communications Board	RS-485 communication	E53-CNH03
Event Input Board	Event input	E53-CNHB

Note: The heater burnout alarm is available by mounting the E53-CNH03 or E53-CNHB Option Unit on the E5CN.

ACCESSORIES

Terminal Cover (Sold Separately)

Applicable Controller	Part number
E5CN	E53-COV10

Current Transformer (Sold Separately)

Item	Hole diameter	Part number
Current Transformer	5.8 dia.	E54-CT1
	12.0 dia.	E54-CT3

■ INPUT RANGES

Platinum Resistance Thermometer Input

Shaded ranges indicate default settings.

	Platinum resistance thermometer input				
Input type		Platinum resistance thermometer			
Name	F	Pt100		JPt1	00
1800 1700 1600 1500 1400 1300 1200 1100 900 800 900 800 500 400 300 200 100 0 -100 -200				500.0	100.0
Set value	0	1	2	3	4

Thermocouple Input

Shaded ranges indicate default settings.

		Thermocouple input							
Input type			Ther	nocouple			ES1A Non-contact Temperature Sensor		Analog input
Name	К	J	T E	L U	N R	S B	K10 to K60 to K115 to 70°C 120°C 165°C	K160 to 260°C	0 to 50 mV
1800 1700 1600 1500 1400 1300 1200 1100 900 800 700 600 500 400 300 200 0 -100 -200		850 			1300	1700 1800 1 1700 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	120 165 -70 - 0 0 0		Usable in the following ranges by scaling: -1999 to 9999 or -199.9 to 999.9
Set value	0 1	2 3	4 5	6 7	8 9	10 11	12 13 14	15	16

Applicable standards by input type are as follows:

K, J, T, E, N, R, S, B: JIS C1602-1995 L: Fe-CuNi, DIN 43710-1985 U: Cu-CuNi, DIN 43710-1985 JPt100: JIS C1604-1989, JIS C1606-1989 Pt100: JIS C1604-1997, IEC751

Note: The ES1A Non-contact Temperature Sensor will be available soon.

E5CN	OMRON	EECN
		E5CN

Specifications _____

■ RATINGS

Supply voltage		100 to 240 VAC, 50/60 Hz	24 VAC, 50/60 Hz/24 VDC	
Operating voltage range		85% to 110% of rated supply voltage		
Power consumption	E5CN	7 VA 4 VA/3 W		
Sensor input		Thermocouple: K, J, T, E, L, U, N, R, S, B Platinum resistance thermometer: Pt100, JPt100 Non-contact temperature sensor: K10 to 70°C, K60 to 120°C, K115 to 165°C, K160 to 260°C Voltage input: 0 to 50 mV		
Control output	Relay output	SPST-NO, 250 VAC, 3A (resistive load), electrical life: 100,000 operations		
	Voltage output	tage output 12 VDC (PNP), max. load current: 21 mA, with short-circuit protection		
Alarm output		SPST-NO, 250 VAC, 1 A (resistive load), electrical life: 100,000 operations		
Control method		PID or ON/OFF control		
Setting method		Digital setting using front panel keys		
Indication method		7-segment digital display and single-lighting indicator		
Other functions		According to Controller model		
Ambient temperature		-10°C to 55°C (14°F to 131°F) with no condensation or icing		
Ambient humidity		25% to 85% relative humidity		
Storage temperature		-25°C to 65°C (-13°F to 149°F) with no condensation or icing		

■ CHARACTERISTICS

Indication accuracy		Thermocouple: $(\pm 0.5\% \text{ of indicated value or } \pm 1^{\circ}\text{C}$, whichever greater) ± 1 digit max. (See Note.) Platinum resistance thermometer: $(\pm 0.5\% \text{ of indicated value or } \pm 1^{\circ}\text{C}$, whichever greater) ± 1 digit max. Analog input: $\pm 0.5\% \text{ FS} \pm 1$ digit max. CT input: $\pm 5\% \text{ FS} \pm 1$ digit max.				
Hysteresis		0.1 to 999.9 EU (in units of 0.1 EU)				
Proportional band (P)		0.1 to 999.9 EU (in units of 0.1 EU)				
Integral time (I)		0 to 3999 s (in units of 1 s)				
Derivative time (D)		0 to 3999 s (in units of 1 s)				
Control period		1 to 99 s (in units of 1 s)				
Manual reset value		0.0% to 100.0% (in units of 0.1%)				
Alarm setting range		-1999 to 9999 (decimal point position of	depends on input	type)		
Sampling period		500 ms				
Insulation resistance		20 MΩ min. (at 500 VDC)				
Dielectric strength		2000 VAC, 50 or 60 Hz for 1min (between different charging terminals)				
Vibration resistance		10 to 55 Hz, 10 m/s ² for 2 hours each in X, Y and Z directions				
Shock resistance		300 m/s ² , 3 times each in 3 axes, 6 directions (relay: 100 m/s ²)				
Weight		Approx. 150 g Mounting bracket: Approx. 10g				
Protective structure	Front panel	NEMA4 for indoor use (equivalent to IP66)				
	Rear case	IP20				
	Terminals	IP00				
Memory protection		EEPROM (non-volatile memory) (number of writes: 100,000)				
EMC		Emission Enclosure: Emission AC Mains: Immunity ESD: Immunity RF-interference: Immunity Conducted Disturbance: Immunity Burst:	EN55011 Grou EN55011 Grou EN61000-4-2: ENV50140: ENV50141: EN61000-4-4:	p 1 class A 4 kV contact discharge (level 2) 8 kV air discharge (level 3) 10 V/m (amplitude modulated, 80 MHz to 1 GHz) (level 3) 10 V/m (pulse modulated, 900 MHz) 10 V (0.15 to 80 MHz) (level 3)		
Approval standards		2 kV I/O signal-line (level 4) UL3121-1, CSA22.2 No. 14, E.B.1402C				
		Conforms to EN50081-2, EN50082-2, Conforms to VDE0106/part 100 (Finge				

Note: The indication of K thermocouples in the -200 to 1300°C range, and T and N thermocouples at a temperature of -100°C or less, and U and L thermocouples at any temperature is ± 2 °C ± 1 digit maximum. The indication of B thermocouples at a temperature of 400°C or less is unrestricted.

The indication of R and S thermocouples at a temperature of 200°C or less is ±3°C±1 digit maximum.

■ COMMUNICATIONS SPECIFICATIONS

Transmission path connection	Multiple points
Communications method	RS-485 (two-wire, half duplex)
Synchronization method	Start-stop synchronization
Baud rate	1,200/2,400/4,800/9,600/19,200 bps
Transmission code	ASCII
Data bit length	7 or 8 bits
Stop bit length	1 or 2 bits
Error detection	Vertical parity (none, even, odd) Frame check sequence (FCS): with SYSMAC WAY Block check character (BCC): with CompoWay/F
Flow control	Not available
Interface	RS-485
Retry function	Not available
Communications buffer	40 bytes

Note: The baud rate, data bit length, stop bit length, or vertical parity can be individually set using the communications setting level.

■ CURRENT TRANSFORMER (SOLD SEPARATELY) RATINGS

Dielectric strength		1,000 VAC (1 min)
Vibration resistance		50 Hz 98 m/s ²
Weight E54-CT1		Approx. 11.5 g
	E54-CT3	Approx. 50 g
Accessories (E54-CT3 only)	Armature	2
	Plug	2

■ HEATER BURNOUT ALARM SPECIFICATIONS


Max. heater current	Single-phase AC: 50 A (See Note 1.)
Input current readout accuracy	±5%FS±1 digit max.
Heater burnout alarm setting range	0.0 to 50.0 A (0.1 A units) (See Note 2.)
Min. detection ON time	190 ms (See Note 3.)

Note: 1. When heater burnout is detected on a 3-phase heater, use the K2CU-F□□A-□GS (with gate input terminal).

- 2. When the set value is "00 A," the heater burnout alarm will always be OFF. When the set value is "50.0 A," the heater burnout alarm will always be ON.
- 3. When the control output ON time is less than 190 ms, heater burnout detection and heater current measurement will not be carried out.

Nomenclature

E5CN



Press this key to select the setup level. The setup level is selected in this order: "operation level" \longleftrightarrow "adjustment level," "initial setting level" \longleftrightarrow "communications setting level."

Press this key to select parameters within each level.

Operation


■ INITIAL SETUP

On previous Controllers, sensor input type, alarm type and control period were set on DIP switches. These hardware settings are now set in parameters in setup menus. The
keys are used to switch between setup menus, and the amount of time that you hold the keys down determines which setup menu you move to. This section describes two typical examples.

Note: On the E5GN, the
Key is the
Key.

1. ON/OFF Control

Typical Application Examples



Typical Example


Input type: 0 K thermocouple -200 to 1300°C

Control method: ON/OFF control Alarm type: 2 upper limit

Alarm value 1: 20°C (For setting deviation)


Set point: 100°C

Change only the alarm value 1 and set point. The rest must be left as default settings.



2. PID Control Using Auto-tuning

Typical Application Example



PV/SP

After AT execution.

While AT is being

After AT execution.

25

150

RE

ōFF

∋ RŁ

ōn

Typical Example


4 T thermocouple -200 to 400°C Input type: Control method: PID control ST (self-tuning): OFF

Calculate PID constants by AT (auto-tuning).

Alarm type: 2 upper limit

Alarm value 1: 30°C (For setting deviation)

Set point: 150°C




Specification Setting After Turning ON Power

■ OUTLINE OF OPERATION PROCEDURES

Key Operation

In the following descriptions, all the parameters are introduced in the display sequence. Some parameters may not be displayed depending on the protect settings and operation conditions.



- Note: 1. Of these levels, the initial setting level, communications setting level, advanced function setting level and calibration level can be used only when control has stopped. Note that control is stopped when these four levels are selected. When switched back to the operation level from one of these levels, control will start.
 - For the calibration mode, refer to the relevant Operation Manual (H100 or H101).
 - 3. On the E5GN, the Key is the Key.

■ DESCRIPTION OF EACH LEVEL

Operation Level

This level is displayed when you turn the power ON. You can move to the protect level, initial setting level and adjustment level from this level.

Normally, select this level during operation. During operation, the process value, set point and manipulated variable can be monitored, and the alarm value and upper- and lower-limit alarms can be monitored and modified.

Adjustment Level

To select this level, press the \bigcirc key once for less than one second.

This level is for entering set values and offset values for control. This level contains parameters for setting the set values, AT (auto-tuning), communications writing enable/disable, hysteresis, multi-SP, input shift values, heater burnout alarm (HBA) and PID constants. You can move to the top parameter of the operation level or initial setting level from here.

Initial Setting Level

To select this level, press the \bigcirc key for at least three seconds in the operation level. This level is for specifying the input type, selecting the control method, control period, setting direct/reverse action and alarm type. You can move to the advanced function setting level or communications setting level from this initial setting level. To return to the operation level, press the \bigcirc key for at least one second. To move to the communications setting level, press the \bigcirc key once for less than one second.

Protect Level

To select this level, simultaneously press the
and
keys for at least one second. This level is to prevent unwanted or accidental modification of parameters. Protected levels will not be displayed, and so the parameters in that level cannot be modified.

Communications Setting Level

To select this level, press the \bigcirc key once for less than one second in the initial setting level. When the communications function is used, set the communications conditions in this level. Communicating with a personal computer (host computer) allows set points to be read and written, and manipulated variables to be monitored.

Advanced Function Setting Level

To select this level, you must enter the password ("-169") in the initial setting level.

You can move only to the calibration level from this level.

This level is for setting the automatic return of display mode, MV limiter, event input assignment, standby sequence, alarm hysteresis, ST (self-tune) and to move to the user calibration level.

Calibration Level


To select this level, you must enter the password ("1201") in the advanced function setting level. This level is for offsetting deviation in the input circuit.

You cannot move to other levels by operating the keys on the front panel from the calibration level. To cancel this level, turn the power OFF then back ON again.

■ SPECIFICATION SETTING (AFTER TURNING ON POWER)

Initial Setting Level

This level is used for setting basic specifications of the Temperature Controller. Using this level, set the input type for selecting the input to be connected such as the thermocouple or platinum resistance thermometer and set the range of set point and the alarm mode.




The move from the operation level to the initial setting level, press \bigcirc key for three seconds or more.

The initial setting level is not displayed when "initial/communications protection" is set to "2." This initial setting level can be used when "initial setting/communications protection" is set to "0" or "1."

The "scaling upper limit," "scaling lower limit," and "decimal point" parameters are displayed when an analog voltage input is selected as the input type.

Initial setting level



To return to the operation level, press the $\ensuremath{\bigcirc}$ key for longer than one second

*Not displayed as default setting.

- Note: 1. Displayed only with models provided with an alarm function.
 - Displayed only with the E5CN provided with a twopoint alarm function.

■ INPUT TYPE

Using a Thermocouple Input Type

When using a thermocouple input type, follow the specifications listed in the following table.

Input type	Specifications	Set Value	Input Temperature Range
Thermocouple	K	0	-200 to 1300 (°C) /-300 to 2300 (°F)
		1	-20.0 to 500.0 (°C) /0.0 to 900.0 (°F)
	J	2	-100 to 850 (°C) /-100 to 1500 (°F)
		3	-20.0 to 400.0 (°C) /0.0 to 750.0 (°F)
	Т	4	-200 to 400 (°C) /-300 to 700 (°F)
	E	5	0 to 600 (°C) /0 to 1100 (°F)
	L	6	-100 to 850 (°C) /-100 to 1500 (°F)
	U	7	-200 to 400 (°C) /-300 to 700 (°F)
	N	8	-200 to 1300 (°C) /-300 to 2300 (°F)
	R	9	0 to 1700 (°C) /0 to 3000 (°F)
	S	10	0 to 1700 (°C) /0 to 3000 (°F)
	В	11	100 to 1800 (°C) /300 to 3200 (°F)
Non-contact temperature sensor ES1A	K10 to 70°C	12	0 to 90 (°C) /0 to 190 (°F)
	K60 to 120°C	13	0 to 120 (°C) /0 to 240 (°F)
	K115 to 165°C	14	0 to 165 (°C) /0 to 320 (°F)
	K160 to 260°C	15	0 to 260 (°C) /0 to 500 (°F)
Analog input	0 to 50mV	16	One of following ranges depending on the results of scaling: 1999 to 9999, 199.9 to 999.9

Note: The initial settings are: 0: -200 to 1300° C/-300 to 2300° F.

Using a Platinum Resistance Thermometer Input Type

When using the platinum resistance thermometer input type, follow the specifications listed in the following table.

Input type	Specifications	Set Value	Input Temperature Range
Platinum resistance thermometer	Pt100	0	-200 to 850 (°C) /-300 to 1500 (°F)
		1	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)
		2	0.0 to 100.0 (°C) /0.0 to 210.0 (°F)
	JPt100	3	-199.9 to 500.0 (°C)/-199.9 to 900.0 (°F)
		4	0.0 to 100.0 (°C) /0.0 to 210.0 (°F)

Note: 1. The initial settings are: 0: Pt100 -200 to 850° C/-300 to 1500° F.

2. The ES1A Non-contact Temperature Sensor will be available soon.

■ ALARM 1 AND ALARM 2


For the alarm 1 and alarm 2, select alarm types out of the 12 alarm types listed in the following table.

Set Value Alarm Type		Alarm Output Operation		
		When X is positive	When X is negative	
0	Alarm function OFF	Output OFF		
1*1	Upper- and lower-limit (deviation)	ON → L H ←	*2	
2	Upper-limit (deviation)	ON X	ON X - X - SP	
3	Lower-limit (deviation)	ON X - X	ON → X ←	
4*1	Upper- and lower-limit range (deviation)	OFF SP	*3	
5 ^{*1}	Upper- and lower-limit with standby sequence (deviation)	OFF SP	*4	
6	Upper-limit with standby sequence (deviation)	ON → X ← SP	OFF SP	
7	Lower-limit with standby sequence (deviation)	ON → X ←	CFF SP	
8	Absolute-value upper-limit	ON X	OFF ⊕X→	
9	Absolute-value lower-limit	ON X	ON ←X→	
10	Absolute-value upper-limit with standby sequence	ON X	ON ←X→	
11	Absolute-value lower-limit with standby sequence	ON ←X→	ON →X→	


^{*1:} With set values 1, 4 and 5, the upper and lower limit values can be set independently for each alarm type and are expressed as "L" and "H."

Following operations are for cases when an alarm set point is "X" or negative.


*2: Set value: 1, upper- and lower-limit alarm



*3: Set value: 4, upper- and lower-limit range



*4: Set value: 5, upper- and lower-limit with standby sequence



Example: When the alarm is set ON at 110 °C/°F or higher.

 When an alarm type other than the absolutevalue alarm is selected

(For alarm types 1 to 7) The alarm value is set as a deviation from the set point.



 When the absolutevalue alarm is selected


(For alarm types 8 to 11) The alarm value is set as an absolute value from the alarm value of 0°C/F.




PARAMETERS

Parameters related to setting items for each level are marked in boxes in the flowcharts and brief descriptions are given as required. At the end of each setting item, press the mode key to return to the beginning of each level.


E5CN No. 1 display E5GN No. 1 display No. 2 display No. 2 display




Operation Level




Initial Setting Level



Adjustment Level



Advanced Function Setting Level



Protect Level



Operation/adjustment protection

Restricts display and modification of menus in the operation and adjustment levels.

Initial setting/communications protection

Restricts display and modification of menus in the initial setting, operation level and adjustment levels.

Setting change protection

Protects changes to setups by operating the front panel keys.

Operation/Adjustment Protection

The following table shows the relationship between set values and the range of protection.

Level		Set value			
		0	1	2	3
Operation level	PV	0	0	0	0
level	PV/SP	0	0	0	0
	Other	0	0	Х	Χ
Adjustment level		0	Χ	Х	Χ

When this parameter is set to "0," parameters are not protected.

Default setting: 0

Can be displayed and changed

: Can be displayed

 \times : Cannot be displayed and move to other levels not possible

Initial Setting/Communications Protection

This protect level restricts movement to the initial setting level, communications setting level and advanced function setting level.

Set value	Initial setting level	Communications setting level	Advanced function setting level
0	0	0	0
1	0	0	Х
2	Х	Х	Χ

Default setting: 1

○ : Move to other levels possible

imes : Move to other levels not possible

Setting Change Protection

This protect level protects setup from being changed by operating the keys on the front panel.

Set value	Description
OFF	Setup can be changed by key operation.
ON	Setup cannot be changed by key operation. (The protect level, can be changed.)

Default setting: OFF

Communications Setting Level


Set the E5CN/E5GN communications specifications in the communications setting level. For setting communications parameters, use the E5CN/E5GN panel. The communications parameters and their settings are listed in the following table.

Parameter	Displayed characters	Set (monitor) value	Set value
Communications unit No.	U-nō	0 to 99	0.1 to 99
Baud rate	bP5	1.2/2.4/4.8/9.6/19.2 (kbps)	1.2/2.4/4.8/9.6/19.2
Data bits	LEn	7/8 (bit)	7/8 (bit)
Stop bits	Sbit	1/2	1/2 (bit)
Parity	PrES	None, even, odd	nōnE/EUEn/ōdd

Note: The highlighted values indicate default settings.

Before executing communications with the E5CN/E5GN, set the communications unit No., baud rate, etc., through key operations as described below. As for other operations, refer to the relevant Operation Manual.

- Press the key for at least three seconds in the "operation level." The level moves to the "initial setting level."
- 2. Press the \infty key for less than one second. The "initial setting level" moves to the "communications setting level."
- 3. Pressing the key advances the parameters as shown in the following figure.
- Press the or keys to change the parameter setups.



Note: On the E5GN, the

Key is the

Key.

Set each communications parameter to match those of the communicating personal computer.

Communications Unit No. (U-nā)

When communicating with the host computer, the unit number must be set in each Temperature Controller so that the host computer can identify each Temperature Controller. The number can be set in a range from 0 to 99 in increments of 1. The default setting is 1. When using more than one Unit, be careful not to use the same number twice. Duplicate settings will cause malfunction. This value becomes valid when the power is turned OFF and ON again.

Baud Rate (695)

Use this parameter to set the speed of communications with the host computer. It can be set to one of the following values; 1.2 (1200 bps), 2.4 (2400 bps), 4.8 (4800 bps), 9.6 (9600 bps), and 19.2 (19200 bps).

This setting becomes valid when the power is turned OFF and ON again.

Data Bits (LEn)

Use this parameter to change the communications data bit length to 7 bits or 8 bits.

Stop Bits (552)

Use this parameter to change the communications stop bit to 1 or 2.

Parity (Pr ES)

Use this parameter to set the communications parity to None, Even, or Odd.

■ TROUBLESHOOTING

When an error occurs, an error code will be displayed on the No. 1 display. Check the contents of an error and take appropriate countermeasures.

No. 1 display	Type of error	Countermeasures	
5.Err	Input error	Check the wiring of inputs for miswiring, disconnections, short-circuits, and the input type.	
EIII	Memory error	First, turn the power OFF then back ON again. If the display remains the same, the Unit must be repaired. If the display is restored, then a probable cause can be external noise affecting the control system. Check for external noise.	
cccc	Display range over	Though not error, this is displayed when the process value exceeds the display range when the control range is larger than the display range.	
2222		• When less than "-1999" CCC	
		When larger than "9999" • When larger than "9999"	
HErr	HB error	First, turn the power OFF then back ON again. If the display remains the same, the controller must be repaired. If the display is restored, then a probable cause can be electrical noise affecting the control system. Check for electrical noise.	

Note: Error will be displayed only when the display is set for the PV or PV/SP.

Fuzzy Self-tuning _____

The fuzzy self-tuning (ST) is a function that automatically calculates an optimum PID constant depending on items to be controlled.

FEATURE

The Temperature Controller determines when to execute this fuzzy self-tuning.

■ FUNCTIONS

SRT: Performs PID tuning according to the step response method when the SP is changed.

LCT: Performs PID tuning according to the limit cycle method when the SP is changed.

Requirements for SRT Functionality

The ST will be executed according to the step response method when the following conditions are satisfied when operation is started or when the SP is changed.

When operation is started	When SP is changed
 The SP at the startup is different from the SP at the time the previous SRT was executed. (See Note.) 	The SP after change is different from the SP at the time the previous SRT was executed. (See Note.)
The temperature upon startup is smaller than the SP in the reverse operation and larger than the SP in the direct operation.	2. In the reverse operation, the value obtained by deducting the SP before change from the SP after change is larger than the ST stable range. In the direct operation, the value obtained by
Restarting of operation is not due to an input error. Note: The "SP that existed when the previous SRT was executed" refers to the SP used for obtaining the PID constant in the previous SRT.	deducting the SP after change from the SP before change is larger than the ST stable range.
	3. The SP change width is larger than the current proportional band x 1.27 + 4.
3	4. The temperature is in the stable state. (It can be in the balanced state if no output is generated when the power is turned ON.)


If the SP is changed while SRT is being executed and if SRT completion conditions are satisfied, no PID change will take place.

Stabilization State

Measured values remain in the stable range for a certain period of time.

Balanced State


Output is 0% for 60 seconds and measured values fluctuate within the width of the stable range.



Dimensions


Unit: mm (inch)

■ E5CN



Note: The suffix "500" is added to the model number of each Controller provided with a E53-COV10 Terminal Cover.

Panel Cutouts




- Recommended panel thickness is 1 to 5 mm.
- Group mounting is not possible in the vertical direction. (Maintain the specified mounting space between Controllers when they are group mounted.) To mount the E5CN so that it is waterproof, apply the waterproof seal to the E5CN.
- When two or more E5CNs are mounted, make sure that the surrounding temperature does not exceed the allowable operating temperature, as specified in the specifications.

■ TERMINAL COVER

E53-COV10






■ CURRENT TRANSFORMER (SOLD SEPARATELY)


E54-CT1





E54-CT3





Installation

SETTING UP OPTION BOARDS


If communications, event input, or heater burnout functions are required, mount the E53-CNH03 Communications Board or the E53-CNHB Event Input Board. The heater burnout function is supported on either of these two Option Boards.

Option Boards

Name	Model	Function	
Communications Board	E53-CNH03	RS-485 communications	
Event Input Board	E53-CNHB	Event inputs	


Note: Terminal label: x1

ASSEMBLY OF UNIT



- Insert the tools (see drawing above) into the slots (one on the top and one on the bottom) and release the hooks.
- Insert the tool in the space between the front and rear panels and slightly pull out the front panel. Hold the top and bottom of the front panel and pull toward yourself to remove it.
- Match up the upper and lower claws with the connection points and insert the Option Board. Mount the Option Board in the center.
- 4. Before inserting the Unit, confirm that the waterproof seal is in place. Insert the Unit into the rear case until you hear a click. When inserting the Unit, press down the hooks on the top and bottom of the rear case, so they firmly hook on the board inserted.

MOUNTING



Attaching the E5CN to a Panel

- 1. Insert the E5CN into the mounting hole in the panel.
- 2. Push the adapter along the E5CN body from the terminals up to the panel and secure it temporarily.
- Tighten the two screws on the adapter. When tightening screws, tighten the two screws alternately, keeping the torque to between 0.29 and 0.39 N•m (2.9 kgf•cm to 3.9 kgf•cm).


Attaching the Terminal Cover

Make sure that the "UP" mark is facing up, and then fit the Terminal Cover (E53-COV10) into the holes on the top and bottom. A E5CN-□-500 Controller is provided with a Terminal Cover

■ WIRING TERMINALS

The voltage output (control output) is not electrically insulated from the internal circuits. When using a grounding thermocouple, do not connect the control output terminals to the ground. If the control output terminals are connected to the ground, errors will occur in the measured temperature values as a result of leakage current.

Standard insulation is applied to the power supply I/O sections. If reinforced insulation is required, connect the input and output terminals to a device without any exposed current-carrying parts or to a device with standard insulation suitable for the maximum operating voltage of the power supply I/O section.




Two input power supplies are available: 100 to 240 VAC or 24 VDC.

■ E5CN OPTION BOARDS


E53-CNHB Event Input Unit

Event Input/Heater Burnout Detection




E53-CNH03 Communications Board

Communications Specification/Heater Burnout Specification



■ WIRING PRECAUTIONS

- Separate input leads and power lines to protect the E5CN and its lines from external noise.
- We recommend using solderless terminals when wiring the E5CN.
- Tighten the terminal screws using a torque no greater than 0.78 N•m.
- Use the following type of solderless terminals for M3.5 screws.



Precautions

OPERATING ENVIRONMENT

- Use the Temperature Controller within the rated operating temperature, storage temperature, and operating humidity specified for each model.
- Use the Temperature Controller according to the performance specifications such as vibration, shock, and degree of protection specified for each model.
- Do not use the Temperature Controller in places where it is subject to dust or corrosive gases.
- Install the Temperature Controller away from the devices that generate high-frequency noise.

■ SERVICE LIFE

The service life of relays used for the control output or alarm output varies depending on mostly switching conditions. Be sure to confirm their performance under actual operating conditions and do not use them beyond the allowable number of switchings. If they are used in a deteriorated condition, insulation between circuits may be damaged and, as a result, the Temperature Controller itself may be damaged or burned.

The service life of electronic devices such as Temperature Controllers is determined not only by the number of switchings of relays, but also by the service life of internal electronic components. The component service life is affected by the ambient temperature: the higher the temperature becomes, the shorter the service life becomes; the lower the temperature becomes, the longer the service life becomes. For this reason, the service life can be extended by lowering the internal temperature of the Temperature Controller.

When two or more Temperature Controllers are mounted horizontally close to each other or vertically next to each other, the internal temperature will increase, due to heat radiated by the Temperature Controllers, and the service life will decrease. In these situations, forced cooling by fans or other means of air ventilation will be required to cool down the Temperature Controllers. When providing forced cooling, however, be careful not to cool down the terminals solely, to avoid measurement errors.

ORDERING PRECAUTIONS

Units separately sold, such as Control Output Units and Current Transformers, are specified for each Temperature Controller. Be sure to order appropriate units according to the application.

■ INSTALLATION

Mounting

Mount the Temperature Controller horizontally level.

Connection

When extending or connecting the thermocouple lead wire, be sure to use compensating wires that match the thermocouple types.

When extending or connecting the lead wire of the platinum resistance thermometer, be sure to use wires that have low resistance.

When wiring the platinum resistance thermometer to the Temperature Controller, keep the wire route as short as possible. Separate this wiring away from the power supply wiring and load wiring to avoid inductive or other forms of noise.

Do not use empty terminals.

Crimp Terminal Connection

Use crimp terminals that match M3.5 screws. M3.5 x 8 self-rising screws are used.

E5CN



Be careful not to excessively tighten the terminals screws.

Soldering Connection

The self-rising screws provide easy soldering connection. Strip the lead wire by a length of 6 to 8 mm.



■ OPERATING PRECAUTIONS

For Temperature Controllers with alarm outputs, alarm output may not be generated correctly when an abnormality occurs in the device. A separate alarm device should be incorporated into the system.

To ensure proper performance, parameters of the Temperature Controllers are set to default values before they are shipped. Change these parameters depending on actual applications. If left unchanged, the Temperature Controller will operate under the default settings.

It takes several seconds for the relay to turn ON from the moment the power is turned ON. Consider this time when incorporating Temperature Controllers in a sequence circuit.

When pulling out the Temperature Controller body, do not apply excessive force. After the body is removed, be careful not to apply any shock to the connectors or other electronic components on the PCB.

Models without any specification on their degree of protection or those with $IP \square 0$ do not offer a waterproofing feature.




OMRON ELECTRONICS, INC.
One East Commerce Drive
Schaumburg, IL 60173
1-800-55-OMRON

OMRON CANADA, INC. 885 Milner Avenue Scarborough, Ontario M1B 5V8 416-286-6465



neptronic®

Specification & Installation instruction



Feature:

 Mounts easy on round & square shaft (with option –8).

External clutch for manual adjustments.

Maintenance free.

· Position indicator.

Control signal fully programmable.

 The fastest actuator of the world (model BM___FF).


• Fail safe by Enerdrive System.¹ (on model 060 & 080).

 Auxiliary switches (on model 020 & 080).

Old Number	
BBM2000A	BM000
BBM2021A	BM020
BBM2060A	BM060
BBM2080A	BM080
BBMF2000A	BM000F
BBMF2021A	BM020F
BBMF2060A	BM060F
BBMF2080A	BM080F
BBMFF2000A	BM000FF
BBMFF2021A	BM020FF
BBMFF2060A	BM060FF
BBMFF2080A	BM080FF

Technical Data	BM000 BBM 2000A	BM020 BBM 2021A	BM060 BBM 2060A	BM080 BBM 2080A	BM000F BBMF 2000A	3M020F 8BMF 2021A	BM060F BBMF 2060A	BM080F BBMF 2080A	BMC00FF BBMFF 2000A	BM020FF BBMFF 2021A	BM060FF BBMFF 2060A	BM080FF <i>BBMFF</i> 2080A
Auxiliary switches	No	Yes(2)	No	Yes(2)	No	Yes(2)	No	Yes(2)	No	Yes(2)	No	Yes(2)
Fail safe - Enerdrive	N	lo	Y	es	N	0	Y	es	N	lo	Y	es
Power consumption	6	VA	15VA 6\	Peak, /A	15	√A		Peak, VA	15 VA		24VA Peak, 15VA	
Torque	50 in.l	50 in.lb. [5,6 Nm] at rated voltage			35 in.lk	. [3,9 Nm	at rated v	oltage	25 in	.lb. [2,8 Nm]		
Running time through 90°	20 to	20 to 30 sec torque dependant 3.5 to 4.5 sec torque dependant 1.5 to 2.5 sec torque depend										
Feedback		4 to 20 mA or 2 to 10 VDC adjustable										
Power supply		22 to 26 VAC or 28 to 32 VDC										
Electrical connection		18 AWG [0.8 mm²] minimum										
Inlet bushing				2 i	nlet bushin	g of 5/8 in	[15.9 mm] & 7/8 in	[22.2 mm]			
Control signal		Analog	, Digital o	r Pulse wit	h modulati	on (PWM)	programn	nable (fact	ory set with	Analog con	troi signal)	
Angle of rotation			(0 to 90 de	grees, med	hanically	adjustable	(factory se	et with 90° s	troke)		
Direction of rotation			Reversible	e, Clockwi	se (CW) or	Counter	lockwise (CCW) (fac	tory set with	CW directi	on)	
Ambient temperature					-22°	F to +122	°F [-30° C	to +50° C				
Storage temperature					-22°	F to +122	°F [-30° C	to +50° C]				
Relative Humidity				· · · · · · · · · · · · · · · · · · ·			non conde					
Weight			***************************************				s. [1.4 kg]					
	Wa	rning:	Do not	press	the clu				s power	ed		

Dimensions



	Dimension	Inches	Metric (mm)	
	A	1.50	38.1	
	В	3.26	82.8	
	С	6.60	167.5	
ח	model 000 & 060	3.01	76.4	
٦	model 020 & 080	3.72	94.5	

Caution

We strongly recommend that all neptronic® products be wired to a separate transformer and that transformer shall service only neptronic® products. This precaution will prevent interference with, and/or possible damage to incompatible equipment.


When multiple actuators are wired on a single transformer, polarity must be observed. Long wiring runs create voltage drop which may affect the actuator performance.






¹ Enerdrive System U.S.A. Patent #5,278,454

Mechanical installation




- Manually close the damper blades and positioned the actuator at 0° or 90°.
- 2. Slide the actuator onto the shaft.
- 3. Tighten the nuts on the "U" bolt to the shaft with a 8mm wrench to a torque of 60 in.lb. [6,7 Nm].
- Slide the mounting bracket under the actuator. Ensure free movement of the slot at the base of the actuator. The bracket pin must be placed in the mid distance of the slot.
- 5. Fix the bracket to the ductwork with #8 self-tapping screws.

Wiring Diagrams



PC Board



Stroke adjustment - No control signal change

- 1. Apply power and, wait for at least 10 seconds.
- Press and release the reset button to start the auto-stroke process. The LED should be illuminated.
 - . First option:

The actuator will then travel in both directions to find it's limit and position itself according to the demand. The LED will extinguish, the process is complete.

Second option:

When the desired end position is reached, press and release the reset button. The actuator will now return back to its original position. (you can also press and release the reset button when It's reaches the original position) The LED will extinguish, the process is complete.

Programming - Change of control signal

- Remove power and put all dip switches "OFF". (factory preset).
- Apply power and, within 10 seconds, press and release the reset button. The LED should be blinking.
- Select the control signal with dip switches:
 - Digital (On/Off or 3 point floating) move switch No1 "ON" and then "OFF".

move switch No2 "ON" and then "OFF".

Analog (factory preset) move switch No3 "ON" and then "OFF".

Stroke adjustment

see the stroke adjustment section above.

Note, If PWM mode is selected:

. Time base: When programming is done,

if switch No3 is "on" time base is 0.1 to 5 sec. (resolution 20 msec.)

If switch No3 is "off" time base is 0.1 to 25 sec. (resolution 100 msec.)

* For 5 sec. time base, we strongly recommend a switch common connection for better position stability.

- Switch 24 VAC: Triac or dry contact, 40mA maximum switching current.
- Switch common: NPN transistor, SCR, Triac or dry contact 75mA maximum switching current.

Feedback selection (CCW direction)

To select CCW direction put switch No1 "ON".

In Analog or 3 point floating mode you can program the feedback control.

If switch No3 is "OFF":

The feedback control is automatically reverse to 4 to 20 mA for 90 to 0 degrees.

If switch No3 is "ON":

The feedback control is to 20 to 4 mA for 90 to 0 degrees.





Zero and span calibration

This feature is applicable to analog control signal only.

- 1. Remove power and put all dip switches "OFF". (factory preset).
- 2. Apply power and, within 10 seconds press and hold the reset button until the LED blinks once. The Zero and span calibration process then start.
- Release the reset button. The LED is now constantly illuminated.
- 4. Apply new minimum voltage.

It can be any value between 0 to 7 VDC, with an external 0 to 10 volt supply (ex: MEP).

- 5. Press and release the reset button to memorize the new minimum voltage. The LED blinks once.
- 6. Apply new maximum voltage.

It can be any value between 3 to 10 VDC, this value should be greater than the new minimum value.

7. Press and release the reset button to memorize the new maximum voltage. The LED blinks once. The Zero and span calibration process is complete.

Note: To reset zero and span to 2 to 10 VDC (factory value). You just have to re-select the analog control signal mode, see Programming.







High-Temperature In-Situ Oxygen Sensor for Combustion Trim Control Applications



MAXIMIZE Combustion Efficiency MINIMIZE NO_x formation **REDUCE** fuel costs

Providing dependable and verifiable oxygen measurement in the fossil fuel-fired environments found in most steel, glass, power generation, petrochem and petroleum refining, as well as kilns and incinerator applications. Oxyfire users worldwide include PPG, Owens Corning, North Star Steel, NIPSCO, Entergy, Hylsa, LTV, Saint Gobain and many others. Oxyfire is a low-cost, Clean Air Act-compliant technology.

Oxyfire "Measures where it Matters" in the combustion chamber, close to the source of combustion. So response to combustion atmosphere change is instant and precise and there is no need for the compensation of an extractive

Features and Performance Advantages:

- High temperature capability (550°C-1600°C)
- Most accurate/rapid response
- Integral T/C
- On-line verification
- Patented high temperature ceramic "boot"
- No external power, calibration or artificial heating required
- Intrinsically safe*
- TÜV certified
- CE marked
- Wet O₂ reading vs. dry reading

or heated system.



Jxvfire



3100 E. Kemper Rd. Cincinnati, OH 45241-7007 (800) 547-1055 (513) 772-1000 fax (513) 326-7090



Operation

Oxyfire works by 1.25" precisely measuring the net concentration of oxygen in a process; i.e. the amount of oxygen that remains after combustion is completed. At its core is the platinum-coated zirconia cell, which measures the emf potential in millivolts, that is generated by the diffusion across the cell wall, and is logarithmically proportional to the oxygen concentration. Also included is a required "B" type (R and S types optional)

Verification Gas (Input) thermocouple which provides the sensor temperature needed

Specifications

for the O_2 calculation.

Net 02 Range

Accuracy $\pm 1.5\%$ of observed process variable or 0.05% 0₂,

whichever is greater

Reference Air (Input)

Control System Interface Marathon VersaPro-O or Smart Transmitter panel Response Time Less than one second for 98% of final value. Stability

Less than 1% deviation in signal output over the life

of the sensor.

Temperature Limits:

550°C - 1600°C, (1022°F - 2912°F)

Terminal Head Ambient to 149°C, (300°F)

Mounting Vertical or horizontal

Construction:

Inner Tube

Outer Protection Sheath

Sensor Head

Integral T/C

Integral Verification Port/Fitting

Alumina, Silicon Carbide, HR-160 high temperature alloy, Zirconia

Air-tight, machined 6061-T6 aluminum, (cast aluminum, Class 1 available)

Type "B" standard, "R" and "S" optional

Sensor Insertion Lengths 6", 12", 18", 24", 30", 36", 42", 48" (non-std)

Speed of Insertion 1 inch (25.4mm) per 5 minutes

Reference Air Requirement 50 – 150 cc per minute (less than 2 psi) clean, dry air

1/4" tubing fittings

Cabling Shielded four conductor, stranded, twisted-pair.

Belden #89418 or equivalent.

* The Oxyfire oxygen sensor is a "simple apparatus" and thereby intrinsically safe per EN50 14 (1977) Clause 1.3.

Oxyfire is industry's Ultimate Answer to precise combustion trim. It is a powerful, proven cost-savings tool that will instantly and permanently reduce fuel use, and maintenance, while it improves productivity.

- If you're a steelmaker, Oxyfire offers another advantage, in that it can substantially reduce process scale.
- Helps reduce costs for fuel and "air" in Oxy-Fuel fired systems.

To find out what Oxyfire can do for YOU, talk with Marathon at (800) 547-1055 or visit www.**MARATHONSENSORS**.com

Marathon Sensors Inc.

OxymitTM Transmitter Operators Manual



F200060

Revision: 00 04/18/2001 01 04/23/2001 02 05/08/2001 03 09/19/2001 04 11/01/2001 05 11/21/2001 06 04/19/2002 07 10/30/2002 08 11/13/2002 09 11/06/2003 10 12/03/2003 11 09/30/2004 12 04/04/2005 13 04/11/2005 14 11/14/2006

COPYRIGHT © 2004 MARATHON SENSORS INC. 3100 East Kemper Road, Cincinnati, Ohio 45241 1-800-547-1055 (513) 772-1000 FAX: (513) 326-7090

All trademarks used in this publication are duly marked and the sole property of their respective owners. No attempt at trademark or copyright infringement is intended or implied.

Marathon Sensors makes no warranties express or implied beyond the written warranty presented at initial purchase. Marathon Sensors Inc. is not responsible for any product, process, damage or injury incurred while using this equipment. Marathon Sensors makes no representations or warranties with respect to the contents hereof and specifically disclaims any warranties of merchantability or fitness for any particular application or purpose.

Table of Contents

GENERAL DESCRIPTION	
SAFETY SUMMARY	3
CONNECTIONS	3
GROUNDING AND SHIELDING	
PARAMETER SELECTIONS	4
Process Type	5
Carbon Process Factor Dew Point Process Factor	5
Oxygen Exponent TC Type ANALOG OUTPUT CHANNELS	6
CALIBRATION	
PROCESS VARIABLE CALCULATIONS	8
PERCENT OXYGEN	8
PERCENT CARBON	
DEWPOINT	8
COMMUNICATIONS	9
Modbus	
RTU Framing	
Address Field	
Function Field	
Data Field Error Check Field (CRC)	
• • •	
MEMORY MAP	12
OPERATIONAL SPECIFICATIONS	

NOTE:

Please specify the following parameters when ordering a transmitter; process type, process range (%, ppm), thermocouple type, temperature scale F/C, analog output 1 process and scale, analog output 2 process and scale.

Typical Oxygen Transmitter Calibration (F840030)

Calibration	Measured Value or	Output / Units
Function	Input	
Cold Junction	Room Temp	°F
Thermocouple	800°F (B type)	°F
min	standard t/c type	
Thermocouple	3000°F (B type)	°F
max	standard t/c type	
Millivolt	0.0 mV	Millivolts
Millivolt	2000 mV	Millivolts
Analog 1 Zero	0% O2	4.0 mA +/- 0.1
Analog 1 Span	20.9% O2	20.0 mA +/- 0.1
Analog 2 Zero	800°F +/- 5°	4.0 mA +/- 0.1
Analog 2 Span	3000°F +/- 5°	20.0 mA +/- 0.1

Typical Carbon Transmitter Calibration (F840031)

Calibration Function	Measured Value or Input	Output / Units
Cold Junction	Room Temp	°F
Thermocouple	MUST BE	°F
Min	SPECIFIED	
Thermocouple	MUST BE	°F
Max	SPECIFIED	
Millivolt	0.0 mV	Millivolts
Millivolt	2000 mV	Millivolts
Analog 1 Zero	0% Carbon	4.0 mA +/- 0.1
Analog 1 Span	2.55% Carbon	20.0 mA +/- 0.1
Analog 2 Zero	MUST BE	4.0 mA +/- 0.1
	SPECIFIED	
Analog 2 Span	MUST BE	20.0 mA +/- 0.1
	SPECIFIED	

General Description

The OxymitTM Transmitter has been designed to work as an analog or digital interface for any zirconia based oxygen probe used to track dew point, carbon potential, or oxygen. The transmitter connects to the temperature and millivolts outputs of an oxygen probe and can produce analog outputs proportional to the selected process value.

The features available are:

- Isolated inputs for thermocouple and probe millivolt
- 24 bit Sigma-Delta ADC for inputs.
- Serial EEPROM to store setup and calibration values.
- Two isolated self-powered 4-20mA outputs for process value and temperature.

The transmitter makes a carbon or oxygen probe an intelligent stand alone sensor. The transmitter is located near the probe, preferably mounted in an enclosure. The transmitter mounts onto a DIN rail and requires a 24VDC power supply. It measures the probe temperature and millivolts. At the time of order the transmitter can be configured to calculate percent carbon, dewpoint, or percent oxygen from these inputs. The results of any of these calculations are made available via two 4-20mA loop outputs. Typically one first loop is set up for the process value the second loop transmits probe temperature.




Figure 1 BLOCK DIAGRAM

Safety Summary

All cautions and instructions that appear in this manual must be complied with to prevent personnel injury or damage to the Probe Transmitter or connected equipment. The specified limits of this equipment must not be exceeded. If these limits are exceeded or if this instrument is used in a manner not intended by Marathon Sensors Inc., damage to this instrument or connected devices could occur.

Do not connect this device directly to AC motors, valves, or other actuators. All AC alarm functions must be connected through an interposing DC coil relay with a maximum coil load of 0.5 amps DC. The Probe Transmitter is not rated to act as a safety device. It should not be used to provide interlocking safety functions for any temperature or process functions. Alarm capabilities are provided for probe test and input faults only and are not to be considered or used as safety contacts in any application.

Connections

The Probe Transmitter has four removable terminal blocks grouped with four terminals each. Each terminal is a wire clamp type with a standard slot screw. Each clamp can accommodate AWG 24 to 12 flexible stranded wire. Maximum torque on the terminal screws should not exceed 0.8 Nm.

The figure below shows the arrangement of the terminals.




Figure 2 Terminal Layout

The next figure shows a schematic representation of the Probe Transmitter and typical connections required in the field.




Figure 3 Schematic Connections

Grounding and Shielding

To minimize the pick-up of electrical noise, the low voltage DC connections and the sensor input wiring should be routed away from high-current power cables. Where it is impractical to do this, use shielded cables with the shield grounded at the Probe Transmitter enclosure ground as show above.

Parameter Selections

The following tables list the parameters available in the Probe Transmitter. Default values are also listed. The default values are loaded if a reset is force in the device. Changes to these parameters must be specified at the time of order.

Process Parameters

The following table shows the process selections and other parameters that effect the process value.

Table 1 Process Parameters

Parameter Name	Selection Default	Units or Options	Range
PROCESS TYPE	%O2	CARBON, DPT, %O2, MV	
CARB PROC FACT	150		0 to 1000
DEWPT PROC FACT	150		0 to 1000
OXYGEN EXPON	0002	POWER OF TEN	0 to 31
TC TYPE	В	B, C, E, J, K, N, NNM, R, S, T	

Process Type

Selecting the process type determines what type of calculation the Smart Transmitter is going to do based on the probe millivolt and probe temperature inputs. The default process value for the Smart Transmitter is %O2 with an exponent selection of 2. This is the selection most often used in Boiler control and Combustion applications.

Percent Carbon and dew point are typically processes that are used in steel treating applications. Percent Carbon is the process value most often used for the control of case depth or the percent of carbon in a steel hardening furnace. Dew Point is used in the control for endothermic generators.

Carbon Process Factor

The carbon process factor can be used to adjust the % carbon value. This number takes into account a number of assumptions that the carbon value is based on. Primary among these is the assumed level of CO in the atmosphere. See the Theory of Process Calculation section for a complete explanation of this value.

It maybe necessary to change the apparent furnace carbon as measured by the oxygen probe if this value is different than actual load samples, shim stocks, or gas analysis. The basic rule of thumb is that an increase is the carbon process factor will decrease the apparent carbon level in the furnace. The default value is 150. Typical values can very from 50 to 400. Increase or decrease the process factor until the desired carbon level is achieved. A process factor that is drastically different than normal may be an indication of a failing probe, water or air leak in the furnace, or excess methane present. Refer to probe troubleshooting guides to determine what other factors maybe effecting the carbon value.

Dew Point Process Factor

The dew point process factor is similar to the carbon process factor but is used to adjust the dew point value if dew point is selected as the process value. This number takes into account a number of assumptions that the dew point value is based on. Primary among these is the assumed level of hydrogen in the atmosphere. See the Theory of Process Calculation section for a complete explanation of this value.

Oxygen Exponent

The range of oxygen is factory configured using the oxygen exponent number. Percent oxygen is the standard setting where the oxygen exponent is set to 2 and the output range is 0.00% to 20.9%. For a part per million (ppm) range the exponent would be set to 6 and the output range of 0.00×10^{-6} to 99.99×10^{-6} .

TC Type

The following table shows the available thermocouple types and the ranges. BOLD indicates the typical oxygen default.

Thermocouple type	Zero °F	Zero °C	Span °F	Span °C
B	800	425	3000	1650
С	32	0	3000	1650
Е	32	0	1300	700
J	32	0	1300	700
K	32	0	2300	1260
N	32	0	2300	1260
NNM	32	0	2000	1090
R	300	150	3000	1650
S	300	150	3000	1650
T	32	0	700	370

The Cold Junction correction is applied to all thermocouple types.

Analog Output Channels

The analog outputs are factory configured to provide 4 to 20mA signals proportional to selectable process values.

NOTE The Analog Output Channels are isolated self-powered current sources and do not require an external supply.

If a chart recorder is to be used, it should have input specifications within 4 to 20 mA. If the recorder only responds to VDC inputs it will be necessary to add a 250 ohm dropping resistor across its input terminals.

The ideal location of the recorder is adjacent to the instrument but it may be located remotely if the connecting wires are properly shielded. For best results, the chart recorder input(s) should be isolated from ground.

Table 2 Analog Outputs

Parameter	Oxygen	Possible	Possible						
Name	Default	Options	Ranges						
OUTPUT 1	O2	O2, CARBON,	O2 = 0 - 9999						
MODE		DEWPT, TEMP, LIN,	%C = 0.00 - 2.55						
	0-20.9%	PROG	DP = -99.9 - 212.0						
	4-20mA		Temp = $-999 - 3000$						
			LIN = -999 – 9999						
			PROG = 0 - 4095						
OUTPUT 2	TEMP	O2, CARBON,	O2 = 0 - 9999						
MODE		DEWPT, TEMP, LIN,	%C = 0.00 - 2.55						
	800-3000°F	PROG	DP = -99.9 - 212.0						
	4-20mA		Temp = $-999 - 3000$						
			LIN = -999 – 9999						
			PROG = 0 - 4095						

NOTE: SEE PAGE 4 FOR TYPICAL CALIBRATION VALUES.

Calibration

The Smart Transmitter is factory calibrated. The calibration can be verified once a year or according to customer calibration schedules. The instrument should be returned to the factory if calibration is required.

Rev. 14

Process Variable Calculations

The transmitter has a selectable process calculation for percent carbon, percent oxygen, or dewpoint. The following equations are used to derive these values;

Percent Oxygen

$$\% O2 = \frac{20.95}{e(E/0.0215*Tk)}$$

Where: E = probe millivolts, Tk = probe temperature in degrees Kelvin.

The 20.95 is the %O2 in air.

Percent Carbon

Where: E = probe millivolts, Tk = probe temperature in Kelvin, and PF is the process factor.

Dewpoint

Where: E = probe millivolts, Tr = probe temperature in Rankin, PF is the process factor, and DP is the dewpoint in Fahrenheit.

Communications

The Transmitter is capable of digital communications using the Modbus protocol. This is possible by connecting to the half duplex RS-485 terminals using a shielded twisted pair.

Modbus

The MODBUS protocol describes an industrial communications and distributed control system (DCS) that integrates PLCs computers, terminals, and other monitoring, sensing, and control devices. MODBUS is a Master/Slave communications protocol, whereby one device, (the Master), controls all serial activity by selectively polling one or more slave devices. The protocol provides for one master device and up to 247 slave devices on a RS-485 half duplex twisted pair line. Each device is assigned an address to distinguish it from all other connected devices. All instruments are connected in a daisy-chain configuration.

The instrument communicates with baud rate settings 1200, 2400, 4800, 9600, or 19.2K. The default baud rate is 19.2Kbuad. The default address is 1. Changes to these values can be made by writing to the appropriate memory register.

The Transmitter communicates in Modbus RTU (Remote Terminal Unit) protocol using 8-bit binary data characters. Message characters are transmitted in a continuous stream. The message stream is setup based on the following structure:

Number of bits per character:

Start bits 1
Data bits (least significant first) 8

Parity None only (no bits for no parity)

Stop bits 1

Error Checking CRC (Cyclical Redundancy Check)

The Transmitter recognizes three RTU commands. These are: read single I registers (command 4), read a single H register (command 3), and preset a single H register (command 6)

In Modbus mode, the Transmitter can be only be configured for the 'none' parity option.

The instrument never initiates communications and is always in receive mode unless responding to a query.

RTU Framing

Frame synchronization can be maintained in RTU transmission mode only by simulating a synchronous message. The instrument monitors the elapsed time between receipt of characters. If three and one-half character times elapse without a new character or completion of the frame, then the instrument flushes the frame and assumes that the next

Page 9 of 23

byte received will be an address. The follow command message structure is used, where T is the required character delay. Response from the instrument is based on the command.

T1,T2,T3 ADDRESS FUNCTION DATA CHECKSUM T1,T2,T3 8-BITS 8-BITS N X 8-BITS 16-BITS

Address Field

The address field immediately follows the beginning of the frame and consists of 8-bits. These bits indicate the user assigned address of the slave device that is to receive the message sent by the attached master.

Each slave must be assigned a unique address and only the addressed slave will respond to a query that contains its address. When the slave sends a response, the slave address informs the master which slave is communicating.

Function Field

The Function Code field tells the addressed slave what function to perform. MODBUS function codes are specifically designed for interacting with a PLC on the MODBUS industrial communications system. Command codes were established to manipulate PLC registers and coils. As far as the Transmitter is concerned, they are all just memory locations, but the response to each command is consistent with Modbus specifications.

The high order bit in this field is set by the slave device to indicate an exception condition in the response message. If no exceptions exist, the high-order bit is maintained as zero in the response message.

Data Field

The data field contains information needed by the slave to perform the specific function or it contains data collected by the slave in response to a query. This information may be values, address references, or limits. For example, the function code tells the slave to read a holding register, and the data field is needed to indicate which register to start at and how many to read.

Error Check Field (CRC)

This field allows the master and slave devices to check a message for errors in transmission. Sometimes, because of electrical noise or other interference, a message may be changed slightly while it is on its way from one device to another. The error checking assures that the slave or master does not react to messages that have changed during transmission. This increases the safety and the efficiency of the MODBUS system.

The error check field uses a CRC-16 check in the RTU mode.

Page 10 of 23

The following is an example of a function 03 call for data at memory location 03. The value returned by the instrument is the hex value 1E.

Transmit from Host or Master

Address	Cmd	Reg HI	Reg LO	Count HI	Count LO	CRC HI	CRC LO
01	03	00	03	00	01	74	0A

Response from Transmitter

Address	Cmd	Byte Count	•	Data HI	Data LO	CRC HI	CRC Lo
		HI	LO				
01	03	00	02	00	1E	38	4C

Note that all the values are interpreted as hexadecimal values. The CRC calculation is based on the A001 polynomial for RTU Modbus. The function 04 command structure is similar to the 03 structure.

The following is an example of a function 06 call to change data in register 01 to 200. The response from the instrument confirms the new value as being set.

Transmit from Host or Master

Address	Cmd	Reg HI	Reg LO	Data HI	Data LO	CRC HI	CRC LO
01	06	00	01	00	C8	D9	9C

Response from Transmitter

Address	Cmd	Reg	Reg	Data	Data	CRC	CRC
		HI	LO	HI	LO	HI	LO
01	06	00	01	00	C8	D9	9C

The Transmitter will respond to several error conditions. The three exception codes that will generate a response from the instrument are:

01 – Illegal Function

02 - Illegal Data Address

03 – Illegal Data Value

04 – Slave Device Failure

The response from the Transmitter with an exception code will have the most significant bit of the requested function set followed by the exception code and the high and low CRC bytes.

Memory Map

NOTE: Modbus refers to the hexadecimal register location. These parameters are formatted as unsigned 16 bit integers. Any real number such as temperature can be evaluated as a signed number, other parameters are bit mapped words that must be evaluated as single bits are bit groups.

			BLOCK 0	
HEX	DEC	PARAMETER	DESCRIPTION	READ/WRITE
00	0	Not used		READ ONLY
01	1	I .	LOW BYTE - TIMER CONTROL BIT 0 – Timer Disabled (0), Timer Enabled (1) BIT 1 – 7 SPARE HIGH BYTE – SIO SETUP BITS 8 – 9 PARITY SETTING 00 = Even Parity, 7 bits, 1 Stop bit 01 = No Parity, 8 bits, 1 Stop bit 10 = Odd Parity, 7 bits, 1 Stop bit BITS 10 – 11 RESPONSE DELAY 0 = No delay applied to response 1 = 10ms delay applied to response 2 = 20ms delay applied to response 3 = 30ms delay applied to response BITS 12 – 14 BAUD SELECT 000 = 76.8K 001 = 38.4K 010 = 19.2K (DEFAULT) 011 = 9600 100 = 4800 101 = 2400 111 = 600 BIT 15 HOST FORMAT 0 = MSI (PROP) 1 = MODBUS (DEFAULT)	READ/WRITE
02	2	TC_ZERO TC_SPAN	LOW BYTE - TC ZERO CALIBRATION NUMBER HIGH BYTE – TC SPAN CALIBRATION NUMBER	READ/WRITE
03	3	MV_ZERO MV_SPAN	LOW BYTE – MV ZERO CALIBRATION NUMBER HIGH BYTE – MV SPAN CALIBRATION NUMBER	READ/WRITE
04	4	PF	PROCESS FACTOR FOR CARBON OR DEWPOINT RANGE = 0 to 4095	READ/WRITE

BLOCK 0						
HEX	DEC	PARAMETER	DESCRIPTION	READ/WRITE		
			DEFAULT = 150			
05	5	EVENT LDLN	LOW BYTE – INPUT EVENT CONFIGURATION Bits 0 – 3 0000 = None 0001 = Auto Mode Selected 0010 = Remote Setpoint Selected 0011 = Acknowledge alarms 0100 = Timer Hold 0101 = Timer End 0110 = Timer Start 0111 = Start probe test 1000 = Process hold Bits 4 – 7 not used.	READ/WRITE		
	_		LOW DYTE OOL D. WINGTON TOWN			
06	6	CJTRM HADR	LOW BYTE - COLD JUNCTION TRIM COLD JUNCTION TRIM (unsigned integer) RANGE = -128 TO +127 WHERE 1 COUNT = 1 DEG (C or F) and -128 = 65408 HIGH BYTE - HOST ADDRESS BITS 0-7 RANGE = 0 - 255			
07	7	SPARE	SPARE			
08	8	CONFIGO	Input Configuration BITS 0-3 TC Input TYPE 0000 = B (DEFAULT) 0001 = E 0010 = J 0011 = K 0100 = N 0101 = R 0110 = S 0111 = T 1000 = SPARE 1001 = SPARE 1010 = SPARE 1010 = SPARE 1110 = SPARE 1110 = SPARE 1110 = SPARE 1110 = SPARE 1111 = SPARE 1111 = SPARE BIT 4 = SPARE BIT 5 0 = NO CJ APPLIED, 1 = CJ APPLIED BIT 6 0 = °F, 1 = °C BIT 7 0 = 60HZ FILTER BIT 8 - 11 Millivolt Input TYPE 0000 = LINEAR (DEFAULT) All other bit combinations are spare	READ/WRITE		
00	_	CONFICS	BITS 12 – 15 are spare			
09	9	CONFIG2	SETUP VALUES			

			BLOCK 0	
HEX	DEC	PARAMETER	DESCRIPTION	READ/WRITE
			BITS 0 - 4 OXYGEN EXPONENT RANGE = 0 to 31, where 2 = % and 6 = ppm DEFAULT = 2 BITS 5 - 6 DISPLAY DECIMAL PLACE where: 0 = no decimal point in display 1 = Display XXX.X 2 = Display XX.XX 3 = Display XX.XX DEFAULT = 0 BITS 8 - 12 REDOX METAL NUMBER RANGE = 0 - 14 DEFAULT = 0 BITS 13 - 15 SPARE	
OA	10	FAULT	FAULT BIT MAP BIT 0 = Temperature Input Open BIT 1 = MV Input Open BIT 2 = Range of input is low BIT 3 = Range of input is high BIT 4 = Timer End BIT 5 = Probe Care Fault BITS 6 - 7 = SPARE BIT 8 = CPU Fault BIT 9 = Min Idle counter = 0 BIT 10 = Keyboard failure, stuck key or a key was pressed during power up. BIT 11 = Flash Erase Failed BIT 12 = Flash Checksum Failed BIT 13 = EEPROM Checksum Failed BIT 14 = Flash/EEPROM Size Fault BIT 15 = ADC Fault	READ ONLY
ОВ	11	ASRC	ANALOG OUT SOURCES LOW BYTE, ANALOG OUTPUT 1 BITS 0 – 3 0000 = N/A 0001 = Temperature 0010 = Linear Input A 0011 = Carbon value 0100 = Dewpoint value 0101 = Oxygen value 0110 = Redox value 0111 = Output Power 1000 = Control Output 1 1001 = Control Output 2 1010 = Linear Input B 1011 = Programmable* *For Programmable, write required output value into DACV1, where DACV1 = 0 is minimum output and DACV1 = 4096 is maximum output. BITS 4 – 7 SPARE	READ/WRITE

			BLOCK 0	
HEX	DEC	PARAMETER	DESCRIPTION	READ/WRITE
ПЕХ	DEC	PARAIVIE I ER	HIGH BYTE, ANALOG OUTPUT 2 BITS 8 – 12 0000 = N/A 0001 = Temperature 0010 = Linear Input A 0011 = Carbon value 0100 = Dewpoint value 0101 = Oxygen value 0110 = Redox value 0111 = Output Power 1000 = Control Output 1 1001 = Control Output 2 1010 = Linear Input B 1011 = Programmable* *For Reference Number and Programmable , write required output value into DACV2, where DACV2 = 0 is minimum output and DACV2 = 4096 is maximum output. BITS 13 – 15 SPARE Special case: If Analog Output 1 = CONTROL OUTPUT 1 and Analog Output 2 = CONTROL OUTPUT 2 and the Control Mode is dual, then Analog Output 1 is 4-20ma for 0 to +100% PO and Analog Output 2 is 4-20ma for 0 to -100% PO.	KEAD/WKITE
0C	12	DAC OFFSET 1	DAC 1 OFFSET CALIBRATION	READ/WRITE
0D	13	DAC_SPAN_1	DAC 1 SPAN CALIBRATION	READ/WRITE
0E	14	+	DAC2 OFFSET CALIBRATION	READ/WRITE
0F	15	DAC_SPAN_2	DAC2 SPAN CALIBRATION	READ/WRITE
10	16	AOUTOF1	ANALOG OUTPUT 1 OFFSET Minimum source value that correlates to minimum Analog Output of 4 mA. The source value is based on the selection in ASRC lower byte	READ/WRITE
11	17	AOUTRN1	ANALOG OUTPUT 1 RANGE Maximum source value that correlates to maximum Analog Output of 20 mA. The source value is based on the selection in ASRC lower byte where	READ/WRITE
12	18	AOUTOF2	ANALOG OUTPUT 2 OFFSET Minimum source value that correlates to minimum Analog Output of 4 mA. The source value is based on the selection in ASRC upper byte	READ/WRITE
13	19	AOUTRN2	ANALOG OUTPUT 2 RANGE Maximum source value that correlates to maximum Analog Output of 20 mA. The	READ/WRITE

	BLOCK 0				
HEX	DEC	PARAMETER	DESCRIPTION	READ/WRITE	
			source value is based on the selection in ASRC upper byte where		
14	20	SPARE	SPARE	READ/WRITE	
15	21	SPARE	SPARE	READ/WRITE	
16	22	SPARE	SPARE	READ/WRITE	
17	23	TEMPFIL	Temperature Input Filter in seconds Range = 0 to 3276. The higher the number the faster the reading update. DEFAULT = 1000	READ/WRITE	

	BLOCK 1					
HEX	DEC	PARAMETER	DESCRIPTION	READ/WRITE		
18	24	MVFIL	Millivolt Input Filter in seconds Range = 0 to 3276. The higher the number the faster the reading update. DEFAULT = 1000	READ/WRITE		
19	25	AZERO	LINEAR OFFSET, Y INTERCEPT LINEAR SCALING FOR INPUT A	READ/WRITE		
1A	26	ANUM	LINEAR SPAN VALUE FOR INPUT A	READ/WRITE		
1B	27	BZERO	LINEAR OFFSET, Y INTERCEPT LINEAR SCALING FOR INPUT B	READ/WRITE		
1C	14	BNUM	LINEAR SPAN VALUE FOR INPUT B	READ/WRITE		
1D	15	PROC	This value is the calculated process value shown as an integer. The decimal point and exponent values are required to determine the actual scaled value. Range = -999 to 9999. For example: If the process = oxygen, display decimal point = 2, and exponent = 6, and PROC = 1234, then the actual value and displayed as 12.34 ppm.	READ ONLY		
1E	16	COLDJCT	COLD JUNCTION Where 1 COUNT = 1°F (°C), RANGE = -99 TO 255°F (°C). Note this parameter is an unsigned integer.	READ ONLY		
1F	17	TEMP	MEASURED TEMPERATURE Where temperature is presented in degrees C or F, based on the C/F setting. Note this parameter is an unsigned integer of temperature -2721 = 62815 Range = max / min range of selected thermocouple.	READ ONLY		
20	18	MV	MEASURED MILLIVOLT Where this value is scaled in 0.1 mV increments, i.e. 10001 = 1000.1. Range = 0 to 2000 mV.	READ ONLY		
21	19	DACV1	ANALOG OUTPUT 1 0 to 4095 is 4 to 20 mA In dual mode 4mA = - 100, 12mA = 0, 20mA = +100	READ/WRITE		

	BLOCK 1					
HEX	DEC	PARAMETER	DESCRIPTION	READ/WRITE		
22	20	DACV2	ANALOG OUTPUT 2 0 to 4095 is 4 to 20 ma In dual mode 4mA = - 100, 12mA = 0, 20mA = +100	READ/WRITE		
23	35	SPARE	SPARE			
24	36	SPARE	SPARE			
25	37	SPARE	SPARE			
26	38	SPARE	SPARE			
27	39	SPARE	SPARE			
28	40	SPARE	SPARE			
29	41	SPARE	SPARE			
2A	42	SPARE	SPARE			
2B	43	SPARE	SPARE			
2C	44	SPARE	SPARE			
2D	45	SPARE	SPARE			
2E	46	SPARE	SPARE			
2F	47	SPARE	SPARE			

Operational Specifications

Power input 21.6 to 26.4 volts DC / 130mA

Thermocouple input

Thermocouple type	Zero °F	Span °F
В	800	3000
С	32	3000
E	32	1300
J	32	1300
K	32	2300
N	32	2300
NNM	32	2000
R	300	3000
S	300	3000
T	32	700

Bold shows default Accuracy after linearization +/- 1 deg F

Millivolt input -200 to 2000 millivolts +/- 0.1 millivolt

Input Impedance 25 Megohm

Cold junction compensation +/- 1 deg F

DC outputs (Isolated) 0 to 20mA (650Ω max).

Isolation 1000V DC/AC

Power input to signal inputs Power input to communications

No Isolation Thermocouple input to Millivolt input, inputs must be differential.

Calculations Percent carbon 0 - 2.55%, no CO compensation

Dewpoint $-99^{\circ}F(-72.8^{\circ}C) - 212^{\circ}F(100^{\circ}C)$, no hydrogen

compensation

Percent oxygen. 0 - 20.9% (default)

CAUTION

DO NOT CONNECT ANY AC SOURCE OR LOAD TO

INSTRUMENT CONTACTS

Calibration Setups Millivolt Null

Millivolt Span

Thermocouple Null Thermocouple Span Cold Junction Trim

Communications port RS-485 Half Duplex Only

Protocol Modbus RTU

Baud rates 1200, 2400, 4800, 9600, 19.2K (**19.2K default**)

Parity None

Address 1 - 254 (Address 1 is default)

Housing

Material Polyamide PA non-reinforced Inflammability Evaluation Class V0 (UL94)

Temperature Range -40 to 100°C

Dielectric Strength 600 kV/cm (IEC243-1)

Mounting Snaps on to EN 50022 top hat (T) style DIN rail.

Terminals

Wire clamp screw terminals on four position removable terminal blocks.

Wire Size AWG 24 – 12 flexible stranded, removable terminal blocks.

Max. Torque 0.8 Nm

CAUTION: DO NOT CONNECT OR DISCONNECT HOUSING PLUGS WHILE MODULE IS POWERED OR UNDER LOAD.

Weight 10 oz

Environmental Conditions

Operating Temperature -20 °C to 55 °C (-4 to 130 F) Storage Temperature -20 °C to 55 °C (-40 to 185 F)

Operating and Storage Humidity

85% max relative humidity, noncondensing, from -20

to 65°C

Certifications and Compliance (PENDING)

Safety EN 61010-1, IEC 1010-1

Safety requirement for electrical equipment for measurement, control, and

laboratory use, Part 1

Electromagnetic Compatibility

Immunity as specified by EN 50082-2

Electrostatic discharge EN 61000-4-2 Level 3: 8 kV air Electromagnetic RF fields EN 61000-403 Level 3: 10 V/m 80 MHz – 1 GHz

Fast Transients	EN 61000-4-4	Level 4: 2 kV I/O
		Level 3: 2 kV power
RF conducted interference	EN 61000-4-6	Level 3: 10 V/rms
		150 KHz - 80 MHz
Emissions as specified by El	V 50081-2	
RF Interference	EN 55011	Enclosure class A
		Power main class A

Note: This instrument is designed for installation inside a grounded metal enclosure. Always observe anti-static precautions when installing or servicing any electronic device. Ground your body to discharge any static field before touching the body or terminals of any electronic device.

This specification can change without notification.



endura manufacturing co. ltd.

MATERIAL SAFETY DATA SHEET

Product Name:

INTERMIX EPOXY PRIMER - Colours

Component A

SECTION 01: CHEMICAL PRODUCT AND COMPANY IDENTIFICATION

Manufacturer/Supplier:

Endura Manufacturing Co. Ltd.

12425 - 149 Street Edmonton, Alberta

T5L 2J6

Ph: (780) 451-4242 Fax: (780) 452-5079

24-Hour Emergency

Number:....

(613) 996-6666 (Canutec)

Product Name:

INTERMIX EPOXY PRIMER - Colours

Item Number:....

UN 1263 CI 3 PG II

Chemical Family:....

Aromatic Hydrocarbons, Ketones, Alcohols, Glycol ethers, Pigments

Material Use: 2 component Epoxy Primer – intermix system.

SECTION 02: COMPOSITION / INFORMATION ON INGREDIENTS

HAZARDOUS INGREDIENTS	C.A.S.	LD/50, ROUTE, SPECIES	LC/50, ROUTE, SPECIES	TLV	% WT
methyl ethyl ketone xylene	78-93-3	>4 g/kg o-r >6 g/kg d-rbt	>5000 ppm/8h i-r	200 ppm	5 – 10
butanol	1330-20-7 71-36-3	4.3 g/kg o-r >2 g/kg d-rbt .79 g/kg o-r	5000 ppm/4h i-r	100 ppm	5 – 15
ethyl benzene	100-41-4	3.5 g/kg o-r 17.8 g/kg d-rbt	8000 ppm/4h i-r N/A	50 ppm	1-5
methyl amyl ketone	110-43-0	1670mg/kg o-r, 12600mL/kg d-rbt	N/A N/A	100 ppm 50 ppm	1 – 5 1 – 10
quartz	14808-60-7	N/A	N/A	0.05 mg/m ³	10 – 20
Some colours contain					
lead chromate	7758-97-6	12000 mg/kg o-r	N/A	.05 ppm	0 – 30
lead sulphate	7446-14-2	2000 mg/kg o-r	N/A	.15 ppm	0-5
molybdenum compounds n.o.s.	-	N/A	N/A	N/A	0 – 5
carbon black	1333-86-4	>15.4 g/kg o-r >3 g/kg d-rbt	N/A	3.5 mg/m ³	0 - 5
antimony trioxide	1309-64-4	N/A	N/A	N/Ã	0 - 5
titanium dioxide	13463-67-7	>25 g/kg o-r >10 g/kg d-rbt	>6.82 mg/l/4h	10 mg/m³/8h	0-30
legend: o=oral	d=dermal	i=inhalation rbt=rabbit	r=rat	p=intraperitoneal	g≍guinea pig

See Sax, N.I. "Dangerous Properties of Industrial Materials" for more information.

SECTION 03: HAZARDS IDENTIFICATION

Eye Contact: Moderately irritating to eyes and can cause tissue damage.

Skin Contact: Low toxicity by skin absorption, but extended contact can cause irritation and dermatitis. Can cause allergic skin reaction.

Vapors are of low to moderate toxicity when inhaled and are irritating to nose, throat and other respiratory passages, especially in higher concentrations. Extended exposure can cause headaches, dizziness, nausea or even loss of muscular control and coordination, narcosis or unconsciousness.

Liquid is of low to moderate toxicity when ingested, but can be hazardous if aspirated into lungs during swallowing or vomiting.

Chronic hazards include narcosis, specific organ damage, permanent brain and nervous system damage or coma if extensively abused. MEK has shown teratogenic effects in laboratory animals. Lead chromate and carbon black are possible carcinogens.

August 1, 2006	Dave 2 of 2
	MATERIAL SAFETY DATA SHEET
	TERMIX EPOXY PRIMER - Colours Omponent A
SECTION 04: FIRST AIL	D MEASURES
Inhalation (acute):	GET IMMEDIATE MEDICAL HELP. DO NOT INDUCE VOMITING. Seek medical help. Give 1 or 2 glasses water or milk, BUT ONLY IF VICTIM IS CONSCIOUS. Check for and remove any contact tenses. Flush eyes IMMEDIATELY with water for 15 minutes and get immediate medical help. Wash with soap and water. Clean contaminated clothing before reuse.
SECTION 05: FIRE FIGH	TING MEASURES
Flash Point (°C) (TCC):	244 7 1
SECTION 06: ACCIDENT	TAL RELEASE MEASURES
Leak / Spill:	Remove all sources of ignition. The product should be contained and absorbed with inert materials and placed into a container. Do not seal the containers until any gas, which might form, has done so.
SECTION 07: HANDLING	S AND STORAGE
Handling Procedures:	Avoid static charges, sparks, flames, ignition sources, excessive heat. Keep containers tightly closed and upright when not in use. Do not allow contact with skin or eyes, and don't breathe vapors. Electrical and mechanical equipment should be explosion-proof. Store in a cool, dry place.
SECTION 08: EXPOSUR	RE CONTROLS / PERSONAL PROTECTION
PROTECTIVE EQUIPMENT	
Eye/Type:	Personnel should wear liquid chemical goggles or a full-face shield. Personnel should wear a suitable air supplied respirator. Personnel should wear chemical-resistant clothing, gloves and footwear. A safety shower and eye wash facility should be available. Adequate ventilation must be assured to prevent the accumulation of dangerous amounts of vapor or mist.

August 1, 2006	Page 3 of 3
	MATERIAL SAFETY DATA SHEET
Product Name:	INTERMIX EPOXY PRIMER - Colours Component A
SECTION 09: PHYSIC	CAL AND CHEMICAL PROPERTIES
Physical State (appearance): Odor	Solvent 1.48 – 1.77 N/A 77 mm Hg Heavier than air N/A 80 N/A N/A
SECTION 10: STABILITY AND REACTIVITY	
Reactivity Conditions:	Will react dangerously with oxidizing materials
SECTION 11: REGULA	ATORY INFORMATION
WHMIS Classification:	B-2, D-2A, D-2B
SECTION 12: DISPOS	AL CONSIDERATIONS
Waste Disposal:	Dispose of waste according to local, provincial and federal regulations. Utilize authorized centers for disposal of combustible chemical material.
SECTION 13: TRANSF	PORT INFORMATION
T.D.G. Classification:	Shipping name: Paint. UN 1263, Cl 3, PG II.
SECTION 14: OTHER	NFORMATION
Note: Prepared By: Preparation Date:	Technical Department . August 1, 2006

August 2, 2006

Page 1 of 3

MATERIAL SAFETY DATA SHEET

Product Name:

INTERMIX EPOXY PRIMER 3:1 COMPONENT "B"

SECTION 01: CHEMICAL PRODUCT AND COMPANY IDENTIFICATION

Manufacturer/Supplier:

Endura Manufacturing Co. Ltd.

12425 - 149 Street Edmonton, Alberta

T5L 2J6

Ph: (780) 451-4242 Fax: (780) 452-5079

24-Hour Emergency

Number:....

(613) 996-6666 (Canutec)

Product Name:....

INTÉRMIX EPOXY PRIMER 3:1 COMPONENT "B"

UN 1263 CI 3 PG II

Item Number:.... Chemical Family:.... Material Use:....

Aromatic Hydrocarbons, Alcohols, Glycol ethers. 2 component Epoxy Primer -intermix system.

SECTION 02: COMPOSITION / INFORMATION ON INGREDIENTS

HAZARDOUS ING	HAZARDOUS INGREDIENTS C.A.S.		LD/50, ROUTE, SPECIE	ES	LC/50, ROUTE, SPECIES	TLV	% WT	
nonylphenol tris(dimethylaminometh butanol xylene Ethylene glycol monobu acetate		84852-15-3 90-72-2 71-36-3 1330-20-7 112-07-2	.58 g/kg o-r 1.2 g/kg o-r 1.28 g/kg .79g/kg o-r 4.3 g/kg o-r >2 g/kg d 2400 mg/kg rat		N/A N/A 8000 ppm/8h i-r 5000 ppm/4h i-r 450 ppm rat	10 ppm N/A 50 ppm 100 ppm 20 ppm	5 - 15 1 - 5 5 - 10 10 - 20 5 - 10	
toluene		108-88-3	636 mg/kg 0-r		8000ppm 4 hr. 1-r	50 ppm	25 - 35	
legend:	o=oral	d=dermal	i=inhalation	rbt=rabbit	r=rat	p=intraperitoneal	g=guinea pig	

See Sax, N.I. "Dangerous Properties of Industrial Materials" for more information.

SECTION 03: HAZARDS IDENTIFICATION

Eye Contact:.... Moderately imitating to eyes and can cause tissue damage. Can cause burning to eyes. Skin Contact:....

Low toxicity by skin absorption, but extended contact can cause irritation and dermatitis. Can cause burning to skin. Inhalation:....

Vapors are of low to moderate toxicity when inhaled and are irritating to nose, throat and other respiratory passages, especially in higher concentrations. Extended exposure can cause headaches, dizziness, nausea or even loss of muscular control and coordination, narcosis or

unconsciousness.

Ingestion:.... Liquid is of low to moderate toxicity when ingested, but can be hazardous if aspirated into lungs during swallowing or vomiting. Can cause

burning to gastrointestinal passages.

Additional Information:..... Chronic hazards include narcosis, specific organ damage, permanent brain and nervous system damage or coma if extensively abused.

August 2, 2006		
, rugues e, mar	Page 2 of 3 MATERIAL SAFETY DATA SHEET	
Product Name:	INTERMIX EPOXY PRIMER 3:1 COMPONENT "B"	
SECTION 04: FIRST	AID MEASURES	
Inhalation (acute): Ingestion: Eye Contact: Skin Contact: Notes to Physician:	GET IMMEDIATE MEDICAL HELP. DO NOT INDUCE VOMITING. Seek medical help. Give 1 or 2 glasses water or milk, BUT ONLY IF VICTIM IS CONSCIOUS. Check for and remove any contact lenses. Flush eyes IMMEDIATELY with water for 15 minutes and get immediate medical help. Wash with soap and water. Clean contaminated clothing before reuse.	ty.
SECTION 05: FIRE F	IGHTING MEASURES	
Flash Point (°C) (TCC):	24471	
Procedures:	wear self-contained breathing apparatus and full protective clothing. Extreme heat may cause pressure build-up in containers and possib explosion, therefore use water to keep containers cool. Sparks, open flame, static discharge or extreme temperature. Vapors from this product are heavier than air and may travel or be moved by currents and be ignited by pilot lights, other flames, smoking, sparks, heaters, electrical equipment, static discharges or other ignition source at locations distant from the point of handling.	hv air
SECTION 06: ACCIDE	ENTAL RELEASE MEASURES	
Leak / Spilf:	Remove all sources of ignition. The product should be contained and absorbed with inert materials and placed into a container. Do not set the containers until any gas, which might form, has done so.	eal
SECTION 07: HANDL	ING AND STORAGE	Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Bright Brigh Bright Bright Bright Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh Brigh
Handling Procedures:	allow contact with skin or eyes, and don't breathe vapors. Electrical and mechanical equipment should be explosion-proof	1
SECTION 08: EXPOS	SURE CONTROLS / PERSONAL PROTECTION	
PROTECTIVE EQUIPMENT		
Eye/Type: Respiratory/Type: Gloves/Clothing/Footwear/Type:. Other/Type: Ventilation Requirements:	Personnel should wear a suitable air supplied respirator. Personnel should wear chemical-resistant clothing, gloves and footwear. A safety shower and eye wash facility should be available	

August 2, 2006		Page 3 of 3
	MATERIAL SAFETY DATA SHEET	Faye 3 01 3
Product Name:	INTERMIX EPOXY PRIMER 3:1 COMPONENT "B"	
SECTION 09: PHYSIC	CAL AND CHEMICAL PROPERTIES	
NOTE: Differences between Com	ponent "B" and the Mixture of A and B are specified as B and M	
Physical State (appearance): Odor:	Solvent 0.895 N/A 16 mm Hg Heavier than air N/A 118 N/A 1/A 1/A N/A N/A N/A	
SECTION 10: STABIL	ITY AND REACTIVITY	
Reactivity Conditions:		
	ATORY INFORMATION	
WHMIS Classification:	B-2, D-2A, D-2B, E	
SECTION 12: DISPOS	AL CONSIDERATIONS	
Waste Disposal:	Dispose of waste according to local, provincial and federal regulations. Utilize authorized centers for disposal of combus material.	stible chemical
SECTION 13: TRANSF	PORT INFORMATION	
T.D.G. Classification:	Shipping name: Paint. UN 1263, Cl 3, PG II.	
SECTION 14: OTHER	INFORMATION	
Note: Prepared By: Preparation Date:	Amanda Dixon . August 2, 2006	

endura manufacturing co. ltd.

July 26, 2006

Page 1 of 3

MATERIAL SAFETY DATA SHEET

Product Name:

EX-2C TOPCOAT and CLEAR

Component A

SECTION 01: CHEMICAL PRODUCT AND COMPANY IDENTIFICATION

Manufacturer/Supplier:

Endura Manufacturing Co. Ltd.

12425 - 149 Street Edmonton, Alberta

T5L 2J6

Ph: (780) 451-4242 Fax: (780) 452-5079

24-Hour Emergency

Number:....

(613) 996-6666 (Canutec)

Product Name:....

EX-2C TOPCOAT and CLEAR. Component A.

UN 1263 CI3 PG II

Ester, Aromatic Hydrocarbon, Ketone, Pigments

Material Use:....

2 Component Plastic Coating - EX-2C Component "A" must be mixed with an EX-2C Component "B"

SECTION 02: COMPOSITION / INFORMATION ON INGREDIENTS

HAZARDOUS INGREDIENTS C.A.S. LD/50, ROUTE, SPECIES LC/50, ROUTE, SPECIES TLV							
<u>Component A</u> - Polyester Solution					<u> </u>		
n-butyl acetate xylene pm acetate ethyl 3-ethoxypropionate acetone	123-86-4 1330-20-7 108-65-6 763-69-9 67-64-1	14 g/kg o-r 4.3 g/kg o-r >2 g/kg d-rbt 8.5 g/kg o-fr >5 g/kg d-rbt 5 g/kg o-r 10 ml/kg d-rbt >9.7 g/kg o-r >20 ml/kg d-rbt	2000 ppm/4h i-r 5000 ppm/4h i-r N/A >1000 ppm/6h i-r >16000 ppm/4h i-r	150 ppm 100 ppm N/A N/A 500 ppm	20 - 40 1 - 5 1 - 5 1 - 5 1 - 5		
Some colours contain	(*) these col-	ours may be reformulated with no lead co	ntent when required.				
chromium hydroxide lead chromate (*) lead sulphate (*) molybdenum compounds n.o.s. (*) mica aluminum flake carbon black tin oxide ferric oxide	1308-14-1 7758-97-6 7446-14-2 	N/A 12000 mg/kg o-r 2000 mg/kg o-r 2000 mg/kg o-r N/A N/A N/A >15.4 g/kg o-r >3 g/kg d-rbt >20000 mg/kg o-r >5000 mg/kg o-r	N/A N/A N/A N/A N/A N/A N/A N/A N/A	.05 mg/m³ .05 ppm .15 ppm N/A 3 mg/m³ 10 mg/m³ 3.5 mg/m³ 2 mg/m³ 10 mg/m³	0 - 1 0 - 50 0 - 15 0 - 5 0 - 15 0 - 15 0 - 5 0 - 1		
antimony trioxide titanium dioxide titanium dioxide aromatic solvent stoddard solvent dichloro dimethyl silane silica-amorphous, precip.	1309-64-4 13463-67-7 1317-80-2 64742-95-6 8052-41-3 68611-44-9 112926-00-8	N/Å >25 g/kg o-r >10 g/kg d-rbt N/A >5 g/kg o-r >3160 mg/kg d-rbt >5 g/kg o-r >3160 mg/kg d-rbt >5 g/kg o-r >3160 mg/kg o-rbt >5000 mg/kg o-r >10000 mg/kg o-r	N/A >6.82 mg/i/4h N/A N/A N/A N/A N/A	N/A 10 mg/m³/8h 10 mg/m³ N/A 100 ppm 10 mg/m³ 10 mg/m³	0-5 0-60 0-10 0-2 0-2 0-1 0-15		
legend: o=oral	d=dermal See Sax,	i=inhalation rbt=rabt N.I. "Dangerous Properties of Industrial Mate		intraperitoneal	fr=female rat		

SECTION 03: HAZARDS IDENTIFICATION

Eye Contact:	Moderately irritating to eyes and can cause tissue damage.
Skin Contact:	Low toxicity by skin absorption, but extended contact can cause irritation and dermatitis. Skin sensitization or reddening, swelling or blistering can occur.
Inhalation:	Vapors are of low to moderate toxicity when inhaled and are irritating to nose, throat and other respiratory passages, especially in higher concentrations. Extended exposure can cause headaches, dizziness, nausea or even loss of muscular control and coordination, narcosis or unconsciousness.
Ingestion:	Liquid is of low to moderate toxicity when ingested, but can be hazardous if aspirated into lungs during swallowing or vomiting. Chronic hazards include narcosis, specific organ damage, permanent brain and nervous system damage or coma if extensively abused. Lead chromate and carbon black are possible carcinogens.

Lul. 00 0000	
July 26, 2006	MATERIAL CAPETY DATA CHEET
	MATERIAL SAFETY DATA SHEET
	EX-2C TOPCOAT and CLEAR omponent A
SECTION 04: FIRST A	ID MÉASURES
Inhalation (acute):	GET IMMEDIATE MEDICAL HELP. DO NOT INDUCE VOMITING. Seek medical help. Give 1 or 2 glasses water or milk, BUT ONLY IF VICTIM IS CONSCIOUS. Check for and remove any contact lenses. Flush eyes IMMEDIATELY with water for 15 minutes and get immediate medical help. Wash with soap and water. Clean contaminated clothing before reuse.
SECTION 05: FIRE FIG	SHTING MEASURES
Flash Point (°C), (TCC):	N/A N/A CO ₂ , foam, dry chemical. Avoid using water except as a fog. CO, CO ₂ . Possibly Oxides of Nitrogen, Sulphur, Lead, Chromium, Antimony or Aluminum. None Can ignite vapors Wear self-contained breathing apparatus and full protective clothing. Extreme heat may cause pressure build-up in containers and possibly explosion, therefore use water to keep containers cool. Sparks, open flame, static discharge or extreme temperature.
SECTION 06: ACCIDEN	ITAL RELEASE MEASURES
Clean up:	Remove all sources of ignition. The product should be contained and absorbed with inert materials and placed into a container. Do not seal the containers until any gas, which might form, has done so.
SECTION 07: HANDLIN	IG AND STORAGE
Handling Procedures:	with skin or eyes, and don't breathe vanors
SECTION 08: EXPOSU	RE CONTROLS / PERSONAL PROTECTION
PROTECTIVE EQUIPMENT	
Eye/Type: Respiratory/Type:	Personnel should wear liquid chemical goggles or a full-face shield. Personnel should wear a suitable air supplied respirator.
Gloves/Clothing/Footwear/Type: Other/Type: Ventilation Requirements:	A safety shower and eye wash facility should be available

July 26, 2006	Po 2 . ()	
	MATERIAL SAFETY DATA SHEET	
i i i oddol Name.	EX-2C TOPCOAT and CLEAR Component A	
SECTION 09: PHYSIC	AL AND CHEMICAL PROPERTIES	
Physical State (appearance): Odor: Density (g/ml): Odor Threshold (ppm): Vapor Pressure (@20°C): Vapor Density (Air=1): Evaporation Rate: Boiling Point (°C): pH: Solubility in Water (% WW): Coefficient of Water/Oil Distribution: Freezing Point (°C): Melting Point (°C):	Solvent like 1 – 1.6 N/A 180 mm Hg Heavier than air 5.7 57 N/A N/A N/A	
SECTION 10: STABILIT	Y AND REACTIVITY	
Reactivity Conditions:	Will react with oxidizing materials.	
SECTION 11: REGULA	TORY INFORMATION	Control of the contro
WHMIS Classification:	B-2, D-2A, D-2B	
SECTION 12: DISPOSA	AL CONSIDERATIONS	
Waste Disposal:	Dispose of waste according to local, provincial and federal regulations. Utilize authorized centers for disposal of combustible chemical material.	
SECTION 13: TRANSPO	DRTINFORMATION	
T.D.G. Classification:	Shipping name: Paint. UN 1263, Cl 3, PG II.	p.AXXX
SECTION 14: OTHER IN	NFORMATION	
Note: Prepared By: Revision Date:	Technical Department July 26, 2006	

Page 1 of 3

MATERIAL SAFETY DATA SHEET

Product Name:

EX-2C COMPONENT B

SECTION 01: CHEMICAL PRODUCT AND COMPANY IDENTIFICATION

Manufacturer/Supplier:....

Endura Manufacturing Co. Ltd.

12425 - 149 Street Edmonton, Alberta

T5L 2J6

Ph: (780) 451-4242 Fax: (780) 452-5079

24-Hour Emergency Number:..... Product Name:....

(613) 996-6666 (Canutec) EX-2C COMPONENT B UN 1263 CI 3 PG II Ester, Ketone, HDI

2 component plastic coating - mix 1 part Component "A" and 1 part Component "B" by volume

SECTION 02: COMPOSITION / INFORMATION ON INGREDIENTS

HAZARDOUS INGREDIENTS	C.A.S.	LD/50, ROUTE, SPECIES	LC/50, ROUTE, SPECIES	TLV	% WT
Methyl Amyl Ketone Ethyl Acetate n-butyl acetate hexamethylene diisocyanate homopolymer of HDI	110-43-0 141-78-6 123-86-4 822-06-0 28182-81-2	1.67 g/kg o-r 12.6 ml/kg d-rbt 5.6 g/kg o-r 20 ml/kg d-rbt 14 g/kg o-r 710 mg/kg o-r 570 mg/kg d-rbt >10 g/kg o-r	4000 ppm/4h i-r 16000 ppm/6h i-r 2000 ppm/4h i-r 310-350 mg/m³/1-4 h i-r	100 ppm 400 ppm 150 ppm .005 ppm N/A	10-15 10-15 20 – 30 **

^{**} Free HDI monomer <0.15% of mixed solution (comp. A & comp. B) at time of manufacture. The monomer content may rise to 0.35% after 3-6 months storage. legend: o=oral d=demail i=inhalation rbt=rabbit r=rat fr=female rat

nt g=guinea pig

See Sax, N.I. "Dangerous Properties of Industrial Materials" for more information.

SECTION 03: HAZARDS IDENTIFICATION

Eye Contact:.... Moderately irritating to eyes and can cause tissue damage. Skin Contact:.... Low toxicity by skin absorption, but extended contact can cause irritation and dermatitis. Skin sensitization or reddening, swelling or blistering can occur. Inhalation:.... Vapors are of low to moderate toxicity when inhaled and are irritating to nose, throat and other respiratory passages, especially in higher concentrations. Extended exposure can cause headaches, dizziness, nausea or even loss of muscular control and coordination, narcosis or unconsciousness. In addition to causing lung irritation, coughing, breathlessness and chest discomfort, isocyanates can cause a reduction in lung function or even bronchitis, bronchial spasm or pulmonary edema in extreme concentrations. Any of these effects can be immediate or delayed. Any pre-existing impairment in lung function will be magnified or sensitization of the lungs can occur, and those in either condition should not be exposed to any level of isocyanate vapor. Ingestion:.... Liquid is of low to moderate toxicity when ingested, but can be hazardous if aspirated into lungs during swallowing or vomiting. Additional Information:.... Chronic hazards include narcosis, specific organ damage, permanent brain and nervous system damage or coma if extensively abused. Component B (and therefore the mixture) contains an isocyanate compound, which carries additional hazards. The vapor's odor is not detectable until dangerous levels have already been reached.

June 8, 2007	
	MATERIAL SAFETY DATA SHEET
Product Name:	EX-2C COMPONENT B
SECTION 04: FIRST	AID MEASURES
Inhalation (acute):	GET IMMEDIATE MEDICAL HELP. DO NOT INDUCE VOMITING. Seek medical help. Give 1 or 2 glasses water or milk, BUT ONLY IF VICTIM IS CONSCIOUS. Check for and remove any contact lenses. Flush eyes IMMEDIATELY with water for 15 minutes and get immediate medical help. Wash with soan and water. Clean contaminated clothing before reuse. Wash with soan and water.
SECTION 05: FIRE	FIGHTING MEASURES
Flash Point (°C) (TCC):	N/A N/A N/A N/A CO ₂ , dry chemical, foam. Avoid using water except as a fog. CO, CO ₂ . Oxides of Nitrogen. Hydrogen Cyanide. HDI None Can ignite vapors Wear self-contained breathing apparatus and full protective clothing. Extreme heat may cause pressure build-up in containers and possibly explosion, therefore use water to keep containers cool.
SECTION 06: ACCID	ENTAL RELEASE MEASURES
Leak / Spili:	Remove all sources of ignition. The product should be contained and absorbed with inert materials and placed into a container. Do not seal the containers until any gas, which might form, has done so.
SECTION 07: HAND	LING AND STORAGE

Handling Procedures:.... Avoid static charges, sparks, flames and excessive heat. Keep containers tightly closed and upright when not in use. Do not allow contact

with skin or eyes, and don't breathe vapors. Storage Needs:....

Store in a cool, dry place.

SECTION 08: EXPOSURE CONTROLS / PERSONAL PROTECTION

PROTECTIVE EQUIPMENT

Eye/Type:.... Personnel should wear liquid chemical goggles or a full-face shield. Personnel should wear a suitable air supplied respirator.

Respiratory/Type:....

Gloves/Clothing/Footwear/Type:..... Personnel should wear chemical-resistant clothing, gloves and footwear. Other/Type:....

A safety shower and eye wash facility should be available.

Ventilation Requirements:.... Adequate ventilation must be assured to prevent the accumulation of dangerous amounts of vapor or mist.

June 8, 2007	Po
	MATERIAL SAFETY DATA SHEET
Product Name:	EX-2C COMPONENT B
SECTION 09: PHYSICAL	AND CHEMICAL PROPERTIES
Physical State (appearance):	Solvent like 0.964 570 g/l 4.74 lbs/gal N/A 76 mm Hg Heavier than air 4.0 77 N/A N/A N/A
SECTION 10: STABILITY Incompatibility:	
SECTION 11: REGULATO	DRY INFORMATION
WHMIS:	B-2, B-3,D-1A, ,D-1A , D-2B
SECTION 12: DISPOSAL	CONSIDERATIONS
Waste Disposał:	Dispose of waste according to local, provincial and federal regulations. Utilize authorized centers for disposal of combustible chemical material.
SECTION 13: TRANSPOR	TINFORMATION
T.D.G. Classification:	Shipping name: Paint. UN 1263, Cl 3, PG II.
SECTION 14: OTHER INF	ORMATION
Note: Prepared By: Revision Date:	Technical Department June 8, 2007

AIR MAKE-UP UNITS

AMU Series

Construction

Welded steel housing finished in grey enamel.

Application

Available in a wide range of sizes handling 75 c.f.m. to 1100 c.f.m.

Designed to use as Air Replacement and Air Make-Up Units, for permanent installation.

To exhaust foul air and replace with fresh outside air.

By drawing on its wide range of tooled, standard parts, **Airdex** engineers can design a blower to meet your specific needs whether high or low air flow. AC motors, high or low resistance, single or double inlet.



Performance Data

Air Delivery (CFM) at R.P.M. Specified

Description	H.P.	R.P.M.	Free Air	1/8" SP	1/4" SP	3/8" SP	1/2" SP	3/4" SP	1" SP	1 1/4" SP
AMU 75	1/60	3000	75	61	54	43	-			-
AMU 130	1/70	1550	130	107	87	30	-	-		
AMU 160	1/40	1600	165	150	135	120	104	-	-	-
AMU 245	1/20	1550	245	225	210	190	162	-	-	-
AMU 265	1/20	1610	265	250	233	215	185	-		
AMU 400	1/12	1550	400	380	365	340	315	200	-	
AMU 465	1/15	1530	465	430	397	357	308	-		-
AMU 525	1/4	1725	525	500	480	460	420	240	120	
AMU 625	1/4	1725	625	600	560	540	500	420	280	100
AMU 845	1/2	1725	845	825	790	760	730	650	570	425
AMU 1100	1/3	1140	1100	1050	1000	950	B60	700	-	-

Tested by The Nozzle Chamber Method as directed in A.M.C.A. Bulletin #210. Figure #4.

Features

115 Volt, 60 Hz

- · Thermal overload protection
- Conduit wiring box
- · Permanently lubricated bearings
- · Horizontal or vertical operation
- · Counter clockwise rotation drive side

- AMU 245, 400, 525, 625, 845 and 1100 supplied with inlet collars.
- Sleeve bearings with oilers
- · 4 discharge positions





AIR MAKE-UP UNITS

AMU Series

Specification Charts









Description	n A	В	С	D	E	К	М	R	S	U	Weight (lbs)
AMU 75	5.34	5.17	4.68	2.50	3.02	1.92	2.75	3.38	2.88	5.35	3.4
AMU 130	7.59	7.09	6.58	3.31	4.30	2.72	3.75	4.69	3.75	6.75	4





Description	n A	В	С	D	Е	К	L	М	N	Р	R	U	Weight (lbs)
AMIL 160	7.80	7.08	6 69	3 34	4 34	2.80	1 50	3.60	4.05	4 75	4.85	6.40	5.4





Description	on A	В	С	D	E	К	L	M	N	U	V	Υ	Z	Weight (lbs)	
AMU 245	9.41	8.73	8.17	4.0	5.33	3.36	5.0	4.75	6.0	9.0	5.0	5.75	6.75	8	
AMU 400	10.61	9.76	9.24	4.44	6.01	3.79	6.0	5.25	6.0	10.75	5.0	6.25	7.25	13	





AIR MAKE-UP UNITS

AMU Series

Specification Charts









Description	Α	В	С	D	E	К	L	M	N	Р	R	S	U	Weight (lbs)
AMU 265	9.93	9.0	8.46	3.9	5.55	3.75	4.37	4.22	4.87	5.0	5.5		7.65	8.05






Description	n A	В	С	D	E	K	L	M	N	Р	R	S	U	Weight (lbs)	
AMU 465	9.93	9.0	8.46	3.9	5.55	3.75	4.37	8.12	8.82	5.0	9.4	4.41	9.46	11.0	Ī






Description	n A	В	С	D	E	к	L	М	N	U	٧	W	Υ	z	Weight (lbs)
AMU 525	11.91	10.85	10.36	4.88	6.98	4.24	8.0	5.5	9.0	13.6	8.0	7. 23	5.0	7.02	24
AMU 625	11.91	10.85	10.36	4.88	6.98	4.24	8.0	6.0	9.0	14.1	8.0	7.23	5.0	7.02	24
AMU 845	13.43	12.19	11.66	5.44	7.60	4.76	8.0	6.0	9.0	14.8	8.0	7.85	5.0	7.02	30
AMU 1100	16.58	14.62	14.06	6.34	9.51	6.28	9.0	7.0	9.0	16.6	8.0	9.81	5.0	7.02	53




Approved by Shop:
Date:
Signature:

WESTLAND ENVIRONMENTAL SERVICES INC.								
Model:	Incine	rator CY-	50-CA-'D'-'0'					
Date:	02-09-2008	Elec	etrical Wiring					
Drawn By:	YP	<u> </u>	Diagram					
Rev.:								
Scale:		Dwg-No:	9 - 3					



		Proje	ct : Eure	ka	
			ENV	STLA	TAL
Approved by Shop:	M M	odel:	Incine	erator CY-	-50-CA-'D'-'O'
Date:	Dr	ate: rawn By: ev. :	May-26-08 YP	Lice	trical Diagram le the Building)
Signature:		cale:	NTS	Dwg-No:	8 - 1



Building - 2
Side Wall

Approved by Shop:

Date:

Signature:

Project: Eureka


WESTLAND

ENVIRONMENTAL
SERVICES INC.


Model: Incinerator CY-50-CA-'D'-'O'

Date: May-26-08
Drawn By: YP
Rev.: Ø
Scale: NTS

Dwg-No: 8 - 2



		Proje	ct : Eurel	ra	
			ENV	STLA IRONMENT. RVICES INC	A L
Approved by Shop:	N N	Model:	Incine	rator CY-	50-CA-'D'-'O'
Date:	Di	Date: Drawn By: Rev. :	May-26-08 YP	Electr (Inside	rical Diagram e the Building)
Signature:		Scale:	NTS	Dwg-No:	8 - 3



Approved by Shop:

Date:_

Signature: