Nunavut Water Bos

EMERGENCY SPILL RESPONSE PLAN

- Identify nature and source of spill fuel drums, hydraulic hose etc.
- Take immediate action to control the spill at source shut off engine, seal leaking drum with Plug 'n Dyke etc.
- Notify on-site supervising geologist.
- 4. Open up spill response kit and use appropriate method to clean up spilled material.
- On-site Supervising Geologist will go to the spill site and ensure appropriate and complete clean-up of spilled material.
- 6. Dispose of waste material.
- 7. Each spill to be documented by on-site Supervising Geologist.

Mike Gunning Geologist Canadian Exploration