



PIPING DETAILS:
- WATER FLOW METERS: PROVIDE 10 DIA. OF STRAIGHT PIPE BEFORE AND 5 DIA. OF STRAIGHT PIPE AFTER METERS. ENSURE THAT THROTTLING VALVES ARE NOT DIRECTLY IN LINE WITH METERS.
- AIR FLOW METERS: PROVIDE 8 DIA. OF STRAIGHT PIPE BEFORE AND 3 DIA. OF STRAIGHT PIPE AFTER METERS, IF POSSIBLE. AVOID TEES AND ELBOWS BEFORE AND AFTER METERS.
- MATERIALS OF VALVES AND FITTINGS TO BE THE SAME AS THE DESCRIPTION AT THE LINE. IF THERE IS A TRANSITION FROM PVC TO STEEL, THE VALVE SHOULD BE BRASS.
- THERE ARE NO SPECIAL PIPING REQUIREMENTS OTHER THAN WHAT IS EXPLAINED ON THE DIAGRAM.
- WHEN PVC HOSE IS SPECIFIED, ALWAYS USE VACUUM HOSE; USE GREEN HOSE FOR PRESSURES LESS THAN 60PSI; USE TANK TRUCK HOSE FOR PRESSURES BETWEEN 60PSI AND 150PSI.
- PVC PIPE MAY BE SUBSTITUTED WITH EQUAL-SIZED PVC HOSE WHERE A FLEXIBLE CONNECTION IS PREFERRED.

THIS INFORMATION IS THE PROPERTY OF FI INC. AND CANNOT BE REUSED OR REPRODUCED WITHOUT THE WRITTEN CONSENT OF FILTER INNOVATIONS INC.

E337697-PM403-50-031-0002			
A	SEPT. 13 2011	MM	FOR REVIEW
LEVEL	DATE	BY	REVISION

DWG. NO:	101002-01 (PAGE 2 OF 3)
TITLE:	PROCESS & INSTRUMENTATION DRAWING
CUSTOMER:	CHEMICAL WATER TREATMENT SYSTEM MARY RIVER WWTP BAFFINLAND
	FILTER INNOVATIONS INC.