




ND-HTS-040-31.5




ND-HTS-040-31.5




ND-HTS-040-33.5




ND-HTS-040-33.5




ND-HTS-060-28.8




ND-HTS-060-28.8




ND-HTS-060-31.0




ND-HTS-060-31.0




ND-HTS-060-33.5




ND-HTS-085-25.3




ND-HTS-085-25.3




ND-HTS-085-29.4




ND-HTS-085-29.4




ND-HTS-085-33.5




ND-HTS-085-33.5




ND-HTS-130-28.8




ND-HTS-130-28.8




ND-HTS-130-31.0




ND-HTS-130-31.0




ND-HTS-130-33.5




ND-HTS-130-33.5




ND-HTS-175-32.5




ND-HTS-175-32.5




ND-HTS-175-33.5




ND-HTS-175-33.5




ND-VTS-040-KT




ND-VTS-060-DS




ND-VTS-060-KT




ND-VTS-060-US




ND-VTS-085-DS




ND-VTS-085-KT




ND-VTS-085-US




ND-VTS-130-DS




ND-VTS-130-KT




ND-VTS-130-US



ND-VTS-175-KT



North Thermosyphon Thermistor Readings



South Thermosyphon Thermistor Readings

