

INCOMING LUGS	SPARE	SPARE	AIR HAND UNIT AHU-1	TERMINAL CONTROL SECTION
①	SIZE 1 ②	SIZE 1 ②	2 HP ③	
SPACE	SPARE	SPARE	EXHAUST FAN EF-3	
④	SIZE 1 ②	SIZE 1 ②	2 HP ⑤	
SPACE	SPACE	POTABLE WATER P-1	GLYCOL HEATING P-3	
④	④	5 HP ⑥	3 HP ⑦	
SPACE	SPACE	POTABLE WATER P-2	GLYCOL HEATING P-4	
④	④	5 HP ⑥	3 HP ⑦	
AIR SCOURER AS-1	BACKWASH PUMP BP-1	SPACE	BOILER B-1 (EXISTING)	
20 HP ⑧	25 HP ⑨	④	3P30A ⑩	
AIR SCOURER AS-2	BACKWASH PUMP BP-2	SPACE	BOILER B-2 (EXISTING)	⑪
20 HP ⑧	25 HP ⑨	④	3P30A ⑩	



MOTOR CONTROL CENTER LAYOUT

SCALE : NTS